

5. Launching the utility




Fig. 5.1. Utility start.

After utility start, it displays a dialog for selection of drive family, model, and utility operation mode: *Normal mode* and *Kernel mode*.

- ◆ ***Normal mode*** – is the main mode of utility operation provided that drive ROM can be read.
- ◆ ***Kernel mode*** – is intended for writing/reading of FLASH ROM in cases, when ROM cannot be read, when ROM firmware version does not match the version of service data on disk surface or when ROM firmware contains adaptive data different from the original data for the head-and-disk assembly. Work in Kernel mode is supported for MHM2xxxAT, MHN2xxxAT, and MHT2xxxAT / AH, MPF3xxxAT, MPG3xxxAT drive families. A detailed description of work in Kernel mode can be found in the corresponding section of this manual (please see section 5.1).

After start, the utility reads HDD ROM header, identifies firmware version and tunes itself using the drive configuration tables from ROM (modules table, table of zone allocation, etc.). If the utility fails to read the ROM, it displays the following message:



Fig. 5.2.

You will be prompted to click [Yes] to make the utility use settings from an existing file (ROM copy read earlier). In that case, you will have to specify a file containing ROM of the corresponding version¹. If you select [No], the utility

¹ – You can check ROM version on the HDA label (see Chapter 13).

will use its default parameters (editable within the utility options dialog window, see section 9.2). If the utility has read the ROM but cannot recognize it (the ROM is not included in the list of supported versions), it will output a dialog box to search for the table of modules (and for the zone allocation table stored in ROM for some drive families). Having displayed the dialog, the utility will attempt to find the required table searching from the start of ROM image. You can perform the procedure manually using the «From beginning» button. If the table is detected, the utility will visualize its data. Drive ROM may virtually contain several areas matching the criteria used while searching for the required table¹. Use the «Next» button to search for all possible offsets.

If the utility finds a new area matching the search criteria, it will analyze and display its data and show the offset in the right part of the dialog box under the «Current offset» label. If the next search attempt fails, the utility will output a corresponding notification. You can confirm your selection using the «OK» button, which will add the information about the new firmware to the utility settings storage. Then you will have to evaluate the data visually to confirm selection validity; use the report on SA structure for that purpose. If the information seems to be correct, enter the utility options dialog and click the «OK» button to save the new firmware version.

After reading the data structures from ROM, the utility reads from the drive its configuration tables and checks the conformity between the physical parameters of the selected model and the actual configuration tables. If the information matches, the utility switches to the normal mode².

The normal mode provides access to the following items of menu hierarchy:

1) Utility status

2) Service information:

Work with ROM

- View information from ROM
- Reading ROM
- Writing ROM

Work with SA

- SA structure test
- Reserve HDD resources
- Read modules
- Write modules
- Regenerate translator³
- Security subsystem
 - View password information
 - Erase password
- Disable heads
- Edit SN
- Work with adaptive data⁴
 - Transfer of adaptive data

3) HDD formatting

4) Logical scanning

¹ – In our practice, we have not encountered cases of several potential table locations.

² – If you have selected the Kernel mode, the utility will not load the tables from a HDD switching to processing of menu commands immediately.

³ – This menu item is not available for HDD of the MHD2xxxAT family.

⁴ – This menu is available just for HDD of MHM2xxxAT and MHN2xxxAT families (the only drive families using adaptive data).

5) Clear SMART¹6) Defect listDefect lists reportGrouping to tracksGrouping to cylindersErase defect lists

The Kernel mode allows access to the following features through the menu hierarchy:

1) Utility status2) Service information:Work with ROM

View information from ROM

Reading ROM

Writing ROM

■ 5.1. Kernel mode

First, we would like to mention that the utility currently supports the Kernel mode for MHM2xxxAT, MHN2xxxAT, and MHT2xxxAT / AH, MPF3xxxAT, and MPG3xxxAT drive families.

The need to record to a ROM detached from its HDA or to read data from it appears when you have to use an electronics board «borrowed» from another drive with incompatible ROM and HDA versions. When such a board is installed to a drive, the latter usually does not report on readiness so you cannot employ the standard tools of the utility to write anything to ROM. Here the Kernel mode of drive microprocessor may be helpful and, particularly, its embedded KERNEL CODE. That software code allows direct recording to ROM and reading of its contents without a HDA installed. Its behaviour has the following peculiarity: the microprocessor attempts to calculate ROM checksum while accessing it; if the checksum does not match, then the Kernel mode will be initiated providing access to ROM recording or reading.

If the ROM already contains normal firmware (of a different version, however) the checksum will match, of course. To prevent that, you will have to short-circuit ROM data lines using tweezers during initialization. Doing so will enable the Kernel mode; the board will immediately report on readiness (the DRD и DSC LEDs will light up). After that you may remove the tweezers. The general procedure is as follows:

- 1) Take the electronics board off the drive HDA case and connect it to the PC-3000 tester and power supply unit (the latter must be off)².
- 2) Use tweezers to short-circuit two I/O data lines of ROM chip (please see appropriate figure in the appendix in the end of this manual). Запустить утилиту, выбрать соответствующее семейство и режим работы Kernel mode.
- 3) Launch the utility, select the corresponding drive family, and enable Kernel mode as its operating mode.
- 4) Power up the drive. The board at that should immediately reach the ready status (the DRD` and DSC LEDs should be turned on). If the board fails to report on readiness, repeat steps 2-4 having connected other I/O data lines.
- 5) Then you may proceed to ROM writing or reading.

¹ – This menu item is not available for HDD of the MHD2xxxAT family (they do not support S.M.A.R.T.).

² – Fujitsu drives can be switched into Kernel mode with an installed PCB as well. For 3.5” drives the procedure is fairly simple because ROM chip is soldered on the external side of the board. For 2.5” drives with ROM chip located on the internal side of the board you will have to find the checkpoints of ROM data lines connection to the external side of the PCB. Please refer to Appendix 3. Checkpoints for switching 2.5” Fujitsu drives to Kernel mode for the figures indicating locations of such checkpoints.

The manufacturer of Fujitsu drives uses several types of Flash ROM chips – SGS Thomson (M29F102BB), Sanyo (LE28F1101T-40), etc. If you encounter difficulties while working in the Kernel mode (they are especially likely with Sanyo chips) try to short-circuit other data lines while switching the board into the Kernel mode. The problem, which is possible here, follows from corruption of Flash ROM chip identification parameters used to tune the utility for further work with the chip.

Warning! To accomplish correct recording to Sanyo Flash chips you should short-circuit the 19th and 20th contact pins to enter the Kernel mode. Connection of other contacts will change the chip code and cause incorrect application of the recording algorithm. Recording should be performed on a board removed from its HDA case.

You can also prepare a temporary file containing just zeros (00) and write it to the chip first. After that, the board will switch to Kernel mode automatically because the checksum will be invalid. Then you can write the necessary data to the chip. It is essential to read the data after writing to Flash ROM and ensure (through file comparison) that the recording procedure has been successful.

Warning! HDDs of MHM2xxxAT, MHN2xxxAT, and MPG3xxxAT drive families use the so-called adaptive data, i.e. microstepping parameters of drive actuator individual for each HDD. Drive ROM contains the start-up adaptive data required for reading of service information from disk surface. Therefore, overwriting ROM contents of a HDD belonging to any of those families with data from another drive (even with the same F/W version), will leave it unable to read its service information. Thus, such ROM overwriting procedure should be followed by an [adaptive data selection procedure](#)¹. To avoid that difficulty, you should [transfer the adaptive data](#) from the original ROM image to the one to be recorded before actual overwriting of ROM.

6. Utility features

Specific utility features can be invoked from the «Tests» and «Tools» → «Utility extensions» menus. The «Tests» menu includes single pass actions while the «Utility extensions» menu accommodates interactive functions of the utility. The remaining features are inherited from the kernel of the PC-3000 suite; they are described in the corresponding part of user documentation.

7. «Tests» menu

7.1. Utility status

This menu item displays the following dialog:




Fig.7.1. Utility status.

¹ – The procedure is not implemented so far in the documented utility version.

Here you can edit the «FW version» parameter. That might be necessary when drive ROM cannot be read. In such case, you should enter firmware version from the label on HDA case (see Chapter 13).

Warning! ROM reading/writing in Normal mode are not implemented in the current utility version for MHT2xxxAT drives; the utility notifies users about that at the start. Therefore, you should correct the FW version in the above dialog window immediately after utility start.

7.2. Service information

The «Service information» menu contains a group of commands for manipulating data in ROM and the service area of disk surface.

7.2.1. Work with ROM

Commands of that menu can be used to view data stored in drive ROM, read and record information to ROM chip.

7.2.1.1. View information from ROM

Selection of the «*View information from ROM*» menu item will tell the utility to read a portion of data from ROM of the drive being tested. Then the results of analysis performed using the information from read ROM tables will be displayed in the «Reports» window tab. A typical sample report is shown below.

```

ROM parameters
ROM recognized

Copyright..... : (C) FUJITSU 1999-
F/W..... : 0C-3E22
Date..... : 17.10.20
Family..... : H13L-02
CS..... : 00004480
Flags..... : 00

Report about modules table in ROM
# ID Length Name
1 01 36 DM
2 02 16 PL
3 03 3 TS
4 04 1 HS
5 05 1 FI
6 06 16 DT
7 07 1 SI
8 08 1 SN
9 09 1
10 0A 1
11 0B 1
12 0C 1 SM
13 0D 1 SU
14 0E 1 CI
15 10 4 SCH
16 11 1 SEQ
17 12 2 WTP
18 13 1 END
19 14 1 ECT
20 15 64 ERR
21 16 24 SVE
22 1D 3
23 1F 7 REC
24 20 8 TA
25 21 2 TC
26 22 1 ADT
27 27 1
28 28 1

```


where:

- ◆ ID – input/output identifier for a given module;
- ◆ Length (sectors) – module length in sectors according to the modules table
- ◆ Loaded – indication whether the table (module) has been read.
- ◆ Heads – the number of heads used by the drive during operation.
- ◆ Head map – map of electrical connections for active heads

The following modules are most typical for the service area:

- ◆ DM module¹ – contains translator for the user data area of a HDD.
- ◆ DT module² – contains the table of positioning adjustment settings for a HDD.
- ◆ TS module³ (Track Skip) – the table of defective tracks in a drive.
- ◆ HS module⁴ – (Head Select) – contains the total heads number and numbers of active heads.
- ◆ PL module – (Primary List) – the table of defective sectors in a drive.
- ◆ SN module – (Serial Number) – contains drive serial number.
- ◆ FI module – (Factory Information) – contains information about manufacturing cycle progress. The utility displays drive manufacture date only and skips other irrelevant data.
- ◆ CI module – (Components Information) – contains information about parts inside the head-and-disk assembly case: magnetic disks (MEDIA), heads (HEADS), read/write preamplifier chip (HD-IC), spindle motor (DCM).
- ◆ ZP module – (Zones Plane) – contains information about allocation of zones.
- ◆ SM module – (Security Master) – contains master password information.
- ◆ SU module – (Security User) – contains user password information.

7.2.2.2. Reserve HDD resources

This menu allows saving of complete HDD service information package to SABackup subdirectory of drive's profile. For Fujitsu HDD the collection includes drive modules (from service area and drive RAM) and ROM image. In addition, the selected folder will include a file containing a report on service data structure (see above) based on read modules and ROM report.

Attention! If the utility has recognized drive ROM⁵, then it uses the list of modules from ROM for subsequent reading and recording of service information. However, a situation is possible when certain modules are skipped at the factory while recording service data to a totally functional drive. In such case, the utility will log a message telling that the module is unreadable. You can ignore the message if you are sure that the drive (being) used for reading of service information is operational. This peculiarity of drive functioning is caused by certain confusion sometimes occurring in the manufacturer's design project. Thus, for instance, the module list in ROM includes module ID=00h; however, in reality there is no such module in a drive, so the utilities will block it (see the black list of modules in the tab showing the list of supported FW within the utility options dialog).

¹ – **Warning!** The module is essential for access to user data.

² – **Warning!** The module is essential for access to user data.

³ – **Warning!** The module is essential for access to user data.

⁴ – **Warning!** In MHT and MHV drive families the module contains data unique for each HDD.

⁵ – If the utility fails to identify drive ROM, it uses a short list of modules selected by default; the list of default modules can be modified in the utility settings dialog.

contains no records for the heads being disabled, otherwise you should clear the defects table. In the mode selection screen the utility displays heads map and offers to disable malfunctioning heads or enable functional ones. You can disable any head unless there are limitations enforced by drive family.

The drive will automatically change model name after disabling/enabling of its heads (except for non-standard models, see Chapter 16).

7.2.2.8. Edit SN

This menu item allows correction of a drive's serial number. Changes enter into effect after switching the drive's power supply off and on again.

7.2.2.9. Work with adaptive data

In the utility version described in this manual, the submenu contains just one action – *«Transfer of adaptive data»*.

Warning! Adaptive data will be transferred between files stored in folders on the computer, where PC-3000 is installed; the procedure **DOES NOT AFFECT THE CONNECTED HDD UNDER TEST IN ANY WAY**. To use the results of that procedure you will have to record the file thus corrected. Please see below the dialog window used for transfer of adaptive data.




Fig. 7.2. Transfer of adaptive data.

«File type» here determines the default extension for the selected file and the algorithm employed for work with it. «Path» stands for actual file path. Transfer of adaptive data is accomplished by copying a block of data containing adaptive information from a source file (from the location determined by source type) to destination file (to the respective location determined by destination type). The said data block is 512 bytes long. In «module file» and «adaptive data file» object types the block is located at offset 0 from the file beginning while in a «ROM file» it can be found at offset FDE0h.

7.3. HDD formatting

HDD formatting starts the internal format procedure (Low-Level Format). Prior to the formatting procedure the drive will erase its translator tables, check the defect lists for quantity and accuracy and start actual formatting. In the process, the drive skips defective sectors and defective tracks, the numbers of which it reads from the defect lists. The formatting procedure cannot be interrupted since after its completion translator recalculation and recording takes place. If format ends in error, it means presence of corrupt servo information or incorrectly compiled defect list (illegal values or values exceeding limits). Then the drive's translator will not be recalculated and that will make impossible its work using the logical parameters. Therefore you are advised to save in a temporary file the service data modules prior to formatting start to allow their subsequent restoration, if necessary. Formatting takes approximately 20 minutes, but it depends on the model, condition of magnetic disks and it can take considerably longer with defective surfaces.

Formatting errors can occur immediately after the procedure begins in case of incorrect contents in PL or TS defect lists. For instance, that happens if some heads were disabled in the process while the PL and TS defects tables contain left-over records about defects for the deactivated heads. That will be indicated in PL and TS tables by the difference between the total number of defective sectors and their total amount for the remaining heads; a message about the

number of structural errors acts as another confirmation. The utility displays in red all records of defects that do not match the existing drive geometry. If such errors are detected, you will have to clear the defect lists for the disabled heads.

7.4. Logical scanning

This menu item initiates the logical scanning procedure performed by the universal utility of the PC-3000 suite. Please see the corresponding manual for a detailed description of that feature.

7.5. Clear S.M.A.R.T.

This command resets all the attributes to initial values except for just a few of them. For example, relocated defects count gets reset in case of successful formatting and regeneration of translator tables while the spindle motor spin up time attribute is calculated every time the power supply is switched on. The attributes reset does not work with some drives, in such case you can use the option for loading an external S.M.A.R.T. module. The actual resetting of attributes is accomplished by overwriting of model attributes' module (ID = 010B) over the current attributes' module (ID = 0109). Therefore, if the model attributes module becomes damaged, it should be copied from a matching profile set of service data.

7.6. Defect lists

The submenu allows both viewing and modification of PL and TS defect lists.

Warning! The utility version described herein has limited functionality for manual or automatic addition of defects. Therefore you are advised to evaluate the necessity of all actions required to modify the tables and consequences thereof.

7.6.1. Defect lists report

This command allows viewing the tables of relocated defects of a drive. First, track defects (TS) are displayed followed by sector defects (PL). Defects are represented in the tables by heads in PCHS (Physical CHS) format and ordered by heads, cylinders and sectors. You can select the table(s) for review before actual report output as well as the heads and zones to be displayed. While viewing the results you can also see drive's statistics: the number of defects for the selected heads and zones, their total number, displayed number, etc. Furthermore, the utility may display the number of «structural errors» (if present), i.e. records of defects for a non-existent head or located in a non-existent zone. Records identified as structural errors are highlighted using colour. This, in particular, allows quick identification of one typical problem causing formatting errors – invalid records in the defect lists. Viewing the defect tables allows the operator to estimate the quality and condition of magnetic disks used in the drive.

7.6.2. Defect lists editing

The submenu contains commands for addition of defects and editing of the PL and TS lists.

- ◆ **Grouping to tracks** is supported while adding defects or editing PL. This action allows the operator to group into defective tracks those defective sectors, which are already entered into the defect list. When the commands are selected, the utility displays its «Grouping threshold» dialog. Use it to enter the threshold number of the defects within a track; once the number is reached, the utility will group sector defects to track defects and move them to the TS list.
- ◆ **Grouping to cylinders** is supported while editing TS. The command allows reordering of track defects into cylinder ones. During the procedure all track defects present in the TS defect list will be automatically copied for all heads while the defects present in the PL list will be filtered by the added tracks. Such an operation allows better relocation of defects since it improves positioning to a cylinder if a track contains corrupt servo labels for one of the heads

7.6.3. Erase effect lists

You will be offered to reset the defects list(s). After the execution of this command the selected defects table(s) is cleaned-up – the number of defective sectors is set to zero. In case of TS table erasing it is necessary to switch off/on the drive power supply to force reloading of dynamic tables; if you use PC-3K PWR2 adapter the operation is performed automatically.

8. «Tools» → «Utility extensions» menu

This menu can be used to access an interactive tool – the «Modules table» wizard. Doing so will make one more tab appear in the utility workspace. Tab appearance is shown below.

ID	Name	Importance	Source	Length	Read	Loaded	Header	Module
0101	DM	Ad	HDA	81	0			DM/DU, translator module
0105	FI	D	HDA	1	0			FI, manufacturer information module
0102	PL	Dd	HDA	41	41			PL, single sector defect list module
0103	TS	Ad	HDA	5	5			TS, P-List, track defect list module
0104	HS	B	HDA	1	1			HS, head map module
0106	DT	Ad	HDA	15	0			DT, translator module
0107	SI	B	HDA	1	0			SI, logical parameters module
0108	SN	B	HDA	1	1			SN, serial number module
010C	SM	B	HDA	1	1	Yes	Ok	SM, Master password module
010D	SU	B	HDA	1	1	Yes	Ok	SU, User password module
010E	CI	D	HDA	1	0			HDD hardware list module (text log)
0130	ZP	B	HDA	1	1	Yes	Ok	ZP, zone allocation table module (form)
012D	FA	C	HDA	1	0			FA, log module

Fig. 8.1. modules table.

Here you can see the following displayed module parameters:

- ◆ identifier
- ◆ symbolic name from modules table
- ◆ source (HDA – disk surface, RAM – PCB memory)
- ◆ length in sectors according to the modules table
- ◆ the number of sectors actually read from the drive
- ◆ brief description
- ◆ module importance for the drive (see section 7.2.2)
- ◆ whether the module has been loaded (this is also shown by the colour square to the left of module identifier, red means reading or writing error)
- ◆ whether the names in modules table and in actual module header match (this is also shown by the colour square to the left of the identifier, green means a loaded module with a matching name while yellow stands for a loaded module with a name mismatch).

You can use the right-click menu to perform the following actions over any module:

- ◆ **Module viewing.** This menu item becomes available when a certain module is selected in the wizard pane and loaded. The viewing dialog is essentially a built-in HEX editor; you can modify the module while viewing it and record it to the drive.
- ◆ **Rewrite module from DB.** This menu item becomes available when a certain module is selected in the wizard pane. It opens a dialog for searching the required module in the database. Search filters can be adjusted as necessary.
- ◆ **Start SA testing.** Here the utility displays a list of modules accessible for reading; the user has to select the necessary set for checking.
- ◆ **Terminate process.** This menu item is available only while a certain wizard task is running. It allows task termination.
- ◆ **Check module.** This menu item becomes available when a certain module is selected in the wizard pane. The utility will attempt to read the module again from the drive.

Besides, the following actions can be performed using the wizard toolbar:

- ◆ **Cloze** (wizard).

write/read modules in the disk service area do not work. In such case, it is necessary to load hardware data into drive RAM first, and then write the data to the service area on disk.

■ 9.4. Modification of drive configuration

Drive model in a certain family is determined according to the heads selection table (HS module). Initially, the module is generated in RAM from ROM, and then a drive reads it from the service area on disk surface setting itself up as a specific model depending on the number of active heads.




Fig. 9.4. Disks arrangement inside the package.

Reconfiguration can be performed from the top downwards by switching off defective sides and magnetic disks. Besides, not only top surfaces can be switched off but also those in the middle of the package. Junior models are thus created from the top ones. In case of configuration modification the model name, logical drive parameters and translator's operation are set up automatically. Upon completion of configuration modifications, it is necessary to switch the drive power supply off/on in order to initialize such drive with new parameters, and reload the utility, selecting a basic model at utility start.

10. Repair of Fujitsu drives

Repair of Fujitsu drives is characterized by some peculiarities. They include the presence of resident microprocessor code (overlay), a large number of incompatible firmware versions, and differences in the HDA construction and service data structure even in the same models with different dates of manufacture. All of the above complicates initial fault diagnostics and selection of control board for replacement in case of its malfunction. Still, there are some general methods applicable for malfunction search.

■ 10.1. Hardwave repair

10.1.1. Initialization

The drive initializes itself at power-up as follows:

- 1) Power-up
- 2) Self-diagnostics 1:
 - ◆ data bus and MPU address test
 - ◆ writing/reading test of microcircuit registers via internal data bus
 - ◆ internal RAM writing/reading test.
- 3) Spindle motor start-up.
- 4) Self-diagnostics 2:
 - ◆ buffer RAM writing/reading test.
- 5) Stabilizing the spindle motor rotation speed.
- 6) Heads release from latch (magnetic heads' unparking).
- 7) Service data reading.
- 8) Recalibration start.
- 9) Setting itself in readiness mode (ATA command waiting).

- 1) corruption of service modules (see Chapter 11).
- 2) incompatibility between the service data version and the firmware recorded in the control board ROM (see Chapter 13).
- 3) defects of reading / data conversion channel of the drive.

In such case ensure that the control board is functional (board swap being the best method), the ROM and HDA versions are compatible, and begin the service data restoration.

Restoration should begin with analysis of report produced after SA structure test (see the corresponding menu item). If a drive hangs while reading a certain module, you can test all the remaining modules using the module table wizard – «Tools \ Utility extensions \ Modules table». You may run the wizard to read a specified set of modules and use it as the basis for subsequent report about service data structure.

ID	Name	Importance	Source	Length	Read	Loaded	Header	Module
0101	DM	Ad	HDA	81	0			DM/DU, translator module
0105	FI	D	HDA	1	0			FI, manufacturer information module
0102	PL	Dd	HDA	41	41			PL, single sector defect list module
0103	TS	Ad	HDA	5	5			TS, P-List, track defect list module
0104	HS	B	HDA	1	1			HS, head map module
0106	DT	Ad	HDA	15	0			DT, translator module
0107	SI	B	HDA	1	0			SI, logical parameters module
0108	SN	B	HDA	1	1			SN, serial number module
010C	SM	B	HDA	1	1	Yes	Ok	SM, Master password module
010D	SU	B	HDA	1	1	Yes	Ok	SU, User password module
010E	CI	D	HDA	1	0			HDD hardware list module (text log)
0130	ZP	B	HDA	1	1	Yes	Ok	ZP, zone allocation table module (form)
012D	FA	C	HDA	1	0			FA, log module

Fig. 10.1. Check module.

In addition to other information, you can see here a brief module description and characteristics of its importance for the drive (in particular, for data accessibility) – the «Importance» column.

If not all the modules are damaged, but just some of them, you can overwrite the defective modules using the methods detailed in Chapter 11.

If most of drive's modules turn out to be damaged including the overlay module 3Dh (MHN2xxxAT and newer models), then you will have to write the modules to drive RAM first and only then record them to disk surface.

Switch HDD power supply off and on to initialize the drive with new parameters.

Possibly, it may be necessary to reset S.M.A.R.T. attributes.

Possibly, it may be necessary to perform a low-level format procedure.

Warning! Performance of the procedure will definitely cause loss of user data.

11. Restoration of service data modules

Corruption of service data modules is a frequently occurring fault. The malfunction manifests itself as follows: the drive spins up the spindle motor, recalibrates itself and outputs an ABR error.

Diagnostics of such malfunction requires to select the «SA structure test» mode in the menu, and to identify the defective modules in the resulting report. Alternatively, you can visually examine and estimate the service area status in the module table wizard - «Tools → Utility extensions → Modules table». Here you can see at once, which modules have been read successfully and which failed, whether module header matches the name in the module table, module importance for the drive, etc. You may run the wizard to read a specified set of modules and use it as the basis for subsequent report about service data structure.

Some of the modules are critical for data protection and should not be overwritten if you wish to preserve the user's data, for example, the modules **01h (DM)**, **03h (TS)** and **06h (DT)**. The DM module contains a table of exceptions, TS module contains the track (cylinder) defects' dynamic table, the DT module contains translator and represents a link between the logical space, defects lists and drive's physical space. The remaining modules are not so essential, and may be re-written, but it is recommended to copy them from the same HDD model with the same service data version, for example, the modules: 04h (HS), 3Dh. Some modules can be copied from any suitable drive, namely: 08h, 09h, 0Bh, 0Ch, 27h, 2Dh, 31h, 32h, 36h, 51h, 52h, 60h, 70h; however, in 95% of cases corruption influences not the whole list but

just a part of it. As a rule, the problem is in log modules, while all the rest cause read errors because of those malfunctioning modules. Rewriting those corrupted modules automatically restores access to the rest. Please see above the importance characteristics of various modules.

Attention! Prior to starting the drive restoration, it is necessary to save all the modules and the ROM firmware to have an opportunity to reverse the changes. Use the «Reserve HDD resources» menu item to do that.

12. ROM data structure

Table 12.1 Represents the firmware structure in ROM, and Fig. 12.1. demonstrates its sample header.

Address	Length	Purpose
00 h	32 bytes	Keyword: © FUJITSU
20 h	4 bytes	Firmware version
24 h	4 bytes	Version date
28 h	2 bytes	Reserved
2A h	1 byte	Version prefix
2B h	1 byte	Flag byte (presence of adaptive data, heads' map and disks' map)
2C h	4 bytes	Checksum for the whole ROM including adaptive data but without header
30 h	16 bytes	ASCII family name
...
...
1FDE0 h	512 bytes	Adaptive data (checksum adjusted and equal to 0) (for families using adaptive data)
1FFE0 h	32 bytes	Keyword: © FUJITSU ¹

```

00000: 28 43 29 20 46 55 4A 49 54 53 55 20 31 39 39 39  © FUJITSU 1999
00010: 2D 20 20 20 20 20 20 20 20 20 20 20 20 20 20  -
00020: 38 22 00 24 20 00 10 31 22 00 0E 00 00 00 DE 63  8" $ 1" . _c
00030: 48 31 33 4C 2D 30 32 20 20 20 20 20 20 20 20  H13L-02

```

Fig. 12.1. Sample firmware header in ROM

The loaded firmware portion, the so-called overlay, has a similar header (MHN2xxxAT and newer). It is located in the service area on disk in the module ID=3Dh (besides, in MHR2xxxAT and newer drive families it is also stored in module 3Eh), and loaded to HDD RAM during initialization. The essential condition is an absolute match between the overlay version and the ROM firmware version. The overlay does not contain adaptive data, and may have different length depending on its version. Its last 32 bytes contain the keyword «©FUJITSU».

12.1. Flags byte in ROM

Among other purposes, those flags are used to select the number of the head that will be used to read service information when drive power is switched on. Therefore, when the original ROM is lost and a drive cannot load using a borrowed ROM, you should try selecting another boot head in the flags byte described in this section. The procedure can be performed in HEX editor since ROM header is not covered by the checksum (unlike main data).

Flags byte is located at offset 2Bh from ROM beginning and consists of 8 bits. The bits meanings are as follows:

¹ – For MHN2xxxAT and newer drive families. The keyword was not used in earlier drive families (the area used to be filled with FFh code).

15. Unlocking password-protected drives

The problem of disabling drive passwords can arise in case when a user set a password on a drive and has forgotten it, or when a password has been set by a malicious virus program. In the first case you can view the password in the «SA structure test» mode. In the second case, unprintable ASCII characters (beyond the 20h – 7Fh range) are frequently used. That is why the «Security subsystem» mode in the utility provides for a password resetting option.

The feature is accessible from the utility startup dialog or from the «Security subsystem» menu.

When the utility starts, it analyzes the HDD ID. If password protection is enabled, then the «Password unlocking» button becomes active.




Fig.15.1 Password removal

Password removal is performed automatically for all supported drive families. For all families (except for MHV2xxxYY) the procedure only requires drive connection to the power supply and ATA cables (password removal in MHV2xxxYY drives will be explained in detail further). The following situations are possible after the procedure:

- ◆ The utility disables password protection successfully. Utility start in standard mode follows. You can analyze the drive firmware, user data are freely accessible.
- ◆ The utility fails to disable password protection. Then it displays a dialog suggesting possible actions. SA access will be limited in some drive families, user data cannot be accessed.

Dialog displayed by the utility in case of password removal failure:




Fig. 15.2. Error dialog.

- ◆ Clicking «Yes» initiates a new attempt to disable password protection.
- ◆ If you click «No», an attempt to launch the utility will be made in order to allow manual security override using tools unknown to the utility.
- ◆ Clicking «Cancel» exits the utility completing work with it.

