





## 2.2. 1.8" HDD

Drive family	Model	Capacity, GB	RPM	Cache buffer, MB	Height, mm	Connector type	Heads
C4K40	HTC424040F9AT00 (DK13FA-40)	40	4200	2	9	2.5"	4
	HTC424020F7AT00 (DK14FA-20)	20			7	2.5"	2
C4K60	HTC426060G9AT00	60	4200	2	9	2.5"	4
	HTC426040G9CE00	40			9	2.5"	4
	HTC426030G7AT00	30			7	2.5"	2
	HTC426020G7CE00	20			7	2.5"	2
	HTC426030G7CE00	30			7	ZIF	2
	HTC426020G7CE00	20			7	ZIF	2
C4K60 Slim	HTC426060G8CE00	60	4200	2	8	ZIF	4
	HTC426040G8CE00	40			8	ZIF	4
	HTC426030G5CE00	30			5	ZIF	2
	HTC426020G5CE00	20			5	ZIF	2

**Abbreviations:** RPM – Revolutions Per Minute – rotational velocity. N/A – data not available.

## 3. Utility features

The utility can perform the following functions:

- ◆ Reset HDD password.
- ◆ Read and write service information.
- ◆ Check service tracks and rewrite them completely.
- ◆ Read microcode from FLASH memory and write it replacing damaged code.
- ◆ Gain access to user data in factory (techno) mode for data recovery purposes, when it cannot be accessed normally.
- ◆ Test drive heads.
- ◆ Read RAM.
- ◆ Read the zone allocation table.
- ◆ Reset S.M.A.R.T.
- ◆ Clear Error Log.
- ◆ After errors, output extensive diagnostic messages about error causes.
- ◆ Clear PList and GList.
- ◆ Assign defects using PList.
- ◆ Indication of extended diagnostic messages informing about errors and HDD status.
- ◆ Indication of LBA-CHS conversion results.



## 3) List of service data modules:

Module ID	Purpose
DR <sup>1</sup>	Serial number
DP <sup>2</sup>	Adaptive data.
PD <sup>3</sup>	Primary Data, PLIST
GD <sup>3</sup>	Grown Data, GLIST и error log
ID <sup>4</sup>	Identification, serial number and Max LBA value in case of its modification.
SD <sup>3</sup>	Secure Data. Password module.
10 00 <sup>5</sup>	SMART, current values.
10 00 <sup>5</sup>	SMART, threshold values.

**Note:**

- 1 – in FB, FA, EB, EA, DA, C4K40, and C4K60 drive families only.
- 2 – in DA family only.
- 3 – AA and BA drive families have no identifier.
- 4 – in AA and BA drive families the module also contains adaptive data.
- 5 – the hexadecimal value acts as module identifier.

4) The modules are protected with a checksum. A HDD reads first the module on cylinder 0 using head 0. If the checksum does not match, then the drive reads the module using head 1. If checksum mismatch occurs again as well, then in AA and BA families drives read modules using heads 2 and 3 (when present) while in B, FA, EB, EA, DA, CA, C4K40, and C4K60 families drives read the modules from cylinder 2. If at least one copy has been read successfully, the HDD switches to the normal operation mode. If none of the copies containing modules DR, DP, PD, GD, and SD can be read, then such HDD switches to inoperability state and responds to all commands with ERR=04h (ABORT).

## 5. Terminal mode


The terminal mode allows the operator to read ROM and RAM content at the specified addresses. The utility also allows reading (and recording) of microcode from (to) microprocessor Flash ROM.

## 6. Preparing for work

- 1) Plug the IDE cable of your PC-3000 tester board into the IDE connector of the PC-2" adapter.
- 2) Connect the power cable to the corresponding connector of the PC-2" adapter. If a PC-3K PWR power supply adapter is present, then it should be used as power source. Otherwise, you have to use a standard external PC power supply unit and switch power off/on manually after a respective request displayed on-screen.
- 3) Connect the drive being tested to the PC-2" adapter; please pay attention to the separate group of contacts on drive and adapter connectors. Set the jumpers in accordance with the on-board scheme for Hitachi HDD.
- 4) Connect the PC-2" adapter to COM port using the PC-KALOK adapter or to USB port using the PC-USB-TERMINAL adapter.
- 5) Switch on the power supply to the drive being tested. If the PC-3K PWR adapter is available, you can control drive power using the Power icon on the utility toolbar.

## 7. Launching the utility

After utility start, it displays a dialog for selection of drive family and model.



*Fig. 7.1. Utility start.*

The utility at the start uses the COM port to read such HDD ID parameters as HDD family, microcode version, microcode checksum; then it sends techno commands and reads the zone allocation table.

Below is a sample report output to utility log after running those checks without errors:

```
Com identification.....: Ok
Code ver.....: K4B62400
Code CS..... : 1287h
Techno On.....: Ok
Techno+ ON.....: Ok
Zone table.....: Ok
```

**Attention!** If the first three checks end in an error (indicating either malfunction of the PCB or COM port of the HDD or its improper connection), then microcode reading and loading, work with passwords, reading of RAM or ROM will be impossible.

After utility start, the following features become available:

1) Utility status

2) Work with ROM

Read RAM  
Read ROM

3) Work with service area

Heads test  
Zone allocation table  
SA structure test  
Read modules  
Write modules  
Reading service tracks  
Writing service tracks  
Read HDD microcode  
Write HDD microcode  
Microcode compilation  
Security subsystem





## 8.3. Work with service area

The «Work with service area» menu contains a group of commands intended for manipulating the data in ROM and in modules within the service area on disk surface.

### 8.3.1. Heads test

The test performs reading of all zones using all physical heads. You can specify the number of reading commands to use per zone in the dialog displayed before the test begins. If the test reveals errors, they are displayed in Cylinder-Head-Sector format, i.e. the utility shows error location.

If you check the «Cancel current head test if an error occurs» option, then error occurrence will exclude the head that has produced it from further testing while the remaining heads will go on. The test will be terminated, if errors occur on all heads.

### 8.3.2. Reading

The «Reading» test has been implemented in the utility for the following reason: after occurrence of any error the program will output an extensive diagnostic message about error cause. The feature is not available in the universal utility. After the test you can estimate the chances for data recovery and HDD repair.

The «Reading» test allows the user to check surface readability in two modes: normal and techno. The data read during the procedure are not transferred anywhere, the test checks reading only.

Selection of that mode opens the following dialog:




Fig. 8.3. Reading.

You can specify the initial and final LBA or enable/disable the «Techno On» checkbox.

If you enable the «Techno On» checkbox, then reading will be performed in factory mode. That might be useful in some cases, when a drive contains corrupted modules preventing data access in normal mode. However, sending the «Techno On» key to such drive may allow reading of user data. After you have discovered the opportunity, you may use Data Extractor PCI for data recovery.

If you disable the «Techno On» checkbox, the utility will perform reading in normal (user) mode.

### 8.3.3. Zone allocation table

Selection of the «Zone allocation table» menu item makes the utility log the table of zone allocation with indication of the initial (Beg Cyl) and final (End Cyl) cylinders of each zone and the number of sectors per zone (SPT – Sector Per Track).

### 8.3.4. SA Structure test

This test reads the table of modules in the service area checking module headers and their checksums. The utility scans modules using all heads that allow module reading and checks cylinders 0 and 2 (where the modules are located). In drive models where modules are located within the 0 cylinder only, the reading routine uses heads as the only criterion.

Test progress is reflected in log; after completion the utility generates a report. Fragment of the report:



If you select the «Writing modules from HDD profile files» option, the following dialog will be displayed:




Fig. 8.5. Writing modules.

If you select the «Writing modules from HDD profile files» option, the following dialog will be displayed:




Fig. 8.6. Writing modules





perform writing using the heads indicated in file names. If you choose «To selected heads», the utility will record data using the heads specified in the head selection field.

### 8.3.9. Read HDD microcode

**Attention!** Correct functioning of that feature requires connection via COM port.

Selection of that mode allows the operator to read the microcode from HDD microprocessor ROM and save it to a file in format necessary for subsequent loading.

At the start of that mode, you should specify in the initial dialog the HDD profile or database as the destination for the copied microcode.

The reading procedure takes 30-40 minutes. It can be interrupted at any time, but the data will be lost in that case. Upon completion of the reading procedure the utility generates two files: «Original.bin» and «Microcode.bin». The first file contains a binary ROM image. The second is used to store compiled microcode required for the «Write HDD microcode» command.

### 8.3.10. Write HDD microcode

Selection of that mode allows the operator to write microcode to Flash ROM inside HDD microprocessor.


Microcode loading takes 1-2 minutes. It is not recommended to interrupt the procedure, because the HDD may cease to function as a result.

At the start of that mode, you should specify in the initial dialog the original microcode file from the HDD profile or database. Correct application of that command requires an available microcode file in special format. The file can be produced using the «Read HDD microcode» or «Microcode compilation» commands. The default name assigned to the file generated by those commands is «Microcode.bin». After file selection the utility starts the loading procedure characterized by a spindle stop before the actual loading and spindle motor spin-up following after successful completion. In case of an error the utility displays a diagnostic message informing about the step during which the failure took place.

### 8.3.11. Microcode compilation

Selection of that command allows conversion of a binary ROM image to special file format required for the «Write HDD microcode» command.

Selection of the «Microcode compilation» command brings up the following dialog:



*Fig. 8.10. Microcode compilation.*

In the dialog you should select the source file and the target location where converted file will be saved: HDD profile folder or database.

The microcode file will be generated as soon as you choose the file and destination and press the «Convert» button.

### 8.3.12. Security subsystem

**Attention!** Correct functioning of that feature requires connection via COM port.

That menu item provides access to reading Master and User passwords. In 5-10 seconds after selection of «Security subsystem» the utility outputs to log both Master and User passwords in ASCII and hex notation. Having thus obtained the passwords, you can launch the universal utility and run «Tools → HDD → Security subsystem» to reset the password using standard means.

### 8.3.13. Clear S.M.A.R.T.

The «Clear S.M.A.R.T.» command returns S.M.A.R.T. attributes to their initial values. In certain cases when S.M.A.R.T. attribute thresholds are exceeded a HDD may cease to function; in such cases the option allows to restore HDD operation.

**Attention!** Interaction of this feature with drives of BA and AA families is studied incompletely yet, the «Clear S.M.A.R.T.» command may function incorrectly. Save copies of the S.M.A.R.T. modules before using it to allow their subsequent restoration, if necessary.

### 8.3.14. Clear S.M.A.R.T. Error Log

The «Clear S.M.A.R.T. Error Log» command clears the error log. The errors are displayed during SMART viewing in the «Summary Error Log» tab. Hitachi HDD log errors detected in the process of reading or verification and append them to GLIST. In some cases it may cause GLIST overflow resulting in drive's inability to operate properly. The «Clear S.M.A.R.T. Error Log» feature can fix the problem. However, the errors are not always registered in GLIST.

## 8.4. Logical test

The menu allows the operator to perform reading/writing based on logical parameters.

Selection of that item brings up the following dialog window:




Fig. 8.11. Logical scan parameters.



The number of defects in PList is displayed in the status line in the lower part of the defects editor window; in this example there are 10 of them.

The defects editor can be used to delete, add or modify the defect records. Pressing the  button displays the following dropdown menu:

Tracks grouping	Alt+1
Write defects into P-List of the HDD	Alt+2
Sort defects	Alt+3
Statistics	Alt+4
Remove iterations and intersections	Alt+5

*Fig. 8.14.*

### 8.5.1.1. Tracks grouping

The command allows the operator to select the heads to be used for arrangement of track defects from defects located within the same track and accessible for the same head.

### 8.5.1.2. Write defects into P-List

Selection of that command will record the defects list into HDD. It is necessary to remove duplicate defects selecting the «Remove iterations and intersections» menu item before recording.

### 8.5.1.3. Sort defects

Selection of that menu item sorts defects in the table in the ascending order by the cylinder numbers.

### 8.5.1.4. Statistics

Selection of the item displays a diagram reflecting the distribution of defects among heads and zones indicating the number of defects per each head and zone.

### 8.5.1.5. Remove iterations and intersecions

Selection of that command deletes from the table records containing links to the same defective locations. That command must be performed before you begin to «Write defects into P-List».

## 8.5.2. Clearing P-LIST

The feature allows the operator to clear P-List. Before its selection you will have to backup the PD module to have an opportunity for its restoration later.

## 8.5.3. Clearing G-LIST

The «Clearing G-List» command allows the operator to partially clear the GList. Hitachi HDD log errors detected in the process of reading or verification and append them to GLIST. In some cases it may cause GLIST overflow resulting in drive's inability to operate properly. The «Clearing G-List» feature can fix the problem. However, it clears only some (not all) errors.

The «Clearing G-List» procedure also verifies P-List integrity. Therefore, if a critical P-List corruption exists, «Clearing G-List» will be applied with an error and access to user data will be blocked in such cases.

## 8.5.4. LBA to CHS conversion

Indication of LBA-CHS conversion results.

Selection of that item brings up the following dialog window:



Fig. 8.15. Conversion LBA->CHS.

Here you can select the initial and final LBA for conversion and the increment that indicates the number of LBA to add to the current LBA for the next conversion operation. E.g., if the initial, final LBA and conversion step values are 0, 10 and 3 respectively, then the conversion will be performed for the LBA 0, 3, 6, and 9.

## 9. Opportunities for data recovery from Hitachi HDD

### 9.1. Problems related to microcode corruption

Malfunctions pertaining to microcode corruption or damage to its integrity are characterized by the following HDD behaviour:

- ◆ HDD reports on readiness immediately after power-up
- ◆ the spindle motor does not spin up and a very quiet sound is heard at power-up
- ◆ an attempt to send any command causes an 04h (ABRT) error.

The same symptoms appear after a failed attempt to write microcode to drive.

However, if the electronics of the HDD is not damaged, you can restore drive functionality by writing to it microcode copied from another HDD (the family and models of both drives must be identical).

Hitachi HDD use lots of various microcode versions. Still, according to our observations, the microcode versions are compatible between HDD belonging to the same drive family and model. They are *incompatible* between HDD of the same family characterized by different capacities.

### 9.2. Problems resulting from damaged modules

As we have noted above, Hitachi HDD use only a few models and not all of them are essential for drive functionality. If at least one sound copy of each module is available, the HDD continues to work.

If a HDD responds to read commands with ABORT, that may be caused by reading errors or mismatch of checksums of all copies available for one of its modules.

#### 9.2.1. Module DR

When all copies of that module are damaged, HDD responds to all data access commands with ERR=04h (ABORT). An attempt to read the service data modules also results in ABORT by the HDD. The situation with a damaged DR module can be corrected only by rewriting all service tracks (not just the DR module). The tracks used for overwriting must be copied from the same HDD model. If you switch power off and on after that, the HDD becomes functional but it will be impossible to access its data. If you perform recording in normal mode all over the disk surface, then the HDD will be ready for operation but the original data will be lost.

## 9.2.2. Module PD

When all copies of that module are damaged, HDD responds to all data access commands with ERR=04h (ABORT). An example of a defect-free module instance for FB, EB, EA, DA, CA, C4K40, and C4K60 drive families:

```
00000000h: 50 44 00 24 00 1E 00 1E 00 1E 00 1E 00 1E 00 1E ; PD.$.....
00000010h: 00 1E FF FF ; .....ÿÿ
00000020h: FF FF 06 3A 00 00 00 00 00 00 00 00 00 00 00 ; ÿÿ:.....
```

The remaining portion of the module contains recorded zeros. If all copies are damaged, you may attempt overwriting one of them with the above sample model or zeros provided that there are no surface defects in the service area. Doing so will provide an opportunity to access disk surface. To access the data, you will have to send the «Techno Off» then «Techno On» command sequence in the «Tools» → «Utility extensions» menu. However, you should keep in mind that if there were surface defects hidden in native PLIST, those defects would re-appear during reading or verification. Since the PLIST module is involved in calculation of the translation table, read data may turn out to be incorrect because of that new shift not yet taken into account while calculating their actual position.

## 9.2.3. Module GD

When all copies of that module are damaged, HDD responds to all data access commands with ERR=04h (ABORT). The structure of that module has not been decrypted completely yet. Unfortunately, it is the only module with unidentified algorithm of checksum calculation. An example of a defect-free module instance for FB, EB, EA, DA, CA, C4K40, and C4K60 drive families:

```
00000000h: 47 44 00 1E 00 00 00 01 00 00 00 00 00 00 00 ; GD.....
00000010h: 00 00 00 00 0F FF FF FF 00 00 00 00 09 F0 00 00 ; .....ÿÿ.....đ..
```

The remaining portion of the module contains recorded zeros. If all copies are damaged, you may attempt overwriting one of them with the above sample model or zeros provided that there are no surface defects in the service area. Doing so will provide an opportunity to access disk surface. To access the data, you will have to send the «Techno Off» then «Techno On» command sequence in the «Tools» → «Utility extensions» menu. However, you should keep in mind that if there were surface defects hidden in native GLIST, those defects would re-appear during reading or verification. Since the GLIST module is involved in calculation of the translation table, read data may turn out to be incorrect because of that new shift not yet taken into account while calculating their actual position.

## 9.2.4. Module SD

When all copies of that module are damaged, HDD responds to all data access commands with ERR=04h (ABORT). In FB, EB, EA, DA, CA, C4K40, and C4K60 drive families HDD also respond with ERR=04h (ABORT) to the Techno ON command when the module is damaged, i.e., in those families corruption of that module will definitely prevent access to user data. Currently no methods for its recovery are known.

However, in AA and BA drive families it is possible to access data. You will have to send the «Techno Off» then «Techno On» command sequence in the «Tools» → «Utility extensions» menu. After that data on disk can be accessed using Data Extractor.

## 9.2.5. Module ID

Corruption of all copies of that module does not affect HDD functioning and user data integrity. Still, its recovery is recommended. To accomplish that, copy an identical module from the same HDD model, modify the 6-character serial number in hex editor to make it match the label on HDA case (taking the last 6 figures of the serial number from HDA case) and recalculate its checksum. After that the modified module can be recorded instead of the damaged one.

Module recovery means taking the following steps. Select in «Tools» menu the «Database» or «Explore profile folder» command and specify any existing ID module (with an .rpm extension). Then the program will open a hex editor window; use it to correct the serial number, then Select All by pressing [Ctrl+A], right-click the selection to produce the context menu and use it to invoke Plug-ins → Hitachi 16 bit check sum (recalculation). The program will recalculate the checksum and after that the module will be ready for saving in the required directory and recording to the HDD service area using the «Writing modules» function.



## 10. Advanced features

The «Tools»→«Utility extensions» provides access to features specific for the Hitachi utility only.

### 10.1. Modules table

Selection of that menu item opens the «Modules table» window. The mode can be used for operations over modules copied from disk surface. Right-clicking within the window opens a context menu containing the following items:

- ◆ View module
- ◆ Start SA structure test
- ◆ Check one module
- ◆ Rewrite module from DB
- ◆ Rewrite modules group from DB
- ◆ Rewrite modules group from files
- ◆ Show log

The same menu items can be accessed by clicking the respective button in the upper window part.

#### 10.1.1. View module

Selection of that menu item opens the hex editor window containing the selected module. You can view, edit, save the module back to the service area on disk surface or to a file, you can also recalculate its checksum.

Checksum recalculation for DR, DP, PD, GD, SD, and ID modules is performed using «Hitachi 16 bit check sum» algorithm while for ~SAT and ~STH modules «Hitachi 8 bit check sum» algorithm is employed.

**The editor also allows loading of a module copied earlier and its subsequent editing and recording to disk surface or to a file.**

#### 10.1.2. Start SA structure test

That menu item opens the «Modules selection» window where you can select all modules or one required module to check. The selected modules will be verified, and the utility will display the result in its log in the lower window part.

Modules will be tested for readability and match between header and checksum.

#### 10.1.3. Check one module

The utility just checks the module highlighted by the cursor.

#### 10.1.4. Rewrite module from DB

This menu item allows rewriting a module with a copy from the database. The utility performs actions described in the «Writing modules» section.

#### 10.1.5. Rewrite modules group from DB

This menu item allows rewriting a group of modules from the database. The utility performs actions described in the «Writing modules» section.

#### 10.1.6. Rewrite modules group from files

This menu item allows rewriting a group of modules from HDD profile. The utility performs actions described in the «Writing modules» section.

#### 10.1.7. Show log

If you enable this option in the menu, the utility will display its log in the lower part of the «Modules table» tab. It helps simultaneously test modules and monitor occurring errors through the log.







## 13. Appendix 2. Plugging a C4K60 Slim HDD with ZIF-connector to PC-3000 USB

1.8" models of HTC426060G8CE00, HTC426040G8CE00, HTC426030G5CE00, and HTC426020G5CE00 HDD belonging to the C4K60 Slim drive family are intended for use in portable devices (video cameras, audio players, etc.). Such drives use parallel ATA interface but they are equipped with a miniature ZIF plug, therefore connection to PC-3000 USB requires a 1.8" ZIF – 3.5" IDE adapter. The adapter is not included into the product package, but it is available for purchase over the Internet, for example, at one of the following web sites:

<http://www.addonics.com/products/io/aaedt18ide25.asp>

<http://www.trademe.co.nz/Computers/Other/auction-197277974.htm>

[http://www.darkwire.com.au/html/zif\\_to\\_3\\_5\\_ide\\_adapter.html](http://www.darkwire.com.au/html/zif_to_3_5_ide_adapter.html)

Figure 13.1 demonstrates HDD connection to one of such adapters




Fig. 13.1.

Some features of the utility require connection to the COM port established via the PC USB Terminal. Terminal connection is arranged by soldering wires between contacts 1 and 2 of the ZIF connector on the adapter and the 10-pin connector on the PC USB Terminal. The scheme for terminal connection is shown in the Figure 13.2.




Fig. 13.2.