

## DESCRIPTION OF FLOPPY TO USB EMULATOR - [FU] version

Model: SFR1M44-FU/FUN/LUN  
SFR1M2-FU  
SFRM72-FU

### Description:

- \*the usb stick used is FAT16/32.
- \*data in root directory and 99 folders can be searched.
- \*long file name and 4-level directory in 99 folders supported.(only for SFR1M44-LUN)
- \*two 8segments indicate the number of folder point at, the number is 2nd and 3th of folder name, the first letter of folder must be '0', folder must be selected before the usb stick plug on.
- \*no capacity limitation of data in root directory and 99 folders.
- \*a built-in memory used to store data and convert format between FAT16/32 and FAT12, data keep even power down.
- \*only 1.44MB/1.2MB/720KB data can be stored into built-in memory and accessed by the system at one time through FDD interface.
- \*if total capacity of data in root directory or folder exceed 1.44MB/1.2MB/720KB, all data is seperate into blocks, all blocks can be searched by press the [IN] button once again.

