



# PC

## 软硬件技术资料大全

〔美〕 Thom Hogan 著

计 帆 译

清华大学出版社

无论你到哪个书店，请你购买清华大学出版社出版的图书——《PC 软硬件技术资料大全》。

这是一本帮助你克服重重困难的工具书。尤其是当你在图书馆查找一些解决关键问题的资料时，此书就会帮助你克服困难。这是唯一的一本把 PC 各个方面的重要内容归纳成一个整体的书，它把已经出版过的各种 PC 方面的书籍综合成一本使用方便的指导书。它是 IBM PC 及其兼容机、PS/2、PC 和 MS-DOS 的资料大全。本书有 500 多页，含有几百个表，包括以下内容：

- 数字转换和字符集
- DOS 命令和用法
- DOS 功能调用和支持表
- DOS BIOS 支持表
- 其它中断，鼠标器，EMS 支持
- Microsoft 窗口
- 芯片，跳线，开关和寄存器
- 硬件描述
- 键盘，显示器适配器和外围设备等

每一个表都包括数据来源、与本书中相关内容的联系以及帮助你使用本书的注释。

《PC 软硬件技术资料大全》快速而准确地为你带来关于计算机及其操作的系统知识。

# PC 软硬件技术资料大全

[美] Thom Hogan 著

计 帆 译

清华大学出版社

## 内 容 简 介

这是一本 IBM PC 及其兼容机、PS/2 的软硬件技术资料大全。全书共有 3 篇，编成 9 章，由 669 个表组成。第 I 篇为基础篇，包括各种数值转换、ASCII 码等。第 II 篇为软件篇，包括 DOS 命令、DOS 功能调用、DOSBIOS 调用、中断、鼠标器、EMS、Microsoft 窗口等。第 III 篇为硬件篇，包括键盘、显示器适配器、外围设备、芯片、接插件、开关、寄存器、硬件描述等。

本书内容丰富、资料齐全，是计算机软硬件人员必备的工具书。

### PC 软硬件技术资料大全

[美] Thom Hogan 著

计 帆 译

责任编辑 范素珍

☆

清华大学出版社出版发行

北京 清华园

清华大学印刷厂印刷

☆

开本：787×1092 1/16 印张：35.75 字数：915 千

1990 年 6 月第 1 版 1990 年 8 月第 2 次印刷

印数：10001~15000

ISBN 7-302-00719-5 / TP · 245

定价：20.00 元

## 译 者 的 话

本书为译书，原书名为《The Programmer's PC Sourcebook》，作者是 Thom Hogan，由 Microsoft 出版社于 1988 年出版。

由于原书是 PC 硬件的基本资料，全书都是表格与数据，读者对其内容可一目了然，所以我们只译了目录，且给出中英文对照，正文一律不译，以保持原书的风格。

本书把有关 IBM PC 的硬件基础知识全部综合在一起，内容丰富，资料齐全。对于某一个问题的，你原来可能需要查找四、五本书，现在只需查阅这一本书就够了。所以，这是一本硬件人员必备的工具书。

作者花费了多年时间，依据 20 多本手册及无数参考书、杂志，收集了各篇内容摘要和详细数据，对 IBM 计算机的所有重要资料进行了系统地整理和提炼。全书共三篇，编成九章，由 669 个表组成。每个表的下方都有注释及此表的资料来源处。为确保每一栏目中所参照的内容准确无误，作者极认真、极细致地编写每一个表格，并且尽量收进最新的资料。

许多计算机专家认为此书极为难得。如果手中有这么一本书，就不用东奔西跑地查找资料了。其内容在五、六年之内不会改变。可以预料，此书将为发展我国的计算机事业做出较大的贡献。望广大计算机工作者对此书提出宝贵的修改意见，以便再版。

译 者

1990 年 4 月

# 导 言

本书把有关 IBM PC 的软件和硬件的技术资料综合在一起，构成了一本 PC 大全。

ASCII 字符定义与 IBM PC 的译码之间的差异是什么呢？往往需要查找两种参考书才能回答，但在本书里答案全有了。假如你用单步调试程序追踪程序的执行，并且程序中隐含有问题的 BIOS 显示功能调用，那么，为了得到问题的答案，你就必须知道 6845（显示器控制器）芯片寄存器的功能是什么，BIOS 的功能是什么，要求什么数据，所有这些问题的答案都在这本书中了。

无论你需要了解什么有关 IBM PC 的知识，例如，插接卡的大小，跳线，ROM BIOS 例行程序，内部寄存器，DOS 功能等等，在这本书里，你至少会找到最基本的答案。

为了向你提供一个有关 PC 的技术知识的概要，现将本书内容简介如下：

- 提供了本书全部资料的来源：IBM 和 Microsoft 技术参考书。
- 提供了书中全部内容的详细目录。
- 把有关 IBM 个人计算机的技术资料逻辑地组织在一起。

下面介绍本书的各种功能及如何使用。

## 一、IBM 和 Microsoft 技术资料的基本来源

IBM 和 Microsoft 的技术资料往往分散地放在许多书中。IBM 个人计算机系列既包括软件，也包括硬件。因此，你要想找到特殊的 BIOS 功能方面的技术资料，你就必须查找四、五本 IBM 参考书，如 XT 参考书，AT 参考书，PS/2 参考书，备选样机和适配器参考书及 BIOS 参考书。

本书从 IBM 和 Microsoft 的技术资料及用户使用参考书中提炼出最重要的内容。因此，在本书中的每一个 BIOS 的相关表都来自于八、九种不同的参考书。我之所以称这本书为最基本知识的来源书，就是因为当你要查找需要的资料时，首先应查找资料的来源，这本书将全部参考书都列在书末的参考文献中了。

## 二、阅读指导

本书中的内容总是先给出原始数据的来源。另外，书中还包括横向联系，即每一个表同时列出与此表相关的其它表。

与相关知识的联系，可从表下方的 Source 和 See Also 栏目中得到。

- Source 栏目告诉你本表的来源书名及页数。
- See Also 栏目告诉你在本书中与本表相关的其它表号及表名。

作者尽量确保 Source 栏目所提供的参阅页码准确无误，但是，由于 IBM 不断地更新它的技术文件，因此自然会有一小部分增加了页码。但 IBM 在新版本中仍保留原页码（例如，可在原版的第 1 页和第 2 页之间加上 1.1 和 1.2）。当需要修改时，IBM 只把整个章节重新编号。因此，你在使用我编的相应版本的本书时，其参考书的页码是准确的或很接近，因而很容易找到在 Source 栏目中所需要的内容。

### 三、全书的组织编排

就象帮助你了解表间的相互关系一样，为了帮助你找到所需要的资料，本书由以下三个主要部分（简称篇）组成：

- 第 I 篇 包括各种各样的基础知识。
- 第 II 篇 包括软件内容。
- 第 III 篇 包括硬件内容。

每一篇进一步编成章。全书所有的章均按顺序编号，而与篇的编号无关，如下所示。

#### 第 I 篇 基础知识

##### 第 1 章 一般知识

#### 第 II 篇 软件

##### 第 2 章 DOS 命令、实用程序和一览表

##### 第 3 章 DOS 功能调用和支持表

##### 第 4 章 DOS BIOS 调用和支持表

##### 第 5 章 其它中断、鼠标器和 EMS 支持

##### 第 6 章 Microsoft 窗口

#### 第 III 篇 一般 PC 硬件

##### 第 7 章 键盘、显示器适配器、外围设备

##### 第 8 章 芯片、跳线、开关、寄存器

##### 第 9 章 硬件描述

所有表都编了号，正如我前面所说的，在 See Also 横向联系参考中使用的这些编号。每个表的编号中的第一个数字表示章号，这样，你将会在以 3 开头的表中找到第 3 章关于 DOS 功能的资料。表编号的第二部分（用·与章号分隔开）是该章表的编号，例如，表 3.148 就是第 3 章 DOS 功能的第 148 个表。

对于全书的结构而言，特别值得说明的是：BIOS 和硬件中断程序均编入本书的软件篇，这是因为在编制软件时会经常用到它们。硬件部分如芯片、开关和寄存器等则放在书中的硬件篇中。这样编排是合乎逻辑的。

### 四. 表是如何表示的

下面是一个有代表性的表的例子。

表上边的黑体字是表的编号及表名。他们可帮助你确认表的内容。编号也可用于本书的横向参照。

如果一个表由于在某些内容上稍有差异而被分成两个小表（例如 PC-XT 与 PS/2 之间），则每一小表的上方都用斜体字标明。

表的左侧及上侧的文字用斜体字，以区别表的内容。表名用大写字母，其下方空一行，用来标明这是一组表。表中的数据项经常使用缩写，例如：

MSB = most significant bit or byte	(最高有效位或字节)
LSB = least significant bit or byte	(最低有效位或字节)
LO = low order	(低有效位)
HO = high order	(高有效位)

- 000 = a binary value of zero, zero, zero (二进制数 000)
- 010 = a binary value of zero, one, zero (二进制数 010)
- 0X1 = a binary value of zero, don't care, one (二进制数 0X1, 其中 X 为任何值, 即 0 或 1 均可)
- 1A(26) = the first value is hexadecimal; the parentheses contain the decimal equivalent (第一个值是十六进制数, 圆括号内是与之相等的十进制数的值)
- string = any group of text characters enclosed in quotes (包括在 31 号中的任一组文本字符)
- command = any valid command (validity depends upon context) (任何有效命令 (有效度依赖于上下文))
- label = a string that corresponds to the label formatting requirements (字符串, 该串对应一个格式所需要的标号)
- state = Boolean TRUE or FALSE value (布尔真或假值)
- char = character (a single byte of information) (字符(信息的单个字节))
- int = integer number (整数)
- filespec = a file's name and optional extension (type) (一个文件名和扩展名(类型))
- dbl word = double word (four bytes) (双字(4 个字节))
- word = two bytes (2 个字节)
- R = reserved (保留的)
- O = obsolete (废除的)

#### 0.0. SOME REFERENCES USED IN COMPILING THIS BOOK

Reference	Edition	Part Number	Publisher	Used in Section
Advanced MS-DOS, by Ray Duncan	NA	ISBN 0-914845-77-2	Microsoft Press	2. DOS
DOS 3.3 Reference Manual	1st (Apr 87)	80X0667	IBM	2. DOS
DOS 3.3 Technical Reference	1st (Apr 87)	80X0945	IBM	2. DOS
IBM Technical Reference Options and Adapters Vol 1	1st (Apr 84)	6137804	IBM	7. Peripherals
IBM Technical Reference Options and Adapters Vol 2	1st (Apr 84)	6137806	IBM	7. Peripherals
Microprocessor and Peripheral Handbook Vol 1	1987	ISBN 1-55512-062-8	Intel	8. Chips
Microprocessor and Peripheral Handbook Vol 2	1987	ISBN 1-55512-062-8	Intel	8. Chips
Microsoft Windows 2.0 User's Guide	NA	NA	Microsoft	6. Windows
MS-DOS 3.3 Programmer's Reference	NA	410630014-330-R04-0787	Microsoft	2. DOS
PS/2 BIOS Technical Reference	1st (Apr 87)	84X1514	IBM	7.,8.,9. Hardware
PS/2 Model 30 Technical Reference	1st (Apr 87)	68X2201	IBM	7.,8.,9. Hardware
PS/2 Model 50 and 60 Technical Reference	1st (Apr 87)	68X2224	IBM	7.,8.,9. Hardware
Technical Reference PC AT	Rev (Mar 86)	6280099	IBM	7.,8.,9. Hardware
Technical Reference PC Network	1st (Sept 84)	6322916	IBM	7. Peripherals
Technical Reference PC/XT	1st (Jan 83)	6936763	IBM	7.,8.,9. Hardware
Technical Reference PC/XT and Portable PC	Mar 86	6280089	IBM	7.,8.,9. Hardware
Windows Programmer's Reference	NA	050-051053-200-10Z-1087	Microsoft	6. Windows

#### Notes:

These references are updated periodically by their publishers. The page numbers referenced in this book are taken from the edition described above and are subject to change.

#### See Also:

Bibliography

下面是一个典型的表，用于通过寄存器传送信息的任何功能或中断调用。如果一个寄存器没有被功能调用使用，则它的内容是空的，就假设它不变化。此表明确地指出了破坏了的寄存器，可帮助你正确地理解功能调用怎样使用寄存器。

### 3.045. FUNCTION 29H -- PARSE FILENAME

Prior to Calling Function		Upon Return From Function		
	High	Low		
AX	29H	Parse control byte	AX	Status*
BX			BX	
CX			CX	
DX			DX	
SP			SP	
BP			BP	
SI	Offset of pointer to string to parse		SI	Offset of pointer 1 byte past parsed string
DI	Offset of pointer to buffer to contain unopened FCB		DI	Offset of pointer to unopened FCB
IP			IP	
flags			flags	
CS			CS	
DS	Segment of pointer to string to parse		DS	Segment of pointer 1 byte past parsed string
SS			SS	
ES	Segment of pointer to buffer for unopened FCB		ES	Segment of pointer to unopened FCB
Buffer	Empty			

**Notes:** \*00=FCB created, no wildcard characters; 01=FCB created, wildcard characters used in filename FFH=drive letter invalid

**Source:** IBM DOS 3.3 Technical Reference, pages 6-95 to 6-97

**See Also:** 2.51. Filename Separator Characters  
3.001. INT 21H Functions by DOS Version Summary  
3.123. Unopened FCB Format  
3.142. Parse Control Byte

在表的末尾都有注释。虽然并非每一个表都有同样的注释内容，但所注释的范畴却是相同的：

- **Version Info:** 告诉你版本或产品的差异。
- **Legend:** 描述仅在某一个表中的缩写。
- **Notes:** 提供与此表及此表所有的脚注有关的资料内容。脚注常用星号表示，一个星号表示第一个脚注，两个星号表示第二个脚注等等。当有四个以上的星号脚注时，用“+”表示第五个脚注，用“¥”表示第六个脚注，“\$”表示第七个脚注。
- **Source:** 提供表中数据的基本来源。
- **See Also:** 提供本书中与此表相关的其它表。

Thom Hogan

# 目 录

## Contents

第 I 篇 基础 <i>Miscellaneous Information</i> .....	1
第 1 章 基本知识 <i>General Information</i> .....	3
数值转换 <i>Numeric Conversions</i>	
十六进制数 <i>Hexadecimal</i>	
1.01 十六进制到十进制数值转换 .....	4
Hexadecimal to Decimal Number Conversion	
1.02 十六进制到二进制数值转换 .....	5
Hexadecimal to Binary Number Conversion	
1.03 十六进制到八进制数值转换 .....	6
Hexadecimal to Octal Number Conversion	
1.04 十六进制数的加法表 .....	7
Hexadecimal Addition Tables	
1.05 十六进制数的乘法表 .....	9
Hexadecimal Multiplication Tables	
二进制数 <i>Binary</i>	
1.06 二进制数值转换 .....	10
Binary Number Conversions	
1.07 二进制到有符号的十进制数值转换 .....	12
Binary to Signed Decimal Number Conversion	
八进制数 <i>Octal</i>	
1.08 八进制到十进制数值转换 .....	13
Octal to Decimal Number Conversion	
1.09 八进制到十六进制数值转换 .....	14
Octal to Hexadecimal Number Conversion	
1.10 八进制到二进制数值转换 .....	15
Octal to Binary Number Conversion	
十进制数 <i>Decimal</i>	
1.11 十进制到二进制数值转换 .....	16
Decimal to Binary Number Conversion	
1.12 十进制到十六进制数值转换 .....	17
Decimal to Hexadecimal Number Conversion	
1.13 十进制到八进制数值转换 .....	18
Decimal to Octal Number Conversion	

## 数据格式 Data Formats

1.14	二进制补码 .....	19
	Two's Complements	
1.15	通用8086系列数据格式 .....	20
	Common 8086 Family Data Formats	
1.16	通用数值数据格式 .....	21
	Common Numeric Data Formats	
1.17	通用字符串格式 .....	22
	Common String Formats	
1.18	通用内存区术语 .....	23
	Common Memory Area Terminology	
1.19	二进制码十进制数值格式 .....	24
	Binary Coded Decimal Number Format	

## ASCII

1.20	ASCII控制码 .....	25
	ASCII Control Codes	
1.21	ASCII字符集 .....	25
	ASCII Character Set	
1.22	IBM ASCII字符集 .....	27
	IBM ASCII Character Set	
1.23	IBM 扩展字符码 .....	29
	IBM Extended Character Codes	
1.24	线形字符集 .....	30
	Line Drawing Character Set	

## EBCDIC

1.25	EBCDIC 字符集 .....	31
	EBCDIC Character Set	

## 其它 Other

1.26	常用基数的数字位 .....	33
	Digit Positions in Common Bases	
1.27	2 的方幂 .....	33
	Powers of Two	
1.28	国际通用的ASCII码次序 .....	34
	International Sort Ordering	
1.29	逻辑运算真值表 .....	35
	Truth Tables for Logical Operations	

第II篇 软件 Software .....	37
第2章 DOS命令,实用程序和一览表 DOS Commands,Utilities,and Summaries ...	39
DOS命令 DOS Commands	
2.01 DOS命令一览表 .....	40
DOS Command Summary	
带有斜线参数的命令集 Summaries of Commands with Slash Parameters	
2.02 APPEND 参数 .....	41
APPEND Parameters	
2.03 ATTRIB 参数 .....	42
ATTRIB Parameters	
2.04 BACKUP 参数 .....	42
BACKUP Parameters	
2.05 CHKDSK 参数 .....	42
CHKDSK Parameters	
2.06 COMMAND 参数 .....	42
COMMAND Parameters	
2.07 COPY 参数 .....	43
COPY Parameters	
2.08 DIR 参数 .....	43
DIR Parameters	
2.09 DISKCOMP 参数 .....	43
DISKCOMP Parameters	
2.10 DISKCOPY 参数 .....	43
DISKCOPY Parameters	
2.11 FIND 参数 .....	43
FIND Parameters	
2.12 FORMAT 参数 .....	44
FORMAT Parameters	
2.13 GRAFTABL 参数 .....	44
GRAFTABL Parameters	
2.14 GRAPHICS 参数 .....	44
GRAPHICS Parameters	
2.15 MODE 参数 .....	45
MODE Parameters	
2.16 PRINT 参数 .....	47
PRINT Parameters	
2.17 PROMPT 专用字符 .....	48
PROMPT Special Characters	

2.18	PROMPT ANSI 控制串 .....	48
	PROMPT ANSI Control Strings	
2.19	PROMPT ANSI 显示属性串 .....	49
	PROMPT ANSI Display Attribute Strings	
2.20	REPLACE 参数 .....	49
	REPLACE Parameters	
2.21	RESTORE 参数 .....	50
	RESTORE Parameters	
2.22	SHARE 参数 .....	50
	SHARE Parameters	
2.23	SORT 参数 .....	50
	SORT Parameters	
2.24	XCOPY 参数 .....	51
	XCOPY Parameters	
<b>DOS 命令实用程序 DOS Command Utilities</b>		
2.25	编辑命令行 .....	51
	Editing Command Lines	
2.26	批处理文件命令集和缺省设置 .....	52
	Batch File Commands and Default Settings	
2.27	CONFIG.SYS命令集和缺省设置 .....	53
	CONFIG.SYS Commands and Default Settings	
2.28	DRIVPARM 和 DRIVER.SYS 参数设置 .....	53
	DRIVPARM and DRIVER.SYS Parameter Settings	
<b>DOS 实用程序 DOS Utilities</b>		
2.29	DEBUG 命令一览表 .....	54
	DEBUG Command Summary	
2.30	EDLIN 命令一览表 .....	55
	EDLIN Command Summary	
2.31	LIB 运算集 .....	56
	LIB Operators Summary	
2.32	LINK 参数集 .....	56
	LINK Parameters Summary	
<b>DOS 磁盘布局 DOS Disk Layouts</b>		
2.33	目录项 .....	57
	Directory Entries	
2.34	文件属性字节 .....	57
	File Attribute Byte	
2.35	日期/时间格式 .....	58
	Date / Time Formats	

2.36	FAT 布局 .....	58
	FAT Layouts	
2.37	磁盘 ID 字节 .....	59
	Disk ID Byte	
2.38	磁盘引导记录布局 .....	60
	Disk Boot Record Layout	
2.39	磁盘分区表布局 .....	60
	Disk Partition Table Layout	
2.40	软磁盘格式集 .....	61
	Floppy Disk Format Summary	
2.41	硬磁盘格式集 .....	61
	Hard Disk Format Summary	
<b>DOS 文件布局 DOS File Layouts</b>		
2.42	EXE 文件标题 .....	62
	EXE File Header	
2.43	COM 程序格式 .....	62
	COM Program Layout	
2.44	COM 文件与 EXE 文件的差别 .....	62
	COM versus EXE File Differences	
2.45	字形文件(码页)布局 .....	63
	Font File (Code Page) Layout	
2.46	操作系统文件集 .....	63
	Operating System Files Summary	
2.47	DOS 命令文件和版本一览表 .....	64
	Included Command Files Summary	
2.48	一般文件类型(扩展名) .....	65
	Common File Types ( Extensions)	
<b>其它 Other</b>		
2.49	典型 DOS 内存使用 .....	68
	Typical DOS Memory Usage	
2.50	在文件名中允许使用的字符 .....	69
	Allowable Characters in Filenames	
2.51	文件名分隔字符 .....	69
	Filename Separator Characters	
<b>第 3 章 DOS 功能调用和支持表 DOS Function Calls and Support Tables .....</b>		
<b>71</b>		
<b>INT 21H 功能一览表 INT 21H Function Summaries</b>		
3.001	DOS 各种版本的 INT 21H 功能一览表 .....	72
	INT 21H Functions by DOS Version Summary	

3.002	INT 21H 键盘功能一览表 .....	74
	INT 21H Keyboard Functions Summary	
3.003	INT 21H 面向 FCB 的功能一览表 .....	75
	INT 21H FCB-oriented Functions Summary	
3.004	INT 21H 面向把柄的功能一览表 .....	76
	INT 21H Handle-oriented Functions Summary	
3.005	INT 21H 面向 IOCTL 设备的功能一览表 .....	77
	INT 21H IOCTL Device-oriented Functions Summary	
3.006	INT 21H 系统功能一览表 .....	78
	INT 21H System Functions Summary	
3.007	INT 21H 网络功能一览表 .....	79
	INT 21H Network Functions Summary	
每个 INT 21H 功能全集 Individual INT 21H Function Summaries		
3.008	典型 DOS 寄存器用法 .....	79
	Typical DOS Register Use	
3.009	功能 00H—终止程序 .....	80
	Function 00H—Terminate Program	
3.010	功能 01H—读键盘和回送 .....	80
	Function 01H—Read Keyboard and Echo	
3.011	功能 02H—显示字符 .....	81
	Function 02H—Display Character	
3.012	功能 03H—辅助输入 .....	81
	Function 03H—Auxiliary Input	
3.013	功能 04H—辅助输出 .....	82
	Function 04H—Auxiliary Output	
3.014	功能 05H—打印字符 .....	82
	Function 05H—Print Character	
3.015	功能 06H—直接控制台输入/输出 .....	83
	Function 06H—Direct Console I/O	
3.016	功能 07H—直接控制台输入无回送 .....	84
	Function 07H—Direct Console Input Without Echo	
3.017	功能 08H—读键盘无回送 .....	84
	Function 08H—Read Keyboard Without Echo	
3.018	功能 09H—显示字符串 .....	85
	Function 09H—Display String	
3.019	功能 0AH—带缓冲区键盘输入 .....	85
	Function 0AH—Buffered Keyboard Input	
3.020	功能 0BH—检查键盘状态 .....	86
	Function 0BH—Check Keyboard Status	

3.021	功能 0CH—清除缓冲区, 读键盘.....	86
	Function 0CH—Flush Buffer, Read Keyboard	
3.022	功能 0DH—复位磁盘 .....	87
	Function 0DH—Reset Disk	
3.023	功能 0EH—选择磁盘.....	87
	Function 0EH—Select Disk	
3.024	功能 0FH—用 FCB 打开文件 .....	88
	Function 0FH—Open File With FCB	
3.025	功能 10H—用 FCB 关闭文件 .....	89
	Function 10H—Close File With FCB	
3.026	功能 11H—用 FCB 寻找第一个目录项 .....	90
	Function 11H—Find First Entry With FCB	
3.027	功能 12H—用 FCB 寻找下一个目录项 .....	91
	Function 12H—Find Next Entry With FCB	
3.028	功能 13H—用 FCB 删除文件 .....	92
	Function 13H—Delete File With FCB	
3.029	功能 14H—用 FCB 顺序读 .....	93
	Function 14H—Sequential Read With FCB	
3.030	功能 15H—用 FCB 顺序写 .....	94
	Function 15H—Sequential Write With FCB	
3.031	功能 16H—用FCB建立文件.....	95
	Function 16H—Create File With FCB	
3.032	功能 17H—用 FCB 改文件名 .....	96
	Function 17H—Rename File With FCB	
3.033	功能 19H—取当前磁盘 .....	96
	Function 19H—Get Current Disk	
3.034	功能 1AH—置磁盘传送地址 .....	97
	Function 1AH—Set Disk Transfer Address	
3.035	功能 1BH—取缺省驱动器数据.....	97
	Function 1BH—Get Default Drive Data	
3.036	功能 1CH—取驱动器数据.....	98
	Function 1CH—Get Drive Data	
3.037	功能 21H—用 FCB 随机读.....	99
	Function 21H—Random Read With FCB	
3.038	功能 22H—用 FCB 随机写 .....	100
	Function 22H—Random Write With FCB	
3.039	功能 23H—用 FCB 取文件大小 .....	101
	Function 23H—Get File Size With FCB	
3.040	功能 24H—用 FCB 置相应记录 .....	102

	Function 24H—Set Relative Record With FCB	
3.041	功能 25H—置中断向量 .....	103
	Function 25H—Set Interrupt Vector	
3.042	功能 26H—建立新的程序段 .....	103
	Function 26H—Create New Program Segment	
3.043	功能 27H—用 FCB 随机块读 .....	104
	Function 27H—Random Block Read With FCB	
3.044	功能 28H—用 FCB 随机块写 .....	105
	Function 28H—Random Block Write With FCB	
3.045	功能 29H—分析文件名 .....	106
	Function 29H—Parse File Name	
3.046	功能 2AH—取系统日期 .....	107
	Function 2AH—Get System Date	
3.047	功能 2BH—置系统日期 .....	108
	Function 2BH—Set System Date	
3.048	功能 2CH—取系统时间 .....	108
	Function 2CH—Get System Time	
3.049	功能 2DH—置系统时间 .....	109
	Function 2DH—Set System Time	
3.050	功能 2EH—置 / 复位检验标志 .....	109
	Function 2EH—Set / Reset Verify Flag	
3.051	功能 2FH—取磁盘传送地址 .....	110
	Function 2FH—Get Disk Transfer Address	
3.052	功能 30H—取 DOS 版本 .....	110
	Function 30H—Get DOS Version	
3.053	功能 31H—保持进程 .....	111
	Function 31H—Keep Process	
3.054	功能 33H—控制 C 检查 .....	111
	Function 33H—Control-C Check	
3.055	功能 35H—取中断向量 .....	112
	Function 35H—Get Interrupt Vector	
3.056	功能 36H—取磁盘自由空间 .....	112
	Function 36H—Get Disk Free Space	
3.057	功能 38H,00H—取国家数据 .....	113
	Function 38H,00H—Get Country Data	
3.058	功能 38H,xxH—置国家数据 .....	113
	Function 38H,xxH—Set Country Data	
3.059	功能 39H—建立子目录 .....	114
	Function 39H—Create Subdirectory	

3.060	功能 3AH—删除子目录 .....	115
	Function 3AH—Remove Subdirectory	
3.061	功能 3BH—改变当前目录 .....	116
	Function 3BH—Change Current Directory	
3.062	功能 3CH—建立文件 .....	117
	Function 3CH—Create File	
3.063	功能 3DH—打开文件 .....	118
	Function 3DH—Open File	
3.064	功能 3EH—关闭文件 .....	118
	Function 3EH—Close File	
3.065	功能 3FH—用句把读 .....	119
	Function 3FH—Read Using Handle	
3.066	功能 40H—用句把写 .....	120
	Function 40H—Write Using Handle	
3.067	功能 41H—删除文件 .....	121
	Function 41H—Delete File	
3.068	功能 42H—移动文件指针 .....	122
	Function 42H—Move File Pointer	
3.069	功能 43H,00H—取文件属性 .....	122
	Function 43H,00H—Get File Attributes	
3.070	功能 43H,01H—置文件属性 .....	123
	Function 43H,01H—Set File Attributes	
3.071	功能 44H,00H—取 IOCTL 数据 .....	123
	Function 44H,00H—Get IOCTL Data	
3.072	功能 44H,01H—置 IOCTL 数据 .....	124
	Function 44H,01H—Set IOCTL Data	
3.073	功能 44H,02H—IOCTL 读字符串 .....	124
	Function 44H,02H—IOCTL Read String	
3.074	功能 44H,03H—IOCTL 写字符串 .....	125
	Function 44H,03H—IOCTL Write String	
3.075	功能 44H,04H—IOCTL 读块 .....	125
	Function 44H,04H—IOCTL Read Block	
3.076	功能 44H,05H—IOCTL 写块 .....	126
	Function 44H,05H—IOCTL Write Block	
3.077	功能 44H,06H—IOCTL 取输入状态 .....	126
	Function 44H,06H—IOCTL Get Input Status	
3.078	功能 44H,07H—IOCTL 取输出状态 .....	127
	Function 44H,07H—IOCTL Get Output Status	
3.079	功能 44H,08H—IOCTL 是可更换的吗? .....	127

	Function 44H,08H—IOCTL Is Removable?	
3.080	功能 44H,09H—IOCTL 是重新定向的块吗? .....	128
	Function 44H,09H—IOCTL Is Redirected Block?	
3.081	功能 44H,0AH—IOCTL 重新定向把柄吗? .....	128
	Function 44H,0AH—IOCTL Is Redirected Handle?	
3.082	功能 44H,0BH—IOCTL 改变重试次数 .....	129
	Function 44H,0BH—IOCTL Change Retry Count	
3.083	功能 44H,0CH—一般的把柄 IOCTL .....	130
	Function 44H,0CH—Generic IOCTL for Handles	
3.084	功能 44H,0DH—一般设备 IOCTL .....	131
	Function 44H,0DH—Generic IOCTL for Devices	
3.085	功能 44H,0EH—取逻辑驱动映象 .....	132
	Function 44H,0EH—Get Logical Drive Map	
3.086	功能 44H,0FH—置逻辑驱动映象 .....	132
	Function 44H,0FH—Set Logical Drive Map	
3.087	功能 45H—复制文件把柄 .....	133
	Function 45H—Duplicate File Handle	
3.088	功能 46H—强迫复制文件把柄 .....	133
	Function 46H—Force Duplicate File Handle	
3.089	功能 47H—取当前目录 .....	134
	Function 47H—Get Current Directory	
3.090	功能 48H—分配内存 .....	134
	Function 48H—Allocate Memory	
3.091	功能 49H—自由分配内存 .....	135
	Function 49H—Free Allocated Memory	
3.092	功能 4AH—置块 .....	135
	Function 4AH—Set Block	
3.093	功能 4BH,00H—装载并执行程序 .....	136
	Function 4BH,00H—Load and Execute Program	
3.094	功能 4BH,03H—装载覆盖 .....	136
	Function 4BH,03H—Load Overlay	
3.095	功能 4CH—结束进程 .....	137
	Function 4CH—End Process	
3.096	功能 4DH—取返回码 .....	137
	Function 4DH—Get Return Code	
3.097	功能 4EH—寻找第一个文件 .....	138
	Function 4EH—Find First File	
3.098	功能 4FH—寻找下一个文件 .....	139
	Function 4FH—Find Next File	

3.099	功能 54H—取检验状态 .....	140
	Function 54H—Get Verify State	
3.100	功能 56H—更换文件名 .....	140
	Function 56H—Rename File	
3.101	功能 57H,00H—取文件的日期或时间 .....	141
	Function 57H,00H—Get Date / Time of File	
3.102	功能 57H,01H—置文件的日期或时间 .....	141
	Function 57H,01H—Set Date / Time of File	
3.103	功能 58H,00H—取分配策略 .....	142
	Function 58H,00H—Get Allocation Strategy	
3.104	功能 58H,01H—置分配策略 .....	143
	Function 58H,01H—Set Allocation Strategy	
3.105	功能 59H,—取扩展错误 .....	144
	Function 59H—Get Extended Error	
3.106	功能 5AH—建立暂存文件 .....	144
	Function 5AH—Create Temporary File	
3.107	功能 5BH—建立新文件 .....	145
	Function 5BH—Create New File	
3.108	功能 5CH,00H—加锁文件 .....	145
	Function 5CH,00H—Lock File	
3.109	功能 5CH,01H—解锁文件 .....	146
	Function 5CH,01H—Unlock File	
3.110	功能 5EH,00H—取机器名 .....	146
	Function 5EH,00H—Get Machine Name	
3.111	功能 5EH,02H—置打印机字符串 .....	147
	Function 5EH,02H—Set Printer String	
3.112	功能 5EH,03H—取打印机字符串 .....	147
	Function 5EH,03H—Get Printer String	
3.113	功能 5FH,02H—取指定清单条目口 .....	148
	Function 5FH,02H—Get Assignment List Entry	
3.114	功能 5FH,03H—产生指定清单条目口 .....	149
	Function 5FH,03H—Make Assignment List Entry	
3.115	功能 5FH,04H—消除指定清单条目口 .....	150
	Function 5FH,04H—Cancel Assignment List Entry	
3.116	功能 62H—取程序段前缀 .....	150
	Function 62H—Get Program Segment Prefix	
3.117	功能 63H—取引导字节表 .....	151
	Function 63H—Get Lead Byte Table	
3.118	功能 65H—取扩展的国家信息 .....	151

	Function 65H—Get Extended Country Info	
3.119	功能 66H,01H—取全局码页 .....	152
	Function 66H,01H—Get Global Code Page	
3.120	功能 66H,02H—置全局码页 .....	152
	Function 66H,02H—Set Global Code Page	
3.121	功能 67H—置把柄次数 .....	153
	Function 67H—Set Handle Count	
3.122	功能 68H—COM执行文件 .....	153
	Function 68H—Commit File	
功能支持表 Function Support Tables		
<i>FCBs FCBs</i>		
3.123	未打开的FCB格式 .....	154
	Unopened FCB Format	
3.124	打开的 FCB 格式 .....	154
	Opened FCB Format	
3.125	扩展的 FCB 格式 .....	154
	Extended FCB Format	
3.126	改名 FCB 格式 .....	155
	Rename FCB Format	
错误码 <i>Error Codes</i>		
3.127	FCB 错误码 .....	155
	FCB Error Codes	
3.128	从功能 59H 返回的扩展错误码 .....	156
	Extended Error Codes Returned from Function 59H	
把柄 <i>Handles</i>		
3.129	把柄存取字节 .....	158
	Handle Access Byte	
3.130	预先定义的把柄 .....	158
	Predefined Handles	
3.131	把柄指针移动方法 .....	159
	Handle Pointer Movement Methods	
3.132	寻找第一个或下一个数据块 .....	159
	Search First / Next Data Blocks	
设备 <i>Devices</i>		
3.133	设备数据字 .....	160
	Device Data Word	
3.134	块设备功能码 .....	160
	Block Device Function Codes	
3.135	设备参数块 .....	161

	Device Parameter Blocks	
系统	<i>System</i>	
3.136	程序段前缀的布局 .....	162
	Program Segment Prefix Layout	
3.137	逻辑驱动数 .....	163
	Logical Drive Numbers	
3.138	执行程序的参数块 .....	163
	Execute Program Parameter Block	
3.139	覆盖程序参数块 .....	164
	Overlay Program Parameter Block	
3.140	内存分配策略 .....	164
	Memory Allocation Strategies	
3.141	环境块 .....	164
	Environment Blocks	
3.142	分析控制字节 .....	165
	Parse Control Byte	
3.143	国家码缓冲区布局 .....	165
	Country Code Buffer Layout	
3.144	国家码 .....	166
	Country Codes	
3.145	DOS 内存控制块 .....	166
	DOS Memory Control Blocks	
3.146	码页参数块 .....	167
	Code Page Parameter Blocks	
3.147	码页的设置 .....	168
	Code Page Assignments	
设备驱动程序	<i>Device Drivers</i>	
3.148	保留的设备名和链序 .....	168
	Reserved Device Names and Chain Order	
3.149	设备驱动程序标题 .....	169
	Device Driver Headers	
3.150	设备属性码 .....	169
	Device Attribute Codes	
3.151	设备请求标题状态字段和错误码 .....	170
	Device Request Header Status Field & Error Codes	
3.152	设备请求标题 .....	171
	Device Request Header	
3.153	INIT 设备请求 .....	172
	INIT Device Request	

3.154	介质检查请求 .....	172
	Media Check Request	
3.155	建立 BIOS 参数块请求 .....	172
	Build BIOS Parameter Block Request	
3.156	读设备请求 .....	173
	Read Device Request	
3.157	写设备请求 .....	173
	Write Device Request	
3.158	不等待非破坏性读请求 .....	173
	Non-destructive Read With No Wait Request	
3.159	打开或关闭请求 .....	174
	Open or Close Request	
3.160	可移动介质请求 .....	174
	Removable Media Request	
3.161	状态请求 .....	174
	Status Request	
3.162	刷新请求 .....	174
	Flush Request	
3.163	普通的 IOCTL 请求 .....	175
	Generic IOCTL Request	
3.164	逻辑驱动映象请求 .....	175
	Logical Drive Map Request	
3.165	介质描述符表的布局 .....	175
	Media Descriptor Table Layout	
3.166	时钟器件表的布局 .....	176
	Clock Device Table Layout	
3.167	设备 BPB 布局 .....	176
	Device BPB Layout	

#### 第 4 章 DOS BIOS 调用和支持表 DOS BIOS Calls and Support Tables

##### BIOS 集和一般数据 BIOS Summaries & General Data

4.001	BIOS 服务一览表 .....	178
	BIOS Services Summary	
4.002	BIOS 存储器用法一览表 .....	183
	BIOS Memory Usage Summary	
4.003	扩展 BIOS 数据域的布局 .....	187
	Extended BIOS Data Area Layout	
4.004	型号字节 .....	187
	Model Number Bytes	

## INT 10H: 显示器服务 Video Services

4.005	INT 10H, AH = 00H—置方式 .....	188
	INT 10H, AH = 00H—Set Mode	
4.006	INT 10H, 显示方式 .....	188
	INT 10H, Display Modes	
4.007	INT 10H, AH = 01H—置光标类型 .....	189
	INT 10H, AH = 01H—Set Cursor Type	
4.008	INT 10H, AH = 02H—置光标位置 .....	189
	INT 10H, AH = 02H—Set Cursor Position	
4.009	INT 10H, AH = 03H—读光标位置 .....	190
	INT 10H, AH = 03H—Read Cursor Position	
4.010	INT 10H, AH = 04H—读光笔位置 .....	190
	INT 10H, AH = 04H—Read Light Pen Position	
4.011	INT 10H, AH = 05H—选择显示页 .....	191
	INT 10H, AH = 05H—Select Display Page	
4.012	INT 10H, AH = 06H—初始化窗口,窗口向上滚动 .....	191
	INT 10H, AH = 06H—Init Window , Scroll Window Up	
4.013	INT 10H, AH = 07H—初始化窗口,窗口向下滚动 .....	192
	INT 10H, AH = 07H—Init Window , Scroll Window Down	
4.014	INT 10H, AH = 08H—读字符和属性 .....	192
	INT 10H, AH = 08H—Read Character and Attribute	
4.015	INT 10H, AH = 09H—写字符和属性 .....	193
	INT 10H, AH = 09H—Write Character and Attribute	
4.016	INT 10H, AH = 0AH—写光标位置上的字符 .....	193
	INT 10H, AH = 0AH—Write Character Only at Cursor	
4.017	INT 10H, AH = 0BH—置调色板 .....	194
	INT 10H, AH = 0BH—Set Color Palette	
4.018	INT 10H, 调色板和彩色值 .....	194
	INT 10H, Palette and Color Values	
4.019	INT 10H, AH = 0CH—写像素 .....	195
	INT 10H, AH = 0CH—Write Pixel	
4.020	INT 10H, AH = 0DH—读像素 .....	195
	INT 10H, AH = 0DH—Read Pixel	
4.021	INT 10H, AH = EH—按电传方式写文本 .....	196
	INT 10H, AH = 0EH—Write Text in Teletype Mode	
4.022	INT 10H, AH = 0FH—取当前显示方式 .....	196
	INT 10H, AH = 0FH—Get Current Display Mode	
4.023	INT 10H, AH = 10H—置调色板寄存器 .....	197
	INT 10H, AH = 10H—Set Palette Registers	

4.024	INT 10H, AH = 11H—字符生成	197
	INT 10H, AH = 11H—Character Generator	
4.025	INT 10H, AH = 12H—更换选择	198
	INT 10H, AH = 12H—Alternate Select	
4.026	INT 10H, AH = 13H—写串	199
	INT 10H, AH = 13H—Write String	
4.027	INT 10H, AH = 1AH, AL = 00H—读显示码	200
	INT 10H, AH = 1AH, AL = 00H—Read Display Codes	
4.028	INT 10H, AH = 1AH, AL = 01H—写显示码	200
	INT 10H, AH = 1AH, AL = 01H—Write Display Codes	
4.029	INT 10H, 显示码	201
	INT 10H, Display Codes	
4.030	INT 10H, AH = 1BH—返回状态	201
	INT 10H, AH = 1BH—Return State	
4.031	INT 10H 显示状态的缓冲区布局	202
	INT 10H, Video State Buffer Layout	
4.032	INT 10H, AH = 1CH, AL = 00H—返回保存或恢复	203
	INT 10H, AH = 1CH, AL = 00H—Return Save / Restore	
4.033	INT 10H, AH = 1CH, AL = 01H—保存状态	203
	INT 10H, AH = 1CH, AL = 01H—Save State	
4.034	INT 10H, AH = 1CH, AL = 02H—恢复状态	204
	INT 10H, AH = 1CH, AL = 02H—Restore State	
4.035	INT 10H, AH = FEH—取显示器缓冲区(Topview)	204
	INT 10H, AH = FEH—Get Video Buffer (Topview)	
4.036	INT 10H, AH = FFH—更新显示器缓冲区(Topview)	205
	INT 10H, AH = FFH—Update Video Buffer (Topview)	
INT 11H:	4.037 取设备清单服务 Get Equipment List Service	205
INT 12H:	4.038 取内存大小服务 Get Memory Size Service	206
INT 13H:	磁盘服务 Disk Services	
4.039	INT 13H, AH = 00H—复位磁盘系统	206
	INT 13H, AH = 00H—Reset Disk System	
4.040	INT 13H, AH = 01H—取磁盘系统状态	207
	INT 13H, AH = 01H—Get Disk System Status	
4.041	INT 13H, 磁盘系统状态的字节布局	207
	INT 13H, Disk System Status Byte Layout	
4.042	INT 13H, AH = 02H—读磁盘	208
	INT 13H, AH = 02H—Read Disk	
4.043	INT 13H, AH = 03H—写磁盘	208
	INT 13H, AH = 03H—Write Disk	

4.044	INT 13H, AH = 04H—检验扇区 .....	209
	INT 13H, AH = 04H—Verify Sectors	
4.045	INT 13H, AH = 05H—格式化磁道柱面 .....	210
	INT 13H, AH = 05H—Format Cylinder	
4.046	INT 13H, AH = 06H—格式化磁道柱面并建立坏的扇区标志 .....	211
	INT 13H, AH = 06H—Format Cylinder Set Bad Sector Flags	
4.047	INT 13H, AH = 07H—在指定磁道柱面开始格式化 .....	212
	INT 13H, AH = 07H—Format Drive Starting at Cylinder	
4.048	INT 13H, AH = 08H—读驱动参数 .....	212
	INT 13H, AH = 08H—Read Drive Parameters	
4.049	INT 13H, AH = 09H—初始化驱动器双特性 .....	213
	INT 13H, AH = 09H—Init Drive Pair Characteristics	
4.050	INT 13H, AH = 0CH—查找 .....	213
	INT 13H, AH = 0CH—Seek	
4.051	INT 13H, AH = 0DH—更换磁盘复位 .....	214
	INT 13H, AH = 0DH—Alternate Disk Reset	
4.052	INT 13H, AH = 10H—测试驱动器就绪 .....	214
	INT 13H, AH = 10H—Test Drive Ready	
4.053	INT 13H, AH = 11H—重新校准驱动器 .....	215
	INT 13H, AH = 11H—Recalibrate Drive	
4.054	INT 13H, AH = 15H—读 DASD 类型 .....	215
	INT 13H, AH = 15H—Read DASD Type	
4.055	INT 13H, AH = 16H—软盘改变行状态 .....	216
	INT 13H, AH = 16H—Diskette Change Line Status	
4.056	INT 13H, AH = 17H—置 DASD 格式类型 .....	216
	INT 13H, AH = 17H—Set DASD Type for Format	
4.057	INT 13H, AH = 18H—置介质格式类型 .....	217
	INT 13H, AH = 18H—Set Media Type for Format	
4.058	INT 13H, 介质描述符表 .....	217
	INT 13H, Media Descriptor Table	
4.059	INT 13H, AH = 19H—停在起始点 .....	218
	INT 13H, AH = 19H—Park Heads	
4.060	INT 13H, AH = 1AH—格式化单元 .....	218
	INT 13H, AH = 1AH—Format Unit	
4.061	INT 13H, 格式化单元修改位 .....	219
	INT 13H, Format Unit Modifier Bits	
INT 14H: 串行通讯 Serial Services		
4.062	INT 14H, AH = 00H—初始化通讯口 .....	219
	INT 14H, AH = 00H—Init Communications Port	

4.063	INT 14H, 调制解调器的状态字节 .....	220
	INT 14H, Modem Status Byte	
4.064	INT 14H, 通讯口参数字节 .....	220
	INT 14H, Com Port Parameter Byte	
4.065	INT 14H, AH = 01H—写字符 .....	221
	INT 14H, AH = 01H—Write Character	
4.066	INT 14H, AH = 02H—读字符 .....	221
	INT 14H, AH = 02H—Read Character	
4.067	INT 14H, AH = 03H—状态请求 .....	222
	INT 14H, AH = 03H—Status Request	
4.068	INT 14H, AH = 04H—扩展初始化 .....	222
	INT 14H, AH = 04H—Extended Init	
4.069	INT 14H, AH = 05H, AL = 00H—读调制解调器的控制寄存器 .....	223
	INT 14H, AH = 05H, AL = 00H—Read Modem Control Register	
4.070	INT 14H, AH = 05H, AL = 01H—写调制解调器的控制寄存器 .....	224
	INT 14H, AH = 05H, AL = 01H—Write Modem Control Register	
INT 15H: 盒式设备及其它扩展服务   Cassette Services / Miscellaneous		
Extended Services		
4.071	INT 15H, AH = 00H—开启盒式设备马达 .....	224
	INT 15H, AH = 00H—Cassette Motor ON	
4.072	INT 15H, AH = 01H—关闭盒式设备马达 .....	225
	INT 15H, AH = 01H—Cassette Motor OFF	
4.073	INT 15H, AH = 02H—读盒式设备数据块 .....	225
	INT 15H, AH = 02H—Cassette Read Data Blocks	
4.074	INT 15H, AH = 03H—写盒式设备数据块 .....	226
	INT 15H, AH = 03H—Cassette Write Data Blocks	
4.075	INT 15H, AH = 0FH—周期中断格式化 .....	226
	INT 15H, AH = 0FH—Format Periodic Interrupt	
4.076	INT 15H, AH = 4FH—键盘截取 .....	227
	INT 15H, AH = 4FH—Keyboard Intercept	
4.077	INT 15H, AH = 80H—打开设备 .....	227
	INT 15H, AH = 80H—Open Device	
4.078	INT 15H, AH = 81H—关闭设备 .....	228
	INT 15H, AH = 81H—Close Device	
4.079	INT 15H, AH = 82H—程序终止 .....	228
	INT 15H, AH = 82H—Program Terminate	
4.080	INT 15H, AH = 83H—事件等待 .....	229
	INT 15H, AH = 83H—Event Wait	
4.081	INT 15H, AH = 84H—控制杆的支持 .....	229

	INT 15H, AH = 84H—Joystick Support	
4.082	INT 15H, AH = 85H—系统请求按键.....	230
	INT 15H, AH = 85H—System Request Key Pressed	
4.083	INT 15H, AH = 86H—等待.....	230
	INT 15H, AH = 86H—Wait	
4.084	INT 15H, AH = 87H—移动块.....	231
	INT 15H, AH = 87H—Move Block	
4.085	INT 15H, AH = 88H—取扩展内存尺寸.....	231
	INT 15H, AH = 88H—Get Extended Memory Size	
4.086	INT 15H, AH = 89H—切换到保护方式.....	232
	INT 15H, AH = 89H—Switch to Protected Mode	
4.087	INT 15H, 全局的描述符表 .....	232
	INT 15H, Global Descriptor Table	
4.088	INT 15H, AH = 90H—设备忙.....	233
	INT 15H, AH = 90H—Device Busy	
4.089	INT 15H, AH = 91H—中断完成.....	234
	INT 15H, AH = 91H—Interrupt Complete	
4.090	INT 15H, AH = C0H—返回系统配置参数 .....	234
	INT 15H, AH = C0H—Return System Config Parameters	
4.091	INT 15H, 系统描述符表.....	235
	INT 15H, System Descriptor Table	
4.092	INT 15H, AH = C1H—返回扩展的 BIOS 程序段地址 .....	235
	INT 15H, AH = C1H—Return Ext BIOS Segment Address	
4.093	INT 15H, AH = C2H, AL = 00H—使能 / 禁止选取的设备.....	236
	INT 15H, AH = C2H, AL = 00H—Enable / Disable Pointing Device	
4.094	INT 15H, AH = C2H, AL = 01H—复位选取的设备.....	236
	INT 15H, AH = C2H, AL = 01H—Reset Pointing Device	
4.095	INT 15H, AH = C2H, AL = 02H—置取样率 .....	237
	INT 15H, AH = C2H, AL = 02H—Set Sample Rate	
4.096	INT 15H, AH = C2H, AL = 03H—置分辨率.....	237
	INT 15H, AH = C2H, AL = 03H—Set Resolution	
4.097	INT 15H, AH = C2H, AL = 04H—读设备类型.....	238
	INT 15H, AH = C2H, AL = 04H—Read Device Type	
4.098	INT 15H, AH = C2H, AL = 05H—初始化选取的设备 .....	238
	INT 15H, AH = C2H, AL = 05H—Initialize Pointing Device	
4.099	INT 15H, AH = C2H, AL = 06H—扩展命令 .....	239
	INT 15H, AH = C2H, AL = 06H—Extended Commands	
4.100	INT 15H, AH = C2H, AL = 07H—设备驱动程序初始化调用.....	240
	INT 15H, AH = C2H, AL = 07H—Device Driver Init Call	

4.101	INT 15H, 鼠标器端口状态字节 .....	240
	INT 15H, Mouse Port Status Bytes	
4.102	INT 15H, AH=C3H—监视器超时 .....	241
	INT 15H, AH=C3H—Watchdog Timeout	
4.103	INT 15H, AH=C4H—程序选择 .....	241
	INT 15H, AH=C4H—Prog Option Select	
INT 16H: 键盘服务 Keyboard Services		
4.104	INT 16H, AH=00H—读字符 .....	242
	INT 16H, AH=00H—Read Character	
4.105	INT 16H, AH=01H—读状态 .....	242
	INT 16H, AH=01H—Read Status	
4.106	INT 16H, AH=02H—读标志 .....	243
	INT 16H, AH=02H—Read Flags	
4.107	INT 16H, 键盘标志字节 .....	243
	INT 16H, Keyboard Flags Byte	
4.108	INT 16H, AH=05H—键盘写 .....	244
	INT 16H, AH=05H—Keyboard Write	
4.109	INT 16H, AH=10H—扩展键盘读 .....	244
	INT 16H, AH=10H—Extended Keyboard Read	
4.110	INT 16H, AH=11H—扩展键盘状态 .....	245
	INT 16H, AH=11H—Extended Keystroke Status	
4.111	INT 16H, AH=12H—扩展移位状态 .....	245
	INT 16H, AH=12H—Extended Shift Status	
4.112	INT 16H, 扩展键盘标志字节 .....	246
	INT 16H, Extended Keyboard Flags Byte	
INT 17H: 打印机服务 Printer Services		
4.113	INT 17H, AH=00H—写字符 .....	246
	INT 17H, AH=00H—Write Character	
4.114	INT 17H, 打印机状态字节 .....	246
	INT 17H, Printer Status Byte	
4.115	INT 17H, AH=01H—初始化打印机端口 .....	247
	INT 17H, AH=01H—Initialize Printer Port	
4.116	INT 17H, AH=02H—状态请求 .....	247
	INT 17H, AH=02H—Status Request	
INT 18H: 4.117 BASIC 装载器 BASIC Loader .....		
INT 19H: 4.118 自举装载器 Bootstrap Loader .....		
INT 1AH: 日期时间服务 Time of Day Services		
4.119	INT 1AH, AH=00H—读时钟计数 .....	249
	INT 1AH, AH=00H—Read Clock Count	

4.120	INT 1AH, AH = 01H—置时钟计数 .....	249
	INT 1AH, AH = 01H—Set Clock Count	
4.121	INT 1AH, AH = 02H—读实时钟时间 .....	250
	INT 1AH, AH = 02H—Read Real Time Clock Time	
4.122	INT 1AH, AH = 03H—置实时钟时间 .....	250
	INT 1AH, AH = 03H—Set Real Time Clock Time	
4.123	INT 1AH, AH = 04H—读实时钟日期 .....	251
	INT 1AH, AH = 04H—Read Real Time Clock Date	
4.124	INT 1AH, AH = 05H—置实时钟日期 .....	251
	INT 1AH, AH = 05H—Set Real Time Clock Date	
4.125	INT 1AH, AH = 06H—置实时钟报警 .....	252
	INT 1AH, AH = 06H—Set Real Time Clock Alarm	
4.126	INT 1AH, AH = 07H—关掉实时钟报警 .....	252
	INT 1AH, AH = 07H—Turn Off Real Time Clock Alarm	
4.127	INT 1AH, AH = 09H—读实时钟报警 .....	253
	INT 1AH, AH = 09H—Read Real Time Clock Alarm	
4.128	INT 1AH, AH = 0AH—读系统计时器天数 .....	253
	INT 1AH, AH = 0AH—Read System Timer Day Count	
4.129	INT 1AH, AH = 0BH—置系统计时器天数 .....	254
	INT 1AH, AH = 0BH—Set System Timer Day Count	

**第 5 章 其它中断,鼠标器,和 EMS 支持 Other Interrupts, Mouse, and EMS Support .....** **255**

5.01	DOS各种版本的中断用法 .....	256
	DOS Interrupt Usage by Version	
5.02	INT 24H 错误码 .....	257
	INT 24H Error Codes	
5.03	INT 25H 绝对磁盘读 .....	258
	INT 25H Absolute Disk Read	
5.04	INT 26H 绝对磁盘写 .....	258
	INT 26H Absolute Disk Write	
5.05	INT 25H和26H错误码 .....	259
	INT 25H and 26H Error Codes	
5.06	INT 2FH 多路复用 .....	259
	INT 2FH Multiplex	
5.07	INT 2FH 错误码 .....	260
	INT 2FH Error Codes	
鼠标器	Mouse	
5.08	INT 33H: 鼠标器功能一览表 .....	260

	INT 33H: Mouse Functions Summary	
5.09	INT 33H, AX = 00H—鼠标器安装标志 .....	261
	INT 33H, AX = 00H—Mouse Installed Flag	
5.10	INT 33H, AX = 01H—显示光标 .....	261
	INT 33H, AX = 01H—Show Cursor	
5.11	INT 33H, AX = 02H—隐示光标 .....	262
	INT 33H, AX = 02H—Hide Cursor	
5.12	INT 33H, AX = 03H—取位置和按钮状态 .....	262
	INT 33H, AX = 03H—Get Position and Button Status	
5.13	INT 33H, AX = 04H—置鼠标器光标位置 .....	263
	INT 33H, AX = 04H—Set Mouse Cursor Position	
5.14	INT 33H, AX = 05H—取按钮按下信息 .....	263
	INT 33H, AX = 05H—Get Button Press Information	
5.15	INT 33H, AX = 06H—取按钮释放信息 .....	264
	INT 33H, AX = 06H—Get Button Release Information	
5.16	INT 33H, AX = 07H—置最小和最大水平位置 .....	264
	INT 33H, AX = 07H—Set Min and Max Horizontal Position	
5.17	INT 33H, AX = 08H—置最小和最大垂直位置 .....	265
	INT 33H, AX = 08H—Set Min and Max Vertical Position	
5.18	INT 33H, AX = 09H—置图形的光标块 .....	265
	INT 33H, AX = 09H—Set Graphics Cursor Block	
5.19	INT 33H, AX = 0AH—置文本光标 .....	266
	INT 33H, AX = 0AH—Set Text Cursor	
5.20	INT 33H, AX = 0BH—读鼠标器移动计数器 .....	266
	INT 33H, AX = 0BH—Read Mouse Motion Counters	
5.21	INT 33H, AX = 0CH—置用户定义子输入屏蔽 .....	267
	INT 33H, AX = 0CH—Set User-Defined Subroutine Input Mask	
5.22	INT 33H, AX = 0DH—置光笔仿真开启 .....	267
	INT 33H, AX = 0DH—Set Light Pen Emulation ON	
5.23	INT 33H, AX = 0EH—置光笔仿真关闭 .....	268
	INT 33H, AX = 0EH—Set Light Pen Emulation OFF	
5.24	INT 33H, AX = 0FH—置鼠标器到屏幕的缩比 .....	268
	INT 33H, AX = 0FH—Set Mickey to Pixel Ratio	
5.25	INT 33H, AX = 10H—条件关闭 .....	269
	INT 33H, AX = 10H—Conditional OFF	
5.26	INT 33H, AX = 13H—置两个速度界限 .....	269
	INT 33H, AX = 13H—Set Double Speed Threshold	
5.27	INT 33H, 屏幕和光标屏蔽 .....	270
	INT 33H, Screen and Cursor Masks	

5.28	INT 33H, 鼠标器驱动器缺省参数 .....	270
	INT 33H, Mouse Driver Default Parameters	
LIM ( Lotus / Intel / Microsoft)EMS(扩展存储规范) LIM		
(Lotus / Intel / Microsoft)EMS(Expanded Memory Specification)		
5.29	INT 67H, 扩展存储管理功能一览表 .....	271
	INT 67H, Expanded Memory manager Functions Summary	
5.30	INT 67H, AH = 40H—取状态 .....	272
	INT 67H, AH = 40H—Get Status	
5.31	INT 67H, AH = 41H—取页帧地址 .....	272
	INT 67H, AH = 41H—Get Page Frame Address	
5.32	INT 67H, AH = 42H—取页数 .....	273
	INT 67H, AH = 42H—Get Page Count	
5.33	INT 67H, AH = 43H—分配页 .....	273
	INT 67H, AH = 43H—Allocate Pages	
5.34	INT 67H, AH = 44H—映象存储 .....	274
	INT 67H, AH = 44H—Map Memory	
5.35	INT 67H, AH = 45H—解除页分配 .....	274
	INT 67H, AH = 45H—Deallocate Pages	
5.36	INT 67H, AH = 46H—取EMM版本 .....	275
	INT 67H, AH = 46H—Get EMM Version	
5.37	INT 67H, AH = 47H—保存页映象 .....	275
	INT 67H, AH = 47H—Save Page Map	
5.38	INT 67H, AH = 48H—恢复页映象 .....	276
	INT 67H, AH = 48H—Restore Page Map	
5.39	INT 67H, AH = 4BH—取把柄数 .....	276
	INT 67H, AH = 4BH—Get Handle Count	
5.40	INT 67H, AH = 4CH—取把柄页数 .....	277
	INT 67H, AH = 4CH—Get Page Count for Handle	
5.41	INT 67H, AH = 4DH—取全部把柄页数 .....	277
	INT 67H, AH = 4DH—Get Page Counts for All Handles	
5.42	INT 67H, AH = 4EH, AL = 00H—取页映象 .....	278
	INT 67H, AH = 4EH, AL = 00H—Get Page Map	
5.43	INT 67H, AH = 4EH, AL = 01H—置页映象 .....	278
	INT 67H, AH = 4EH, AL = 01H—Set Page Map	
5.44	INT 67H, AH = 4EH, AL = 02H—交换页映象 .....	279
	INT 67H, AH = 4EH, AL = 02H—Swap page Map	
5.45	INT 67H, AH = 4EH, AL = 03H—取页映象阵列尺寸 .....	279
	INT 67H, AH = 4EH, AL = 03H—Get Page Map Array Size	
5.46	INT 67H, AH = 60H—取物理窗口阵列 .....	280

	INT 67H, AH = 60H—Get Physical Window Array	
5.47	INT 67H, AH = 68H—取系统物理窗口阵列 .....	280
	INT 67H, AH = 68H—Get System Physical Window Array	
5.48	INT 67H, AH = 69H—映象页到窗口 .....	281
	INT 67H, AH = 69H—Map Page to Window	
5.49	INT 67H, AH = 6AH, AL = 00H—取系统映象 .....	281
	INT 67H, AH = 6AH, AL = 00H—Get System Map	
5.50	INT 67H, AH = 6AH, AL = 01H—置系统映象 .....	282
	INT 67H, AH = 6AH, AL = 01H—Set System Map	
5.51	INT 67H, AH = 6AH, AL = 02H—交换系统映象 .....	282
	INT 67H, AH = 6AH, AL = 02H—Swap System Map	
5.52	INT 67H, AH = 6AH, AL = 03H—取映象尺寸 .....	283
	INT 67H, AH = 6AH, AL = 03H—Get Map Size	
5.53	INT 67H, AH = 6AH, AL = 04H—置标准变换 .....	283
	INT 67H, AH = 6AH, AL = 04H—Set Standard Mapping	
5.54	INT 67H, AH = 6AH, AL = 05H—置交替变换 .....	284
	INT 67H, AH = 6AH, AL = 05H—Set Alternate Mapping	
5.55	INT 67H, AH = 6AH, AL = 06H—解除初始系统页分配 .....	284
	INT 67H, AH = 6AH, AL = 06H—Deallocate Initial System Pages	
5.56	INT 67H, 扩展内存管理程序错误码 .....	285
	INT 67H, Expanded Memory Manager Error Codes	
<b>第 6 章</b>	<b>Microsoft 窗口 Microsoft Windows .....</b>	<b>287</b>
	输入设备 Input Devices	
6.01	保留系统关键字 .....	288
	Reserved System Keys	
6.02	通用键盘作用 .....	288
	Recommended Keyboard Actions	
6.03	虚拟键 .....	289
	Virtual Keys	
6.04	窗口终端—VT52键仿真 .....	290
	Windows Terminal—VT52 Key Emulations	
6.05	通用鼠标器用法 .....	290
	Recommended Mouse Usage	
文件	Files	
6.06	窗口操作环境文件 .....	291
	Windows Operating Environment Files	
6.07	窗口 C 程序库文件 .....	291
	Windows C Programming Library Files	

6.08	窗口开发实用程序 .....	292
	Windows Development Utilities	
	格式 Formats	
6.09	扩展 ANSI 字符码 .....	292
	Extended ANSI Character Codes	
6.10	窗口 EXE 文件格式 .....	296
	Windows EXE File Format	
	数据格式 Data Formats	
6.11	带标记的映像文件格式(TIFF) .....	296
	Tag Image File Format (TIFF)	
6.12	动态数据交换规程 .....	298
	Dynamic Data Exchange Protocol	
6.13	窗口覆盖文件格式 .....	298
	Windows Paint File Format	
6.14	字型文件格式(版本1) .....	299
	Font File Format(version 1)	
6.15	书写板格式 .....	299
	Clipboard Formats	
6.16	元文件格式 .....	300
	MetaFile Format	
	源本文件 Resource Script File	
6.17	源本文件命令 .....	303
	Resource Script File Directives	
6.18	单行源语句 .....	303
	Single-line Resource Statements ( ICON, CURSOR, BITMAP, FONT )	
6.19	菜单源本定义 .....	304
	Menu Resource Script Definitions	
6.20	对话框源本定义 .....	304
	Dialog Resource Script Definitions	
6.21	对话框控制定义 .....	305
	Dialog Box Control Definitions	
6.22	加速程序源本定义 .....	307
	Accelerator Resource Script Definitions	
6.23	公用编辑菜单加速程序键定义 .....	307
	Common Edit Menu Accelerator Key Definitions	
6.24	字符串表源本定义 .....	308
	STRINGTABLE Resource Script Definitions	
	WIN.INI 文件 WIN.INI File	
6.25	WIN.INI 扩展设置 .....	308

	WIN.INI Extension Settings	
6.26	WIN.INI 窗口设置 .....	308
	WIN.INI Windows Settings	
6.27	WIN.INI 设备设置 .....	309
	WIN.INI Devices Settings	
6.28	WIN.INI 彩色设置 .....	309
	WIN.INI Colors Settings	
6.29	WIN.INI PIF 设置 .....	309
	WIN.INI PIF Settings	
6.30	缺省 PIF 设置 .....	310
	Default PIF Settings	
6.31	WIN.INI 端口设置 .....	310
	WIN.INI Ports Settings	
6.32	WIN.INI 国际设置 .....	310
	WIN.INI International Settings	
6.33	WIN.INI 字形设置 .....	311
	WIN.INI Fonts Settings	
窗口功能 Windows Functions		
数据类型 <i>Data Types</i>		
6.34	窗口变量名使用的数据类型 .....	311
	Data Types Used in Windows Argument Names	
6.35	可作为 C 关键字的数据类型 .....	311
	Data Types Available as C Keywords	
6.36	窗口处理和指针类型 .....	312
	Windows Handle and Pointer Types	
6.37	按名字列出的 Include 文件常数定义 .....	313
	Include File Constants Definitions by Name	
6.38	按用法列出的 Include 文件常数定义 .....	329
	Include File Constants Definitions by Use	
结构 <i>Structures</i>		
6.39	BITMAP 结构格式 .....	345
	BITMAP Structure Format	
6.40	COMSTAT 结构格式 .....	345
	COMSTAT Structure Format	
6.41	CREATESTRUCT 结构格式 .....	345
	CREATESTRUCT Structure Format	
6.42	DCB 结构格式 .....	346
	DCB Structure Format	
6.43	DLGTEMPLATE 结构格式 .....	347

	DLGTEMPLATE Structure Format	
6.44	EXTTEXTMETRIC 结构格式 .....	347
	EXTTEXTMETRIC Structure Format	
6.45	HANDLETABLE 结构格式 .....	348
	HANDLETABLE Structure Format	
6.46	KERNPAIR 结构格式 .....	348
	KERNPAIR Structure Format	
6.47	KERNTRACK 结构格式 .....	348
	KERNTRACK Structure Format	
6.48	LOGBRUSH 结构格式 .....	348
	LOGBRUSH Structure Format	
6.49	LOGFONT 结构格式 .....	349
	LOGFONT Structure Format	
6.50	LOGPEN 结构格式 .....	349
	LOGPEN Structure Format	
6.51	MENUITEMTEMPLATE 结构格式 .....	349
	MENUITEMTEMPLATE Structure Format	
6.52	METAFILEPICT 结构格式 .....	350
	METAFILEPICT Structure Format	
6.53	MSG 结构格式 .....	350
	MSG Structure Format	
6.54	OFSTRUCT 结构格式 .....	350
	OFSTRUCT Structure Format	
6.55	PAINTSTRUCT 结构格式 .....	351
	PAINTSTRUCT Structure Format	
6.56	POINT 结构格式 .....	351
	POINT Structure Format	
6.57	RECT 结构格式 .....	351
	RECT Structure Format	
6.58	RGB 结构格式 .....	351
	RGB Structure Format	
6.59	TEXTMETRIC 结构格式 .....	352
	TEXTMETRIC Structure Format	
6.60	WNDCLASS 结构格式 .....	352
	WNDCLASS Structure Format	
信息	<i>Messages</i>	
6.61	一个窗口信息的格式 .....	353
	Format of a Windows Message	
6.62	窗口的一般信息编号 .....	353

	<b>Windows General Message Numbering</b>	
6.63	窗口管理信息 .....	354
	<b>Window Management Messages</b>	
6.64	初始化信息 .....	355
	<b>Initialization Messages</b>	
6.65	输入信息 .....	356
	<b>Input Messages</b>	
6.66	系统信息 .....	358
	<b>System Information Messages</b>	
6.67	书写板信息 .....	358
	<b>Clipboard Messages</b>	
6.68	控制信息 .....	359
	<b>Control Messages</b>	
6.69	标志码 .....	360
	<b>Notification Codes</b>	
6.70	非委托区信息 .....	360
	<b>Non-Client Area Messages</b>	
功能	<b>Functions</b>	
6.71	按版列出的窗口功能一览表 .....	361
	<b>Windows Functions Summary by Version</b>	
6.72	按功能名列出的窗口功能一览表 .....	365
	<b>Windows Function Summary by Name of Function</b>	
6.73	按函数类型列出的窗口功能一览表 .....	374
	<b>Windows Function Summary by Type of Function</b>	
功能支持表	<b>Function Support Tables</b>	
6.74	诊断和错误码 .....	383
	<b>Diagnostic and Error Codes</b>	
6.75	窗口逻辑坐标变换 .....	383
	<b>Windows Logical Coordinate Mapping</b>	
6.76	窗口方式 .....	384
	<b>Window Styles</b>	
6.77	窗口文件类型 .....	385
	<b>Windows File Types</b>	
6.78	显示上下文缺省设置 .....	385
	<b>Display Context Default Settings</b>	
6.79	二级光栅操作码(ROP2) .....	386
	<b>Binary Raster Operation Codes (ROP2)</b>	
6.80	三级光栅操作码 .....	386
	<b>Tertiary Raster Operation Codes</b>	

6.81	GDI 信息索引数据 .....	387
	GDI Information Index Data	
6.82	位图数据结构 .....	388
	Bitmap Data Structures	
窗口实用程序 Windows Utility		
6.83	符号调试(SYMDEB)命令一览表 .....	389
	Symbolic Debugger (SYMDEB) Command Summary	

### 第三篇 一般 PC 硬件 General PC Hardware

第 7 章	键盘,显示器适配器,和外围设备 Keyboards, Video Adapters, and Peripherals .....	393
-------	---------------------------------------------------------------------	-----

一般信息和背景 General Information and Background		
7.01	机器一览表和历史 .....	394
	Machine Summary and History	
7.02	PC, AT和 PS/2 存储使用概要 .....	395
	PC, AT, and PS/2 Memory Usage Summary	
7.03	I/O端口使用概要 .....	396
	I/O Port Usage Summary	
7.04	PC 中断使用概要 .....	397
	PC Interrupt Usage Summary	

键盘 Keyboard		
7.05	PC 键盘键数和扫描码 .....	400
	PC Keyboard Key Numbers and Scan Codes	
7.06	AT 84 键 键数和扫描码 .....	401
	AT 84-key Key Numbers and Scan Codes	
7.07	AT 101 / 102 键 键数和扫描码 .....	403
	AT 101 / 102-key Key Numbers and Scan Codes	
7.08	PS/2 键数和扫描码 .....	405
	PS/2 Key Numbers and Scan Codes	
7.09	PC 和 XT 键入预置缓冲区布局 .....	407
	PC & XT Typeahead Buffer Layout	

键盘输入 / 输出使用 Keyboard I/O Usage		
7.10	AT 键盘状态寄存器 .....	407
	AT Keyboard Status Register	
7.11	AT 键盘 I/O 命令一览表 .....	408
	AT Keyboard I/O Command Summary	
7.12	AT 键盘输入端口位的定义 .....	408
	AT Keyboard Input Port Bit Definitions	
7.13	AT 键盘输出端口位的定义 .....	408

	AT Keyboard Output Port Bit Definitions	
7.14	AT 键盘自动打印键定义 .....	409
	AT Keyboard Typematic Rate Definitions	
显示器适配器集 Video Adapter Summaries		
7.15	显示器适配器内存使用和输出规格 .....	410
	Video Adapter Memory Usage and Output Specifications	
7.16	显示器方式一览表 .....	410
	Video Modes Summary	
7.17	显示器字符字形尺寸 .....	411
	Video Character Font Sizes	
7.18	显示器监视器使用一览表 .....	411
	Video Monitor Use Summary	
MDA(单色显示适配器) MDA (Monochrome Display Adapter)		
7.19	MDA 存储映象 .....	411
	MDA Memory Map	
7.20	MDA 字符框 .....	412
	MDA Character Box	
7.21	MDA 字符属性 .....	412
	MDA Character Attributes	
7.22	MDA I/O 端口用法 .....	413
	MDA I/O Port Usage	
CGA (彩色图形适配器) CGA(Color Graphics Adapter)		
7.23	CGA 存储映象 .....	413
	CGA Memory Map	
7.24	CGA 字符框 .....	416
	CGA Character Box	
7.25	CGA 字符属性 .....	416
	CGA Character Attributes	
7.26	CGA I/O 端口用法 .....	417
	CGA I/O Port Usage	
EGA(增强图形适配器) EAG(Enhanced Graphics Adapter)		
7.27	EGA 存储映象 .....	418
	EGA Memory Map	
7.28	EGA 字符框 .....	422
	EGA Character Box	
7.29	EGA 字符属性 .....	422
	EGA Character Attributes	
7.30	EGA I/O 端口的用法 .....	423
	EGA I/O Port Usage	

## VGA(显示器图形阵列) VGA(Video Graphics Array)

7.31	VGA 存储映象 .....	424
	VGA Memory Map	
7.32	VGA 字符框 .....	428
	VGA Character Box	
7.33	VGA 字符属性 .....	429
	VGA Character Attributes	
7.34	VGA I/O 端口的用法 .....	430
	VGA I/O Port Usage	
异步适配器 Async Adapter		
7.35	异步通讯 I/O 端口适配器的用法 .....	430
	Asynchronous Adapter I/O Port Usage	
异步适配器寄存器 Async Adapter Registers		
7.36	行控制寄存器 .....	431
	Line Control Register	
7.37	分频器, 锁定寄存器 .....	431
	Divisor, Latch Register	
7.38	行状态寄存器 .....	431
	Line Status Register	
7.39	中断标识寄存器 .....	432
	Interrupt Identification Register	
7.40	中断允许寄存器 .....	432
	Interrupt Enable Register	
7.41	调制解调器控制寄存器 .....	432
	Modem Control Register	
7.42	调制解调器状态寄存器 .....	432
	Modem Status Register	
游戏适配器 Game Adapter		
7.43	游戏适配器 I/O 端口用法 .....	433
	Game Adapter I/O Port Usage	
7.44	游戏适配器 AB 操纵杆数据字节 .....	433
	Game Adapter AB Joystick Data Byte	
7.45	游戏适配器 ABCD 开关数据字节 .....	433
	Game Adapter ABCD Paddle Data Byte	
打印机适配器 Printer Adapter		
7.46	打印机适配器 I/O 端口用法 .....	434
	Printer Adapter I/O Port Usage	
打印机 Printers		
7.47	IBM 打印机控制码一览表 .....	435

	IBM Printer Control Codes Summary	
7.48	HP 激光打印机控制码一览表 .....	437
	HP Laserjet Printer Control Codes Summary	
<b>RTC (实时钟) RTC(Real Time Clock)</b>		
7.49	AT 实时钟 RAM 配置用法 .....	439
	AT Real Time Clock RAM Configuration Usage	
7.50	AT 实时钟状态寄存器 A .....	440
	AT Real Time Clock Status Register A	
7.51	AT 实时钟状态寄存器 B .....	440
	AT Real Time Clock Status Register B	
7.52	AT 实时钟状态寄存器 C .....	440
	AT Real Time Clock Status Register C	
7.53	AT 实时钟状态寄存器 D .....	441
	AT Real Time Clock Status Register D	
7.54	AT 实时钟诊断状态字节 .....	441
	AT Real Time Clock Diagnostic Status Byte	
7.55	AT 实时钟软盘驱动类型字节 .....	441
	AT Real Time Clock Diskette Drive Type Byte	
7.56	AT 实时钟硬驱动类型字节 .....	441
	AT Real Time Clock Fixed Drive Type Byte	
7.57	AT 实时钟设备字节 .....	441
	AT Real Time Clock Equipment Byte	
<b>第 8 章</b>	<b>芯片, 跳线, 开关和寄存器 Chips, jumpers, Switches, and Registers</b>	<b>443</b>
<b>CPU 芯片 CPU Chips</b>		
8.01	8086 系列存储寻址方式 .....	444
	8086 Family Memory Addressing Modes	
8.02	8086 系列指令集一览表 .....	445
	8086 Family Instruction Set Summary	
8.03	8086 系列寄存器一览表 .....	449
	8086 Family Register Summary	
8.04	8086 系列 CPU 芯片版本 .....	450
	8086 Family CPU Chip Versions	
<b>数学协处理器芯片 Math Coprocessor Chips</b>		
8.05	8087 系列指令集一览表 .....	451
	8087 Family Instruction Set Summary	
8.06	8087 系列寄存器一览表 .....	453
	8087 Family Register Summary	
8.07	8087 系列芯片版本 .....	453

## 8087 Family Chip Versions

### 外围支持芯片 Peripheral Support Chips

8.08	8250 I/O 端口用法(寄存器) .....	454
	8250 I/O Port Usage (Registers)	
8.09	8253 I/O 端口的用法(寄存器) .....	454
	8253 I/O port Usage (Registers)	
8.10	8253 控制字字节 .....	454
	8253 Control Word Byte	
8.11	8253 命令寄存器字节 .....	455
	8253 Command Register Byte	
8.12	6845 寄存器 .....	455
	6845 Registers	
8.13	6845 端口和选择因子 .....	456
	6845 Port and Select Factors	

### 跳线和开关 Jumpers and Switches

8.14	AT J18 RAM 跳线 .....	457
	AT J18 RAM Jumper	
8.15	AT 显示开关(SW1) .....	457
	AT Display Switch (SW1)	

### 开关设置 Switch Settings

8.16	PC 系统板开关设置 .....	457
	PC System Board Switch Settings	
8.17	XT 系统板开关设置 .....	458
	XT System Board Switch Settings	

### 软盘控制器 Floppy Disk Controller

8.18	PC 和 XT 软盘控制器命令一览表 .....	458
	PC and XT Floppy Disk Controller Command Summary	
8.19	PC 和 XT 软盘控制器状态寄存器0 .....	460
	PC and XT Floppy Disk Controller Status Register 0	
8.20	PC 和 XT 软盘控制器状态寄存器1 .....	461
	PC and XT Floppy Disk Controller Status Register 1	
8.21	PC 和 XT 软盘控制器状态寄存器2 .....	461
	PC and XT Floppy Disk Controller Status Register 2	
8.22	PC 和 XT 软盘控制器状态寄存器3 .....	462
	PC and XT Floppy Disk Controller Status Register 3	
8.23	PC 和 XT FDC 磁盘程序控制寄存器 .....	462
	PC and XT FDC Disk Program Control Registers	

### XT 和 AT 硬盘 XT & AT Fixed Disks

8.24	XT 硬盘控制器命令一览表 .....	462
------	---------------------	-----

	XT Fixed Disk Controller Command Summary	
8.25	XT 硬盘控制器端口的使用 .....	464
	XT Fixed Disk Controller Port Usage	
8.26	XT 硬盘控制器设备控制块 .....	465
	XT Fixed Disk Controller Device Control Block	
8.27	XT 硬盘控制器状态寄存器 .....	465
	XT Fixed Disk Controller Status Register	
8.28	XT 硬盘控制器读出字节 .....	466
	XT Fixed Disk Controller Sense Bytes	
8.29	XT 硬盘控制器错误码 .....	466
	XT Fixed Disk Controller Error Codes	
8.30	AT 硬盘驱动类型 .....	467
	AT Fixed Disk Drive Types	
PS / 2	50 / 60 / 80 型 PS / 2 Model 50 / 60 / 80	
8.31	PS / 2 POS I / O 地址空间 .....	467
	PS / 2 POS I / O Address Space	
8.32	PS / 2 POS 描述符文件格式 .....	468
	PS / 2 POS Descriptor File Format	
8.33	PS / 2 POS ID 分配 .....	469
	PS / 2 POS ID Assignments	
8.34	PS / 2 50 / 60 / 80型 DMA I / O 地址变换 .....	469
	PS / 2 Model 50 / 60 / 80 DMA I / O Address Map	
8.35	PS / 2 DMA 寄存器 .....	470
	PS / 2 DMA Registers	
8.36	PS / 2 计数器寄存器 .....	471
	PS / 2 Counter Registers	
8.37	PS / 2 系统控制端口 A (92H) .....	472
	PS / 2 System Control Port A (92H)	
8.38	PS / 2 系统控制端口 B (61H) .....	472
	PS / 2 System Control Port B (61H)	
8.39	PS / 2 RT / CMOS 和 NMI 屏蔽 (70H) .....	472
	PS / 2 RT / CMOS and NMI Mask (70H)	
<b>第 9 章</b>	<b>硬件描述 Hardware Descriptions</b> .....	<b>473</b>
	接插件 Connectors	
	串行接插件 Serial Connectors	
9.01	9针串行端口接插件 .....	474
	9-pin Serial Port Connector	
9.02	25针串行端口接插件 .....	474

	25-pin Serial Port Connector	
9.03	PS / 2 串行端口接插件 .....	474
	PS / 2 Serial Port Connector	
9.04	RS-232C 串行端口接插件 (DTE 器件).....	475
	RS-232C Serial Port Connector (DTE Device)	
	<b>显示器接插件 Video Connectors</b>	
9.05	PS / 2 15 针显示器接插件 .....	476
	PS / 2 15-pin Video Connector	
9.06	CGA 复合显示器接插件 .....	476
	CGA Composite Video Connector	
9.07	EGA 功能部件接插件 .....	477
	EGA Feature Connector	
9.08	CGA 光笔接插件 .....	477
	CGA Light Pen Connector	
9.09	CGA RF 调制器接插件 .....	477
	CGA RF Modulator Connector	
9.10	MDA 显示器接插件 .....	478
	MDA Video Connector	
9.11	CGA RGB 接插件 .....	478
	CGA RGB Connector	
9.12	EGA RGB 接插件.....	478
	EGA RGB Connector	
9.13	VGA RGB 接插件 .....	479
	VGA RGB Connector	
	<b>磁盘接插件 Disk Connectors</b>	
9.14	PC 和 XT 软盘控制器内部接插件.....	479
	PC & XT Floppy Disk Controller Internal Connector	
9.15	PC 和 XT 软盘控制器外部接插件.....	480
	PC & XT Floppy Disk Controller External Connector	
9.16	XT 硬盘控制器接插件 J1 .....	480
	XT Fixed Disk Controller Connector J1	
9.17	XT 硬盘控制器接插件 J2 和 J3 .....	481
	XT Fixed Disk Controller Connectors J2 and J3	
9.18	PS / 2 30 型软盘驱动接插件 .....	481
	PS / 2 Model 30 Diskette Drive Connector	
9.19	PS / 2 30 型硬驱动接插件 .....	482
	PS / 2 Model 30 Fixed Drive Connector	
9.20	PS / 2 50 型软盘驱动接插件 .....	483
	PS / 2 Model 50 Diskette Drive Connector	

电源接插件 *Power Supply Connectors*

9.21	PC 和 XT 电源接插件.....	484
	PC & XT Power Supply Connectors	
9.22	AT 电池接插件 J21 .....	484
	AT Battery Connector J21	
9.23	AT 电源接插件 PS8,PS9,PS10,PS11, 和 PS12 .....	485
	AT Power Supply Connectors PS8,PS9,PS10,PS11,and PS12	
9.24	PS / 2 30 型电源接插件 .....	485
	PS / 2 Model 30 Power Supply Connectors	
9.25	PS / 2 50 型电源接插件 .....	486
	PS / 2 Model 50 Power Supply Connector	
9.26	PS / 2 60 型电源接插件 .....	487
	PS / 2 Model 60 Power Supply Connector	

其它接插件 *Miscellaneous Connectors*

9.27	PC 和 XT 键盘接插件.....	487
	PC & XT Keyboard Connector	
9.28	PS / 2 键盘和鼠标器接插件 .....	487
	PS / 2 Keyboard and Mouse Connector	
9.29	AT电源指示和键锁接插件J20 .....	487
	AT Power LED and Keylock Connector J20	
9.30	PS / 2 50 / 60 / 80 型存储器模块接插件 .....	488
	PS / 2 Model 50 / 60 / 80 / Memory Module Connector	
9.31	PS / 2 并行口接插件.....	488
	PS / 2 Parallel Port Connector	
9.32	Centronics 并行接插件.....	489
	Centronics Parallel Connector	
9.33	游戏适配器接插件 .....	489
	Game Adapter Connector	
9.34	并行打印机接插件 .....	490
	Parallel Printer Connector	
9.35	PC 和 XT 扬声器接插件.....	490
	PC & XT Speaker Connector	

引出脚 *Pinouts*

*CPU* 芯片引出脚 *CPU Chip Pinouts*

9.36	8088 和 8086 引出脚 .....	491
	8088 and 8086 Pinouts	
9.37	80286 引出脚 .....	492
	80286 Pinouts	
9.38	80386 引出脚 .....	494

	80386 Pinouts	
	数学协处理器芯片引出脚 <i>Math Coprocessor Chip Pinouts</i>	
9.39	8087 (协处理器) 引出脚 .....	495
	8087 (Coprocessor) Pinouts	
9.40	80287 (协处理器) 引出脚 .....	496
	80287 (Coprocessor) Pinouts	
9.41	80387 (协处理器) 引出脚 .....	497
	80387 (Coprocessor) Pinouts	
	内存芯片引出脚 <i>Memory Chip Pinouts</i>	
9.42	RAM 芯片引出脚一览表 .....	498
	RAM Chip Pinouts Summary	
	外围芯片引出脚 <i>Peripherals Pinouts</i>	
9.43	6845 (显示器控制器) 引出脚 .....	499
	6845 (Video Controller) Pinouts	
9.44	8284 (时钟发生器) 引出脚 .....	499
	8284 (Clock Generator) Pinouts	
9.45	8237 (DMA控制器) 引出脚 .....	500
	8237 (DMA Controller) Pinouts	
9.46	8250 (串行接口控制器) 引出脚 .....	501
	8250 (Serial Interface Controller) Pinouts	
9.47	8253 (可编程间隔时钟控制器) 引出脚 .....	501
	8253 (Programmable Interval Controller) Pinouts	
9.48	8255 (并行接口控制器) 引出脚 .....	502
	8255 (Parallel Interface Controller) Pinouts	
9.49	8259 (可编程的中断控制器) 引出脚 .....	503
	8259 (Programmable Interrupt Controller) Pinouts	
9.50	8288 (总线控制器) 引出脚 .....	503
	8288 (Bus Controller) Pinouts	
9.51	MC146818 (AT 时钟控制器) 引出脚 .....	504
	MC146818 (AT Clock Controller) Pinouts	
9.52	PD765 (软盘控制器) 引出脚 .....	505
	PD765 (Floppy Disk Controller) Pinouts	
	I/O 通道 I/O Channel	
9.53	PC和XT附加卡尺寸 .....	505
	PC & XT Add-on Card Size	
9.54	AT 附加卡尺寸 .....	506
	AT Add-on Card Size	
9.55	微通道卡尺寸 .....	506
	Microchannel Card Size	

9.56	PC 和 XT I/O 通道 (系统总线) 引出脚 .....	507
	PC & XT I/O Channel (System Bus) Pinouts	
9.57	AT I/O 通道(系统总线)引出脚.....	508
	AT I/O Channel (System Bus) Pinouts	
9.58	PS/2 50/60/80 型微通道总线引出脚 .....	509
	PS/2 Model 50/60/80 Microchannel Bus Pinouts	
<b>参考文献 Bibliography .....</b>		<b>513</b>
<b>索引 Index .....</b>		<b>517</b>

—PART—

**I**

MISCELLANEOUS  
INFORMATION

---



— SECTION —

# 1

General  
Information

---

1.01. HEXADECIMAL TO DECIMAL NUMBER CONVERSION

**Byte Values**

**Least Significant Digit**

		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
<b>Most Significant Digit</b>	00	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
	10	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
	20	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
	30	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
	40	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
	50	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95
	60	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
	70	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
	80	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
	90	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
	A0	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
	B0	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191
	C0	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
	D0	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
	E0	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
	F0	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255

**To Use This Table:** To determine the decimal value of A4 hex, you look in the row labeled A0 (the most significant hex digit is A) and the column labeled 4 (the least significant hex digit is 4). The value at the intersection of these two headings (164) is the decimal value for A4.

**Nibble**

Hex	Dec
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
A	10
B	11
C	12
D	13
E	14
F	15

**Byte**

Hex	Dec
00	0
10	16
20	32
30	48
40	64
50	80
60	96
70	112
80	128
90	144
A0	160
B0	176
C0	192
D0	208
E0	224
F0	240

**Byte+Nibble**

Hex	Dec
000	0
100	256
200	512
300	768
400	1024
500	1280
600	1536
700	1792
800	2048
900	2304
A00	2560
B00	2816
C00	3072
D00	3328
E00	3584
F00	3840

**Word**

Hex	Dec
0000	0
1000	4096
2000	8192
3000	12288
4000	16384
5000	20480
6000	24576
7000	28672
8000	32768
9000	36864
A000	40960
B000	45056
C000	49152
D000	53248
E000	57344
F000	61440

**To Use This Table:** To convert a two-byte (word) hexadecimal value to decimal, find the value associated with each hex digit place in the above table; add these numbers together. For example, the hex value A5D7 would be equal to 40960 (the A000 value) plus 1280 (the 500 value) plus 208 (the D0 value) plus 7, or 42455.

**See Also:**

- 1.06. Binary Number Conversions
- 1.09. Octal to Hexadecimal Number Conversion
- 1.12. Decimal to Hexadecimal Number Conversion

1.02. HEXADECIMAL TO BINARY NUMBER CONVERSION

Byte Values		Hex		Binary		Hex		Binary		Hex		Binary	
Hex	Binary	Hex	Binary	Hex	Binary	Hex	Binary	Hex	Binary	Hex	Binary	Hex	Binary
0	0000 0000	40	0100 0000	80	1000 0000	C0	1100 0000						
1	0000 0001	41	0100 0001	81	1000 0001	C1	1100 0001						
2	0000 0010	42	0100 0010	82	1000 0010	C2	1100 0010						
3	0000 0011	43	0100 0011	83	1000 0011	C3	1100 0011						
4	0000 0100	44	0100 0100	84	1000 0100	C4	1100 0100						
5	0000 0101	45	0100 0101	85	1000 0101	C5	1100 0101						
6	0000 0110	46	0100 0110	86	1000 0110	C6	1100 0110						
7	0000 0111	47	0100 0111	87	1000 0111	C7	1100 0111						
8	0000 1000	48	0100 1000	88	1000 1000	C8	1100 1000						
9	0000 1001	49	0100 1001	89	1000 1001	C9	1100 1001						
A	0000 1010	4A	0100 1010	8A	1000 1010	CA	1100 1010						
B	0000 1011	4B	0100 1011	8B	1000 1011	CB	1100 1011						
C	0000 1100	4C	0100 1100	8C	1000 1100	CC	1100 1100						
D	0000 1101	4D	0100 1101	8D	1000 1101	CD	1100 1101						
E	0000 1110	4E	0100 1110	8E	1000 1110	CE	1100 1110						
F	0000 1111	4F	0100 1111	8F	1000 1111	CF	1100 1111						
10	0001 0000	50	0101 0000	90	1001 0000	D0	1101 0000						
11	0001 0001	51	0101 0001	91	1001 0001	D1	1101 0001						
12	0001 0010	52	0101 0010	92	1001 0010	D2	1101 0010						
13	0001 0011	53	0101 0011	93	1001 0011	D3	1101 0011						
14	0001 0100	54	0101 0100	94	1001 0100	D4	1101 0100						
15	0001 0101	55	0101 0101	95	1001 0101	D5	1101 0101						
16	0001 0110	56	0101 0110	96	1001 0110	D6	1101 0110						
17	0001 0111	57	0101 0111	97	1001 0111	D7	1101 0111						
18	0001 1000	58	0101 1000	98	1001 1000	D8	1101 1000						
19	0001 1001	59	0101 1001	99	1001 1001	D9	1101 1001						
1A	0001 1010	5A	0101 1010	9A	1001 1010	DA	1101 1010						
1B	0001 1011	5B	0101 1011	9B	1001 1011	DB	1101 1011						
1C	0001 1100	5C	0101 1100	9C	1001 1100	DC	1101 1100						
1D	0001 1101	5D	0101 1101	9D	1001 1101	DD	1101 1101						
1E	0001 1110	5E	0101 1110	9E	1001 1110	DE	1101 1110						
1F	0001 1111	5F	0101 1111	9F	1001 1111	DF	1101 1111						
20	0010 0000	60	0110 0000	A0	1010 0000	E0	1110 0000						
21	0010 0001	61	0110 0001	A1	1010 0001	E1	1110 0001						
22	0010 0010	62	0110 0010	A2	1010 0010	E2	1110 0010						
23	0010 0011	63	0110 0011	A3	1010 0011	E3	1110 0011						
24	0010 0100	64	0110 0100	A4	1010 0100	E4	1110 0100						
25	0010 0101	65	0110 0101	A5	1010 0101	E5	1110 0101						
26	0010 0110	66	0110 0110	A6	1010 0110	E6	1110 0110						
27	0010 0111	67	0110 0111	A7	1010 0111	E7	1110 0111						
28	0010 1000	68	0110 1000	A8	1010 1000	E8	1110 1000						
29	0010 1001	69	0110 1001	A9	1010 1001	E9	1110 1001						
2A	0010 1010	6A	0110 1010	AA	1010 1010	EA	1110 1010						
2B	0010 1011	6B	0110 1011	AB	1010 1011	EB	1110 1011						
2C	0010 1100	6C	0110 1100	AC	1010 1100	EC	1110 1100						
2D	0010 1101	6D	0110 1101	AD	1010 1101	ED	1110 1101						
2E	0010 1110	6E	0110 1110	AE	1010 1110	EE	1110 1110						
2F	0010 1111	6F	0110 1111	AF	1010 1111	EF	1110 1111						
30	0011 0000	70	0111 0000	B0	1011 0000	F0	1111 0000						
31	0011 0001	71	0111 0001	B1	1011 0001	F1	1111 0001						
32	0011 0010	72	0111 0010	B2	1011 0010	F2	1111 0010						
33	0011 0011	73	0111 0011	B3	1011 0011	F3	1111 0011						
34	0011 0100	74	0111 0100	B4	1011 0100	F4	1111 0100						
35	0011 0101	75	0111 0101	B5	1011 0101	F5	1111 0101						
36	0011 0110	76	0111 0110	B6	1011 0110	F6	1111 0110						
37	0011 0111	77	0111 0111	B7	1011 0111	F7	1111 0111						
38	0011 1000	78	0111 1000	B8	1011 1000	F8	1111 1000						
39	0011 1001	79	0111 1001	B9	1011 1001	F9	1111 1001						
3A	0011 1010	7A	0111 1010	BA	1011 1010	FA	1111 1010						
3B	0011 1011	7B	0111 1011	BB	1011 1011	FB	1111 1011						
3C	0011 1100	7C	0111 1100	BC	1011 1100	FC	1111 1100						
3D	0011 1101	7D	0111 1101	BD	1011 1101	FD	1111 1101						
3E	0011 1110	7E	0111 1110	BE	1011 1110	FE	1111 1110						
3F	0011 1111	7F	0111 1111	BF	1011 1111	FF	1111 1111						

Nibble Values

Hex	Binary	Hex	Binary
0	0000	8	1000
1	0001	9	1001
2	0010	A	1010
3	0011	B	1011
4	0100	C	1100
5	0101	D	1101
6	0110	E	1110
7	0111	F	1111

**To Use This Table:** Find the hexadecimal byte value you are looking up in one of left-most columns, and read its binary value in the same row in the column immediately to the right. For example, a hexadecimal value of 2B would result in a binary value of 0010 1011.

**To Use This Table:** To convert a long hexadecimal number into binary, simply use the table at the left to substitute for each hexadecimal digit. Thus a hexadecimal value of 9AF2 is 1001 1010 1111 0010 in binary.

- See Also:**
- 1.06. Binary Number Conversions
  - 1.10. Octal to Binary Number Conversion
  - 1.11. Decimal to Binary Number Conversion

## 1.03. HEXADECIMAL TO OCTAL NUMBER CONVERSION

**Byte Values**

Hex	Octal	Hex	Octal	Hex	Octal	Hex	Octal
0	000	40	100	80	200	C0	300
1	001	41	101	81	201	C1	301
2	002	42	102	82	202	C2	302
3	003	43	103	83	203	C3	303
4	004	44	104	84	204	C4	304
5	005	45	105	85	205	C5	305
6	006	46	106	86	206	C6	306
7	007	47	107	87	207	C7	307
8	010	48	110	88	210	C8	310
9	011	49	111	89	211	C9	311
A	012	4A	112	8A	212	CA	312
B	013	4B	113	8B	213	CB	313
C	014	4C	114	8C	214	CC	314
D	015	4D	115	8D	215	CD	315
E	016	4E	116	8E	216	CE	316
F	017	4F	117	8F	217	CF	317
10	20	50	120	90	220	D0	320
11	21	51	121	91	221	D1	321
12	22	52	122	92	222	D2	322
13	23	53	123	93	223	D3	323
14	24	54	124	94	224	D4	324
15	25	55	125	95	225	D5	325
16	26	56	126	96	226	D6	326
17	27	57	127	97	227	D7	327
18	30	58	130	98	230	DB	330
19	31	59	131	99	231	D9	331
1A	32	5A	132	9A	232	DA	332
1B	33	5B	133	9B	233	DB	333
1C	34	5C	134	9C	234	DC	334
1D	35	5D	135	9D	235	DD	335
1E	36	5E	136	9E	236	DE	336
1F	37	5F	137	9F	237	DF	337
20	40	60	140	A0	240	E0	340
21	41	61	141	A1	241	E1	341
22	42	62	142	A2	242	E2	342
23	43	63	143	A3	243	E3	343
24	44	64	144	A4	244	E4	344
25	45	65	145	A5	245	E5	345
26	46	66	146	A6	246	E6	346
27	47	67	147	A7	247	E7	347
28	50	68	150	A8	250	E8	350
29	51	69	151	A9	251	E9	351
2A	52	6A	152	AA	252	EA	352
2B	53	6B	153	AB	253	EB	353
2C	54	6C	154	AC	254	EC	354
2D	55	6D	155	AD	255	ED	355
2E	56	6E	156	AE	256	EE	356
2F	57	6F	157	AF	257	EF	357
30	60	70	160	B0	260	F0	360
31	61	71	161	B1	261	F1	361
32	62	72	162	B2	262	F2	362
33	63	73	163	B3	263	F3	363
34	64	74	164	B4	264	F4	364
35	65	75	165	B5	265	F5	365
36	66	76	166	B6	266	F6	366
37	67	77	167	B7	267	F7	367
38	70	78	170	B8	270	F8	370
39	71	79	171	B9	271	F9	371
3A	72	7A	172	BA	272	FA	372
3B	73	7B	173	BB	273	FB	373
3C	74	7C	174	BC	274	FC	374
3D	75	7D	175	BD	275	FD	375
3E	76	7E	176	BE	276	FE	376
3F	77	7F	177	BF	277	FF	377

**Nibble Values**

Hex	Octal
0	0C0
1	001
2	002
3	003
4	004
5	005
6	006
7	007
8	010
9	011
A	012
B	013
C	014
D	015
E	016
F	017

**To Use This Table:** Find the hexadecimal byte value you are looking up in one of the left-most columns and read its octal value in the same row in the column immediately to the right. For example, a hexadecimal value of 84 would result in an octal value of 204.

**See Also:**

- 1.08. Octal to Decimal Number Conversion
- 1.09. Octal to Hexadecimal Number Conversion
- 1.10. Octal to Binary Number Conversion
- 1.13. Decimal to Octal Number Conversion

1.04. HEXADECIMAL ADDITION TABLES

*Results in Hexadecimal*

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
1		2	3	4	5	6	7	8	9	A	B	C	D	E	F	10
2			4	5	6	7	8	9	A	B	C	D	E	F	10	11
3				6	7	8	9	A	B	C	D	E	F	10	11	12
4					8	9	A	B	C	D	E	F	10	11	12	13
5						A	B	C	D	E	F	10	11	12	13	14
6							C	D	E	F	10	11	12	13	14	15
7								E	F	10	11	12	13	14	15	16
8									10	11	12	13	14	15	16	17
9										12	13	14	15	16	17	18
A											14	15	16	17	18	19
B												16	17	18	19	1A
C													18	19	1A	1B
D														1A	1B	1C
E															1C	1D
F																1E

*Results in Decimal*

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1		2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
2			4	5	6	7	8	9	10	11	12	13	14	15	16	17
3				6	7	8	9	10	11	12	13	14	15	16	17	18
4					8	9	10	11	12	13	14	15	16	17	18	19
5						10	11	12	13	14	15	16	17	18	19	20
6							12	13	14	15	16	17	18	19	20	21
7								14	15	16	17	18	19	20	21	22
8									16	17	18	19	20	21	22	23
9										18	19	20	21	22	23	24
A											20	21	22	23	24	25
B												22	23	24	25	26
C													24	25	26	27
D														26	27	28
E															28	29
F																30

**To Use This Table:** Find the column/row intersection of the two hexadecimal nibble values you want to add -- the value in that cell is the result of adding the two hex nibbles together.

Table 1.04. Continued

**Results in Hexadecimal**

10	20	30	40	50	60	70	80	90	A0	B0	C0	D0	E0	F0	
10	20	30	40	50	60	70	80	90	A0	B0	C0	D0	E0	F0	100
20		40	50	60	70	80	90	A0	B0	C0	D0	E0	F0	100	110
30			60	70	80	90	A0	B0	C0	D0	E0	F0	100	110	120
40				80	90	A0	B0	C0	D0	E0	F0	100	110	120	130
50					A0	B0	C0	D0	E0	F0	100	110	120	130	140
60						C0	D0	E0	F0	100	110	120	130	140	150
70							E0	F0	100	110	120	130	140	150	160
80								100	110	120	130	140	150	160	170
90									120	130	140	150	160	170	180
A0										140	150	160	170	180	190
B0											160	170	180	190	1A0
C0												180	190	1A0	1B0
D0													1A0	1B0	1C0
E0														1C0	1D0
F0															1E0

**Results in Decimal**

10	20	30	40	50	60	70	80	90	A0	B0	C0	D0	E0	F0	
10	32	48	64	80	96	112	128	144	160	176	192	208	224	240	256
20		64	80	96	112	128	144	160	176	192	208	224	240	256	272
30			96	112	128	144	160	176	192	208	224	240	256	272	288
40				128	144	160	176	192	208	224	240	256	272	288	304
50					160	176	192	208	224	240	256	272	288	304	320
60						192	208	224	240	256	272	288	304	320	336
70							224	240	256	272	288	304	320	336	352
80								256	272	288	304	320	336	352	368
90									288	304	320	336	352	368	384
A0										320	336	352	368	384	400
B0											352	368	384	400	416
C0												384	400	416	432
D0													416	432	448
E0														448	464
F0															480

**To Use This Table:** Find the result at the intersection of the column and row that contain the hex numbers you are adding. If you are adding hexadecimal byte values that don't end in 0 (e.g., B4 + A6), first look up the results for the least significant digits (4 + 6 = A), then add this value to the results for the most significant digits (B0 + A0 = 150, so B4 + A6 = 15A). Remember to carry if necessary (B + B = 16, so BB + AB = 166).

**See Also:** 1.05. Hexadecimal Multiplication Tables

1.05. HEXADECIMAL MULTIPLICATION TABLES

Results in Hexadecimal

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
1		1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2			4	6	8	A	C	E	10	12	14	16	18	1A	1C	1E
3				9	C	F	12	15	18	1B	1E	21	24	27	2A	2D
4					10	14	18	1C	20	24	28	2C	30	34	38	3C
5						19	1E	23	28	2D	32	37	3C	41	46	4B
6							24	2A	30	36	3C	42	48	4E	54	5A
7								31	38	3F	46	4D	54	5B	62	69
8									40	48	50	58	60	68	70	78
9										51	5A	63	6C	75	7E	87
A											64	6E	78	82	8C	96
B												79	84	8F	9A	A5
C													90	9C	A8	B4
D														A9	B6	C3
E															C4	D2
F																E1

Results in Decimal

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
1		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
2			4	6	8	10	12	14	16	18	20	22	24	26	28	30
3				9	12	15	18	21	24	27	30	33	36	39	42	45
4					16	20	24	28	32	36	40	44	48	52	56	60
5						25	30	35	40	45	50	55	60	65	70	75
6							36	42	48	54	60	66	72	78	84	90
7								49	56	63	70	77	84	91	98	105
8									64	72	80	88	96	104	112	120
9										81	90	99	108	117	126	135
A											100	110	120	130	140	150
B												121	132	143	154	165
C													144	156	168	180
D														169	182	195
E															196	210
F																225

**To Use This Table:** Find the column/row intersection of the two hexadecimal nibble values you want to multiply -- the value in that cell is the result of multiplying the two hex nibbles together

**See Also:** 1.04. Hexadecimal Addition Tables

## 1.06. BINARY NUMBER CONVERSIONS

Binary	Decimal	Hex	Octal	Binary	Decimal	Hex	Octal
0000 0000	0	0	0	0100 0000	64	40	100
0000 0001	1	1	1	0100 0001	65	41	101
0000 0010	2	2	2	0100 0010	66	42	102
0000 0011	3	3	3	0100 0011	67	43	103
0000 0100	4	4	4	0100 0100	68	44	104
0000 0101	5	5	5	0100 0101	69	45	105
0000 0110	6	6	6	0100 0110	70	46	106
0000 0111	7	7	7	0100 0111	71	47	107
0000 1000	8	8	10	0100 1000	72	48	110
0000 1001	9	9	11	0100 1001	73	49	111
0000 1010	10	A	12	0100 1010	74	4A	112
0000 1011	11	B	13	0100 1011	75	4B	113
0000 1100	12	C	14	0100 1100	76	4C	114
0000 1101	13	D	15	0100 1101	77	4D	115
0000 1110	14	E	16	0100 1110	78	4E	116
0000 1111	15	F	17	0100 1111	79	4F	117
0001 0000	16	10	20	0101 0000	80	50	120
0001 0001	17	11	21	0101 0001	81	51	121
0001 0010	18	12	22	0101 0010	82	52	122
0001 0011	19	13	23	0101 0011	83	53	123
0001 0100	20	14	24	0101 0100	84	54	124
0001 0101	21	15	25	0101 0101	85	55	125
0001 0110	22	16	26	0101 0110	86	56	126
0001 0111	23	17	27	0101 0111	87	57	127
0001 1000	24	18	30	0101 1000	88	58	130
0001 1001	25	19	31	0101 1001	89	59	131
0001 1010	26	1A	32	0101 1010	90	5A	132
0001 1011	27	1B	33	0101 1011	91	5B	133
0001 1100	28	1C	34	0101 1100	92	5C	134
0001 1101	29	1D	35	0101 1101	93	5D	135
0001 1110	30	1E	36	0101 1110	94	5E	136
0001 1111	31	1F	37	0101 1111	95	5F	137
0010 0000	32	20	40	0110 0000	96	60	140
0010 0001	33	21	41	0110 0001	97	61	141
0010 0010	34	22	42	0110 0010	98	62	142
0010 0011	35	23	43	0110 0011	99	63	143
0010 0100	36	24	44	0110 0100	100	64	144
0010 0101	37	25	45	0110 0101	101	65	145
0010 0110	38	26	46	0110 0110	102	66	146
0010 0111	39	27	47	0110 0111	103	67	147
0010 1000	40	28	50	0110 1000	104	68	150
0010 1001	41	29	51	0110 1001	105	69	151
0010 1010	42	2A	52	0110 1010	106	6A	152
0010 1011	43	2B	53	0110 1011	107	6B	153
0010 1100	44	2C	54	0110 1100	108	6C	154
0010 1101	45	2D	55	0110 1101	109	6D	155
0010 1110	46	2E	56	0110 1110	110	6E	156
0010 1111	47	2F	57	0110 1111	111	6F	157
0011 0000	48	30	60	0111 0000	112	70	160
0011 0001	49	31	61	0111 0001	113	71	161
0011 0010	50	32	62	0111 0010	114	72	162
0011 0011	51	33	63	0111 0011	115	73	163
0011 0100	52	34	64	0111 0100	116	74	164
0011 0101	53	35	65	0111 0101	117	75	165
0011 0110	54	36	66	0111 0110	118	76	166
0011 0111	55	37	67	0111 0111	119	77	167
0011 1000	56	38	70	0111 1000	120	78	170
0011 1001	57	39	71	0111 1001	121	79	171
0011 1010	58	3A	72	0111 1010	122	7A	172
0011 1011	59	3B	73	0111 1011	123	7B	173
0011 1100	60	3C	74	0111 1100	124	7C	174
0011 1101	61	3D	75	0111 1101	125	7D	175
0011 1110	62	3E	76	0111 1110	126	7E	176
0011 1111	63	3F	77	0111 1111	127	7F	177

(Continued)

Table 1.06. Continued

Binary	Decimal	Hex	Octal	Binary	Decimal	Hex	Octal
1000 0000	128	80	200	1100 0000	192	C0	300
1000 0001	129	81	201	1100 0001	193	C1	301
1000 0010	130	82	202	1100 0010	194	C2	302
1000 0011	131	83	203	1100 0011	195	C3	303
1000 0100	132	84	204	1100 0100	196	C4	304
1000 0101	133	85	205	1100 0101	197	C5	305
1000 0110	134	86	206	1100 0110	198	C6	306
1000 0111	135	87	207	1100 0111	199	C7	307
1000 1000	136	88	210	1100 1000	200	C8	310
1000 1001	137	89	211	1100 1001	201	C9	311
1000 1010	138	8A	212	1100 1010	202	CA	312
1000 1011	139	8B	213	1100 1011	203	CB	313
1000 1100	140	8C	214	1100 1100	204	CC	314
1000 1101	141	8D	215	1100 1101	205	CD	315
1000 1110	142	8E	216	1100 1110	206	CE	316
1000 1111	143	8F	217	1100 1111	207	CF	317
1001 0000	144	90	220	1101 0000	208	D0	320
1001 0001	145	91	221	1101 0001	209	D1	321
1001 0010	146	92	222	1101 0010	210	D2	322
1001 0011	147	93	223	1101 0011	211	D3	323
1001 0100	148	94	224	1101 0100	212	D4	324
1001 0101	149	95	225	1101 0101	213	D5	325
1001 0110	150	96	226	1101 0110	214	D6	326
1001 0111	151	97	227	1101 0111	215	D7	327
1001 1000	152	98	230	1101 1000	216	D8	330
1001 1001	153	99	231	1101 1001	217	D9	331
1001 1010	154	9A	232	1101 1010	218	DA	332
1001 1011	155	9B	233	1101 1011	219	DB	333
1001 1100	156	9C	234	1101 1100	220	DC	334
1001 1101	157	9D	235	1101 1101	221	DD	335
1001 1110	158	9E	236	1101 1110	222	DE	336
1001 1111	159	9F	237	1101 1111	223	DF	337
1010 0000	160	A0	240	1110 0000	224	E0	340
1010 0001	161	A1	241	1110 0001	225	E1	341
1010 0010	162	A2	242	1110 0010	226	E2	342
1010 0011	163	A3	243	1110 0011	227	E3	343
1010 0100	164	A4	244	1110 0100	228	E4	344
1010 0101	165	A5	245	1110 0101	229	E5	345
1010 0110	166	A6	246	1110 0110	230	E6	346
1010 0111	167	A7	247	1110 0111	231	E7	347
1010 1000	168	A8	250	1110 1000	232	E8	350
1010 1001	169	A9	251	1110 1001	233	E9	351
1010 1010	170	AA	252	1110 1010	234	EA	352
1010 1011	171	AB	253	1110 1011	235	EB	353
1010 1100	172	AC	254	1110 1100	236	EC	354
1010 1101	173	AD	255	1110 1101	237	ED	355
1010 1110	174	AE	256	1110 1110	238	EE	356
1010 1111	175	AF	257	1110 1111	239	EF	357
1011 0000	176	B0	260	1111 0000	240	F0	360
1011 0001	177	B1	261	1111 0001	241	F1	361
1011 0010	178	B2	262	1111 0010	242	F2	362
1011 0011	179	B3	263	1111 0011	243	F3	363
1011 0100	180	B4	264	1111 0100	244	F4	364
1011 0101	181	B5	265	1111 0101	245	F5	365
1011 0110	182	B6	266	1111 0110	246	F6	366
1011 0111	183	B7	267	1111 0111	247	F7	367
1011 1000	184	B8	270	1111 1000	248	F8	370
1011 1001	185	B9	271	1111 1001	249	F9	371
1011 1010	186	BA	272	1111 1010	250	FA	372
1011 1011	187	BB	273	1111 1011	251	FB	373
1011 1100	188	BC	274	1111 1100	252	FC	374
1011 1101	189	BD	275	1111 1101	253	FD	375
1011 1110	190	BE	276	1111 1110	254	FE	376
1011 1111	191	BF	277	1111 1111	255	FF	377

**To Use This Table:** Find the value you want to look up by locating its binary equivalent in one of the left-most columns. Read the converted value in the appropriate column on the same row; e.g., the octal equivalent of binary 1110 is 16 (the third column).

**See Also:** 1.02. Hexadecimal to Binary Number Conversion  
 1.10. Octal to Binary Number Conversion  
 1.11. Decimal to Binary Number Conversion

1.07. BINARY TO SIGNED DECIMAL NUMBER CONVERSION

Binary	Decimal	Binary	Decimal	Binary	Decimal	Binary	Decimal
0000 0000	0	0100 0000	64	1000 0000	-128	1100 0000	-64
0000 0001	1	0100 0001	65	1000 0001	-127	1100 0001	-63
0000 0010	2	0100 0010	66	1000 0010	-126	1100 0010	-62
0000 0011	3	0100 0011	67	1000 0011	-125	1100 0011	-61
0000 0100	4	0100 0100	68	1000 0100	-124	1100 0100	-60
0000 0101	5	0100 0101	69	1000 0101	-123	1100 0101	-59
0000 0110	6	0100 0110	70	1000 0110	-122	1100 0110	-58
0000 0111	7	0100 0111	71	1000 0111	-121	1100 0111	-57
0000 1000	8	0100 1000	72	1000 1000	-120	1100 1000	-56
0000 1001	9	0100 1001	73	1000 1001	-119	1100 1001	-55
0000 1010	10	0100 1010	74	1000 1010	-118	1100 1010	-54
0000 1011	11	0100 1011	75	1000 1011	-117	1100 1011	-53
0000 1100	12	0100 1100	76	1000 1100	-116	1100 1100	-52
0000 1101	13	0100 1101	77	1000 1101	-115	1100 1101	-51
0000 1110	14	0100 1110	78	1000 1110	-114	1100 1110	-50
0000 1111	15	0100 1111	79	1000 1111	-113	1100 1111	-49
0001 0000	16	0101 0000	80	1001 0000	-112	1101 0000	-48
0001 0001	17	0101 0001	81	1001 0001	-111	1101 0001	-47
0001 0010	18	0101 0010	82	1001 0010	-110	1101 0010	-46
0001 0011	19	0101 0011	83	1001 0011	-109	1101 0011	-45
0001 0100	20	0101 0100	84	1001 0100	-108	1101 0100	-44
0001 0101	21	0101 0101	85	1001 0101	-107	1101 0101	-43
0001 0110	22	0101 0110	86	1001 0110	-106	1101 0110	-42
0001 0111	23	0101 0111	87	1001 0111	-105	1101 0111	-41
0001 1000	24	0101 1000	88	1001 1000	-104	1101 1000	-40
0001 1001	25	0101 1001	89	1001 1001	-103	1101 1001	-39
0001 1010	26	0101 1010	90	1001 1010	-102	1101 1010	-38
0001 1011	27	0101 1011	91	1001 1011	-101	1101 1011	-37
0001 1100	28	0101 1100	92	1001 1100	-100	1101 1100	-36
0001 1101	29	0101 1101	93	1001 1101	-99	1101 1101	-35
0001 1110	30	0101 1110	94	1001 1110	-98	1101 1110	-34
0001 1111	31	0101 1111	95	1001 1111	-97	1101 1111	-33
0010 0000	32	0110 0000	96	1010 0000	-96	1110 0000	-32
0010 0001	33	0110 0001	97	1010 0001	-95	1110 0001	-31
0010 0010	34	0110 0010	98	1010 0010	-94	1110 0010	-30
0010 0011	35	0110 0011	99	1010 0011	-93	1110 0011	-29
0010 0100	36	0110 0100	100	1010 0100	-92	1110 0100	-28
0010 0101	37	0110 0101	101	1010 0101	-91	1110 0101	-27
0010 0110	38	0110 0110	102	1010 0110	-90	1110 0110	-26
0010 0111	39	0110 0111	103	1010 0111	-89	1110 0111	-25
0010 1000	40	0110 1000	104	1010 1000	-88	1110 1000	-24
0010 1001	41	0110 1001	105	1010 1001	-87	1110 1001	-23
0010 1010	42	0110 1010	106	1010 1010	-86	1110 1010	-22
0010 1011	43	0110 1011	107	1010 1011	-85	1110 1011	-21
0010 1100	44	0110 1100	108	1010 1100	-84	1110 1100	-20
0010 1101	45	0110 1101	109	1010 1101	-83	1110 1101	-19
0010 1110	46	0110 1110	110	1010 1110	-82	1110 1110	-18
0010 1111	47	0110 1111	111	1010 1111	-81	1110 1111	-17
0011 0000	48	0111 0000	112	1011 0000	-80	1111 0000	-16
0011 0001	49	0111 0001	113	1011 0001	-79	1111 0001	-15
0011 0010	50	0111 0010	114	1011 0010	-78	1111 0010	-14
0011 0011	51	0111 0011	115	1011 0011	-77	1111 0011	-13
0011 0100	52	0111 0100	116	1011 0100	-76	1111 0100	-12
0011 0101	53	0111 0101	117	1011 0101	-75	1111 0101	-11
0011 0110	54	0111 0110	118	1011 0110	-74	1111 0110	-10
0011 0111	55	0111 0111	119	1011 0111	-73	1111 0111	-9
0011 1000	56	0111 1000	120	1011 1000	-72	1111 1000	-8
0011 1001	57	0111 1001	121	1011 1001	-71	1111 1001	-7
0011 1010	58	0111 1010	122	1011 1010	-70	1111 1010	-6
0011 1011	59	0111 1011	123	1011 1011	-69	1111 1011	-5
0011 1100	60	0111 1100	124	1011 1100	-68	1111 1100	-4
0011 1101	61	0111 1101	125	1011 1101	-67	1111 1101	-3
0011 1110	62	0111 1110	126	1011 1110	-66	1111 1110	-2
0011 1111	63	0111 1111	127	1011 1111	-65	1111 1111	-1

**To Use This Table:** Find the binary value you want to convert in one of the left columns. Read its corresponding signed decimal value in the same row in the column to the right.

**See Also:** 1.06. Binary Number Conversions

## 1.08. OCTAL TO DECIMAL NUMBER CONVERSION

Octal	Dec	Octal	Dec	Octal	Dec	Octal	Dec
0	0	40	32	100	64	140	96
1	1	41	33	101	65	141	97
2	2	42	34	102	66	142	98
3	3	43	35	103	67	143	99
4	4	44	36	104	68	144	100
5	5	45	37	105	69	145	101
6	6	46	38	106	70	146	102
7	7	47	39	107	71	147	103
10	8	50	40	110	72	150	104
11	9	51	41	111	73	151	105
12	10	52	42	112	74	152	106
13	11	53	43	113	75	153	107
14	12	54	44	114	76	154	108
15	13	55	45	115	77	155	109
16	14	56	46	116	78	156	110
17	15	57	47	117	79	157	111
20	16	60	48	120	80	160	112
21	17	61	49	121	81	161	113
22	18	62	50	122	82	162	114
23	19	63	51	123	83	163	115
24	20	64	52	124	84	164	116
25	21	65	53	125	85	165	117
26	22	66	54	126	86	166	118
27	23	67	55	127	87	167	119
30	24	70	56	130	88	170	120
31	25	71	57	131	89	171	121
32	26	72	58	132	90	172	122
33	27	73	59	133	91	173	123
34	28	74	60	134	92	174	124
35	29	75	61	135	93	175	125
36	30	76	62	136	94	176	126
37	31	77	63	137	95	177	127

**To Use This Table:** Find the octal value in one of the left-most columns and read its corresponding decimal value in the column to its right in the same row

**Notes:** Octal is rarely used for values greater than 128 decimal

**See Also:** 1.03. Hexadecimal to Octal Number Conversion  
1.06. Binary Number Conversions  
1.13. Decimal to Octal Number Conversion

## 1.09. OCTAL TO HEXADECIMAL NUMBER CONVERSION

Octal	Hex	Octal	Hex	Octal	Hex	Octal	Hex
0	0	40	20	100	40	140	60
1	1	41	21	101	41	141	61
2	2	42	22	102	42	142	62
3	3	43	23	103	43	143	63
4	4	44	24	104	44	144	64
5	5	45	25	105	45	145	65
6	6	46	26	106	46	146	66
7	7	47	27	107	47	147	67
10	8	50	28	110	48	150	68
11	9	51	29	111	49	151	69
12	A	52	2A	112	4A	152	6A
13	B	53	2B	113	4B	153	6B
14	C	54	2C	114	4C	154	6C
15	D	55	2D	115	4D	155	6D
16	E	56	2E	116	4E	156	6E
17	F	57	2F	117	4F	157	6F
20	10	60	30	120	50	160	70
21	11	61	31	121	51	161	71
22	12	62	32	122	52	162	72
23	13	63	33	123	53	163	73
24	14	64	34	124	54	164	74
25	15	65	35	125	55	165	75
26	16	66	36	126	56	166	76
27	17	67	37	127	57	167	77
30	18	70	38	130	58	170	78
31	19	71	39	131	59	171	79
32	1A	72	3A	132	5A	172	7A
33	1B	73	3B	133	5B	173	7B
34	1C	74	3C	134	5C	174	7C
35	1D	75	3D	135	5D	175	7D
36	1E	76	3E	136	5E	176	7E
37	1F	77	3F	137	5F	177	7F

**To Use This Table:** Find the octal value in one of the left-most columns and read its corresponding hexadecimal value in the column to the right in the same row

**Notes:** Octal is rarely used for values greater than 128 decimal

**See Also:** 1.03. Hexadecimal to Octal Number Conversion

**1.10. OCTAL TO BINARY NUMBER CONVERSION**

Octal	Binary	Octal	Binary	Octal	Binary	Octal	Binary
0	0000 0000	40	0010 0000	100	0100 0000	140	0110 0000
1	0000 0001	41	0010 0001	101	0100 0001	141	0110 0001
2	0000 0010	42	0010 0010	102	0100 0010	142	0110 0010
3	0000 0011	43	0010 0011	103	0100 0011	143	0110 0011
4	0000 0100	44	0010 0100	104	0100 0100	144	0110 0100
5	0000 0101	45	0010 0101	105	0100 0101	145	0110 0101
6	0000 0110	46	0010 0110	106	0100 0110	146	0110 0110
7	0000 0111	47	0010 0111	107	0100 0111	147	0110 0111
10	0000 1000	50	0010 1000	110	0100 1000	150	0110 1000
11	0000 1001	51	0010 1001	111	0100 1001	151	0110 1001
12	0000 1010	52	0010 1010	112	0100 1010	152	0110 1010
13	0000 1011	53	0010 1011	113	0100 1011	153	0110 1011
14	0000 1100	54	0010 1100	114	0100 1100	154	0110 1100
15	0000 1101	55	0010 1101	115	0100 1101	155	0110 1101
16	0000 1110	56	0010 1110	116	0100 1110	156	0110 1110
17	0000 1111	57	0010 1111	117	0100 1111	157	0110 1111
20	0001 0000	60	0011 0000	120	0101 0000	160	0111 0000
21	0001 0001	61	0011 0001	121	0101 0001	161	0111 0001
22	0001 0010	62	0011 0010	122	0101 0010	162	0111 0010
23	0001 0011	63	0011 0011	123	0101 0011	163	0111 0011
24	0001 0100	64	0011 0100	124	0101 0100	164	0111 0100
25	0001 0101	65	0011 0101	125	0101 0101	165	0111 0101
26	0001 0110	66	0011 0110	126	0101 0110	166	0111 0110
27	0001 0111	67	0011 0111	127	0101 0111	167	0111 0111
30	0001 1000	70	0011 1000	130	0101 1000	170	0111 1000
31	0001 1001	71	0011 1001	131	0101 1001	171	0111 1001
32	0001 1010	72	0011 1010	132	0101 1010	172	0111 1010
33	0001 1011	73	0011 1011	133	0101 1011	173	0111 1011
34	0001 1100	74	0011 1100	134	0101 1100	174	0111 1100
35	0001 1101	75	0011 1101	135	0101 1101	175	0111 1101
36	0001 1110	76	0011 1110	136	0101 1110	176	0111 1110
37	0001 1111	77	0011 1111	137	0101 1111	177	0111 1111

**To Use This Table:**

Find the octal value in one of the left-most columns and read its corresponding binary value in the column to the right in the same row

**Notes:**

Octal is rarely used for values greater than 128 decimal

**See Also:**

- 1.06. Binary Number Conversions
- 1.08. Octal to Decimal Number Conversion
- 1.09. Octal to Hexadecimal Number Conversion

1.11 DECIMAL TO BINARY NUMBER CONVERSION

Dec	Binary	Dec	Binary	Dec	Binary	Dec	Binary
0	0000 0000	64	0100 0000	128	1000 0000	192	1100 0000
1	0000 0001	65	0100 0001	129	1000 0001	193	1100 0001
2	0000 0010	66	0100 0010	130	1000 0010	194	1100 0010
3	0000 0011	67	0100 0011	131	1000 0011	195	1100 0011
4	0000 0100	68	0100 0100	132	1000 0100	196	1100 0100
5	0000 0101	69	0100 0101	133	1000 0101	197	1100 0101
6	0000 0110	70	0100 0110	134	1000 0110	198	1100 0110
7	0000 0111	71	0100 0111	135	1000 0111	199	1100 0111
8	0000 1000	72	0100 1000	136	1000 1000	200	1100 1000
9	0000 1001	73	0100 1001	137	1000 1001	201	1100 1001
10	0000 1010	74	0100 1010	138	1000 1010	202	1100 1010
11	0000 1011	75	0100 1011	139	1000 1011	203	1100 1011
12	0000 1100	76	0100 1100	140	1000 1100	204	1100 1100
13	0000 1101	77	0100 1101	141	1000 1101	205	1100 1101
14	0000 1110	78	0100 1110	142	1000 1110	206	1100 1110
15	0000 1111	79	0100 1111	143	1000 1111	207	1100 1111
16	0001 0000	80	0101 0000	144	1001 0000	208	1101 0000
17	0001 0001	81	0101 0001	145	1001 0001	209	1101 0001
18	0001 0010	82	0101 0010	146	1001 0010	210	1101 0010
19	0001 0011	83	0101 0011	147	1001 0011	211	1101 0011
20	0001 0100	84	0101 0100	148	1001 0100	212	1101 0100
21	0001 0101	85	0101 0101	149	1001 0101	213	1101 0101
22	0001 0110	86	0101 0110	150	1001 0110	214	1101 0110
23	0001 0111	87	0101 0111	151	1001 0111	215	1101 0111
24	0001 1000	88	0101 1000	152	1001 1000	216	1101 1000
25	0001 1001	89	0101 1001	153	1001 1001	217	1101 1001
26	0001 1010	90	0101 1010	154	1001 1010	218	1101 1010
27	0001 1011	91	0101 1011	155	1001 1011	219	1101 1011
28	0001 1100	92	0101 1100	156	1001 1100	220	1101 1100
29	0001 1101	93	0101 1101	157	1001 1101	221	1101 1101
30	0001 1110	94	0101 1110	158	1001 1110	222	1101 1110
31	0001 1111	95	0101 1111	159	1001 1111	223	1101 1111
32	0010 0000	96	0110 0000	160	1010 0000	224	1110 0000
33	0010 0001	97	0110 0001	161	1010 0001	225	1110 0001
34	0010 0010	98	0110 0010	162	1010 0010	226	1110 0010
35	0010 0011	99	0110 0011	163	1010 0011	227	1110 0011
36	0010 0100	100	0110 0100	164	1010 0100	228	1110 0100
37	0010 0101	101	0110 0101	165	1010 0101	229	1110 0101
38	0010 0110	102	0110 0110	166	1010 0110	230	1110 0110
39	0010 0111	103	0110 0111	167	1010 0111	231	1110 0111
40	0010 1000	104	0110 1000	168	1010 1000	232	1110 1000
41	0010 1001	105	0110 1001	169	1010 1001	233	1110 1001
42	0010 1010	106	0110 1010	170	1010 1010	234	1110 1010
43	0010 1011	107	0110 1011	171	1010 1011	235	1110 1011
44	0010 1100	108	0110 1100	172	1010 1100	236	1110 1100
45	0010 1101	109	0110 1101	173	1010 1101	237	1110 1101
46	0010 1110	110	0110 1110	174	1010 1110	238	1110 1110
47	0010 1111	111	0110 1111	175	1010 1111	239	1110 1111
48	0011 0000	112	0111 0000	176	1011 0000	240	1111 0000
49	0011 0001	113	0111 0001	177	1011 0001	241	1111 0001
50	0011 0010	114	0111 0010	178	1011 0010	242	1111 0010
51	0011 0011	115	0111 0011	179	1011 0011	243	1111 0011
52	0011 0100	116	0111 0100	180	1011 0100	244	1111 0100
53	0011 0101	117	0111 0101	181	1011 0101	245	1111 0101
54	0011 0110	118	0111 0110	182	1011 0110	246	1111 0110
55	0011 0111	119	0111 0111	183	1011 0111	247	1111 0111
56	0011 1000	120	0111 1000	184	1011 1000	248	1111 1000
57	0011 1001	121	0111 1001	185	1011 1001	249	1111 1001
58	0011 1010	122	0111 1010	186	1011 1010	250	1111 1010
59	0011 1011	123	0111 1011	187	1011 1011	251	1111 1011
60	0011 1100	124	0111 1100	188	1011 1100	252	1111 1100
61	0011 1101	125	0111 1101	189	1011 1101	253	1111 1101
62	0011 1110	126	0111 1110	190	1011 1110	254	1111 1110
63	0011 1111	127	0111 1111	191	1011 1111	255	1111 1111

**To Use This Table:** Find the decimal byte value you are looking up in one of left columns and read its binary value in the same row in the column immediately to the right. For example, a decimal value of 43 would result in a binary value of 0010 1011.

**See Also:** 1.06. Binary Number Conversions  
1.10. Octal to Binary Number Conversion

**1.12. DECIMAL TO HEXADECIMAL NUMBER CONVERSION**

Dec	Hex
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	A
11	B
12	C
13	D
14	E
15	F
16	10
17	11
18	12
19	13
20	14
21	15
22	16
23	17
24	18
25	19
26	1A

Dec	Hex
27	1B
28	1C
29	1D
30	1E
31	1F
32	20
33	21
34	22
35	23
36	24
37	25
38	26
39	27
40	28
41	29
42	2A
43	2B
44	2C
45	2D
46	2E
47	2F
48	30
49	31
50	32
51	33
52	34

Dec	Hex
53	35
54	36
55	37
56	38
57	39
58	3A
59	3B
60	3C
61	3D
62	3E
63	3F
64	40
65	41
66	42
67	43
68	44
69	45
70	46
71	47
72	48
73	49
74	4A
75	4B
76	4C
77	4D
78	4E

Dec	Hex
79	4F
80	50
81	51
82	52
83	53
84	54
85	55
86	56
87	57
88	58
89	59
90	5A
91	5B
92	5C
93	5D
94	5E
95	5F
96	60
97	61
98	62
99	63
100	64
200	C8
300	12C
400	190
500	1F4

Dec	Hex
600	258
700	2BC
800	320
900	384
1000	3E8
2000	7D0
3000	BB8
4000	FA0
5000	1388
6000	1770
7000	1B58
8000	1F40
9000	2328
10000	2710
20000	4E20
30000	7530
40000	9C40
50000	C350
60000	EA60
70000	11170
80000	13880
90000	15F90
100000	186A0

**To Use This Table:**

Find the decimal value in the left column and read the corresponding hexadecimal value in the same row in the column to its right. If you are converting a decimal number larger than 100, you may have to perform the conversion in steps, adding the results together. For example, to convert 12345 into hex, first obtain the hex value of decimal 10000 (2710H), then add this to the value for 2000 decimal (7D0H), then add this to the value for 300 decimal (12CH), then add this to the value for 45 decimal (2DH). The proper result is 3039H; remember that the numbers you are adding are in hexadecimal. (See 1.04. Hexadecimal Addition Tables)

**See Also:**

- 1.01. Hexadecimal to Decimal Number Conversion
- 1.04. Hexadecimal Addition Tables

## 1.13. DECIMAL TO OCTAL NUMBER CONVERSION

Dec	Octal
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	10
9	11
10	12
11	13
12	14
13	15
14	16
15	17
16	20
17	21
18	22
19	23
20	24
21	25
22	26
23	27
24	30
25	31
26	32

Dec	Octal
27	33
28	34
29	35
30	36
31	37
32	40
33	41
34	42
35	43
36	44
37	45
38	46
39	47
40	50
41	51
42	52
43	53
44	54
45	55
46	56
47	57
48	60
49	61
50	62
51	63
52	64

Dec	Octal
53	65
54	66
55	67
56	70
57	71
58	72
59	73
60	74
61	75
62	76
63	77
64	100
65	101
66	102
67	103
68	104
69	105
70	106
71	107
72	110
73	111
74	112
75	113
76	114
77	115
78	116

Dec	Octal
79	117
80	120
81	121
82	122
83	123
84	124
85	125
86	126
87	127
88	130
89	131
90	132
91	133
92	134
93	135
94	136
95	137
96	140
97	141
98	142
99	143
100	144
200	310
300	454
400	620
500	764

Dec	Octal
600	1130
700	1274
800	1440
900	1604
1000	1750
2000	3720
3000	5670
4000	7640
5000	11610
6000	13560
7000	15530
8000	17500
9000	21450
10000	23420
20000	47040
30000	72460
40000	116100
50000	141520
60000	165140
70000	210560
80000	234200
90000	257620
100000	303240

**To Use This Table:**

Find the decimal value in the left column and read the corresponding octal value in the same row in the column to the right. If you are converting a decimal number larger than 100, you may have to perform the conversion in steps, adding the results together. For example, to convert 12345 into octal, first obtain the octal value of decimal 10000 (23420), then add this to the value for 2000 decimal (3720), then add this to the value for 300 decimal (454), then add this to the value for 45 decimal (55). The proper result is 30071; remember that the numbers you are adding are in octal.

**See Also:**

1.08. Octal to Decimal Number Conversion

1.14. TWO'S COMPLEMENTS

Binary	Complement	Binary	Complement	Binary	Complement	Binary	Complement
1111 1111	0000 0001	1011 1111	0100 0001	0111 1111	1000 0001	0011 1111	1100 0001
1111 1110	0000 0010	1011 1110	0100 0010	0111 1110	1000 0010	0011 1110	1100 0010
1111 1101	0000 0011	1011 1101	0100 0011	0111 1101	1000 0011	0011 1101	1100 0011
1111 1100	0000 0100	1011 1100	0100 0100	0111 1100	1000 0100	0011 1100	1100 0100
1111 1011	0000 0101	1011 1011	0100 0101	0111 1011	1000 0101	0011 1011	1100 0101
1111 1010	0000 0110	1011 1010	0100 0110	0111 1010	1000 0110	0011 1010	1100 0110
1111 1001	0000 0111	1011 1001	0100 0111	0111 1001	1000 0111	0011 1001	1100 0111
1111 1000	0000 1000	1011 1000	0100 1000	0111 1000	1000 1000	0011 1000	1100 1000
1111 0111	0000 1001	1011 0111	0100 1001	0111 0111	1000 1001	0011 0111	1100 1001
1111 0110	0000 1010	1011 0110	0100 1010	0111 0110	1000 1010	0011 0110	1100 1010
1111 0101	0000 1011	1011 0101	0100 1011	0111 0101	1000 1011	0011 0101	1100 1011
1111 0100	0000 1100	1011 0100	0100 1100	0111 0100	1000 1100	0011 0100	1100 1100
1111 0011	0000 1101	1011 0011	0100 1101	0111 0011	1000 1101	0011 0011	1100 1101
1111 0010	0000 1110	1011 0010	0100 1110	0111 0010	1000 1110	0011 0010	1100 1110
1111 0001	0000 1111	1011 0001	0100 1111	0111 0001	1000 1111	0011 0001	1100 1111
1110 0000	0001 0000	1010 0000	0101 0000	0110 0000	1001 0000	0010 0000	1101 0000
1110 1111	0001 0001	1010 1111	0101 0001	0110 1111	1001 0001	0010 1111	1101 0001
1110 1110	0001 0010	1010 1110	0101 0010	0110 1110	1001 0010	0010 1110	1101 0010
1110 1101	0001 0011	1010 1101	0101 0011	0110 1101	1001 0011	0010 1101	1101 0011
1110 1100	0001 0100	1010 1100	0101 0100	0110 1100	1001 0100	0010 1100	1101 0100
1110 1011	0001 0101	1010 1011	0101 0101	0110 1011	1001 0101	0010 1011	1101 0101
1110 1010	0001 0110	1010 1010	0101 0110	0110 1010	1001 0110	0010 1010	1101 0110
1110 1001	0001 0111	1010 1001	0101 0111	0110 1001	1001 0111	0010 1001	1101 0111
1110 1000	0001 1000	1010 1000	0101 1000	0110 1000	1001 1000	0010 1000	1101 1000
1110 0111	0001 1001	1010 0111	0101 1001	0110 0111	1001 1001	0010 0111	1101 1001
1110 0110	0001 1010	1010 0110	0101 1010	0110 0110	1001 1010	0010 0110	1101 1010
1110 0101	0001 1011	1010 0101	0101 1011	0110 0101	1001 1011	0010 0101	1101 1011
1110 0100	0001 1100	1010 0100	0101 1100	0110 0100	1001 1100	0010 0100	1101 1100
1110 0011	0001 1101	1010 0011	0101 1101	0110 0011	1001 1101	0010 0011	1101 1101
1110 0010	0001 1110	1010 0010	0101 1110	0110 0010	1001 1110	0010 0010	1101 1110
1110 0001	0001 1111	1010 0001	0101 1111	0110 0001	1001 1111	0010 0001	1101 1111
1110 0000	0010 0000	1010 0000	0110 0000	0110 0000	1010 0000	0010 0000	1110 0000
1101 1111	0010 0001	1001 1111	0110 0001	0101 1111	1010 0001	0001 1111	1110 0001
1101 1110	0010 0010	1001 1110	0110 0010	0101 1110	1010 0010	0001 1110	1110 0010
1101 1101	0010 0011	1001 1101	0110 0011	0101 1101	1010 0011	0001 1101	1110 0011
1101 1100	0010 0100	1001 1100	0110 0100	0101 1100	1010 0100	0001 1100	1110 0100
1101 1011	0010 0101	1001 1011	0110 0101	0101 1011	1010 0101	0001 1011	1110 0101
1101 1010	0010 0110	1001 1010	0110 0110	0101 1010	1010 0110	0001 1010	1110 0110
1101 1001	0010 0111	1001 1001	0110 0111	0101 1001	1010 0111	0001 1001	1110 0111
1101 1000	0010 1000	1001 1000	0110 1000	0101 1000	1010 1000	0001 1000	1110 1000
1101 0111	0010 1001	1001 0111	0110 1001	0101 0111	1010 1001	0001 0111	1110 1001
1101 0110	0010 1010	1001 0110	0110 1010	0101 0110	1010 1010	0001 0110	1110 1010
1101 0101	0010 1011	1001 0101	0110 1011	0101 0101	1010 1011	0001 0101	1110 1011
1101 0100	0010 1100	1001 0100	0110 1100	0101 0100	1010 1100	0001 0100	1110 1100
1101 0011	0010 1101	1001 0011	0110 1101	0101 0011	1010 1101	0001 0011	1110 1101
1101 0010	0010 1110	1001 0010	0110 1110	0101 0010	1010 1110	0001 0010	1110 1110
1101 0001	0010 1111	1001 0001	0110 1111	0101 0001	1010 1111	0001 0001	1110 1111
1101 0000	0011 0000	1001 0000	0111 0000	0101 0000	1011 0000	0001 0000	1111 0000
1100 1111	0011 0001	1000 1111	0111 0001	0100 1111	1011 0001	0000 1111	1111 0001
1100 1110	0011 0010	1000 1110	0111 0010	0100 1110	1011 0010	0000 1110	1111 0010
1100 1101	0011 0011	1000 1101	0111 0011	0100 1101	1011 0011	0000 1101	1111 0011
1100 1100	0011 0100	1000 1100	0111 0100	0100 1100	1011 0100	0000 1100	1111 0100
1100 1011	0011 0101	1000 1011	0111 0101	0100 1011	1011 0101	0000 1011	1111 0101
1100 1010	0011 0110	1000 1010	0111 0110	0100 1010	1011 0110	0000 1010	1111 0110
1100 1001	0011 0111	1000 1001	0111 0111	0100 1001	1011 0111	0000 1001	1111 0111
1100 1000	0011 1000	1000 1000	0111 1000	0100 1000	1011 1000	0000 1000	1111 1000
1100 0111	0011 1001	1000 0111	0111 1001	0100 0111	1011 1001	0000 0111	1111 1001
1100 0110	0011 1010	1000 0110	0111 1010	0100 0110	1011 1010	0000 0110	1111 1010
1100 0101	0011 1011	1000 0101	0111 1011	0100 0101	1011 1011	0000 0101	1111 1011
1100 0100	0011 1100	1000 0100	0111 1100	0100 0100	1011 1100	0000 0100	1111 1100
1100 0011	0011 1101	1000 0011	0111 1101	0100 0011	1011 1101	0000 0011	1111 1101
1100 0010	0011 1110	1000 0010	0111 1110	0100 0010	1011 1110	0000 0010	1111 1110
1100 0001	0011 1111	1000 0001	0111 1111	0100 0001	1011 1111	0000 0001	1111 1111
1100 0000	0100 0000	1000 0000	1000 0000	0100 0000	1100 0000	0000 0000	0000 0000


To Use This Table:

Find the binary value you want to convert in one of the left columns. Read its corresponding two's complement value in the same row in the column to the right.

See Also:


1.06. Binary Number Conversions

1.15. COMMON 8086 FAMILY DATA FORMATS



**Notes:** Numbers in boxes are the bit numbers; note that the numbering of bits starts with the least significant bit labeled as zero

*Integer Storage Abilities*




Smallest Integer Value	Largest Integer Value
0	15
-128	127
-32,768	32,767
-2,147,483,648	2,147,483,647

**Notes:** Numbers beneath boxes indicate bit numbers (high=most significant)

**See Also:** 1.14. Two's Complements  
 1.16. Common Numeric Data Formats  
 1.17. Common String Formats

1.16. COMMON NUMERIC DATA FORMATS




Notes:

- Numbers beneath boxes indicate bit numbers (high=most significant)
- A bit value of 1 in the sign position (±) indicates the value is negative
- Exponent specifies the power of two by which the significand must be raised to obtain the value of a real number
- Significand specifies a binary value to be raised by the exponent
- Note that some data formats are "normalized" (i.e., have an assumed left-most bit of 1). Also, note that the decimal point in real numbers will be to the right of the left-most digit in the significand.
- The IEEE floating point format has an assumed high-order bit of 1 (i.e., is "normalized")
- Note that the exponent for IEEE floating point numbers is "biased" by an implementation-dependent amount. For the 8087, the real exponent = exponent - 1023.

Table 1.16. Continued

Layout of 8087 Data in Memory



**To Use This Table:** This table shows where each bit position is stored in memory, and what it is used for. Each letter or symbol in the boxes represents one bit (lower right is the least significant, upper left is most significant); each row represents one byte in memory.


Numeric Ranges Acceptable to Data Formats

	Smallest Value Accepted	Largest Value Accepted
8087 Word Integer	-32,768	32,767
8087 Short Integer	-2,147,483,648	2,147,483,647
8087 Long Integer	-9,223,372,036,854,775,808	9,223,372,036,854,775,807
8087 Packed Decimal	-(10 <sup>18</sup> )-1	(10 <sup>18</sup> )-1
8087 Short Real	8.43 x 10 <sup>-37</sup>	3.37 x 10 <sup>38</sup>
8087 Long Real	4.19 x 10 <sup>-307</sup>	1.67 x 10 <sup>308</sup>
8087 Temporary Real	3.4 x 10 <sup>-4932</sup>	1.2 x 10 <sup>4932</sup>
IEEE Floating Point	4.19 x 10 <sup>-307</sup>	1.67 x 10 <sup>308</sup>
MASM Long Real		
MASM Short Real		

**Source:** Intel 8087 Data Book, IEEE

**See Also:** 1.14. Two's Complements  
 1.15. Common 8086 Family Data Formats

1.17. COMMON STRING FORMATS



**Notes:** \*\*Not all C and Pascal compilers follow these formats exactly, but this is the recognized standard for each  
 \*\*\*Note that for BASICA, the string and the information about it are not stored consecutively in memory

**See Also:** 1.15. Common 8086 Family Data Formats  
 1.16. Common Numeric Data Formats

1.18. COMMON MEMORY AREA TERMINOLOGY

Term	Bits	Possible Values	Description	Conventional Use
Bit	1	2	Binary digit - a single digital element	Boolean value
Nibble	4	16	One-half a byte is a "nibble"	Binary Coded Digit (0-9) or hex digit (0-F)
Byte	8	256	Standard "cell" of data, especially ASCII characters	ASCII character
Word	16	65536	8086 family of CPUs deal with this amount of data at a time	Short Integer; memory address (not including segment)
Double Word	32	4294967296	Smallest memory area that can handle an 8086 segment:offset address	Long integers or segment addresses
Paragraph	128	NA	16 consecutive bytes of data	Memory allocation blocks
Page	2048	NA	256 consecutive bytes of data	2 pages = 1 sector of data
Segment	NA	NA	65536 consecutive bytes of data	DS, CS, ES, or SS segment
Kilobyte	NA	NA	1024 bytes	NA
Megabyte	NA	NA	1048576 bytes	NA

See Also: 1.27. Powers of Two

## 1.19. BINARY CODED DECIMAL NUMBER FORMAT

**Nibble (one BCD value)**

Decimal	BCD
0	0000
1	0001
2	0010
3	0011
4	0100
5	0101
6	0110
7	0111
8	1000
9	1001

**Byte (two BCD values)**

Decimal	BCD
00	0000 0000
01	0000 0001
02	0000 0010
03	0000 0011
04	0000 0100
05	0000 0101
06	0000 0110
07	0000 0111
08	0000 1000
09	0000 1001
10	0001 0000
11	0001 0001
12	0001 0010
13	0001 0011
14	0001 0100
15	0001 0101
16	0001 0110
17	0001 0111
18	0001 1000
19	0001 1001
20	0010 0000
21	0010 0001
22	0010 0010
23	0010 0011
24	0010 0100

Decimal	BCD
25	0010 0101
26	0010 0110
27	0010 0111
28	0010 1000
29	0010 1001
30	0011 0000
31	0011 0001
32	0011 0010
33	0011 0011
34	0011 0100
35	0011 0101
36	0011 0110
37	0011 0111
38	0011 1000
39	0011 1001
40	0100 0000
41	0100 0001
42	0100 0010
43	0100 0011
44	0100 0100
45	0100 0101
46	0100 0110
47	0100 0111
48	0100 1000
49	0100 1001

Decimal	BCD
50	0101 0000
51	0101 0001
52	0101 0010
53	0101 0011
54	0101 0100
55	0101 0101
56	0101 0110
57	0101 0111
58	0101 1000
59	0101 1001
60	0110 0000
61	0110 0001
62	0110 0010
63	0110 0011
64	0110 0100
65	0110 0101
66	0110 0110
67	0110 0111
68	0110 1000
69	0110 1001
70	0111 0000
71	0111 0001
72	0111 0010
73	0111 0011
74	0111 0100

Decimal	BCD
75	0111 0101
76	0111 0110
77	0111 0111
78	0111 1000
79	0111 1001
80	1000 0000
81	1000 0001
82	1000 0010
83	1000 0011
84	1000 0100
85	1000 0101
86	1000 0110
87	1000 0111
88	1000 1000
89	1000 1001
90	1001 0000
91	1001 0001
92	1001 0010
93	1001 0011
94	1001 0100
95	1001 0101
96	1001 0110
97	1001 0111
98	1001 1000
99	1001 1001

**Notes:**

Two binary coded digits may be stored in one byte, as shown in the lower table

**See Also:**

- 1.11. Decimal to Binary Number Conversion
- 1.15. Common 8086 Family Data Formats
- 1.16. Common Numeric Data Formats

## 1.20. ASCII CONTROL CODES

Dec	Hex	Binary	Mnemonic	Name	Definition
0	00	0000 0000	NUL	Null	Space filler character/used in output timing for some device drivers
1	01	0000 0001	SOH	Start of header	Marks beginning of message header
2	02	0000 0010	STX	Start of text	Marks beginning of data block (text)
3	03	0000 0011	ETX	End of text	Marks end of data block (text)
4	04	0000 0100	EOT	End of transmission	Marks end of transmission session
5	05	0000 0101	ENQ	Inquiry	Request for identification or information
6	06	0000 0110	ACK	Acknowledgement	"Yes" answer to queries or "ready for next transmission"/ used in asynchronous protocols for timing
7	07	0000 0111	BEL	Bell	Rings bell or audible alarm on terminal
8	08	0000 1000	BS	Backspace	Moves cursor position back one character
9	09	0000 1001	HT	Horizontal tab	Moves cursor position to next tab stop on line
10	0A	0000 1010	LF	Line feed	Moves cursor position down one line
11	0B	0000 1011	VT	Vertical tab	Moves cursor position down to next "tab line"
12	0C	0000 1100	FF	Form feed	Moves cursor position to top of next page
13	0D	0000 1101	CR	Carriage return	Moves cursor to left margin
14	0E	0000 1110	SO	Shift out	Next characters do not follow ASCII definitions
15	0F	0000 1111	SI	Shift in	Next characters revert to ASCII meaning
16	10	0001 0000	DLE	Data link escape	Used to control transmissions using "escape sequences"
17	11	0001 0001	DC1	Device control 1	Not defined; normally used for ON controls; usually user defined
18	12	0001 0010	DC2	Device control 2	Not defined; normally used for ON controls; usually user defined
19	13	0001 0011	DC3	Device control 3	Not defined; normally used for OFF controls; usually user defined
20	14	0001 0100	DC4	Device control 4	Not defined; normally used for OFF controls; usually user defined
21	15	0001 0101	NAK	Negative acknowledgment	"No" answer to questions or "errors found, retransmit"/used in asynchronous protocols
22	16	0001 0110	SYN	Synchronous idle	Sent by synchronous devices when idle to insure sync
23	17	0001 0111	ETB	End of transmission block	Marks block boundaries in transmission
24	18	0001 1000	CAN	Cancel	Indicates previous transmission should be disregarded
25	19	0001 1001	EM	End of medium	Marks end of physical media, as in paper tape
26	1A	0001 1010	SUB	Substitute	Used to replace a character known to be wrong
27	1B	0001 1011	ESC	Escape	Marks beginning of an Escape control sequence
28	1C	0001 1100	FS	File separator	Marker for major portion of transmission
29	1D	0001 1101	GS	Group separator	Marker for submajor portion of transmission
30	1E	0001 1110	RS	Record separator	Marker for minor portion of transmission
31	1F	0001 1111	US	Unit separator	Marker for most minor portion of transmission

- Notes:**
- ASCII control codes are sometimes used to "formalize" a communications session between communications devices
  - DC1, DC2, DC3, DC4, FS, GS, RS, and US all have user-defined meanings, and may vary in use between sessions or devices
  - DC4 is often used as a general "stop transmission character"
  - Codes used to control cursor position may be used to control print devices, and move the print head accordingly. Not all devices support the full set of positioning codes, however.

**See Also:** 1.21 ASCII Character Set

## 1.21. ASCII CHARACTER SET

Dec	Hex	Octal	Binary	Name	Character
0	00	0	0000 0000	NUL	None
1	01	1	0000 0001	SCH	^A*
2	02	2	0000 0010	STX	^B*
3	03	3	0000 0011	ETX	^C*
4	04	4	0000 0100	EOT	^D*
5	05	5	0000 0101	END	^E*
6	06	6	0000 0110	ACK	^F*
7	07	7	0000 0111	BEL	^G*
8	08	10	0000 1000	BS	^H*
9	09	11	0000 1001	HT	^I*
10	0A	12	0000 1010	LF	^J*
11	0B	13	0000 1011	VT	^K*
12	0C	14	0000 1100	FF	^L*
13	0D	15	0000 1101	CR	^M*
14	0E	16	0000 1110	SO	^N*
15	0F	17	0000 1111	SI	^O*
16	10	20	0001 0000	DLE	^P*
17	11	21	0001 0001	DC1	^Q*
18	12	22	0001 0010	DC2	^R*
19	13	23	0001 0011	DC3	^S*
20	14	24	0001 0100	DC4	^T*
21	15	25	0001 0101	NAK	^U*
22	16	26	0001 0110	SYN	^V*
23	17	27	0001 0111	ETB	^W*
24	18	30	0001 1000	CAN	^X*
25	19	31	0001 1001	EM	^Y*
26	1A	32	0001 1010	SUB	^Z*
27	1B	33	0001 1011	ESC	^[*
28	1C	34	0001 1100	FS	^[\*
29	1D	35	0001 1101	GS	^]*
30	1E	36	0001 1110	RS	^^*
31	1F	37	0001 1111	US	^_*
32	20	40	0010 0000	space	Space
33	21	41	0010 0001	exclamation point	!
34	22	42	0010 0010	quotation mark	"
35	23	43	0010 0011	number sign	#
36	24	44	0010 0100	dollar sign	\$
37	25	45	0010 0101	percent sign	%
38	26	46	0010 0110	ampersand	&
39	27	47	0010 0111	apostrophe	'
40	28	50	0010 1000	opening parenthesis	(
41	29	51	0010 1001	closing parenthesis	)
42	2A	52	0010 1010	asterisk	*
43	2B	53	0010 1011	plus sign	+
44	2C	54	0010 1100	comma	,
45	2D	55	0010 1101	hyphen or minus sign	-
46	2E	56	0010 1110	period	.
47	2F	57	0010 1111	slash	/
48	30	60	0011 0000	zero	0
49	31	61	0011 0001	one	1
50	32	62	0011 0010	two	2
51	33	63	0011 0011	three	3
52	34	64	0011 0100	four	4
53	35	65	0011 0101	five	5
54	36	66	0011 0110	six	6
55	37	67	0011 0111	seven	7
56	38	70	0011 1000	eight	8
57	39	71	0011 1001	nine	9
58	3A	72	0011 1010	colon	:
59	3B	73	0011 1011	semicolon	;
60	3C	74	0011 1100	less than sign	<
61	3D	75	0011 1101	equal sign	=
62	3E	76	0011 1110	greater than sign	>
63	3F	77	0011 1111	question mark	?

## Notes:

\*IBM does not use the ASCII codes for all characters, using, for example, the lower 32 characters for graphics (See 1.22. IBM ASCII Character Set)

\*\*ASCII defines characters 0-31 to be control characters (or nonprinting characters). On many systems the characters will display as shown and you can use the control sequence shown to enter these values from most systems' keyboards.

Dec	Hex	Octal	Binary	Name	Character
64	40	100	0100 0000	at sign	@
65	41	101	0100 0001	capital A	A
66	42	102	0100 0010	capital B	B
67	43	103	0100 0011	capital C	C
68	44	104	0100 0100	capital D	D
69	45	105	0100 0101	capital E	E
70	46	106	0100 0110	capital F	F
71	47	107	0100 0111	capital G	G
72	48	110	0100 1000	capital H	H
73	49	111	0100 1001	capital I	I
74	4A	112	0100 1010	capital J	J
75	4B	113	0100 1011	capital K	K
76	4C	114	0100 1100	capital L	L
77	4D	115	0100 1101	capital M	M
78	4E	116	0100 1110	capital N	N
79	4F	117	0100 1111	capital O	O
80	50	120	0101 0000	capital P	P
81	51	121	0101 0001	capital Q	Q
82	52	122	0101 0010	capital R	R
83	53	123	0101 0011	capital S	S
84	54	124	0101 0100	capital T	T
85	55	125	0101 0101	capital U	U
86	56	126	0101 0110	capital V	V
87	57	127	0101 0111	capital W	W
88	58	130	0101 1000	capital X	X
89	59	131	0101 1001	capital Y	Y
90	5A	132	0101 1010	capital Z	Z
91	5B	133	0101 1011	opening bracket	[
92	5C	134	0101 1100	backward slash	\
93	5D	135	0101 1101	closing bracket	]
94	5E	136	0101 1110	caret	^
95	5F	137	0101 1111	underscore	_
96	60	140	0110 0000	grave	`
97	61	141	0110 0001	lowercase A	a
98	62	142	0110 0010	lowercase B	b
99	63	143	0110 0011	lowercase C	c
100	64	144	0110 0100	lowercase D	d
101	65	145	0110 0101	lowercase E	e
102	66	146	0110 0110	lowercase F	f
103	67	147	0110 0111	lowercase G	g
104	68	150	0110 1000	lowercase H	h
105	69	151	0110 1001	lowercase I	i
106	6A	152	0110 1010	lowercase J	j
107	6B	153	0110 1011	lowercase K	k
108	6C	154	0110 1100	lowercase L	l
109	6D	155	0110 1101	lowercase M	m
110	6E	156	0110 1110	lowercase N	n
111	6F	157	0110 1111	lowercase O	o
112	70	160	0111 0000	lowercase P	p
113	71	161	0111 0001	lowercase Q	q
114	72	162	0111 0010	lowercase R	r
115	73	163	0111 0011	lowercase S	s
116	74	164	0111 0100	lowercase T	t
117	75	165	0111 0101	lowercase U	u
118	76	166	0111 0110	lowercase V	v
119	77	167	0111 0111	lowercase W	w
120	78	170	0111 1000	lowercase X	x
121	79	171	0111 1001	lowercase Y	y
122	7A	172	0111 1010	lowercase Z	z
123	7B	173	0111 1011	opening brace	{
124	7C	174	0111 1100	vertical line	
125	7D	175	0111 1101	closing brace	}
126	7E	176	0111 1110	tilde	~
127	7F	177	0111 1111	DEL	Delete

## See Also:

1.20. ASCII Control Codes

1.22. IBM ASCII CHARACTER SET

Dec	Hex	Octal	Binary	Name	Character
0	00	0	0000 0000	blank	
1	01	1	0000 0001	happy face	☺
2	02	2	0000 0010	inverse happy face	☹
3	03	3	0000 0011	heart	♥
4	04	4	0000 0100	diamond	♦
5	05	5	0000 0101	club	♣
6	06	6	0000 0110	spade	♠
7	07	7	0000 0111	bullet	•
8	08	10	0000 1000	inverse bullet	◼
9	09	11	0000 1001	circle	○
10	0A	12	0000 1010	inverse circle	◐
11	0B	13	0000 1011	male sign	♂
12	0C	14	0000 1100	female sign	♀
13	0D	15	0000 1101	single note	♪
14	0E	16	0000 1110	double note	♫
15	0F	17	0000 1111	sun	☀
16	10	20	0001 0000	right triangle	▸
17	11	21	0001 0001	left triangle	◀
18	12	22	0001 0010	up/down arrow	↕
19	13	23	0001 0011	double exclamation	!!
20	14	24	0001 0100	paragraph sign	¶
21	15	25	0001 0101	section sign	§
22	16	26	0001 0110	rectangular bullet	▬
23	17	27	0001 0111	up/down to line	↕
24	18	30	0001 1000	up arrow	↑
25	19	31	0001 1001	down arrow	↓
26	1A	32	0001 1010	right arrow	→
27	1B	33	0001 1011	left arrow	←
28	1C	34	0001 1100	lower left box	└
29	1D	35	0001 1101	left/right arrow	↔
30	1E	36	0001 1110	up triangle	▲
31	1F	37	0001 1111	down triangle	▼
32	20	40	0010 0000	space	Space
33	21	41	0010 0001	exclamation point	!
34	22	42	0010 0010	quotation mark	"
35	23	43	0010 0011	number sign	#
36	24	44	0010 0100	dollar sign	\$
37	25	45	0010 0101	percent sign	%
38	26	46	0010 0110	ampersand	&
39	27	47	0010 0111	apostrophe	'
40	28	50	0010 1000	opening parenthesis	(
41	29	51	0010 1001	closing parenthesis	)
42	2A	52	0010 1010	asterisk	*
43	2B	53	0010 1011	plus sign	+
44	2C	54	0010 1100	comma	,
45	2D	55	0010 1101	hyphen or minus sign	-
46	2E	56	0010 1110	period	.
47	2F	57	0010 1111	slash	/
48	30	60	0011 0000	zero	0
49	31	61	0011 0001	one	1
50	32	62	0011 0010	two	2
51	33	63	0011 0011	three	3
52	34	64	0011 0100	four	4
53	35	65	0011 0101	five	5
54	36	66	0011 0110	six	6
55	37	67	0011 0111	seven	7
56	38	70	0011 1000	eight	8
57	39	71	0011 1001	nine	9
58	3A	72	0011 1010	colon	:
59	3B	73	0011 1011	semicolon	;
60	3C	74	0011 1100	less than sign	<
61	3D	75	0011 1101	equal sign	=
62	3E	76	0011 1110	greater than sign	>
63	3F	77	0011 1111	question mark	?

Dec	Hex	Octal	Binary	Name	Character
64	40	100	0100 0000	at sign	@
65	41	101	0100 0001	capital A	A
66	42	102	0100 0010	capital B	B
67	43	103	0100 0011	capital C	C
68	44	104	0100 0100	capital D	D
69	45	105	0100 0101	capital E	E
70	46	106	0100 0110	capital F	F
71	47	107	0100 0111	capital G	G
72	48	110	0100 1000	capital H	H
73	49	111	0100 1001	capital I	I
74	4A	112	0100 1010	capital J	J
75	4B	113	0100 1011	capital K	K
76	4C	114	0100 1100	capital L	L
77	4D	115	0100 1101	capital M	M
78	4E	116	0100 1110	capital N	N
79	4F	117	0100 1111	capital O	O
80	50	120	0101 0000	capital P	P
81	51	121	0101 0001	capital Q	Q
82	52	122	0101 0010	capital R	R
83	53	123	0101 0011	capital S	S
84	54	124	0101 0100	capital T	T
85	55	125	0101 0101	capital U	U
86	56	126	0101 0110	capital V	V
87	57	127	0101 0111	capital W	W
88	58	130	0101 1000	capital X	X
89	59	131	0101 1001	capital Y	Y
90	5A	132	0101 1010	capital Z	Z
91	5B	133	0101 1011	opening bracket	[
92	5C	134	0101 1100	backward slash	\
93	5D	135	0101 1101	closing bracket	]
94	5E	136	0101 1110	caret	^
95	5F	137	0101 1111	underscore	_
96	60	140	0110 0000	grave	`
97	61	141	0110 0001	lowercase A	a
98	62	142	0110 0010	lowercase B	b
99	63	143	0110 0011	lowercase C	c
100	64	144	0110 0100	lowercase D	d
101	65	145	0110 0101	lowercase E	e
102	66	146	0110 0110	lowercase F	f
103	67	147	0110 0111	lowercase G	g
104	68	150	0110 1000	lowercase H	h
105	69	151	0110 1001	lowercase I	i
106	6A	152	0110 1010	lowercase J	j
107	6B	153	0110 1011	lowercase K	k
108	6C	154	0110 1100	lowercase L	l
109	6D	155	0110 1101	lowercase M	m
110	6E	156	0110 1110	lowercase N	n
111	6F	157	0110 1111	lowercase O	o
112	70	160	0111 0000	lowercase P	p
113	71	161	0111 0001	lowercase Q	q
114	72	162	0111 0010	lowercase R	r
115	73	163	0111 0011	lowercase S	s
116	74	164	0111 0100	lowercase T	t
117	75	165	0111 0101	lowercase U	u
118	76	166	0111 0110	lowercase V	v
119	77	167	0111 0111	lowercase W	w
120	78	170	0111 1000	lowercase X	x
121	79	171	0111 1001	lowercase Y	y
122	7A	172	0111 1010	lowercase Z	z
123	7B	173	0111 1011	opening brace	{
124	7C	174	0111 1100	vertical line	
125	7D	175	0111 1101	closing brace	}
126	7E	176	0111 1110	tilde	~
127	7F	177	0111 1111	small house	♠

(Continued)

Table 1.22. Continued

Dec	Hex	Octal	Binary	Name	Character	Dec	Hex	Octal	Binary	Name	Character
128	80	200	1000 0000	C cedilla	Ç	192	C0	300	1100 0000	single lower left	↳
129	81	201	1000 0001	u umlaut	ü	193	C1	301	1100 0001	single lower junction	⋈
130	82	202	1000 0010	e acute	é	194	C2	302	1100 0010	single upper junction	⋈
131	83	203	1000 0011	a circumflex	â	195	C3	303	1100 0011	single left junction	⋈
132	84	204	1000 0100	a umlaut	ä	196	C4	304	1100 0100	single horizontal	—
133	85	205	1000 0101	a grave	à	197	C5	305	1100 0101	single intersection	+
134	86	206	1000 0110	a ring	å	198	C6	306	1100 0110	2 to 1 left junction	⋈
135	87	207	1000 0111	c cedilla	ç	199	C7	307	1100 0111	1 to 2 left junction	⋈
136	88	210	1000 1000	e circumflex	ê	200	C8	310	1100 1000	double lower left	↳↳
137	89	211	1000 1001	e umlaut	ë	201	C9	311	1100 1001	double upper left	⋈⋈
138	8A	212	1000 1010	e grave	è	202	CA	312	1100 1010	double lower junction	⋈⋈
139	8B	213	1000 1011	i umlaut	ï	203	CB	313	1100 1011	double upper junction	⋈⋈
140	8C	214	1000 1100	i circumflex	î	204	CC	314	1100 1100	double left junction	⋈⋈
141	8D	215	1000 1101	i grave	ì	205	CD	315	1100 1101	double horizontal	==
142	8E	216	1000 1110	A umlaut	Ä	206	CE	316	1100 1110	double intersection	⋈⋈
143	8F	217	1000 1111	A ring	Å	207	CF	317	1100 1111	1 to 2 lower junction	⋈
144	90	220	1001 0000	E acute	É	208	D0	320	1101 0000	2 to 1 lower junction	⋈
145	91	221	1001 0001	ae ligature	Æ	209	D1	321	1101 0001	1 to 2 upper junction	⋈
146	92	222	1001 0010	AE ligature	Æ	210	D2	322	1101 0010	2 to 1 upper junction	⋈
147	93	223	1001 0011	o circumflex	ô	211	D3	323	1101 0011	1 to 2 lower left	↳
148	94	224	1001 0100	o umlaut	ö	212	D4	324	1101 0100	2 to 1 lower left	↳
149	95	225	1001 0101	o grave	ò	213	D5	325	1101 0101	2 to 1 upper left	↳
150	96	226	1001 0110	u circumflex	û	214	D6	326	1101 0110	1 to 2 upper left	↳
151	97	227	1001 0111	u grave	ù	215	D7	327	1101 0111	2 to 1 intersection	⋈
152	98	230	1001 1000	y umlaut	ÿ	216	D8	330	1101 1000	1 to 2 intersection	⋈
153	99	231	1001 1001	O umlaut	Û	217	D9	331	1101 1001	single lower right	↘
154	9A	232	1001 1010	U umlaut	Ü	218	DA	332	1101 1010	single upper left	↖
155	9B	233	1001 1011	cent sign	¢	219	DB	333	1101 1011	inverse space	␣
156	9C	234	1001 1100	pound sign	£	220	DC	334	1101 1100	lower inverse	␣
157	9D	235	1001 1101	yen sign	¥	221	DD	335	1101 1101	left inverse	␣
158	9E	236	1001 1110	Pt	℞	222	DE	336	1101 1110	right inverse	␣
159	9F	237	1001 1111	function	f	223	DF	337	1101 1111	upper inverse	␣
160	A0	240	1010 0000	a acute	á	224	E0	340	1110 0000	alpha	α
161	A1	241	1010 0001	i acute	í	225	E1	341	1110 0001	beta	β
162	A2	242	1010 0010	o acute	ó	226	E2	342	1110 0010	gamma	γ
163	A3	243	1010 0011	u acute	ú	227	E3	343	1110 0011	pi	π
164	A4	244	1010 0100	n tilde	ñ	228	E4	344	1110 0100	sigma	σ
165	A5	245	1010 0101	N tilde	Ñ	229	E5	345	1110 0101	sigma	σ
166	A6	246	1010 0110	a macron	ā	230	E6	346	1110 0110	mu	μ
167	A7	247	1010 0111	o macron	ō	231	E7	347	1110 0111	tau	τ
168	A8	250	1010 1000	opening question mark	¿	232	E8	350	1110 1000	phi	φ
169	A9	251	1010 1001	upper left box	⌞	233	E9	351	1110 1001	theta	θ
170	AA	252	1010 1010	upper right box	⌟	234	EA	352	1110 1010	omega	ω
171	AB	253	1010 1011	1/2	½	235	EB	353	1110 1011	delta	δ
172	AC	254	1010 1100	1/4	¼	236	EC	354	1110 1100	infinity	∞
173	AD	255	1010 1101	opening exclamation	¡	237	ED	355	1110 1101	phi	φ
174	AE	256	1010 1110	<<	«	238	EE	356	1110 1110	epsilon	ε
175	AF	257	1010 1111	>>	»	239	EF	357	1110 1111	intersection of sets	∩
176	B0	260	1011 0000	light block	█	240	F0	360	1111 0000	is identical to	≡
177	B1	261	1011 0001	medium block	▒	241	F1	361	1111 0001	plus/minus sign	±
178	B2	262	1011 0010	dark block	▓	242	F2	362	1111 0010	greater/equal sign	≥
179	B3	263	1011 0011	single vertical	∟	243	F3	363	1111 0011	less/equal sign	≤
180	B4	264	1011 0100	single right junction	└	244	F4	364	1111 0100	top half integral	∫
181	B5	265	1011 0101	2 to 1 right junction	┘	245	F5	365	1111 0101	lower half integral	∫
182	B6	266	1011 0110	1 to 2 right junction	┐	246	F6	366	1111 0110	divide by sign	÷
183	B7	267	1011 0111	1 to 2 upper right	┌	247	F7	367	1111 0111	approximately	≈
184	B8	270	1011 1000	2 to 1 upper right	┐	248	F8	370	1111 1000	degree	°
185	B9	271	1011 1001	double right junction	└┐	249	F9	371	1111 1001	filled in degree	◦
186	BA	272	1011 1010	double vertical	∥	250	FA	372	1111 1010	small bullet	•
187	BB	273	1011 1011	double upper right	┐┐	251	FB	373	1111 1011	square root	√
188	BC	274	1011 1100	double lower right	┘┘	252	FC	374	1111 1100	superscript n	ⁿ
189	BD	275	1011 1101	1 to 2 lower right	┘	253	FD	375	1111 1101	superscript 2	²
190	BE	276	1011 1110	2 to 1 lower right	┘	254	FE	376	1111 1110	box	◻
191	BF	277	1011 1111	single upper right	┘	255	FF	377	1111 1111	phantom space	

**Notes:** The line drawing characters are given arbitrary names in this table in this manner: the left-most component is named first, followed by the word "to," followed by the right-most component. Thus, if we were naming the upper left corner of a single-line box, it would be "1 to 1 upper left." If the left side of the box were double lined, it would be "2 to 1 upper left."

**Source:** IBM PC/XT Technical Reference, pages C-12, 13

**See Also:** 1.21. ASCII Character Set  
1.23. IBM Extended Character Codes

1.23. IBM EXTENDED CHARACTER CODES

Dec	Hex	Octal	Binary	Actual Keys Pressed
3	03	3	0000 0011	Null character (none)
15	0F	17	0000 1111	Shift Tab
16	10	20	0001 0000	Alt + Q
17	11	21	0001 0001	Alt + W
18	12	22	0001 0010	Alt + E
19	13	23	0001 0011	Alt + R
20	14	24	0001 0100	Alt + T
21	15	25	0001 0101	Alt + Y
22	16	26	0001 0110	Alt + U
23	17	27	0001 0111	Alt + I
24	18	30	0001 1000	Alt + O
25	19	31	0001 1001	Alt + P
30	1E	36	0001 1110	Alt + A
31	1F	37	0001 1111	Alt + S
32	20	40	0010 0000	Alt + D
33	21	41	0010 0001	Alt + F
34	22	42	0010 0010	Alt + G
35	23	43	0010 0011	Alt + H
36	24	44	0010 0100	Alt + J
37	25	45	0010 0101	Alt + K
38	26	46	0010 0110	Alt + L
44	2C	54	0010 1100	Alt + Z
45	2D	55	0010 1101	Alt + X
46	2E	56	0010 1110	Alt + C
47	2F	57	0010 1111	Alt + V
48	30	60	0011 0000	Alt + B
49	31	61	0011 0001	Alt + N
50	32	62	0011 0010	Alt + M
59	3B	73	0011 1011	Function key 1
60	3C	74	0011 1100	Function key 2
61	3D	75	0011 1101	Function key 3
62	3E	76	0011 1110	Function key 4
63	3F	77	0011 1111	Function key 5
64	40	100	0100 0000	Function key 6
65	41	101	0100 0001	Function key 7
66	42	102	0100 0010	Function key 8
67	43	103	0100 0011	Function key 9
68	44	104	0100 0100	Function key 10
71	47	107	0100 0111	Home
72	48	110	0100 1000	Up arrow
73	49	111	0100 1001	Page Up
75	4B	113	0100 1011	Left arrow
77	4D	115	0100 1101	Right arrow
79	4F	117	0100 1111	End
80	50	120	0101 0000	Down arrow
81	51	121	0101 0001	Page Down
82	52	122	0101 0010	Insert
83	53	123	0101 0011	Delete
84	54	124	0101 0100	Shift + F1

Dec	Hex	Octal	Binary	Actual Keys Pressed
85	55	125	0101 0101	Shift + F2
86	56	126	0101 0110	Shift + F3
87	57	127	0101 0111	Shift + F4
88	58	130	0101 1000	Shift + F5
89	59	131	0101 1001	Shift + F6
90	5A	132	0101 1010	Shift + F7
91	5B	133	0101 1011	Shift + F8
92	5C	134	0101 1100	Shift + F9
93	5D	135	0101 1101	Shift + F10
94	5E	136	0101 1110	Control + F1
95	5F	137	0101 1111	Control + F2
96	60	140	0110 0000	Control + F3
97	61	141	0110 0001	Control + F4
98	62	142	0110 0010	Control + F5
99	63	143	0110 0011	Control + F6
100	64	144	0110 0100	Control + F7
101	65	145	0110 0101	Control + F8
102	66	146	0110 0110	Control + F9
103	67	147	0110 0111	Control + F10
104	68	150	0110 1000	Alt + F1
105	69	151	0110 1001	Alt + F2
106	6A	152	0110 1010	Alt + F3
107	6B	153	0110 1011	Alt + F4
108	6C	154	0110 1100	Alt + F5
109	6D	155	0110 1101	Alt + F6
110	6E	156	0110 1110	Alt + F7
111	6F	157	0110 1111	Alt + F8
112	70	160	0111 0000	Alt + F9
113	71	161	0111 0001	Alt + F10
114	72	162	0111 0010	Control + PrtSc
115	73	163	0111 0011	Control + Left arrow
116	74	164	0111 0100	Control + Right arrow
117	75	165	0111 0101	Control + End
118	76	166	0111 0110	Control + PgDn
119	77	167	0111 0111	Control + Home
120	78	170	0111 1000	Alt + upper row 1
121	79	171	0111 1001	Alt + upper row 2
122	7A	172	0111 1010	Alt + upper row 3
123	7B	173	0111 1011	Alt + upper row 4
124	7C	174	0111 1100	Alt + upper row 5
125	7D	175	0111 1101	Alt + upper row 6
126	7E	176	0111 1110	Alt + upper row 7
127	7F	177	0111 1111	Alt + upper row 8
128	80	200	1000 0000	Alt + upper row 9
129	81	201	1000 0001	Alt + upper row 0
130	82	202	1000 0010	Alt + hyphen
131	83	203	1000 0011	Alt + equals
132	84	204	1000 0100	Control + PgUp

**Notes:** Extended codes are preceded by a byte of 00H;  
(e.g., 00H, 81H means Alt and Zero were held down)

**Source:** IBM PC/XT Technical Reference, page 2-14

**See Also:** 1.21. ASCII Character Set  
1.22. IBM ASCII Character Set

## 1.24. LINE DRAWING CHARACTER SET

218 ┌	196 —	194 ┐	191 └	201 ┌	203 ┐	187 └
179 						
195 ┌		197 ┐	180 └	204 ┌	206 ┐	185 └
192 └	193 ┐		217 ┌	200 ┌	202 ┐	188 └
213 ┌	205 =	209 ┐	184 └	214 ┌	210 ┐	183 └
				186 		
198 ┌		216 ┐	181 └	199 ┌	215 ┐	182 └
212 └	207 ┐		190 ┌	211 ┌	208 ┐	189 └

**Notes:** Line characters can be drawn by holding down the Alt key and typing the associated three-digit number on the number pad

**Source:** IBM PC/XT Technical Reference, page C-13

**See Also:** 1.22. IBM ASCII Character Set

1.25. EBCDIC CHARACTER SET

Dec	Hex	Octal	Binary	Name	Character
0	00	0	0000 0000	NUL	
1	01	1	0000 0001	SCH	
2	02	2	0000 0010	STX	
3	03	3	0000 0011	ETX	
4	04	4	0000 0100	PF	
5	05	5	0000 0101	HT	
6	06	6	0000 0110	LC	
7	07	7	0000 0111	DEL	
8	08	10	0000 1000	GE	
9	09	11	0000 1001	RLF	
10	0A	12	0000 1010	SMM	
11	0B	13	0000 1011	VT	
12	0C	14	0000 1100	FF	
13	0D	15	0000 1101	CR	
14	0E	16	0000 1110	SO	
15	0F	17	0000 1111	SI	
16	10	20	0001 0000	DLE	
17	11	21	0001 0001	DC1	
18	12	22	0001 0010	DC2	
19	13	23	0001 0011	TM	
20	14	24	0001 0100	RES	
21	15	25	0001 0101	NL	
22	16	26	0001 0110	BS	
23	17	27	0001 0111	IL	
24	18	30	0001 1000	CAN	
25	19	31	0001 1001	EM	
26	1A	32	0001 1010	CC	
27	1B	33	0001 1011	CU1	
28	1C	34	0001 1100	IFS	
29	1D	35	0001 1101	IGS	
30	1E	36	0001 1110	IRS	
31	1F	37	0001 1111	IUS	
32	20	40	0010 0000	DS	
33	21	41	0010 0001	SOS	
34	22	42	0010 0010	FS	
35	23	43	0010 0011		
36	24	44	0010 0100	BYP	
37	25	45	0010 0101	LF	
38	26	46	0010 0110	ETB	
39	27	47	0010 0111	ESC	
40	28	50	0010 1000		
41	29	51	0010 1001		
42	2A	52	0010 1010	SM	
43	2B	53	0010 1011	CU2	
44	2C	54	0010 1100		
45	2D	55	0010 1101	END	
46	2E	56	0010 1110	ACK	
47	2F	57	0010 1111	BEL	
48	30	60	0011 0000		
49	31	61	0011 0001		
50	32	62	0011 0010	SYN	
51	33	63	0011 0011		
52	34	64	0011 0100	FN	
53	35	65	0011 0101	RS	
54	36	66	0011 0110	LC	
55	37	67	0011 0111	EOT	
56	38	70	0011 1000		
57	39	71	0011 1001		
58	3A	72	0011 1010		
59	3B	73	0011 1011	CU3	
60	3C	74	0011 1100	DC4	
61	3D	75	0011 1101	NAK	
62	3E	76	0011 1110		
63	3F	77	0011 1111	SUB	

Dec	Hex	Octal	Binary	Name	Character
64	40	100	0100 0000	SP	
65	41	101	0100 0001		
66	42	102	0100 0010		
67	43	103	0100 0011		
68	44	104	0100 0100		
69	45	105	0100 0101		
70	46	106	0100 0110		
71	47	107	0100 0111		
72	48	110	0100 1000		
73	49	111	0100 1001		
74	4A	112	0100 1010	€	
75	4B	113	0100 1011		
76	4C	114	0100 1100	<	
77	4D	115	0100 1101	(	
78	4E	116	0100 1110	+	
79	4F	117	0100 1111		
80	50	120	0101 0000	&	
81	51	121	0101 0001		
82	52	122	0101 0010		
83	53	123	0101 0011		
84	54	124	0101 0100		
85	55	125	0101 0101		
86	56	126	0101 0110		
87	57	127	0101 0111		
88	58	130	0101 1000		
89	59	131	0101 1001		
90	5A	132	0101 1010	!	
91	5B	133	0101 1011	\$	
92	5C	134	0101 1100	*	
93	5D	135	0101 1101	)	
94	5E	136	0101 1110	:	
95	5F	137	0101 1111	-	
96	60	140	0110 0000	-	
97	61	141	0110 0001	/	
98	62	142	0110 0010		
99	63	143	0110 0011		
100	64	144	0110 0100		
101	65	145	0110 0101		
102	66	146	0110 0110		
103	67	147	0110 0111		
104	68	150	0110 1000		
105	69	151	0110 1001		
106	6A	152	0110 1010	!	
107	6B	153	0110 1011	.	
108	6C	154	0110 1100	%	
109	6D	155	0110 1101	-	
110	6E	156	0110 1110	>	
111	6F	157	0110 1111	?	
112	70	160	0111 0000		
113	71	161	0111 0001		
114	72	162	0111 0010		
115	73	163	0111 0011		
116	74	164	0111 0100		
117	75	165	0111 0101		
118	76	166	0111 0110		
119	77	167	0111 0111		
120	78	170	0111 1000		
121	79	171	0111 1001		
122	7A	172	0111 1010	:	
123	7B	173	0111 1011	#	
124	7C	174	0111 1100	@	
125	7D	175	0111 1101	'	
126	7E	176	0111 1110	=	
127	7F	177	0111 1111	"	

(Continued)

Table 1.25. Continued

Dec	Hex	Octal	Binary	Name	Character	Dec	Hex	Octal	Binary	Name	Character
128	80	200	1000 0000			192	C0	300	1100 0000		
129	81	201	1000 0001		a	193	C1	301	1100 0001		A
130	82	202	1000 0010		b	194	C2	302	1100 0010		B
131	83	203	1000 0011		c	195	C3	303	1100 0011		C
132	84	204	1000 0100		d	196	C4	304	1100 0100		D
133	85	205	1000 0101		e	197	C5	305	1100 0101		E
134	86	206	1000 0110		f	198	C6	306	1100 0110		F
135	87	207	1000 0111		g	199	C7	307	1100 0111		G
136	88	210	1000 1000		h	200	C8	310	1100 1000		H
137	89	211	1000 1001		i	201	C9	311	1100 1001		I
138	8A	212	1000 1010			202	CA	312	1100 1010		
139	8B	213	1000 1011			203	CB	313	1100 1011		
140	8C	214	1000 1100			204	CC	314	1100 1100		∅
141	8D	215	1000 1101			205	CD	315	1100 1101		
142	8E	216	1000 1110			206	CE	316	1100 1110		ψ
143	8F	217	1000 1111			207	CF	317	1100 1111		
144	90	220	1001 0000			208	D0	320	1101 0000		∫
145	91	221	1001 0001		j	209	D1	321	1101 0001		J
146	92	222	1001 0010		k	210	D2	322	1101 0010		K
147	93	223	1001 0011		l	211	D3	323	1101 0011		L
148	94	224	1001 0100		m	212	D4	324	1101 0100		M
149	95	225	1001 0101		n	213	D5	325	1101 0101		N
150	96	226	1001 0110		o	214	D6	326	1101 0110		O
151	97	227	1001 0111		p	215	D7	327	1101 0111		P
152	98	230	1001 1000		q	216	D8	330	1101 1000		Q
153	99	231	1001 1001		r	217	D9	331	1101 1001		R
154	9A	232	1001 1010			218	DA	332	1101 1010		
155	9B	233	1001 1011			219	DB	333	1101 1011		
156	9C	234	1001 1100			220	DC	334	1101 1100		
157	9D	235	1001 1101			221	DD	335	1101 1101		
158	9E	236	1001 1110			222	DE	336	1101 1110		
159	9F	237	1001 1111			223	DF	337	1101 1111		
160	A0	240	1010 0000			224	E0	340	1110 0000		\
161	A1	241	1010 0001		~	225	E1	341	1110 0001		
162	A2	242	1010 0010		s	226	E2	342	1110 0010		S
163	A3	243	1010 0011		t	227	E3	343	1110 0011		T
164	A4	244	1010 0100		u	228	E4	344	1110 0100		U
165	A5	245	1010 0101		v	229	E5	345	1110 0101		V
166	A6	246	1010 0110		w	230	E6	346	1110 0110		W
167	A7	247	1010 0111		x	231	E7	347	1110 0111		X
168	A8	250	1010 1000		y	232	E8	350	1110 1000		Y
169	A9	251	1010 1001		z	233	E9	351	1110 1001		Z
170	AA	252	1010 1010			234	EA	352	1110 1010		
171	AB	253	1010 1011			235	EB	353	1110 1011		
172	AC	254	1010 1100			236	EC	354	1110 1100		∂
173	AD	255	1010 1101			237	ED	355	1110 1101		
174	AE	256	1010 1110			238	EE	356	1110 1110		
175	AF	257	1010 1111			239	EF	357	1110 1111		
176	B0	260	1011 0000			240	F0	360	1111 0000		0
177	B1	261	1011 0001			241	F1	361	1111 0001		1
178	B2	262	1011 0010			242	F2	362	1111 0010		2
179	B3	263	1011 0011			243	F3	363	1111 0011		3
180	B4	264	1011 0100			244	F4	364	1111 0100		4
181	B5	265	1011 0101			245	F5	365	1111 0101		5
182	B6	266	1011 0110			246	F6	366	1111 0110		6
183	B7	267	1011 0111			247	F7	367	1111 0111		7
184	B8	270	1011 1000			248	F8	370	1111 1000		8
185	B9	271	1011 1001			249	F9	371	1111 1001		9
186	BA	272	1011 1010			250	FA	372	1111 1010		∫
187	BB	273	1011 1011			251	FB	373	1111 1011		
188	BC	274	1011 1100			252	FC	374	1111 1100		
189	BD	275	1011 1101			253	FD	375	1111 1101		
190	BE	276	1011 1110			254	FE	376	1111 1110		
191	BF	277	1011 1111			255	FF	377	1111 1111		EO

See Also: 1.21. ASCII Character Set

## 1.26. DIGIT POSITIONS IN COMMON BASES

*Digit Position Value*

Base	Name	6th Pos.	5th Pos.	4th Pos.	3rd Pos.	2nd Pos.	1st Pos.
2	binary	32	16	8	4	2	1
8	octal	32768	4096	512	64	8	1
10	decimal	100000	10000	1000	100	10	1
16	hexadecimal	1048576	65536	4096	256	16	1

**Notes:** The first digit position is the least significant

**See Also:** 1.11. Decimal to Binary Number Conversion  
1.12. Decimal to Hexadecimal Number Conversion  
1.13. Decimal to Octal Number Conversion

## 1.27. POWERS OF TWO

Power	Value	Common Definitions and Usage
2 <sup>1</sup>	2	(1 bit may have 2 possible values) (2 bytes = word)
2 <sup>2</sup>	4	(4 bits = nibble, BCD Digit) (4 bytes = double word)
2 <sup>3</sup>	8	(8 bits = byte, ASCII Character)
2 <sup>4</sup>	16	(16 bits = word, Near Address) (16 bytes = paragraph)
2 <sup>5</sup>	32	(32 bits = double word, Far Address)
2 <sup>6</sup>	64	
2 <sup>7</sup>	128	
2 <sup>8</sup>	256	(1 byte may have 256 possible values) (256 bytes = page)
2 <sup>9</sup>	512	
2 <sup>10</sup>	1,024	(1,024 bytes = kilobyte)
2 <sup>11</sup>	2,048	
2 <sup>12</sup>	4,096	
2 <sup>13</sup>	8,192	
2 <sup>14</sup>	16,384	
2 <sup>15</sup>	32,768	
2 <sup>16</sup>	65,536	(65,536 bytes = segment)
2 <sup>17</sup>	131,072	
2 <sup>18</sup>	262,144	
2 <sup>19</sup>	524,288	
2 <sup>20</sup>	1,048,576	(1,048,576 bytes = megabyte)
2 <sup>21</sup>	2,097,152	
2 <sup>22</sup>	4,194,304	
2 <sup>23</sup>	8,388,608	
2 <sup>24</sup>	16,777,216	
2 <sup>25</sup>	33,554,432	

**Notes:** 2<sup>15</sup> means "2 raised to the 15th power"

**See Also:** 1.15. Common 8086 Family Data Formats  
1.18. Common Memory Area Terminology

### 1.28. INTERNATIONAL SORT ORDERING

In ASCII sort ordering, characters are sorted as follows:

-Lower numbered ASCII characters appear before higher numbered ones, thus:

-All uppercase characters appear before lowercase ones

-Characters with diacritical marks come after all other letters

ASCII sort ordering would treat the alphabet like this:

ASCII Code	Character
65	A
66	B
67	C
68	D
69	E
70	F
71	G
72	H
73	I
74	J
75	K
76	L
77	M
78	N
79	O
80	P
81	Q
82	R
83	S
84	T
85	U
86	V
87	W
88	X
89	Y
90	Z
97	a
98	b
99	c
100	d
101	e
102	f
103	g
104	h
105	i
106	j
107	k
108	l
109	m
110	n
111	o
112	p
113	q

ASCII Code	Character
114	r
115	s
116	t
117	u
118	v
119	w
120	x
121	y
122	z
128	Ç
129	ü
130	é
131	â
132	ä
133	à
134	á
135	ç
136	ê
137	ë
138	è
139	ì
140	î
141	ï
142	À
143	Á
144	É
145	æ
146	Æ
147	ô
148	ö
149	ò
150	ù
151	û
152	ÿ
153	Ö
154	Ü
160	á
161	í
162	ó
163	ú
164	ñ
165	Ñ
225	ß

Table 1.28. Continued

In International sort ordering, ASCII sort order is changed, as follows:  
 -Characters are sorted by alphabetical position: A and a are equal and come before B  
 -Characters with diacritical marks are expanded accordingly: umlauted a becomes ae for sort ordering, ß becomes ss, etc.  
 -Lowercase characters are applied first, for example, deJesus appears before DeJesus  
 -Norwegian, Danish, Swedish, and Finnish å, Å and umlauted characters are placed at the end of the regular alphabet for those countries  
 International sort ordering would treat the alphabet like this:

ASCII Code	Character
97	a
132	ä
160	á
133	à
131	â
65	A
142	Å
98	b
66	B
99	c
135	ç
67	C
128	Ç
100	d
68	D
101	e
137	ë
130	é
138	è
136	ê
69	E
144	É
102	f
70	F
103	g
71	G
104	h
72	H
105	i

ASCII Code	Character
139	ï
161	í
141	ì
140	î
73	I
106	j
74	J
107	k
75	K
108	l
76	L
109	m
77	M
110	n
164	ñ
78	N
165	Ñ
111	o
148	ö
162	ó
149	ô
147	õ
79	O
153	Ö
112	p
80	P
113	q
81	Q
114	r

ASCII Code	Character
82	R
115	s
225	ß
83	S
116	t
84	T
117	u
129	ü
163	ú
151	û
150	ù
85	U
154	Ü
118	v
86	V
119	w
87	W
120	x
88	X
121	y
152	ÿ
89	Y
122	z
90	Z
134	å
143	Ä
145	æ
146	Æ

Source: Paradox 2.0 User's Guide, pages 519 to 521

## 1.29. TRUTH TABLES FOR LOGICAL OPERATIONS

**AND**

Condition 1	Condition 2	Result
TRUE	TRUE	TRUE
TRUE	FALSE	FALSE
FALSE	TRUE	FALSE
FALSE	FALSE	FALSE

**OR**

Condition 1	Condition 2	Result
TRUE	TRUE	TRUE
TRUE	FALSE	TRUE
FALSE	TRUE	TRUE
FALSE	FALSE	FALSE

**EXCLUSIVE OR**

Condition 1	Condition 2	Result
TRUE	TRUE	FALSE
TRUE	FALSE	TRUE
FALSE	TRUE	TRUE
FALSE	FALSE	FALSE

**EXCLUSIVE AND**

Condition 1	Condition 2	Result
TRUE	TRUE	FALSE
TRUE	FALSE	TRUE
FALSE	TRUE	TRUE
FALSE	FALSE	TRUE

**NOT**

Condition	Result
TRUE	FALSE
FALSE	TRUE

**Notes:** The resulting value is read by finding a row in which the conditions you are looking up are met and by reading the result in the right-most column of that row

— PART —

**II**

SOFTWARE

---



— SECTION —

# 2

DOS Commands,  
Utilities, and  
Summaries

---

2.01. DOS COMMAND SUMMARY

Command Syntax	Function	Example	Comments
APPEND d:\path\ [d:\path...]	Locates files outside current directory	APPEND c:\files	See 2.02. APPEND Parameters
ASSIGN [A-Y: ]	Routes disk I/O to another drive	ASSIGN a=c-b-c	
ATTRIB [pams] [d:\path\filespec\pams]	Modifies file attributes	ATTRIB -r myfile.doc /s	See 2.03. ATTRIB Parameters
BACKUP [d:\path\filespec d:\pams]	Backs up one disk to another	BACKUP c:\*.* /s/f	See 2.04. BACKUP Parameters
BREAK [ON/OFF]	Defines status of control break	BREAK ON	Must execute NLSFUNC first
CHCP [number]	Selects code page DOS uses	CHCP 850	May be abbreviated to CD
CHDIR [d:\path]	Sets or displays current path	CD c:\wp\word\data	See 2.05. CHKDSK Parameters
CHKDSK [d:\path\filespec\pams]	Analyzes disk and FAT	CHKDSK c:/f	
CLS	Clears display screen	CLS	
COMMAND [d:\path\pams]	Starts a secondary command processor	COMMAND c:\ut /p	See 2.06. COMMAND Parameters
COMP [d:\path\filespec\ [d:\path\filespec]	Compares contents of files	COMP "BAT A" "BAT	
COPY [pams] [d:\path\filespec\pams] [d:\path\filespec\pams]	Copies a file or set of files	COPY *.* c:	See 2.07. COPY Parameters
CTTY device name	Changes stdin and stdout to auxiliary console	CTTY COM1	
DATE [date]	Enteres, changes, or displays date	DATE 1-12-87	
DEL [d:\path\filespec]	Deletes specified file or files	DEL *.bak	See also ERASE below
DIR [d:\path\filespec\pams]	Lists directory entries	DIR c:\w	See 2.08. DIR Parameters
DISKCOMP [d:\pams]	Compares contents of two disks	DISKCOMP a: b:	See 2.09. DISKCOMP Parameters
DISKCOPY [d:\pams]	Copies a disk	DISKCOPY a: b:	See 2.10. DISKCOPY Parameters
ERASE [d:\path\filespec]	Deletes specified file or files	ERASE *.bak	See also DEL above
FASTOPEN [d:=number]	Stores location of opened files in memory	FASTOPEN c:=100	
FDISK	Creates, changes, or displays DOS partitions	FDISK	
FIND [pams] "string" [d:\path\filespec. ]	Finds lines in files with matching "string"	FIND /N "Trom" c:\m\file.dat	See 2.11. FIND Parameters
FORMAT [d:\pams]	Formats disk for use	FORMAT a: s	See 2.12. FORMAT Parameters
GRAFTABL [437/860/863/865] (STATUS)	Loads additional character data into memory	GRAFTABLE 437	See 2.13. GRAFTABL Parameters
GRAPHICS printer\pams]	Sets system to print graphic displays	GRAPHICS COLOR /R	
JOIN or JOIN [d:\device] or JOIN d: /D	Logically connects drives	JOIN b: /d	See 2.14. GRAPHICS Parameters
KEYB [x] [y] [z] [d:\path\filespec]]	Loads keyboard driver or replace BIOS routines	KEYBUK	
LABEL [d:\label]	Creates, changes, or displays volume label	LABEL c:\romboot	May be abbreviated to MD
MDIR [d:\path]	Creates subdirectory	MDIR c:\ss\excd\data	See 2.15. MDIR Parameters
MODE [LPT#] [d:\m] [d]	Sets printer specifications	MODE lpt1:132:8:p	See 2.15. MDIR Parameters
MODE n	Sets video display mode	MODE 80,71	See 2.15. MDIR Parameters
MODE [d:\m] [T]	Sets video display mode	MODE lpt1:=com1	See 2.15. MDIR Parameters
MODE COM# [baud] [parity] [data bits] [stop bits] [P]]]]	Sets serial port specifications	MODE lpt1: cp prep=(850,863)4201.cpl	See 2.15. MDIR Parameters
MODE device CODEPAGE PREPARE=(cp) [d:\path\filespec]	Prepares code pages	MODE lpt1: cp prep=(850,863)4201.cpl	See 2.15. MDIR Parameters
MODE device CODEPAGE SELECT=cp	Selects or activates code pages	MODE lpt1: cp select=863	See 2.15. MDIR Parameters
MODE device CODEPAGE /STATUS	Displays active code page	MODE lpt1: cp	See 2.15. MDIR Parameters
MODE device CODEPAGE REFRESH	Refreshes a code page	MODE lpt1: cp refresh	See 2.15. MDIR Parameters
MORE	Reads data from stdin, sends paged to stdout	MORE -screen.doc	
NLSFUNC [d:\path\filespec]	Provides extended country support	NLSFUNC c:\ut\country.sys	
PATH [d:\path] [d:\path]]	Sets search path for commands	PATH c:\c:\uc\idos	
PRINT [pams] [d:\path\filespec...]	Puts selected files in print queue	PRINT c:\*.asm	See 2.16. PRINT Parameters
PROMPT [prompt]	Sets new DOS prompt	PROMPT \$p\$g	See 2.17. PROMPT Special Characters
RECOVER [d:\path\filespec or RECOVER d:	Recovers files from defective disk	RENAME b:\rom	May be abbreviated to REN
RENAME [d:\path\filespec filespec2	Renames a file	REPLACE a:\*.doc c:\*.f/s/p	See 2.20. REPLACE Parameters
REPLACE [d:\path\filespec [d:\path\pams]	Selectively replaces matching files on target	RESTORE a: c:\*.* /s	See 2.21. RESTORE Parameters
RESTORE d: [d:\path\filespec\pams]	Restores backed up files to disk	RD c:\values\123	May be abbreviated to RD
RMDIR [d:\path]	Deletes a subdirectory from disk	RD c:\values\123	
SELECT [A B C ... path] xxx yy	Installs DOS on new disk	SELECT a: 001	
SET [name=value]	Installs string with value in environment	SET sidekickin = YES	
SHARE [pams]	Loads file sharing support	SHARE /F:4048	See 2.22. SHARE Parameters
SORT [pams]	Sorts data read from stdin, sends to stdout	dir /SORT /+14	See 2.23. SORT Parameters
SUBST d: d:\path or SUBST d: /D or SUBST	Sets up different drive specifier for drive or path	SUBST a: c:\wp\lws	
SYS d:	Copies DOS onto disk	SYS a:	
TIME [time]	Shows changes, or displays time	TIME 15:10	
TREE [d:\f]	Displays directory paths	TREE c:/f	

(Continued)

Table 2.01. Continued

Command Syntax	Function	Example	Comments
TYPE [d:]path\filespec	Displays contents of file on stdout	TYPE myfile.asm	
VER	Displays DOS version number	VER	
VERIFY[ON OFF]	Sets verify after write setting	VERIFY OFF	
VOL [d:]	Displays volume label	VOL c:	
XCOPY [d:]path\filespec [d:]path\filespec [/parms]	Selectively copies groups of files to disk	XCOPY *.dat c:/E/S	See 2.24. XCOPY Parameters
XCOPY [d:]path\filespec [d:]path\filespec [/parms]	Selectively copies groups of files to disk	XCOPY \wp c:\wp\wp	See 2.24. XCOPY Parameters
XCOPY [d:]path\filespec [d:]path\filespec [/parms]	Selectively copies groups of files to disk	XCOPY c:\a\copy /S	See 2.24. XCOPY Parameters

**Notes:**  
 \*Some of the above commands may not be in all versions of DOS (See 2.47. Included Command Files Summary)  
 \*IBM syntax specifications are followed except this table uses "filespec" for "filename\ext"

**Source:** IBM DOS 3.3 Reference, section 7  
**See Also:** 2.25. Editing Command Lines  
 2.26. Batch File Commands and Default Settings  
 2.27. CONFIG.SYS Commands and Default Settings

**2.02. APPEND PARAMETERS**

**APPEND general command form:** APPEND d:path[:d:]path... | or APPEND [X|J|E]

Parameter	Function	Comments
/X	Processes SEARCH FIRST, FIND FIRST, and EXEC functions	
/E	Keeps APPEND paths in the DOS environment	must issue APPEND ; before using BACKUP or RESTORE!

**Version Info:** Applies to all versions of DOS beginning with 3.3

**Notes:**  
 •Parameters may be used only on the first invocation of APPEND in each session  
 •Each subsequent APPEND command takes the place of the previous one

**Source:** IBM DOS 3.3 Reference, pages 7-13 to 7-17

**See Also:** The description of PATH in the IBM DOS 3.3 Reference

### 2.03. ATTRIB PARAMETERS

**ATTRIB general command form: ATTRIB [+R|-R][+A|-A][filespec]/S]**

Parameter	Function	Comments
+R	Set read-only attribute for file	
-R	Set read/write attribute for file (normal file)	Default state
+A	Set archive attribute bit for file	Means file needs to be backed up
-A	Cancel archive attribute bit for file	
/S	Process files in the specified directory and all its subdirectories	

**Version Info:** Attrb has been enhanced with each minor release of DOS:  
 Version 3.0 supports +R and -R only  
 Version 3.2 supports +R, -R, +A, -A  
 Version 3.3 supports all listed parameters

**Notes:** The archive attribute bit is cleared by BACKUP and RESTORE (and most backup programs)

**Source:** IBM DOS 3.3 Reference, pages 7-22 to 7-24

### 2.04. BACKUP PARAMETERS

**BACKUP general command form: BACKUP d:[path][sourcefilespec] d: [parameters]**

Parameter	Function	Comments
/A	Add files to those already present on backup disk	
/D:mm-dd-yy	Back up only files modified on or after date specified	Date specified in format consistent with country code
/F	Format target disk if it is not already formatted*	
/L[filespec]	Create log file naming disk number of each file backed up	If no name specified, uses BACKUP.LOG in root directory
/M	Back up only files modified since last backup	i.e., files with Archive attribute bit set
/S	Back up files in the specified directory and all its subdirectories	
/T:hh:mm:ss	Back up only files modified on or after time specified	Time specified in format consistent with country code

**Version Info:** \*Applies to all versions of DOS beginning with 2.0  
 \*\*Added beginning with DOS 3.0

**Notes:** The archive attribute bit is cleared by BACKUP for files that are backed up

**Source:** IBM DOS 3.3 Reference, pages 7-25 to 7-30

**See Also:** 2.21. RESTORE Parameters

### 2.05. CHKDSK PARAMETERS

**CHKDSK general command form: CHKDSK [d:][path][filespec][parameters]**

Parameter	Function	Comments
/F	Fix errors found in directory or FAT	Lost allocation units are stored in files named FILE####.CHK
/V	Display all files and paths found on drive	

**Notes:** CHKDSK filespec with no parameters checks for file fragmentation

**Source:** IBM DOS 3.3 Reference, pages 7-63 to 7-66

### 2.06. COMMAND PARAMETERS

**COMMAND general command form: COMMAND [d:][path][parameters]**

Parameter	Function	Comments
/Cstring	Passes string to the new command processor	
/E:#	Sets size of the environment	Must be in range 160 to 32768 in bytes*
/P	Makes command processor permanent in memory	Must restart DOS to remove command processor

**Notes:** \*Unless /P parameter used, command processor is unloaded by typing EXIT  
 \*Earlier versions (3.0, for example) express this number in paragraphs

**Source:** IBM DOS 3.3 Reference, pages 7-68 to 7-69

**2.07. COPY PARAMETERS**

**COPY general command form:** *COPY [/A]/[B]filespec1[/A]/[B] [filespec2][parameters]*

Parameter	Function	Comments
/A	Treats file as ASCII text	For source file: copies up to first 1AH; for dest: adds 1AH to end
/B	Treats file as binary file (based on size in directory)	For source file: copies entire file; for dest: does not add 1AH
/V	Turns verify check ON during copy operation	Verify may already be set to ON by DOS

**Notes:** /A and /B may be used prior to source or dest filespec, or at end of command

**Source:** IBM DOS 3.3 Reference, pages 7-75 to 7-85

**See Also:** 2.24. XCOPY Parameters

**2.08. DIR PARAMETERS**

**DIR general command form:** *DIR [d:][path][filespec][parameters]*

Parameter	Function	Comments
/P	Pause when screen is full	General 23 lines; any key displays next page of directory
/W	Display names only in wide format	

**Source:** IBM DOS 3.3 Reference, pages 7-94 to 7-98

**2.09. DISKCOMP PARAMETERS**

**DISKCOMP general command form:** *DISKCOMP [d:d:][parameter]*

Parameter	Function	Comments
/1	Compare only first side of disk	
/8	Compare only first 8 sectors/track	Applies even if disk is formatted 9 sectors/track

**Source:** IBM DOS 3.3 Reference, pages 7-99 to 7-104

**2.10. DISKCOPY PARAMETERS**

**DISKCOPY general command form:** *DISKCOPY [d: [d:]][/1]*

Parameter	Function	Comments
/1	Copy only first side of disk	

**Source:** IBM DOS 3.3 Reference, pages 7-105 to 7-111

**See Also:** 2.07. COPY Parameters  
2.24. XCOPY Parameters

**2.11. FIND PARAMETERS**

**FIND general command form:** *FIND [parameters] "string" [d:][path]filespec...*

Parameter	Function	Comments
/C	Display number of lines containing "string"	
/N	Display relative line number of each match	Ignored if /C is also specified
/V	Display all lines NOT containing "string"	

**Notes:**

- File is searched only until first end-of-file marker (1AH byte)
- Double quotes (") are required around string
- FIND is case sensitive; "B" does not match "b"

**Source:** IBM DOS 3.3 Reference, pages 7-120 to 7-122

**2.12. FORMAT PARAMETERS**

**FORMAT general command form: *FORMAT d:[parameters]***

<i>Parameter</i>	<i>Function</i>	<i>Comments</i>
/1	Format disk for single-sided use	Only for 5.25 inch disks
/4	Format 360 KB disk in 1.2 MB drive	Disk reliable only for use with 1.2 MB drives
/8	Format 8 sectors per track	Only for floppy drives
/B	Format 8 sectors/track, space for DOS	
/N:#	Format # sectors/track	Must be used with /T; must be less than maximum for disk
/S	Copy operating system files to formatted disk	DOS copied from default drive; makes disk "bootable"
/T:#	Format # tracks on disk	Must be used with /N; must be less than maximum for disk
/V	Request volume name for disk after format	

**Source:** IBM DOS 3.3 Reference, pages 7-123 to 7-132

**2.13. GRAFTABL PARAMETERS**

**GRAFTABL general command form: *GRAFTABL [parameters]***

<i>Parameter</i>	<i>Function</i>	<i>Comments</i>
437	Use United States character data	Default value
860	Use Portugal character data	
863	Use French Canadian character data	
865	Use Norwegian and Danish character data	
/STATUS	Display number of selected code page	

**Version Info:** Parameters were added beginning with DOS 3.3

**Notes:** GRAFTABL returns errorlevel values as follows:  
 0 = no previously defined char table; code page already resident  
 1 = previously loaded table exists; new table replaced old  
 2 = no previously loaded char table exists; no new table was loaded  
 3 = unrecognized parameter  
 4 = incorrect DOS version (3.3 required)

**Source:** IBM DOS 3.3 Reference, pages 7-133 to 7-134

**See Also:** 3.146. Code Page Parameter Blocks  
 3.147. Code Page Assignments

**2.14. GRAPHICS PARAMETERS**

**GRAPHICS general command form: *GRAPHICS [parameters]***

<i>Parameter</i>	<i>Function</i>	<i>Comments</i>
printer <sub>type</sub>	Specifies type of printer being used	COLOR1 = IBM Color printer; black ribbon; uses four shades of grey COLOR4 = IBM Color printer; RGB ribbon; prints using red, green, blue, black COLOR8 = IBM Color printer; CMY ribbon; prints using black, cyan, mag.,yellow COMPACT = IBM Compact printer; prints black and white only GRAPHICS = IBM Graphics or Proprinter; prints black and white only (default) THERMAL = IBM Convertible printer; prints black and white only*
/B	Print background color	Applicable to COLOR4 and COLOR8 types only
/LCD*	Print as displayed on LCD display	Applicable to IBM Convertible computer only
/R	Print as displayed on monitor	Default is to print white pixels as black, and to not print black pixels

**Version Info:** \*Parameter was added beginning with DOS 3.3

**Source:** IBM DOS 3.3 Reference, pages 7-135 to 7-137

**See Also:** 7.48. IBM Printer Control Codes

2.15. MODE PARAMETERS

**Using MODE to Switch Display Modes:**

Parameter	Function	Comments
40	Set display width to 40 characters	CGA, PCJr, and EGA only
80	Set display width to 80 characters	CGA, PCJr, and EGA only (default)
BW40	Set display width to 40 chars on CGA; disable color	CGA, PCJr, and EGA only
BW80	Set display width to 80 chars on CGA; disable color	CGA, PCJr, and EGA only
CO40	Set display width to 40 chars on CGA; enable color	CGA, PCJr, and EGA only
CO80	Set display width to 80 chars on CGA; enable color	CGA, PCJr, and EGA only
MONO	Set display to MDA	MDA only
R	Shift display slightly to right	CGA, PCJr, and EGA only
L	Shift display slightly to left	CGA, PCJr, and EGA only
T	Display test pattern	CGA, PCJr, and EGA only

**General Form:** MODE displaywidth [, [shiftparm][. T]]

**Examples:** MODE BW40 Sets CGA to 40 column width, disables color  
 MODE CO80,R,T Sets CGA to 80 column width, enables color, shifts display right 2 chars, shows test pattern  
 MODE .L,T Shifts display left 1 or 2 chars, shows test pattern

**Using MODE to Set Printer:**

Parameter	Function	Comments
n	Set page print width	Must be 80 or 132 only (default=80)
m	Set vertical spacing	Must be 6 or 8 only (default=6)
P	Set continuous retry on time-out errors	

**General Form:** MODE LPT#[:][n][.][m][.P]]

**Examples:** MODE LPT1:132,8,P Sets 132 column page width, 8 lines per inch, and continuous retry  
 MODE LPT2:.,P Leaves page width and lines per inch intact, sets continuous retry  
 MODE LPT1 .8 Sets 8 line per inch, page width left intact, no continuous retry

**Using MODE to Set Async Port:**

Parameter	Function	Comments
baud	Set baud rate for communications	Must be 110,150,300,600,1200,2400,4800,9600, or 19200; default=1200
parity	Set parity type for transmissions	Must be one of N (none), O (odd), or E (even); default=E
databits	Set number of databits per byte transmitted	Must be either 7 or 8; default=7
stopbits	Set number of bits between transmitted bytes	Must be either 1 or 2; default=2 for 110, 1 for all other baud rates)
P	Set continuous retry on time-out errors	

**General Form:** MODE COM#[:]baud[, [parity][. [databits][. [stopbits][. P]]]]

**Examples:** MODE COM1:1200,e,7,1,p (default setting plus continuous retry on timeouts)  
 MODE COM1:.,7,p Resets databits to 7 (others left unchanged) and sets continuous retries  
 MODE COM1 19200,.,2 Resets baud to 19200, stopbits to 2 (others left unchanged), no retries

**Using Mode to Redirect Output:**

**General Form:** MODE LPT#[:] =COM#

**Examples:** MODE LPT1:=COM2 Redirects printer output to COM2  
 MODE LPT1=COM1 Redirects printer output to COM1

(Continued)

Table 2.15. Continued

**Using MODE to prepare Code Page:**

Parameter	Function	Comments
device	Set device for code page use	Must be one of CON, PRN, LPT1, LPT2, or LPT3
cp	Set code page number	May be a list in parentheses; must be 437, 850, 860, 863, or 865

**General Form:** MODE device CODEPAGE PREPARE = ((cp)[d:][path]filespec)

**Examples:** MODE LPT1 CODEPAGE PREPARE = (437)4201.CPI Prepares US code page for IBM Proprinter  
 MODE LPT1 CP PREP = (437)4201.CPI Same, only uses abbreviations for CODEPAGE PREPARE

**Using MODE to Select Code Page:**

Parameter	Function	Comments
device	Set device for code page use	Must be one of CON, PRN, LPT1, LPT2, or LPT3
cp	Set code page number	Must be one of 437, 850, 860, 863, or 865

**General Form:** MODE device CODEPAGE SELECT = cp

**Examples:** MODE LPT1 CODEPAGE SELECT = 437 Selects US code page for use  
 MODE LPT1 CP SELECT = 437 Same, only uses abbreviation for CODEPAGE

**Using MODE to Identify Code Page:**

Parameter	Function	Comments
device	Set device for code page use	Must be one of CON, PRN, LPT1, LPT2, or LPT3
/STATUS	Display status for code pages	

**General Form:** MODE device CODEPAGE [/STATUS]

**Examples:** MODE LPT1 CODEPAGE Identifies current code page  
 MODE LPT1 CP /STATUS Same, only uses abbreviation and shows status of all code page possibilities

**Using MODE to Refresh a Code Page:**

Parameter	Function	Comments
device	Set device for code page use	Must be one of CON, PRN, LPT1, LPT2, or LPT3

**General Form:** MODE device CODEPAGE REFRESH

**Examples:** MODE LPT1 CODEPAGE REFRESH Reestablishes active code page for LPT1  
 MODE LPT1 CP REFRESH Same, only uses abbreviation

**Version Info:** Code page options apply to DOS 3.3 only

**Source:** IBM DOS 3.3 Reference, pages 7-153 to 7-164

**See Also:** 3.146. Code Page Parameter Blocks  
 3.147. Code Page Assignments

2.16. PRINT PARAMETERS

**PRINT general command form:** PRINT [parameters][d:][path][filespec...]

Parameter	Function	Comments
/B:buffersize*	Sets size of internal print buffer to buffersize; in bytes	Default is 512
/C	Cancels list of files from print queue	
/D:device*	Specifies print device to use	Default is PRN; if used, must be first parameter
/M:maxtick*	Sets number of clock ticks print device gets	Default is 2; range is from 1 to 255
/P	Sets print mode	
/Q:queue size*	Sets number of files that can be in queue at once	Default is 10; range is from 1 to 32
/S:timeslice*	Specifies time slice value	Default is 8; range is from 1 to 255
/T	Cancels all queued files; printing stops	
/U:busytick*	Sets number of clock ticks to wait for print device availability	Sounds printer's alarm, prints cancellation message if file being printed Default is 1

**Version Info:** PRINT added to DOS beginning with version 2.0

**Notes:** \*Can only be specified the first time PRINT is used

**Source:** IBM DOS 3.3 Reference, pages 7-171 to 7-176

## 2.17. PROMPT SPECIAL CHARACTERS

Character	Displays As	Example	Example Displays As
\$b	Vertical slash ( ) ASCII 124	\$p\$b	C:\MYDIR
\$d	Current system date	\$d \$n\$g	Mon 9-5-1986 C>
\$e	Escape character ASCII 27	See 2.18. PROMPT ANSI Control Strings	
\$g	Greater than sign (>) ASCII 62	\$p\$g	C:\MYDIR>
\$h	Destructive backspace ASCII 8	\$t\$h\$h\$h \$p\$g	09:30:26 C:\MYDIR>
\$l	Less than sign (<) ASCII 60	\$l\$n\$g	<C>
\$n	Current drive letter	Drive is \$n\$g	Drive is C>
\$p	Current pathname directory	Path is \$p\$g	Path is C:\MYDIR>
\$q	Equals sign (=) ASCII 61	Drive \$q \$n\$g	Drive = C>
\$t	Current system time	Time is \$t	Time is 09:30:25.93
\$v	DOS version number	\$v	IBM Personal Computer DOS Version 3.20
\$_	Carriage return/line feed ASCII 13,10	\$t\$h\$h\$h\$h\$_\$p\$g	9:30:25 C:\MYDIR>
\$\$	Dollar sign (\$) ASCII 36	Time is \$\$g	Time is \$>
Any other	Treated as character typed	This is a prompt	This is a prompt

**Version Info:** Applies to all versions of DOS beginning with version 2.0

**Notes:** Examples assume that the current system date is September 5, 1986, the current time is 9:30:26, and the current logged drive and directory are C:\MYDIR

**Source:** IBM DOS 3.3 Reference, page 7-177

**See Also:** 2.18. PROMPT ANSI Control Strings  
2.19. PROMPT ANSI Display Attribute Strings

## 2.18. PROMPT ANSI CONTROL STRINGS

String	Function
\$e[ #;#f \$e[ =# h	Moves to row (first number), column (second #) Sets display mode according to number (#): 0 = 40x25 monochrome 1 = 40x25 color 2 = 80x25 monochrome 3 = 80x25 color 4 = 320x200 color graphics 5 = 320x200 monochrome graphics 6 = 640x200 monochrome graphics 7 = wrap at end of line
\$e[ #;#j	Moves cursor to line (first #) and row (second #) position
\$e[ K	Clears line from cursor to end of line
\$e[ =# l	Resets display mode according to number (#): 0 = 40x25 monochrome 1 = 40x25 color 2 = 80x25 monochrome 3 = 80x25 color 4 = 320x200 color graphics 5 = 320x200 monochrome graphics 6 = 640x200 monochrome graphics 7 = wrap at end of line
\$e[ #;...;#m	Sets display attributes (see 2.19. PROMPT ANSI Display Attribute Strings)
\$e[ #;#p	Reassigns first key (first #) to second (second #) or remap key (first#) to ASCII string
\$e[ s	Saves current cursor position
\$e[ u	Restores cursor to saved position
\$e' #A	Moves cursor up number of rows indicated by # (ignored if cursor on top line)
\$e' #B	Moves cursor down number of rows indicated by # (ignored if cursor on bottom line)
\$e' #C	Moves cursor right number of columns indicated by # (ignored if cursor in last column)
\$e' #D	Moves cursor left number of columns indicated by # (ignored if cursor in first column)
\$e' H	Moves cursor to the Home position (row 1, column 1)
\$e' #;#H	Moves cursor to row (first #) and column (second #) position
\$e' 2J	Clears display screen (see also \$e' #;#f)
\$e' K	Erases from cursor to end of line, including cursor position
\$e' #;#R	Reports cursor position through standard input
Esc [6n	Console driver outputs cursor position report sequence (cannot be used as part of prompt)

**Version Info:** Applies to all versions of DOS beginning with version 2.0

**Notes:** There should be no spaces shown in the ANSI control strings shown

**Source:** IBM DOS 3.3 Technical Reference, pages 3-1 to 3-20

**See Also:** 2.17. PROMPT Special Characters  
2.19. PROMPT ANSI Display Attribute Strings

**2.19. PROMPT ANSI DISPLAY ATTRIBUTE STRINGS**

String	Sets Display Attributes to	Video Adapter			
		MDA	CGA	EGA	VGA
\$ef 0 m	Normal text	X	X	X	X
\$ef 1 m	Bright text (intensity bit set)	X	X	X	X
\$ef 4 m	Underscored text	X			
\$ef 5 m	Blinking text	X			
\$ef 7 m	Reversed text	X	X	X	X
\$ef 8 m	Canceled (invisible) text	X			
\$ef 30 m	Black text		X	X	X
\$ef 31 m	Red text		X	X	X
\$ef 32 m	Green text		X	X	X
\$ef 33 m	Yellow text		X	X	X
\$ef 34 m	Blue text		X	X	X
\$ef 35 m	Magenta text		X	X	X
\$ef 36 m	Cyan text		X	X	X
\$ef 37 m	White text		X	X	X
\$ef 40 m	Black background		X	X	X
\$ef 41 m	Red background		X	X	X
\$ef 42 m	Green background		X	X	X
\$ef 43 m	Yellow background		X	X	X
\$ef 44 m	Blue background		X	X	X
\$ef 45 m	Magenta background		X	X	X
\$ef 46 m	Cyan background		X	X	X
\$ef 47 m	White background		X	X	X

**Version Info:** Applies to all versions of DOS beginning with version 2.0

**Source:** IBM DOS 3.3 Technical Reference, page 3-15

**See Also:** 2.17. PROMPT Special Characters  
2.18. PROMPT ANSI Control Strings

**2.20. REPLACE PARAMETERS**

**REPLACE general command form:** *REPLACE [d:][path]filespec[d:][path][parameters]*

Parameter	Function	Comments
/A	Copies all files in source that do not exist on target	Cannot be used with /S
/P	Prompts when source file also found on target	Copy proceeds only if user presses Y
/R	Replaces files that have read-only attribute bit set on target	
/S	Searches all directories of target for source file match	Cannot be used with /A;
/W	Prompts for disk change before REPLACE continues	

**Version Info:** REPLACE added to DOS beginning with version 3.0

**Notes:** REPLACE sets errorlevel on completion as follows:  
 2 = no source file(s) were found  
 3 = the source or target path was invalid (not found)  
 5 = the access code was incorrect; try repeating command using /R  
 8 = insufficient memory to perform operation  
 11 = invalid parameter or format of REPLACE command  
 15 = invalid drive specified in source or target path  
 22 = incorrect version of DOS being used with REPLACE  
 (For complete error code list see 3.128. Extended Error Codes)

**Source:** IBM DOS 3.3 Reference, pages 7-185 to 7-188

## 2.21. RESTORE PARAMETERS

**RESTORE general command form: RESTORE d: [d:][path]filespec[parameters]**

Parameter	Function	Comments
/A:mm-dd-yy	Restore files modified on or after date mm-dd-yy	Date entered in format appropriate for current country code
/B:mm-dd-yy	Restore files modified on or before date mm-dd-yy	Date entered in format appropriate for current country code
/E:hh:mm	Restore files modified on or before time hh:mm	Time entered in format appropriate for current country code
/L:hh:mm	Restore files modified on or after time hh:mm	Time entered in format appropriate for current country code
/M	Restore files modified or deleted since last backup	
/N	Restore files that no longer exist on target	Should not be used with /B or /A
/P	Prompt for each file to restore	
/S	Restore files to proper subdirectories	

**Version Info:** RESTORE added to DOS beginning with version 2.0

**Notes:** RESTORE sets errorlevel on completion as follows:  
 0 = normal completion; no errors  
 1 = no files were found to restore  
 2 = some files not restored due to sharing conflicts  
 3 = operation terminated due to Ctrl-Break or Esc key pressed by user  
 4 = other error caused termination

**Source:** IBM DOS 3.3 Reference, pages 7-189 to 7-192

**See Also:** 2.04. BACKUP Parameters

## 2.22. SHARE PARAMETERS

**SHARE general command form: SHARE [parameters]**

Parameter	Function	Comments
/F:filesize	Allocates filesize bytes to record sharing info	Default is 2048; must be 25 bytes per shared file
/L:locks	Allocates space for number of locks to maintain	Default is 20

**Version Info:** SHARE added to DOS beginning with version 3.1

**Source:** IBM DOS 3.3 Reference, pages 7-200 to 7-201

## 2.23. SORT PARAMETERS

**SORT general command form: SORT [parameters]**

Parameter	Function	Comments
/R	Sort in reverse order (Z before A)	
/+#	Sort starting with column # specified	Default is column 1

**Version Info:** SORT added to DOS beginning with version 2.0

**Notes:** Sort equates lower and uppercase letters; characters with ASCII values above 127 are sorted according to rules based on current country code.

**Source:** IBM DOS 3.3 Reference, pages 7-202 to 7-203

## 2.24. XCOPY PARAMETERS

**XCOPY general command form:** XCOPY [d:][path][filespec] [d:][path][filespec][parameters]

Parameter	Function	Comments
/A	Copy only files that have archive bit set	Source file archive bit is not changed
/D:mm-dd-yy	Copy files whose date is the same or later than specified	Date is in format appropriate to current country code
/E	Create subdirectories, even if empty, on target	
/M	Copy only files that have archive bit set	Source file archive bit is cleared
/P	Prompt before copying each file	Only files which are responded to by a Y by user are copied
/S	Copy files in directory and all its subdirectories	
/V	Verifies that target disk was recorded correctly	
/W	Causes XCOPY to wait until user presses key to start copying	

**Version Info:** XCOPY added to DOS beginning with version 3.2

**Source:** IBM DOS 3.3 Reference, pages 7-222 to 7-229

## 2.25 EDITING COMMAND LINES

Key	Function
F1	Supplies next character from the command buffer
F2	Supplies all characters from the command buffer up to the next character you type (e.g., [F2][r] is up to r)
F3	Supplies all remaining characters from the command buffer
F4	Skips all characters from the command buffer up to next character typed (e.g., [F4][r] skips to r)
F5	Erases previous command buffer and replaces it with current command line
Esc	Erases current command line
-->	Supplies next character from the command buffer
Ins	Inserts a character at current spot in the command buffer
Del	Deletes the character at the current spot in the command buffer

**Notes:** DOS keeps the last command typed in a buffer, and it is available even after the execution of a program, e.g., BASICA "myprog" runs a BASIC program named "myprog." After the program has finished, the DOS command line buffer still contains BASICA "myprog."

**Source:** IBM DOS 3.3 Reference, page 2-5

## 2.26. BATCH FILE COMMANDS AND DEFAULT SETTINGS

Command	Function	Syntax	Allowable Settings	Default	Example
label	Label (destination of a GOTO statement)	string	Colon followed by any characters		:ENDOFBATCHFILE
@command	Does not echo command on display	@string	Any valid DOS or batch command		@ECHO OFF
%#	Substitutes command line parameter	%number	0-9 (0=command name)		DIR %1.%2
%string%	Substitutes environment variable (SET)	%string%	Any variable created with SET		IF NOT %OKAY% == "DONE" SET OKAY=DONE
CALL	Calls another batch file as a subroutine	CALL filename	Filename may include path		CALL DOINST
ECHO	Sets echo status or displays string	ECHO state, ECHO string	ON, OFF, message string	ON	ECHO This is a message.
FOR	Controls execution of commands	FOR %var IN (set) DO command	%variable name		FOR %file IN (DOS WRITE) DO DEL %file.DAT
GOTO	Branches execution to new location in batch file	GOTO label	Any valid label		GOTO ENDOFBATCHFILE
IF ERRORLEVEL	Controls execution based upon error level	IF ERRORLEVEL number command	0-255		IF ERRORLEVEL 65 GOTO ENDOFBATCHFILE
IF EXIST	Controls execution based upon existence of file	IF EXIST filename command	Any DOS filename		IF EXIST hogan.%1 ERASE hogan.%1
IF s1 == s2	Controls execution based upon string comparison	IF string==string command	Any string or %parameter		IF %1=="hogan" GOTO DEALWITHHOGAN
PAUSE	Pauses execution until key pressed	PAUSE string	Any message string		PAUSE Press a key to continue.
REM	Non-executable remark	REM string	Any message string		REM This won't display if echo is off
SHIFT	Shifts command line parameters down one number	SHIFT	NA		SHIFT

**Version info:**

- \*@ is only available in DOS 3.3

- \*CALL is only available in DOS 3.3

- %string% and SET are not documented in all versions of DOS but appear starting in DOS 2.x

- \*ECHO and REM should be followed by at least one non-space character in DOS 3.x

**Notes:**

- \*Command may be any valid DOS command

**Source:**

- IBM DOS 3.3 Reference, pages 7-31 to 7-55

## 2.27. CONFIG.SYS COMMANDS AND DEFAULT SETTINGS

Command	Allowable Settings	Default Settings	Example
AVAILDEV=state	TRUE,FALSE	TRUE	AVAILDEV=FALSE
BREAK=state	OFF,ON	OFF	BREAK=ON
BUFFERS=#	1-99	2 (XT), 3 (AT)*	BUFFERS=20
COUNTRY=#	See 3.144. Country Codes	001	COUNTRY=044
COUNTRY=#,#,filename	Country code, code page, file containing country info	001,437,\country.sys	COUNTRY=044,850,c:\dos\country.sys
DEVICE=name	Any DOS path and file name	None	DEVICE=DRIVER.SYS
DRIVPARM	See 2.28. DRIVPARM and DRIVER.SYS Parameter Settings	/F:0 /T:80 /H:2 /S:9	DRIVPARM /D:1 /F:1
FCBS=#,#	1-255, 0-255 (first number must be >= second)	4,0	FCBS=20,20
FILES=#	8-255	8	FILES=20
LASTDRIVE=letter	A-Z	E	LASTDRIVE=H
SHELL=name	Any DOS pathname	SHELL=COMMAND.COM	SHELL=C:\DOS\COMMAND.COM
STACKS=#,#	8-64, 32-512 (0,0=no dynamic stacks)	9,128	STACKS=12,256
SWITCHAR=char	Any character	\	SWITCHAR=/

**Version Info:**

- \*For DOS 2.0-3.2. Beginning with DOS 3.3, if RAM >128K, BUFFERS=5; if RAM >256K, BUFFERS=10; if RAM >512K, BUFFERS=15.
- AVAILDEV and SWITCHAR are undocumented, and work only in DOS version 2.x
- COUNTRY, FCBS, and LASTDRIVE are available only in DOS 3.0 and later
- STACKS is available only in DOS 3.2 and later
- DRIVPARM available only in DOS 3.2

**Source:** IBM DOS 3.3 Reference, pages 4-1 to 4-44

**See Also:** 2.28. DRIVPARM and DRIVER.SYS Parameter Settings  
3.144. Country Codes

## 2.28. DRIVPARM AND DRIVER.SYS PARAMETER SETTINGS

Parameter	Function	Allowable Settings	Default
/C	Changeline support required	None	None
/D:#	Drive number	0-255 (A=0, B=1, etc.)*	None
/F:#	Form factor	0=160/180K or 320/360K floppy 1=1.2M floppy (AT) 2=720K microfloppy (3.5") 7=1.4MB microfloppy (3.5")	2
/H:#	Max # of heads	1-99	2
/N	Nonremovable media	None	None
/S:#	Sectors per track	1-99	9
/T:#	Tracks per side	1-999	80

**Version Info:**

- DRIVER:SYS information applies to all versions of DOS beginning with version 3.0 (DRIVPARM version 3.2 only)
- DRIVPARM information applies to all versions of DOS beginning with version 3.2

**Notes:** \*2-127 reference external floppy drives; 128-255 reference fixed drives

**Source:** IBM DOS 3.3 Reference, pages 4-21 to 4-27

**See Also:** 2.27. CONFIG.SYS Commands and Default Settings

2.29. DEBUG COMMAND SUMMARY

Command Syntax	Function	Example	Example Explanation	Comments
A	Assemble statements into memory immediately following last assembly entry	A	Assemble statements at current pointer	Entry continues until ENTER pressed at start of line
A address	Assemble statements into memory beginning at address	A 100	Assemble statements at 100H	Entry continues until ENTER pressed at start of line
C range address	Compare two blocks of memory	C 100 L20 200	Compare 32 bytes at 100H to 32 bytes at 200H	
D	Dump (display) contents of memory starting at last position displayed	D	Display memory at current pointer	
D address	Dump (display) contents of memory starting at address	D 208	Display 600H bytes of memory	
D range	Dump (display) contents of memory of entire range specified	D 100 L600	Enter data beginning at 50H in Data Segment	Entry continues until ENTER pressed. SPACE skips entry for a byte
E address	Enter hex bytes of data beginning at address specified	E DS:50	Enter two spaces at 100 H in current segment	Extra items in list that would fill beyond end of range are ignored
E address list	Enter list of bytes beginning at address specified	F DS:00 L0F "TEH"	Enter five repetitions of TEH at start of Data Seg.	
F range list	Fill memory range with sequence of bytes in list	G	Execute instructions at CS:IP	
G	G (begins execution) at current instruction (CS:IP)	G	Start execution at 0100H in current CS	
G address	Go (begins execution) at address	G = 100	Same as above, but break if 10AH or 213H reached	
H value1 value2	Hex math: performed (add 2 to 1, subtract 2 from 1) on value1 and value2	H 0F 8	Add 8 to 0F, subtract 8 from 0F	Results displayed on next line
I portaddress	Input one byte from portaddress	I 2E6	Get input from port 2E6H	Results displayed on next line
L address	Load file whose file specification is at CS:80	L 506	Load file whose name and type are at CS:80	File loaded beginning at CS:100
L address	Load file whose file specification is at CS:80	DS:100 2 0.3	Load first three sectors of drive C beginning at DS:100	COM and EXE files are always loaded at CS:100, however
L address	Load sector2 disk sectors from drive, beginning with sector1, into address	M 100 L10 500	Move 16 bytes from 100H to 500H	Moves always performed without loss of memory during transfer
L range address	Move memory from range to new address	N c:debug.com	Prepare debug.com for use by debugger	
filespec	Name file to place at CS:81 and in PCBs	O 2E6 FF	Send FFH to port 2E6H	
P	Send a byte to specified port	P	Execution starts at CS:IP	P uses same syntax a T(trace) instruction
P address	Proceed to end of call, loop, interrupt, or repeat string instruction	P = 1044	Execution starts at CS:1044	P uses same syntax a T(trace) instruction
P address	Proceed from address to end of call, loop, interrupt, or repeat instruction	P = 1044 10	Execution starts at CS:1044 for no more than 16 bytes	P uses same syntax a T(trace) instruction
P address value	Proceed from address to end of call, loop, int, or repeat, or value instructions	Q	DEBUG is terminated immediately	Working memory is NOT saved by this command
Q	Quit DEBUG	Q		
R	Display all registers	R	Display current contents of all registers	Pressing ENTER only leaves contents unchanged
R registername	Display contents of registername and allow entry of new value	R AX	Display AX contents and waits for new value	
S range list	Search for range of memory for the contents in list	R 100 L 100 "TEH"	Search for pattern "TEH" in 100H bytes at CS:100H	
T address	Trace a single instruction	T	Trace instructions from CS:IP, display registers	
T address	Trace a single instruction at address	T CS:106	Trace instructions from CS:106H, display registers	
U address	Unassemble instructions beginning at address	T 100:10	Trace 16 instructions from CS:100H	0=trace forever (same as G)
U address	Unassemble instructions at CS:IP	U	Display disassembly of instructions at CS:IP	
U range	Unassemble instructions at address	U 100	Display disassembly of instructions at 100H	
U range	Unassemble instructions at CS:IP for range bytes	U 100:108	Display disassembly of instructions from 100H to 108H	May display slightly more bytes than requested
W address	Write file (named at CS:80H) to disk	W	Write file in memory to disk	BX,CX must contain number of bytes to write
W address	Write file (named at CS:80H) to disk beginning with byte at address	W 108	Write file beginning at 108H in memory to disk	BX,CX must contain number of bytes to write
W address drive sector1 sector2	Write data at address to drive starting with sector1 for sector2 sectors	W 108 2 0.3	Write first three sectors to drive C from memory at 108H	

Notes: Lowercase names in command syntax indicate items you replace with values

Source: IBM DOS 3.3 Technical Reference, pages 13-15 to 13-58

See Also: 6.83. SYMDEB Command Summary

2.30. EDLIN COMMAND SUMMARY

Command Syntax	Function	Example	Example Explanation	Comments
A	Append lines from file to memory	A	Append lines from file until 75% of memory is full	Applies only if file is too large to fit into memory
#A	Append # lines from file to memory	5A	Append 5 lines from file	Applies only if file is too large to fit into memory
line C	Copy current line to line	10C	Copy current line to line 10	
line1, line2, line3 C	Copy range of line 1 to line 2 to area beginning with line 3	1,2,3C	Copy lines 1 and 2 to lines 3 and 4	
line1, line2, line3, count C	Copy range of line 1 to line 2 count times to area starting at line 3	1,2,3,2C	Copy lines 1 and 2 to lines 3 and 4, 5 and 6	
D	Delete current line from memory	D	Delete current line	
line1, line2 D	Delete range of lines between line 1 and line 2 from memory	1,3D	Delete lines 1 through 3	
line	Edit current line		Edit current line	
E	Edit line number specified	10	Edit line number 10	
E	End EDLIN and save file	E	End EDLIN and saves changes to file	Saves original as file .BAK
I	Insert line at current line	I	Insert new line in front of current line	
line I	Insert line before line specified	10 I	Insert new line in front of current line 10	
L	List 23 lines (11 before current, current, 11 after current)	L	Show current line in context	
line1, line2 L	List lines from line 1 to line 2	1,10L	Show current line through 10	
line M	Move current line to line specified	10M	Move current line to line 10	
line1, line2, line3 M	Move range from line 1 to line 2 to area beginning at line 3	1,5,10M	Move lines 1 through 5 to line 10 (through 14)	
line1, line2 P	List 23 lines and move current line to last one displayed	P	Page through lines in file	
O	Quit EDLIN without saving changes	O	List first 10 lines and makes line 10 the current one	User is prompted before leaving EDLIN
R string1 Z string2	Replace string 1 with string 2 from current line to last line	Righ:ZTEH	Immediately leaves EDLIN	
line1, line2 R string1 Z string2	Replace string 1 with string 2 in lines from line 1 to line 2	17Riny'Zour	Replace "teh" with "our" in lines 1 through 7	
S string	Search for string in current line through last line in memory	SIBM	Search for "IBM" in lines starting with current one	If no string specified, uses last string searched for
line1, line2 S string	Search for string in range of lines from line 1 to line 2	1,10SIBM	Search for "IBM" in lines 1 through 10	If no string specified, uses last string searched for
T filespec	Transfer contents of file into memory starting before current line	1,AUTOEXEC.BAT	Transfer contents of AUTOEXEC.BAT to file	
line 1 filespec	Transfer contents of file into memory starting before line	10,CONFIG.SYS	Transfer contents of CONFIG.SYS to area before line 10	
W	Write lines from memory to file until 75% of memory is available	W	Write lines to file until 75% of memory is free	Applies only if file is too large to fit into memory
#W	Writes # lines from memory to file	10W	Write 10 lines to file	Applies only if file is too large to fit into memory

Notes: -Lowercase names in command syntax indicate items you replace with values  
 \*In general, if a line number is omitted from a command, the current line number is used  
 IBM DOS 3.3 Reference, pages 8-11 to 8-36

Source:

2.31. LIB OPERATORS SUMMARY

**LIB general command form:** LIB [libfile [pagesize] operators [(listfile)] [(newlib)] [(c)]

Operator	Function	Example	Example Explanation
+	Add contents of object or library file to the library	LIB YOUR.LIB+NEW.OBJ	Add NEW.OBJ code to YOUR.LIB library
-	Delete a module from the library	LIB YOUR-MINE	Delete module MINE.OBJ from YOUR.LIB library
*	Extract object module from library, place in new file	LIB YOUR.LIB*MY.OBJ	Delete module MY.OBJ from YOUR.LIB and places it in file MY.OBJ
+-	Delete existing module and replace with new one	LIB YOUR+MY	Delete module MY.OBJ from YOUR.LIB, then adds new MY.OBJ to library
*-	Extract object module from library and delete it	LIB YOUR.LIB-MINE	Delete module MINE.OBJ from YOUR.LIB and saves it in file MINE.OBJ

**Notes:** \*Operations are performed in the order: 1) erasures and removals, 2) additions  
 \*Library files have assumed type of LIB if not explicitly referenced; object files have an assumed type of OBJ

**Source:** IBM DOS 3.3 Technical Reference, pages A-3 to A-8

2.32. LINK PARAMETERS SUMMARY

**LINK general command form:** LINK objlist, runfile, mapfile, liblist[parameters]...

Parameter	Function	Comments
/DSALLOCATION	Defines data to be at high end of DGROUP	Default is to load data at the low end of DGROUP
/HIGH	Causes run image to be placed as high in memory as possible	Default is to place the file as low in memory as possible
/LINE	Causes line numbers and addresses in input modules to be included in list file	
/MAP	Lists all public symbols defined in input modules and their run file locations	The public symbols are listed at end of the list file
/PAUSE	Directs LINK to pause before creation of EXE file	Message is displayed to change diskettes prior to creating EXE file
/STACK:size	Overrides stack directive in source	Maximum is 65536; if an odd number, 1 is subtracted for even boundary
/X	Sets number of segments EXE file can contain	Default is 256 segments; limits are 0 to 1024 segments
/O	Links object modules created by version 1 of Pascal or FORTRAN compilers	

**Notes:** \*Parameters may be added to your responses to the four prompts LINK displays when invoked as LINK <Enter>  
 \*Only the forward slash and first letter are required for the parameters

**Source:** IBM DOS 3.3 Technical Reference, pages 12-14 to 12-18

**2.33. DIRECTORY ENTRIES**

Offset	Length	Description	Format	Comments
0 (0)	8 bytes	File name**	ASCII chars.	Must be padded with spaces to fill field
8 (8)	3 bytes	File type (Extension)	ASCII chars.	Must be padded with spaces to fill field
B (11)	byte	File attribute byte	Bit codes: Bit 0 = read-only Bit 1 = hidden Bit 2 = system Bit 3 = volume label Bit 4 = directory Bit 5 = archive Bit 6 = UNUSED Bit 7 = UNUSED	See 2.34. File Attribute Byte
C (12)	10 bytes	RESERVED		
16 (22)	word	Time file last updated*	Coded word: (unsigned 16-bit integer) Time = Hr*2048+Min*32+Sec+2	See 2.35. Date/Time Formats
18 (24)	word	Date file last updated*	Coded word: (see above) Date = (Yr-1980)*512+Mon*32+Day	See 2.35. Date/Time Formats
1A (26)	word	Starting cluster number*	Word binary integer*	See 1.15. Common 8086 Family Data Formats
1C (28)	dbl word	File size*	Double word binary integer*	See 1.15. Common 8086 Family Data Formats

- Notes:**
- There is no period separating the file name and type fields
  - Least significant byte first
  - The first byte of the file name indicates status of directory entry, as follows:
    - 00H = name never used
    - 05H = first character of name is really E5H (sigma)
    - E5H = file was used, but has been erased
    - 2EH = entry is a directory (if second byte also 2EH, cluster field contains cluster # of parent directory)

**Source:** IBM DOS 3.3 Technical Reference, pages 5-10 to 5-13

- See Also:**
- 1.15. Common 8086 Family Data Formats
  - 2.34. File Attribute Byte
  - 2.35. Date/Time Formats
  - 2.50. Allowable Characters in Filenames
  - 2.51. File Separator Characters

**2.34. FILE ATTRIBUTE BYTE**

Bit Number									
7	6	5	4	3	2	1	0	Meaning if Set to 1	Meaning if Set to 0
							X	Read-only file	Read/write file
						X		Hidden file	Visible file
				X				System file	Regular file
			X					Volume name	Regular file
		X						Directory name	Regular file
	X							File changed since last backup	File unchanged since last backup
X	X							RESERVED	RESERVED

**Version Info:** DOS 1.x used only bits 0-3

- Notes:**
- Bits 3 and 4 are mutually exclusive; you may set none, one or the other one, but not both
  - Only one file (in the root directory) may have Bit 3 set

**Source:** IBM DOS Technical Reference, pages 5-11 to 5-12

- See Also:**
- 2.33. Directory Entries

### 2.35. DATE/TIME FORMATS

In DOS Functions 2AH, 2BH, 2CH, and 2DH, the Date and Time are Passed Using Registers, as Follows:

Element	Register	Format	Allowable Values
Day of Week	AL	Coded value	0=Sunday 1=Monday 2=Tuesday 3=Wednesday 4=Thursday 5=Friday 6=Saturday
Day	DL	Binary value	1-31 (corresponds to date)
Month	DH	Binary value	1-12 (corresponds to month number)
Year	CX	Binary value	1980-2099 (must be in this range)
Hundredths	DL	Binary value	0-99 (corresponds to hundredths of a second)
Seconds	DH	Binary value	0-59 (corresponds to seconds)
Minutes	CL	Binary value	0-59 (corresponds to minutes)
Hour	CH	Binary value	0-23 (hour in military 24-hour style)

In Directory Entries and Function 57H the Date and Time are Kept as Separate 16-bit Values (Least Significant Byte First), as Follows:

Element	Bits Used	Format	Allowable Values
Day	0 - 4	5-bit binary value	1-31 (corresponds to date)
Month	5 - 8	4-bit binary value	1-12 (corresponds to month number)
Year	9 - 15	7-bit binary value	0-119 (year biased by 1980)
Seconds	0 - 4	5-bit binary value	0-29 (multiply by 2 to get seconds)
Minutes	5 - 10	6-bit binary value	0-60 (corresponds to minutes)
Hours	11 - 15	5-bit binary value	0-24 (corresponds to military hours)

**Notes:** Note unusual format of seconds in directory entries

**Source:** IBM DOS 3.3 Technical Reference, pages 5-12 to 5-13, 6-98, 6-100

**See Also:** 3.006. System Functions  
3.046. Function 2AH -- Get System Date  
3.047. Function 2BH -- Set System Date  
3.048. Function 2CH -- Get System Time  
3.049. Function 2DH -- Set System Time  
3.101. Function 57H,00H -- Get Date/Time of File  
3.102. Function 57H,01H -- Set Date/Time of File

### 2.36. FAT LAYOUTS

12-bit FAT Layout			
Entry #	Example Value	Use	
0	FF8	Disk ID byte	
1	FFF	Filler	
2	003	Cluster value:	000 = unused cluster
3	004		001-FEF = next cluster number
4	005		FF0-FF6 = reserved cluster
5	FFF		FF7 = cluster marked bad
6	000		FF8-FFF = last cluster in file

*Reserved for DOS* points to entries 0 and 1.  
*From Directory Entry's Starting Cluster Number* points to entries 2 through 6.

**Note:** In this example FAT, the first entry indicates that it is a FAT for a hard disk (FF8). The first directory entry in the directory for that disk has a starting cluster of 2, thus pointing to cluster number two in this table. The second cluster points to the third, the third to the fourth, the fourth to the fifth. The fifth cluster is the last cluster in the file, thus has a value of FFFH.

(Continued)

Table 2.36. Continued

Entry #	Example Value	Use
0	FFF8	Disk ID byte
1	FFFF	Filler
2	0003	Cluster value: 0000 = unused cluster 0001-FFFF = next cluster number FFF0-FFF6 = reserved cluster FFF7 = cluster marked bad FFF8-FFFF = last cluster in file
3	0004	
4	0005	
5	FFFF	
6	0000	

*Reserved for DOS* points to entries 0 and 1.

*From Directory Entry's Starting Cluster Number* points to entries 2 through 6.

**Note:** In this example FAT, the first entry indicates that it is a FAT for a hard disk (FFF8H). The first directory entry in the directory for that disk has a starting cluster of 2, thus pointing to cluster number two in this table. The second cluster points to the third, the third to the fourth, the fourth to the fifth. The fifth cluster is the last cluster in the file, thus has a value of FFFFH. Remember, words in the FAT are byte swapped (i.e., least significant byte first).

**Source:** IBM DOS 3.3 Technical Reference, pages 5-5 to 5-9

**See Also:** 2.37. Disk ID Bytes

2.37. DISK ID BYTE

ID Byte	Tracks/side	Sectors	Sides	Format
FFH	40	8	2	5.25-inch floppy disk
FEH	40	8	1	5.25-inch floppy disk
	77	2, 6, or 8	1	8-inch floppy disk
FDH	40	9	2	5.25-inch floppy disk
	77	26	2	8-inch floppy disk
FCH	40	9	1	5.25-inch floppy disk
FBH	80	8	2	5.25-inch floppy disk
	80	8	2	3.5-inch microfloppy disk
FAH	80	8	1	5.25-inch floppy disk
	80	8	1	3.5-inch microfloppy disk
F0H	80	18	2	3.5-inch high-density microfloppy disk
F9H	80	9	2	3.5-inch microfloppy disk
	80	15	2	5.25-inch high-density floppy disk
F8H	-	-	-	Fixed disk

**Version Info:** Beginning with DOS 2.x, the usefulness of the disk ID byte in the FAT was reduced, and it is now considered meaningless, since multiple formats may have the same ID. Microsoft recommends that you use the information in the media descriptor table to determine the type of disk being used.

**Notes:** The disk ID byte is the low-order byte of the first cluster indicator in the FAT (e.g., a first cluster value of FFF8H yields a disk ID byte of F8H)

**Source:** IBM DOS 3.3 Technical Reference, page 5-6

**See Also:** 2.39. Disk Partition Table Layout  
3.165. Media Descriptor Table

## 2.38. DISK BOOT RECORD LAYOUT

Offset	Length	Description
0 (0)	3 bytes	JMP to boot code*
3 (3)	8 bytes	OEM name and version
B (11)	word	Bytes per sector
D (13)	byte	Sectors per cluster (must be a power of 2)
E (14)	word	Reserved sectors (for Dir, FAT, etc.)
10 (16)	byte	Number of copies of FAT
11 (17)	word	Maximum number of root directory entries
13 (19)	word	Total number of sectors in logical image
15 (21)	byte	Media descriptor byte
16 (22)	word	Number of sectors in FAT
18 (24)	word	Number of sectors per track
1A (26)	word	Number of heads
1C (28)	word	Number of hidden sectors

**Version Info:** \*Note that media descriptor bytes are not necessarily valid beginning with DOS 2.x  
 \*For DOS 2.x = 3-byte near jump  
 For DOS 3.x = 2-byte short jump + NOP

**Notes:** OEM name and version are not always present (IBM does not use)

**Source:** IBM DOS 3.3 Technical Reference, page 2-31

**See Also:** 1.27. Powers of Two

## 2.39. DISK PARTITION TABLE LAYOUT

Offset	Length	Name	Contents
0 (0)	byte	Partition status	0=inactive; 80H=bootable, active
1 (1)	byte	Starting head	Binary value
2 (2)	word	Starting sector and cylinder	See note *
4 (4)	byte	Partition type	1=DOS with 12-bit FAT 4=DOS with 16-bit FAT 5=extended DOS 6=reserved for future use DBH=concurrent DOS
5 (5)	byte	Ending head	Binary value
6 (6)	word	Ending sector and cylinder	See note *
8 (8)	dbl word	Starting absolute sector	Binary value (least significant word first and byte swapped in each word)
C (12)	dbl word	Number of sectors	Binary value (least significant word first and byte swapped in each word)

**16-byte Block Repeats, as Above, for Each Partition, and Is Followed By:**

01FEH	word	Signature	55AAH (indicates valid boot record)
-------	------	-----------	-------------------------------------

**Notes:**

- Some manufacturers allow additional partition types in order to divide large capacity hard disks into several drives.
- The partition tables begin at an offset of 1BEH in the boot record. The actual boot record is defined by the starting head, cylinder, and sector number, and that sector is loaded to location 7C00H.
- Cylinder and sector are stored in bit-position-coded notation. This applies to the starting cylinder and head and the ending cylinder and head. See below.

byte n						byte n+1					
c	c	s	s	s	s	c	c	c	c	c	c
M		M				L					L
S		S				S					S
B		B				B					B

The two most significant bits of byte n precede the eight bits of byte n+1 to form the ten-bit cylinder number. The six least significant bits of byte n form the sector number.

**Source:** IBM DOS 3.3 Technical Reference, pages 9-6 to 9-16

**See Also:** 2.38. Disk Boot Record Layout

**2.40. FLOPPY DISK FORMAT SUMMARY**

<i>System That Commonly Uses This Format</i>	<i>Obsolete</i>	<i>Obsolete</i>	<i>Obsolete</i>	<i>PC/XT</i>	<i>AT</i>	<i>Convert.</i>	<i>PS/2</i>
Disk size	5.25	5.25	5.25	5.25	5.25	3.5	3.5
Disk ID byte (in FAT)*	FE	FF	FC	FD	F9	F9	F0
Number of heads	1	2	1	2	2	2	2
Tracks per side	40	40	40	40	80	80	80
Sectors per track	8	8	9	9	15	9	18
Bytes per sector	512	512	512	512	512	512	512
Sectors per cluster	1	2	1	2	1	2	1
Number of reserved sectors	1	1	1	1	1	1	1
Number of sectors per FAT	1	1	2	2	7	3	9
Number of FATs per disk	2	2	2	2	2	2	2
Number of root directory sectors	4	7	4	7	14	7	14
Maximum number of root directory entries allowed	64	112	64	112	224	112	224
Total number of sectors on disk	320	640	360	720	2400	1440	2880
Total number of usable sectors on disk	313	630	351	708	2371	1426	2847
Total number of usable clusters on disk	313	315	351	354	2371	713	2847
Capacity of disk	160 KB	320KB	180 KB	360 KB	1.2 MB	720 KB	1.5 MB
<i>Format introduced with DOS version</i>	1	1.1	2	2	3	3	3.3

**Notes:**

•Total usable sectors and total usable clusters will change if bad sectors are found during formatting.  
 •\*FAT disk ID bytes are unreliable. Use disk parameter block to determine media type.

**Source:**

MS-DOS 3.2 Programmer's Reference, pages 3-9, 3-10

**See Also:**

2.41. Hard Disk Format Summary

**2.41. HARD DISK FORMAT SUMMARY**

<i>System That Commonly Uses This Format</i>	<i>XT</i>	<i>AT</i>	<i>Model 50</i>	<i>Model 60</i>	<i>Model 80</i>
Disk size	5.25	5.25	3.5	3.5	3.5
Disk ID byte (in FAT)*	F8	F8	F8	F8	F8
Interleave	6 to 1	3 to 1	1 to 1	1 to 1	1 to 1
Heads per disk	4	4			
Cylinders	306	615			
Sectors per track	17	17			
Bytes per sector	512	512	512	512	512
Sectors per cluster	8	4			
Number of reserved sectors	1	1			
Number of sectors per FAT	8	40			
Number of FATs per disk	2	2			
Number of root directory sectors	32	32			
Maximum number of root directory entries allowed	512	512			
Total number of sectors on disk	20808	41820			
Total number of usable sectors on disk	20759	41707			
Total number of usable clusters on disk	2595	10427			
Capacity of disk in kilobytes	10MB	20MB	20MB	44MB	70MB
<i>Format introduced with DOS version</i>	2	2	3.3	3.3	3.3

**Notes:**

•All numbers assume that the entire hard disk is formatted as a DOS partition (i.e., no non-DOS partitions on disk).  
 •\*FAT disk ID bytes are unreliable. Use disk parameter block to determine media type.

**Source:**

IBM PC/XT Technical Reference, pages 1-151 to 1-152.

**See Also:**

2.40. Floppy Disk Format Summary

## 2.42. EXE FILE HEADER

Offset	Length	Usual Contents	Description	Comments
0 (0)	word	4D5AH	EXE file signature	
2 (2)	word		Length of last used sector in file	Modulo 512
4 (4)	word		Size of file, including header	In 512-byte pages
6 (6)	word		Number of relocation table items	
8 (8)	word		Size of header	In 16-byte paragraphs
A (10)	word		Minimum paragraphs needed above program	In 16-byte paragraphs
C (12)	word		Maximum paragraphs desired above program	In 16-byte paragraphs
E (14)	word		Displacement of stack segment in module	Relative to start of program, in paragraphs
10 (16)	word		Contents of SP register at entry	
12 (18)	word		Checksum	Two's complement
14 (20)	word		Contents of IP register at entry	
16 (22)	word		Displacement of code module	Relative to start of program (in paragraphs)
18 (24)	word		Offset to first relocation item in file	Relative to start of file (in bytes)
1A (26)	word		Overlay number	0 for resident part of program
1C (28)	varies		Variable RESERVED space	
varies	varies		Relocation table	
varies	varies		Variable RESERVED space	
varies	varies		Program and data segments	
varies	varies		Stack segment	

**Notes:** EXE files created for use with Microsoft Windows use a different format (See 6.10. Windows EXE File Format)

**Sources:** IBM DOS 3.3 Technical Reference, pages 10-3 to 10-6

**See Also:** 2.43. COM Program Layout  
6.10. Windows EXE File Format

## 2.43. COM PROGRAM LAYOUT

Offset	Length	Description	Comments
0 (0)	256 bytes	Program segment prefix	Values filled in by DOS
100 (256)	varies	Code and data segment	Only one segment allowed
varies	varies	Stack	Usually at top of segment

**Notes:** The program segment prefix is not usually part of the actual file. It is created and filled in by DOS at program load time. COM files must have code segment ORGed at 100H.

**Source:** IBM DOS 3.3 Technical Reference, page 7-9

**See Also:** 2.42. EXE File Header  
2.44. COM versus EXE File Differences  
3.136. Program Segment Prefix Layout

## 2.44. COM VERSUS EXE FILE DIFFERENCES

Item	COM Programs	EXE Programs
Max. program size	65278*	No limit
Segment use	One segment only	Multiple segments allowed
Entry point	PSP:0100H	Defined by END Segment
CS at entry	PSP	Segment containing module with entry point
IP at entry	0100H	Offset of entry point within its segment
DS at entry	PSP	PSP
ES at entry	PSP	PSP
SS at entry	PSP	Segment with STACK attribute
SP at entry	0FFFEH or top word, whichever is lower	Size of segment defined with STACK attribute
Stack at entry	Zero word on stack	Initialized or uninitialized
Stack size	65536 - (ProgramSize+256)	Defined in segment with STACK attribute (up to 65536 bytes)
Memory allocation	All free memory allocated to program	May be set to allocate portion of memory (offset 0CH in EXE header)
Subroutine calls	NEAR CALLs only	NEAR or FAR CALLs allowed
Size of file	Exact size of program (might not include PSP)	Size of program plus EXE header (which is multiple of 512 bytes)

**Notes:** \*65536 - 256-byte PSP - 2-byte STACK

**Sources:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan

**See Also:** 2.42. EXE File Header  
2.43. COM Program Layout  
3.136. Program Segment Prefix Layout

**2.45. FONT FILE (CODE PAGE) LAYOUT**

Offset	Length	Name	Contents
0 (0)	8 bytes	File tag	FFH followed by "font," followed by three spaces
8 (8)	8 bytes	RESERVED	
10 (16)	word	Number of pointers in header	1 for DOS 3.3
12 (18)	byte	Type of pointer	1 for DOS 3.3
13(19)	dbl word	Offset to info from start of file	Binary value
17(23)	word	Number of entries	Binary value
19(25)	word	Size of code	Binary value
1B(27)	dbl word	Pointer to header of next entry	0000H for last header
1F(31)	word	Device type	1=display, 2=printer
21(33)	8 bytes	Device name (ID)	ASCII text padded with spaces
29(41)	word	Code page ID	437
2B(43)	3 words	RESERVED	
31(49)	dbl word	Pointer to font info	Binary value
35(53)	word	RESERVED	Must be 1
37(55)	word	Number of fonts	Binary value
39(57)	word	Length of font data	Binary value

**For Display Font:**

3B(59)	byte	Rows in character box	Binary value
3C(60)	byte	Columns in character box	Binary value
3D(61)	2 bytes	Aspect ratio	Currently not used, = 0,0
3F(63)	word	Number of characters in font	Usually 256
41(65)	varies	Font data	Stored as pixel descriptions

**For Printer Font:**

3B(59)	word	Printer selection type	1=4201, 2=5202
3D(61)	word	Total bytes in control sequences	Binary value
3F(63)	varies	Hardware code page	Maximum length of 31
varies	varies	Downloadable code page	Maximum length of 31
varies	varies	Downloadable character definitions	See Printer Technical Reference

**Version Info:** Applies to DOS 3.3 only

**Source:** IBM DOS 3.3 Technical Reference, pages 7-17 to 7-20

**See Also:** 3.147. Code Page Assignments

**2.46. OPERATING SYSTEM FILES SUMMARY**

**IBM PC-DOS Version**

File	1	1.1	2	2.1	3	3.1	3.2	3.3
IBMBIO.COM	1920	1920	4608	4736	8964	9564	16369	22100
IBMDOS.COM	6400	6400	17152	17024	27920	27760	28477	30159
COMMAND.COM	3231	4959	17664	17792	22042	23210	23791	25307
Total file sizes	11551	13279	39424	39552	58926	60534	68637	77566

**Microsoft MS-DOS Version**

File	1	1.1	2	2.1	3	3.1	3.2	3.3
IO.SYS	*	*	*	*	*	*	15138	22357
MS-DOS.SYS	*	*	*	*	*	*	28480	30128
COMMAND.COM	*	*	*	*	*	*	23612	25276
Total file sizes	*	*	*	*	*	*	68230	77761

**Notes:**

- The first total shown is for the entire operating system files only.
- The actual amount of memory used by the operating system is dependent upon the environment size, device drivers that have been loaded, and the settings of the BUFFERS and FILES parameters.
- MS-DOS released only through OEMs, so file sizes vary.

**Source:** DOS Disks

**See Also:** 2.47. Included System Files Summary  
2.49. Typical DOS Memory Usage

INCLUDED COMMANDS (BUILT-IN)

Command Name	DOS Version Number									
	1	1.1	2	2.1	3	3.1	3.2	3.3		
CD/CHDIR			X	X	X	X	X	X	X	
CLS			X	X	X	X	X	X		
COPY	X		X	X	X	X	X	X		
CTTY			X	X	X	X	X	X		
DATE	X		X	X	X	X	X	X		
DEL/ERASE	X		X	X	X	X	X	X		
DIR	X		X	X	X	X	X	X		
MD/MKDIR			X	X	X	X	X	X		
PATH			X	X	X	X	X	X		
PROMPT			X	X	X	X	X	X		
REN/RENAME	X		X	X	X	X	X	X		
RM/RMDIR			X	X	X	X	X	X		
SET			X	X	X	X	X	X		
TIME	X		X	X	X	X	X	X		
TYPE	X		X	X	X	X	X	X		
VERIFY			X	X	X	X	X	X		
VOL			X	X	X	X	X	X		

2.47. INCLUDED COMMAND FILES SUMMARY\*

Command File	DOS Version Number									
	1	1.1	2	2.1	3	3.1	3.2	3.3		
APPEND								X		
ASSIGN			X	X	X	X	X	X		
ATTRIB			X	X	X	X	X	X		
BACKUP			X	X	X	X	X	X		
BASIC	X		X	X	X	X	X	X		
BASICA	X		X	X	X	X	X	X		
CHCP								X		
CHKDSK	X		X	X	X	X	X	X		
COMP	X		X	X	X	X	X	X		
DEBUG	X		X	X	X	X	X	**		
DISKCOMP	X		X	X	X	X	X	X		
DISKCOPY	X		X	X	X	X	X	X		
EDLIN	X		X	X	X	X	X	X		
EXE2BIN	X		X	X	X	X	X	**		
FASTOPEN								X		
FDISK			X	X	X	X	X	X		
FIND			X	X	X	X	X	X		
FORMAT	X		X	X	X	X	X	X		
GRAFTABL			X	X	X	X	X	X		
GRAPHICS			X	X	X	X	X	X		
JOIN								X		
KEYBK								X		
KEYBGR								X		
KEYBFR								X		
KEYBIT								X		
KEYBSP								X		
LABEL	X		X	X	X	X	X	**		
LINK	X		X	X	X	X	X	X		
MODE	X		X	X	X	X	X	X		
MORE	X		X	X	X	X	X	X		
NLS/LJNC								X		
PRINT			X	X	X	X	X	X		
RECOVER			X	X	X	X	X	X		
REPLACE								X		
RESTORE			X	X	X	X	X	X		
SELECT								X		
SHARE								X		
SORT			X	X	X	X	X	X		
SUBST								X		
SYS	X		X	X	X	X	X	X		
TREE			X	X	X	X	X	X		
XCOPY								X		

Notes:

- \*\*These COM and EXE files are from the IBM PC-DOS versions. The MS-DOS versions may differ slightly.
- \*\*Supplied with Technical Reference manual (Continued)

BATCH FILE COMMANDS (BUILT-IN)

Command	DOS Version Number									
	1	1.1	2	2.1	3	3.1	3.2	3.3		
CALL								X		
ECHO	X		X	X	X	X	X	X		
FOR	X		X	X	X	X	X	X		
GOTO	X		X	X	X	X	X	X		
IF	X		X	X	X	X	X	X		
PAUSE	X		X	X	X	X	X	X		
REM	X		X	X	X	X	X	X		
SHIFT	X		X	X	X	X	X	X		

See Also: 2.46. Operating System Files Summary

## 2.48. COMMON FILE TYPES (EXTENSIONS)

File Type	Program	Description
\$\$\$	DOS	A "pipe" file created by using the redirection flag ( ) in a DOS command
@@@	CodeviewDisk	
ACT	BITCOM	Communications account data file
ACT	Actor	Source code file for Actor programming language
AIO	APL	APL file transfer format file
AMG	Actor	System image file for Actor programming language
APL	APL	APL work space format file
APP	SQL Windows	Application file
ARF	BASCOM	Automatic response file created by the BM series of compilers; similar to batch files
ARF	FORTRAN	Automatic response file created by the BM series of compilers; similar to batch files
ARF	COBOL	Automatic response file created by the BM series of compilers; similar to batch files
ASC	Many	ASCII text file; may be typed to the screen
ASM	MASM	Assembly language source code file
AUX	Paradox	
BAK	Many	A backup file; contains a previous version of the information in the file
BAS	BASIC	A file containing BASIC program code; may not be in ASCII format!
BAS	BASICA	A file containing BASIC program code; may not be in ASCII format!
BAS	MS-QuickBASIC	A file containing BASIC program code; may not be in ASCII format!
BAS	Turbo BASIC	A file containing BASIC program code; may not be in ASCII format!
BAT	DOS	Batch file; contains commands to be executed by DOS, in order
BIN	Many	Binary file; often same as an OBJ file; contains 8-bit information (i.e., not ASCII)
BLK	ShowPartner	Block file; contains information about a block manipulated by ShowPartner
BMP	MS-Windows	Bitmap file; contains data for a Windows bitmap structure
C	C compilers	Contains C source code
CAL	SuperCalc	Spreadsheet file; contains contents of a spreadsheet
CCL	Intalk	Communication command language file
CFG	Many	A configuration file; contains information about machine and environment
CHK	CHKDSK	Recovered data file; contains data recovered when using the /F option in CHKDSK
CLR	ShowPartner	Color palette file
CLS	Actor	Class library file for Actor programming language
CMD	dBASE	Command file; used for file that contains dBASE programs
CMD	CP/M-86	Transient command file (similar to DOS EXE and COM files)
CMP	MS-Word	Compare file; contains dictionary of words to compare for spelling
CNF	Many	A configuration file; contains information about machine environment
COB	COBOL	COBOL program source code
COD	FORTRAN	FORTRAN program compiled code file
COL	MS-Multiplan	Spreadsheet data file; contains contents of a spreadsheet
COM	DOS	Command (program) file
CRF	MASM	Cross reference file; listing produced by MASM compiler
CRS	World Tour Golf	Course data file
CTX	Microsoft	Course text file; contains information for on-line tutorials
CUR	MS-Windows	Cursor file; contains data for a Windows cursor
DAT	Many	Data file; usually contains ASCII or specifically-formatted data
DB	Paradox	Data file; contains data for a Paradox table
DBD	Bricklin's DEMO	Demonstration data file
DBF	dBASE	Data file; contains data for a dBASE database
DBS	SQL Windows	Data file; contains data for a SQL Windows database
DBT	dBASE	Data file; contains dBASE textual database information
DBT	SQL Windows	Temporary data file
DCT	SpellStar	Dictionary file; contains spelling dictionary
DEF	MS-Windows	Module definition file
DEF	Access	
DES	Access	
DEV	Many	Device driver file; contains code needed by CONFIG.SYS to install a new device
DFM	Palantir Filer	Data entry form file
DGS	PC-DOS	Diagnostics file
DIC	Many	Dictionary file; contains spelling dictionary
DIF	Many	Data interchange format file; used to interchange data between programs
DIR	Sidekick	Directory file; used with dialing options
DIS	Q&A	Startup file used by Q&A
DOC	Many	Document file; may be in ASCII or word processor-specific format
DOC	MS-Word	Document file; contains formatted document in non-ASCII form
DRV	Many	Device driver file; contains information to drive a specific device
DTF	Q&A, PFS	Data file; contains data for a PFS or Q&A database
EMU	BITCOM	Terminal emulation file; contains definitions used to emulate a terminal
EPS	Pagemaker	Encapsulated postscript file; contains condensed postscript printer data
EXE	DOS	Executable program file
FMT	dBASE	Screen format file; contains information about how data is to be displayed on screen
F#	Paradox	Form file; contains form definition information

(Continued)

Table 2.48. Continued

File Type	Program	Description
FNT	Windows	Font file; contains description of what a font should look like
FNT	LaserFonts	Font file; contains description of what a font should look like
FNT	Paintbrush	Font file; contains description of what a font should look like
FON	Windows	GD! loadable font file
FOR	FORTTRAN	FORTTRAN source code file
FRM	dBASE	Report form file; contains information about how a dBASE report should be formatted
GRB	MS-Windows	
GX1	ShowPartner	Graphics screen capture file
H	C compilers	Header file; contains C source code definitions to be merged with other files
HEX	DEBUG	Hex file; contains ASCII only numbers formatted in Intel HEX format
HIN	Access	
HLP	Many	Help file; contains information to help user understand command or function
ICO	MS-Windows	Icon file; contains bit image of an icon
IDX	Q&A	Index file; contains indexing information for a database
IMG	MS-Windows	Hi-res scanned image file
IMP	Pascal	Implementation file for IBM Pascal
INC	Pascal	Include file for Microsoft Pascal
INC	Turbo BASIC	Include file for Borland Turbo BASIC
INI	MS-Windows	Initialization file; contains information about initial state of system
INI	MS-Word	Printer initialization file
INT	Pascal	Interface file for IBM Pascal
INT	Xywrite	Command file for Xywrite
IT	Intalk	Settings file
JOR	SQL Windows	Journal file
KBD	Xywrite	Keyboard configuration file
LAY	Superkey	Layout file; contains keyboard reconfiguration information
LBL	dBASE	Label file
LIB	Many	Library file; normally created by a compiler in one of several standard formats
LNK	MS-Windows/C	
LOD	Many	Load file; used by one copy-protection scheme
LST	MASM	Listing file; lists assembled source code
MAC	Prokey	Keyboard macro file; contains instructions to execute when certain keys are pressed
MAC	Superkey	Keyboard macro file; contains instructions to execute when certain keys are pressed
MAP	LINK	Map file; a list file created by LINK during the linking process
MDM	Access	Modem file; contains information about modems
ME	Many	Usually a READ.ME file containing information about files on disk
MEM	dBASE	Memory file
MNU	Access	Menu file; contains menu definition
MSG	Multiplan	Message file
MSG	Sidekick	Message file; used with appointment calendar
MSP	MS-Windows	Windows Paint file; contains data for a picture drawn with Windows Paint
MOD	MS-Windows	
NDX	dBASE	Index file; contains indexing information for a database
NET	Paradox	Network configuration file
OBJ	LINK	Object code file; contains result of an assembly or compile in a specified format
OVD	Paradox	Overlay file
OVL	Many	Overlay file; contains part of program to be loaded at a later time
OVR	Many	Overlay file; contains part of program to be loaded at a later time
OY#	Many	Overlay file; contains part of program to be loaded at a later time
PAL	Paintbrush	Palette file
PAS	Pascal	Pascal source code file
PCX	Paintbrush	Picture file
PCC	Paintbrush	Cutout picture file

(Continued)

Table 2.48. Continued

File Type	Program	Description
PFM	MS-Windows	Printer font metric file
PGM	Many	Usually a program overlay file
PHB	Access	
PIC	Many	Picture file
PIX	Many	File containing one or more pictures
PIF	MS-Windows	Program information file; used by TopView and Windows to load program into memory
PJ	SuperProject	Project file; contains information about a scheduling project
PRD	MS-Word	Printer definition file; contains information about how to talk to printer
PRF	VisiCalc	Print format file (spreadsheet printed to disk)
PRG	dBASE	Procedure or program file
PRJ	Harvard TPM	Project data file
PRN	Many	Print format file (print to disk)
PRS	MS-Word	
PUB	Pagemaker	Publication file; contains data for page layout
PX	Paradox	Primary Index file
RC	MS-Windows	Resource Script file; contains a list of resource definitions used by MS-Windows
REF	CREF	Printable cross-reference file (see CRF)
R#	Paradox	Report format file; contains a report definition
SC	Paradox	Script file; contains a PAL script (program)
SCN	Microsoft	Screen file; contains screen displays for on-line tutorials
SCP	BITCOM	Script file; contains a macro script for communications session
SCR	Access	Script file
SET	Paradox	Settings file; contains information about settings for a form or table
SOB	Microsoft	Part of on-line tutorials
SOM	Paradox	Sort information file
SPL	SQL Windows	SQLTALK Spooler file
SPS	Mouse	
SQL	SQL Windows	Data file
STY	MS-Word	Style sheet; contains style formatting information
SYM	MS-Windows	Symbolic debugging definitions
SYN	Word Finder	Synonym file; contains information for thesaurus program
SYS	Many	Device driver file; contains information to create a device driver under CONFIG.SYS
TIF	Microsoft	Tagged info file format (see 6.11. Tag Image File Format)
TMP	Many	Temporary file
TPL	Access	
TXT	Many	Text file
VAL	Paradox	Validity check file
VC	VisiCalc	VisiCalc spreadsheet file
WK1	Lotus 1-2-3	1-2-3 spreadsheet file (version 2)
WKS	Lotus 1-2-3	1-2-3 spreadsheet file (version 1)
WMF	MS-Windows	Metafile picture (see 6.16. Metafile Format)
WRI	MS-Windows	Windows Write document file
X#	Paradox	Index file
XLC	MS-Excel	Chart file
XLS	MS-Excel	Spreadsheet file
Y#	Paradox	Index file
Z#	Paradox	Index file

**Notes:**

- A # sign indicates a position held by a digit, 0-9
- MS-Windows can associate file types with a program. Registration of types is done in the MS-Windows programming SIG on Genie.

**2.49. TYPICAL DOS MEMORY USAGE**

<i>Address</i>	<i>Memory Usage</i>
0000:0000	Interrupt vector table (see 7.22. I/O Port Usage)
0000:0400	ROM BIOS parameter area
0000:0500	DOS parameter area
0000:0700	IBMBIO
0000:0E30	IBMDOS
0000:4DB9	Device drivers (includes ANSI.SYS, BUFFERS=, FILES=, etc.)
0000:53F0	Resident COMMAND.COM
0000:5FD0	Master environment for COMMAND.COM (see 3.141. Environment Blocks)
0000:6080	Environment for program (if any)
0000:60B0	Application program (if any) (see 3.136. Program Segment Prefix Layout) (see 2.44. COM versus EXE File Differences)
0009:C9E0	Stack (expands towards beginning of memory)
0009:CBE0	Transient COMMAND.COM (error messages, command table, last command)
000A:0000	Hardware RESERVED (video adapters, ROM, ROM expansion) (see 7.02. IBM Reserved Memory Layout)
0010:0000	

**Notes:** Memory addresses are for PC-DOS 2.1 only. Other DOS versions will use the same ordering, but the memory addresses may vary.

**Source:** IBM DOS 3.3 Technical Reference, pages 7-4, 7-5

**See Also:** 2.44. COM versus EXE File Differences  
3.136. Program Segment Prefix Layout  
3.141. Environment Blocks  
7.02. PC Memory Use  
7.22. I/O Port Usage

**2.50. ALLOWABLE CHARACTERS IN FILENAMES**

ASCII Codes	Character(s)	Allowed	Illegal
00H-1FH	Control codes		X
20H	Space		X
21H	Exclamation point	X	
22H	Quotation mark		X
23H-29H	Misc. punctuation	X	
2AH	Asterisk		X**
2BH	Plus sign		X
2CH	Comma		X
2DH	Hyphen	X	
2EH	Period		X**
2FH	Slash		X
30H-39H	Numbers	X	
3AH	Colon		X**
3BH	Semicolon		X
3CH	Less than sign		X
3DH	Equals sign		X
3EH	Greater than sign		X
3FH	Question mark		X**
40H	At sign	X	
41H-5AH	Capital letters	X	
5BH	Opening bracket		X
5CH	Backslash		X**
5DH	Closing bracket		X
5EH-60H	Misc. punctuation	X	
61H-7AH	Lowercase letters	X*	
7BH	Opening brace	X	
7CH	Vertical line		X
7DH	Closing brace	X	
7EH	Tilde	X	
7FH	DEL	X*	
80H-FFH	IBM extended ASCII	X*	

**Notes:**

- This same table applies to file types, volume, and directory names
- \*Cannot necessarily be entered directly from keyboard
- \*\*Has special meaning in filenames

**Source:** IBM DOS 3.3 Reference, page 2-4

**See Also:** 2.51. Filename Separator Characters

**2.51. FILENAME SEPARATOR CHARACTERS**

ASCII Codes	Character(s)	Separator	Terminator
00H-1FH	Control codes		X
09H	Tab	X	X
20H	Space	X	X
22H	Quotation mark	X	X
2BH	Plus sign	X	X
2CH	Comma	X	X
2EH	Period	X	X
2FH	Forward slash	X	X
3AH	Colon	X	X
3BH	Semicolon	X	X
3CH	Less than sign	X	X
3DH	Equals sign	X	X
3EH	Greater than sign	X	X
5BH	Opening bracket	X	X
5CH	Backslash	X	X
5DH	Closing bracket	X	X
7CH	Vertical line	X	X

**Notes:** Filename separators and terminators are used in parsing filenames

**Source:** Microsoft DOS 3.2 Programmer's Reference, page 1-107

**See Also:** 2.50. Allowable Characters in Filenames  
3.045. Function 29H -- Parse Filename



— SECTION —

# 3

DOS Function  
Calls and  
Support Tables

---

3.001. INT 21H FUNCTIONS BY DOS VERSION SUMMARY

		DOS Versions That Support the Function							
Func.Number	Function Name	1	1.1	2	2.1	3	3.1	3.2	3.3
0 (0)	Terminate program	X	X	O	O	O	O	O	O
1 (1)	Read keyboard and echo	X	X	X	X	X	X	X	X
2 (2)	Display character	X	X	X	X	X	X	X	X
3 (3)	Auxiliary input	X	X	X	X	X	X	X	X
4 (4)	Auxiliary output	X	X	X	X	X	X	X	X
5 (5)	Print character	X	X	X	X	X	X	X	X
6 (6)	Direct console I/O	X	X	X	X	X	X	X	X
7 (7)	Direct console input without echo	X	X	X	X	X	X	X	X
8 (8)	Read keyboard without echo	X	X	X	X	X	X	X	X
9 (9)	Display string	X	X	X	X	X	X	X	X
A (10)	Buffered keyboard input	X	X	X	X	X	X	X	X
B (11)	Check keyboard status	X	X	X	X	X	X	X	X
C (12)	Flush buffer, do function	X	X	X	X	X	X	X	X
D (13)	Reset disk	X	X	X	X	X	X	X	X
E (14)	Select disk	X	X	X	X	X	X	X	X
F (15)	Open file	X	X	O	O	O	O	O	O
10 (16)	Close file	X	X	O	O	O	O	O	O
11 (17)	Search for first entry	X	X	O	O	O	O	O	O
12 (18)	Search for next entry	X	X	O	O	O	O	O	O
13 (19)	Delete file	X	X	O	O	O	O	O	O
14 (20)	Sequential read	X	X	O	O	O	O	O	O
15 (21)	Sequential write	X	X	O	O	O	O	O	O
16 (22)	Create file	X	X	O	O	O	O	O	O
17 (23)	Rename file	X	X	O	O	O	O	O	O
18 (24)	RESERVED	R	R	R	R	R	R	R	R
19 (25)	Get current disk	X	X	O	O	O	O	O	O
1A (26)	Set disk transfer address	X	X	X	X	X	X	X	X
1B (27)	Get default drive data	X	X	O	O	O	O	O	O
1C (28)	Get drive data	X	X	O	O	O	O	O	O
1D (29)	RESERVED	R	R	R	R	R	R	R	R
1E (30)	RESERVED	R	R	R	R	R	R	R	R
1F (31)	RESERVED	R	R	R	R	R	R	R	R
20 (32)	RESERVED	R	R	R	R	R	R	R	R
21 (33)	Random read	X	X	O	O	O	O	O	O
22 (34)	Random write	X	X	O	O	O	O	O	O
23 (35)	Get file size	X	X	O	O	O	O	O	O
24 (36)	Set random record field	X	X	O	O	O	O	O	O
25 (37)	Set interrupt vector	X	X	X	X	X	X	X	X
26 (38)	Create new program segment	X	X	X	X	X	X	X	X
27 (39)	Random block read	X	X	O	O	O	O	O	O
28 (40)	Random block write	X	X	O	O	O	O	C	O
29 (41)	Parse file name	X	X	C	O	O	O	O	O
2A (42)	Get date	X	X	X	X	X	X	X	X
2B (43)	Set date	X	X	X	X	X	X	X	X
2C (44)	Get time	X	X	X	X	X	X	X	X
2D (45)	Set time	X	X	X	X	X	X	X	X
2E (46)	Set/reset verify flag	X	X	X	X	X	X	X	X
2F (47)	Get DTA			X	X	X	X	X	X
30 (48)	Get DOS version number			X	X	X	X	X	X
31 (49)	Terminate but stay resident			X	X	X	X	X	X
32 (50)	RESERVED	R	R	R	R	R	R	R	R
33 (51)	Control-C check			X	X	X	X	X	X
34 (52)	RESERVED	R	R	R	R	R	R	R	R
35 (53)	Get interrupt vector			X	X	X	X	X	X
36 (54)	Get disk free space			X	X	X	X	X	X
37 (55)	RESERVED	R	R	R	R	R	R	R	R
38,0(56,0)	Get country			X	X	X	X	X	X
38,X(56,X)	Set country (X=cuntry code)					X	X	X	X
39 (57)	Create directory			X	X	X	X	X	X
3A (58)	Removed directory			X	X	X	X	X	X
3B (59)	Change current directory			X	X	X	X	X	X
3C (60)	Create file			X	X	X	X	X	X
3D (61)	Open file			X	X	E	E	E	E
3E (62)	Close file			X	X	X	X	X	X
3F (63)	Read file or device			X	X	X	X	X	X
40 (64)	Write file or device			X	X	X	X	X	X
41 (65)	Delete file			X	X	X	X	X	X
42 (66)	Move file pointer			X	X	X	X	X	X
43 (67)	Get/set file attributes			X	X	X	X	X	X
44,0(68,0)	IOCTL get data			X	X	X	X	X	X
44,1(68,1)	IOCTL set data			X	X	X	X	X	X
44,2(68,2)	IOCTL read character			X	X	X	X	X	X
44,3(68,3)	IOCTL write character			X	X	X	X	X	X

(Continued)

Table 3.001. Continued

		DOS Versions That Support the Function							
Func.Number	Function Name	1	1.1	2	2.1	3	3.1	3.2	3.3
44.4(68.4)	IOCTL read block			X	X	X	X	X	X
44.5(68.5)	IOCTL write block			X	X	X	X	X	X
44.6(68.6)	IOCTL get input status			X	X	X	X	X	X
44.7(68.7)	IOCTL get output status			X	X	X	X	X	X
44.8(68.8)	IOCTL is changeable?					X	X	X	X
44.9(68.9)	IOCTL is redirected block?						X	X	X
44.A(68.10)	IOCTL is redirected handle?						X	X	X
44.B(68.11)	IOCTL change retry count					X	X	X	X
44.C(68.12)	Generic IOCTL for handles							X	X
44.D(68.13)	Generic IOCTL for devices							X	X
44.E(68.14)	Get drive							X	X
44.F(68.15)	Set drive							X	X
45 (69)	Duplicate file handle			X	X	X	X	X	X
46 (70)	Force duplicate file handle			X	X	X	X	X	X
47 (71)	Get current directory			X	X	X	X	X	X
48 (72)	Allocate memory			X	X	X	X	X	X
49 (73)	Free allocated memory			X	X	X	X	X	X
4A (74)	SETBLOCK			X	X	X	X	X	X
4B.0(75.0)	Load and execute program			X	X	X	X	X	X
4B.3(75.3)	Load overlay			X	X	X	X	X	X
4C (76)	End process			X	X	X	X	X	X
4D (77)	Get return code of subprocess			X	X	X	X	X	X
4E (78)	Find first file			X	X	X	X	X	X
4F (79)	Find next file			X	X	X	X	X	X
50 (80)	RESERVED	R	R	R	R	R	R	R	R
51 (81)	RESERVED	R	R	R	R	R	R	R	R
52 (82)	RESERVED	R	R	R	R	R	R	R	R
53 (83)	RESERVED	R	R	R	R	R	R	R	R
54 (84)	Get verify state			X	X	X	X	X	X
55 (85)	RESERVED	R	R	R	R	R	R	R	R
56 (86)	Rename file			X	X	X	X	X	X
57 (87)	Get/set date/time of file			X	X	X	X	X	X
58 (88)	Get/set allocation strategy					X	X	X	X
59 (89)	Get extended error					X	X	X	X
5A (90)	Create temporary file					X	X	X	X
5B (91)	Create new file					X	X	X	X
5C.0(92.0)	Lock					X	X	X	X
5C.1(92.1)	Unlock					X	X	X	X
5D (93)	RESERVED	R	R	R	R	R	R	R	R
5E.0(94.0)	Get machine name						X	X	X
5E.2(94.2)	Printer set:up						X	X	X
5F.2(95.2)	Get assign list entry						X	X	X
5F.3(95.3)	Make assign list entry						X	X	X
5F.4(95.4)	Cancel assign list entry						X	X	X
60 (96)	RESERVED	R	R	R	R	R	R	R	R
61 (97)	RESERVED	R	R	R	R	R	R	R	R
62 (98)	Get PSP address					X	X	X	X
63 (99)	Get lead byte table				2.25*				
65 (101)	Get extended country information								X
66 (102)	Get/set global code page								X
67 (103)	Set handle count								X
68 (104)	Commit file								X

**Legend:** X=supported, O=supported but considered obsolete, E=extended from previous versions, R=reserved

**Version Info:** \*Note that function 63 (99) is available only in DOS 2.25

**Notes:** Function numbers with multiple values indicate that the AL register is also used to specify function (e.g. 5EH.1 represents function 5EH with the AL register set to 1)

**Source:** IBM DOS 3.3 Technical Reference, pages 6-6 to 6-7

**See Also:** 3.009-3.122. Individual INT 21H Functions

**3.002. INT 21H KEYBOARD FUNCTIONS SUMMARY**

<i>INT 21H Function #</i>	<i>Waits for Character</i>	<i>Echos Character</i>	<i>Interrupt on Ctrl-C</i>	<i>Buffer Register Used</i>
01 (1)	Yes	Yes	Yes	AL
06 (6)	No	No	No	AL
07 (7)	Yes	No	No	AL
08 (8)	Yes	No	Yes	AL
0A (10)	Yes	No	Yes	DS:DX=buffer address
0B (11)	Keyboard status only			
0C (12)	Varies upon function requested			
3F (63)	Yes	No	Yes	DS:DX=buffer address

**Notes:** Control-C checking can be turned off completely using function 33H

**Source:** IBM DOS 3.3 Technical Reference, pages 6-35, 6-52, 6-57 to 6-60, 6-62 to 6-64, 6-137 to 6-138

**See Also:** 3.010. Function 01H -- Read Keyboard and Echo  
 3.015. Function 06H -- Direct Console I/O  
 3.016. Function 07H -- Direct Console Input Without Echo  
 3.017. Function 08H -- Read Keyboard Without Echo  
 3.019. Function 0AH -- Buffered Keyboard Input  
 3.020. Function 0BH -- Check Keyboard Status  
 3.021. Function 0CH -- Flush Buffer, Read Keyboard  
 3.065. Function 3FH -- Read Using Handle

## 3.003. INT 21H FCB-ORIENTED FUNCTIONS SUMMARY

INT 21H Function #	Function Name	Type of FCB Used*	Replaced by Function #
F (15)	Open file	Unopened FCB	3DH -- open handle
10 (16)	Close file	Opened FCB	3EH -- close handle
11 (17)	Search for first entry	Unopened FCB	4EH -- find first file
12 (18)	Search for next entry	Unopened FCB**	4FH -- find next file
13 (19)	Delete file	Unopened FCB	41H -- delete file
14 (20)	Sequential read	Opened FCB	3FH -- read handle
15 (21)	Sequential write	Opened FCB	40H -- write handle
16 (22)	Create file	Unopened FCB	3CH -- create handle 5AH -- create temp file 5BH -- create new file
17 (23)	Rename file	Rename FCB	56H -- change dir entry
21 (33)	Random read	Opened FCB	3FH -- read handle
22 (34)	Random write	Opened FCB	40H -- write handle
23 (35)	Get file size	Unopened FCB	42H -- move file pointer
24 (36)	Set relative record	Opened FCB	42H -- move file pointer
27 (39)	Random block read	Opened FCB	3FH -- read handle
28 (40)	Random block write	Opened FCB	40H -- write handle

**Notes:**      \*Opened and unopened FCBs may also be extended if you need to set or are using the file attribute byte  
                   \*\*Must be unchanged from use of function 11H -- search for first entry

**Source:**      IBM DOS 3.3 Technical Reference, pages 6-35, 6-36, 6-67 to 6-80, 6-85 to 6-88, 6-91 to 6-94

**See Also:**     3.004. INT 21H Handle-oriented Functions Summary  
                   3.024. Function 0FH -- Open File With FCB  
                   3.025. Function 10H -- Close File With FCB  
                   3.026. Function 11H -- Find First Entry With FCB  
                   3.027. Function 12H -- Find Next Entry With FCB  
                   3.028. Function 13H -- Delete File With FCB  
                   3.029. Function 14H -- Sequential Read With FCB  
                   3.030. Function 15H -- Sequential Write With FCB  
                   3.031. Function 16H -- Create File With FCB  
                   3.032. Function 17H -- Rename File With FCB  
                   3.037. Function 21H -- Random Read With FCB  
                   3.038. Function 22H -- Random Write With FCB  
                   3.039. Function 23H -- Get File Size With FCB  
                   3.040. Function 24H -- Set Relative Record With FCB  
                   3.043. Function 27H -- Random Block Read With FCB  
                   3.044. Function 28H -- Random Block Write With FCB  
                   3.062. Function 3CH -- Create File  
                   3.063. Function 3DH -- Open File  
                   3.064. Function 3EH -- Close File  
                   3.065. Function 3FH -- Read Using Handle  
                   3.066. Function 40H -- Write Using Handle  
                   3.067. Function 41H -- Delete File  
                   3.068. Function 42H -- Move File Pointer  
                   3.097. Function 4EH -- Find First File  
                   3.098. Function 4FH -- Find Next File  
                   3.106. Function 5AH -- Create Temporary File  
                   3.107. Function 5BH -- Create New File  
                   3.123. Unopened FCB Format  
                   3.124. Opened FCB Format  
                   3.126. Rename FCB Format

## 3.004. INT 21H HANDLE-ORIENTED FUNCTIONS SUMMARY

INT 21H Function #	Function Name	Use
3C (60)	Create handle	Creates file for subsequent I/O; erases existing file, if any
3D (61)	Open handle	Readies file for I/O; assigns handle number
3E (62)	Close handle	Closes handle; frees handle number
3F (63)	Read handle	Reads from file at current pointer location
40 (64)	Write handle	Writes to file at current pointer location
41 (65)	Delete file	Deletes file
42 (66)	Move file pointer	Moves location of pointer in file
43 (67)	Get/set file attributes	Changes or retrieves attribute byte for file
45 (69)	Duplicate file handle	Assigns additional handle number to existing handle
46 (70)	Force duplicate file handle	Forces existing handle to refer to file that has a different handle
56 (86)	Rename file	Renames file
57 (87)	Get/set file date/time	Changes or retrieves Last Update time and date associated with file
5A (90)	Create temporary file	Creates file with unique name for subsequent I/O
5B (91)	Create new file	Creates file for subsequent I/O only if it does not already exist
67 (103)	Set handle count	Allows you to specify more than 20 handles (default maximum)
68 (104)	Commit file	Insures file is written to disk (flushes buffer)

**Notes:** The first five handle numbers are preassigned by DOS (See 3.130. Predefined Handles)

**Source:** IBM DOS 3.3 Technical Reference, pages 6-36, 6-37, 6-122 to 6-146, 6-186 to 6-187, 6-206 to 6-209, 6-213 to 6-215, 6-239 to 6-240

**See Also:** 3.003. INT 21H FCB-oriented Functions Summary  
 3.062. Function 3CH -- Create File  
 3.063. Function 3DH -- Open File  
 3.064. Function 3EH -- Close File  
 3.065. Function 3FH -- Read Using Handle  
 3.066. Function 40H -- Write Using Handle  
 3.067. Function 41H -- Delete File  
 3.068. Function 42H -- Move File Pointer  
 3.069. Function 43H, 00H -- Get File Attributes  
 3.070. Function 43H, 01H -- Set File Attributes  
 3.087. Function 45H -- Duplicate File Handle  
 3.088. Function 46H -- Force Duplicate File Handle  
 3.097. Function 4EH -- Find First File  
 3.098. Function 4FH -- Find Next File  
 3.100. Function 56H -- Rename File  
 3.101. Function 57H, 00H -- Get Date/Time of File  
 3.102. Function 57H, 01H -- Set Date/Time of File  
 3.106. Function 5AH -- Create Temporary File  
 3.107. Function 5BH -- Create New File  
 3.121. Function 67H -- Set Handle Count  
 3.122. Function 68H -- Commit File

**3.005. INT 21H IOCTL DEVICE-ORIENTED FUNCTIONS SUMMARY**

<i>INT 21H Func.Num.*</i>	<i>Function Name</i>	<i>Use</i>
44H.00H	Get data	Gets the device data word used to control device
44H.01H	Set data	Sets the device data word used to control device
44H.02H	Read character	Receives a character from character-oriented device
44H.03H	Write character	Sends a character to character-oriented device
44H.04H	Read block	Receives a block of data from block-oriented device
44H.05H	Write block	Sends a block of data to block-oriented device
44H.06H	Get input status	Checks input device for readiness
44H.07H	Get output status	Checks output device for readiness
44H.08H	Is changeable?	Reports whether block device contains removable media
*44H.09H	Is redirected block?	Reports whether block device is local or remote (network)
44H.0AH	Is redirected handle?	Reports whether handle referencing device is local or remote
44H.0BH	Change retry count	Sets number of retries and pause between them for a file-sharing device
44H.0CH	Generic IOCTL for handles	Sets or gets number of retries for printer devices
44H.0DH	Generic IOCTL for devices	Sets/gets block device parameters; writes/reads/formats/verifies tracks
44H.0EH	Get drive map	Reports logical drive mapping
44H.0FH	Set drive map	Sets logical to physical drive mapping

**Notes:** \*The first number is the AH function number, the second the AL subfunction number

**Source:** IBM DOS 3.3 Technical Reference, pages 6-36, 6-147 to 6-184

**See Also:** 3.004. INT 21H Handle-oriented Functions Summary  
 3.069. Function 43H, 00H -- Get File Attributes  
 3.070. Function 43H, 01H -- Set File Attributes  
 3.073. Function 44H, 02H -- IOCTL Read String  
 3.074. Function 44H, 03H -- IOCTL Write String  
 3.075. Function 44H, 04H -- IOCTL Read Block  
 3.076. Function 44H, 05H -- IOCTL Write Block  
 3.077. Function 44H, 06H -- IOCTL Get Input Status  
 3.078. Function 44H, 07H -- IOCTL Get Output Status  
 3.079. Function 44H, 08H -- IOCTL Is Removable?  
 3.080. Function 44H, 09H -- IOCTL Is Redirected Block?  
 3.081. Function 44H, 0AH -- IOCTL Is Redirected Handle?  
 3.082. Function 44H, 0BH -- IOCTL Change Retry Count  
 3.083. Function 44H, 0CH -- Generic IOCTL For Handles  
 3.084. Function 44H, 0DH -- Generic IOCTL For Devices  
 3.085. Function 44H, 0EH -- Get Logical Drive Map  
 3.086. Function 44H, 0FH -- Set Logical Drive Map  
 3.148. Reserved Device Names and Chain Order

## 3.006. INT 21H SYSTEM FUNCTIONS SUMMARY

INT 21H Function #	Function Name	Use
1A (26)	Set DTA	Make new disk transfer address
25 (37)	Set interrupt vector	Replace interrupt vector address in low memory
26 (38)	Create program segment	Make new program segment
2A (42)	Get system date	Retrieve current system date
2B (43)	Set system date	Store new system date
2C (44)	Get system time	Retrieve current system time
2D (45)	Set system time	Store new system time
2E (46)	Set/reset verify flag	Report or set verify flag state
2F (47)	Get DTA	Report current disk transfer address
30 (48)	Get DOS version number	Report DOS version being used
31 (49)	Keep process	End program execution but keep resident
33 (51)	Control-C check	Report or change Control-C check status
35 (53)	Get interrupt vector	Report address associated with Interrupt
36 (54)	Get disk free space	Report information about disk status
38 (56)	Get/set country code	Report or change country information
39 (57)	Create directory	Make a new directory on disk
3A (58)	Remove directory	Remove an existing directory from disk
3B (59)	Change current directory	Change to specified directory on disk
47 (71)	Get current directory	Report current directory on disk
48 (72)	Allocate memory	Get specified memory amount for use by program
49 (73)	Free allocated memory	Free memory currently being used by program
4A (74)	SETBLOCK	Change size of memory block being used
4B (75)	Load program or overlay	Load program and execute it, or load overlay
4C (76)	End process	End program execution and report errorlevel
4D (77)	Get return code	Get errorlevel report from child process
54 (84)	Get verify state	Report current verify flag setting
58 (88)	Get/set allocation strategy	Report or change memory allocation strategy used
59 (89)	Get extended error	Report details about last DOS function error
62 (98)	Get PSP address	Report current location of program segment prefix
65 (101)	Get/set extended country	Report or change country information
66 (102)	Get/set global code page	Report or change memory area used for country font info

**Source:** IBM DOS 3.3 Technical Reference, pages 6-35 to 6-37, 6-82, 6-89 to 6-90, 6-98 to 6-121, 6-188 to 6-201, 6-205, 6-210 to 6-212, 6-232 to 6-238

**See Also:** 3.034. Function 1AH -- Set Disk Transfer Address  
3.041: Function 25H -- Set Interrupt Vector  
3.042. Function 26H -- Create New Program Segment  
3.046. Function 2AH -- Get System Date  
3.047. Function 2BH -- Set System Date  
3.048. Function 2CH -- Get System Time  
3.049. Function 2DH -- Set System Time  
3.050. Function 2EH -- Set/Reset Verify Flag  
3.051. Function 2FH -- Get Disk Transfer Address  
3.052. Function 30H -- Get DOS Version  
3.053. Function 31H -- Keep Process  
3.054. Function 33H -- Control-C Check  
3.055. Function 35H -- Get Interrupt Vector  
3.056. Function 36H -- Get Disk Free Space  
3.057. Function 38H, 00H -- Get Country Data  
3.058. Function 38H, xxH -- Set Country Data  
3.059. Function 39H -- Create Subdirectory  
3.060. Function 3AH -- Remove Subdirectory  
3.061. Function 3BH -- Change Current Directory  
3.089. Function 47H -- Get Current Directory  
3.090. Function 48H -- Allocate Memory  
3.091. Function 49H -- Free Allocated Memory  
3.092. Function 4AH -- Set Block  
3.093. Function 4BH, 00H -- Load and Execute Program  
3.095. Function 4CH -- End Process  
3.096. Function 4DH -- Get Return Code  
3.099. Function 54H -- Get Verify State  
3.103. Function 58H, 00H -- Get Allocation Strategy  
3.104. Function 58H, 01H -- Set Allocation Strategy  
3.105. Function 59H -- Get Extended Error  
3.116. Function 62H -- Get Program Segment Prefix  
3.118. Function 65H -- Get Extended Country Info  
3.119. Function 66H, 01H -- Get Global Code Page  
3.120. Function 66H, 02H -- Set Global Code Page

**3.007. INT 21H NETWORK FUNCTIONS SUMMARY**

<i>INT 21H Function #</i>	<i>Function Name</i>	<i>Use</i>
44H,09H	Is redirected block?	Reports whether drive letter is local or remote (network)
44H,0AH	Is redirected handle?	Reports whether device name is local or remote (network)
5CH,00H	Lock file	Locks region of file from use by others
5CH,01H	Unlock file	Unlocks locked region of file (restores to public use)
5EH,00H	Get machine name	Reports network name of the workstation
5EH,02H	Printer setup	Defines string of characters to be sent with each file to printer
5FH,02H	Get assign list entry	Reports IDs and names of drives/devices reassigned to network
5FH,03H	Make assign list entry	Redirects local drive/device to a network directory/device
5FH,04H	Cancel assign list entry	Cancel redirection created with function 5F.03

**Version Info:** Network functions require DOS 3.1 or later

**Source:** IBM DOS 3.3 Technical Reference, pages 6-36, 6-37, 6-155 to 6-156, 6-216 to 6-231

**See Also:**

- 3.080. Function 44H, 09H -- IOCTL Is Redirected Block?
- 3.081. Function 44H, 0AH -- IOCTL Is Redirected Handle?
- 3.108. Function 5CH, 00H -- Lock File
- 3.109. Function 5CH, 01H -- Unlock File
- 3.110. Function 5EH, 00H -- Get Machine Name
- 3.111. Function 5EH, 02H -- Set Printer String
- 3.113. Function 5FH, 02H -- Get Assignment List Entry
- 3.114. Function 5FH, 03H -- Make Assignment List Entry
- 3.115. Function 5FH, 04H -- Cancel Assignment List Entry

**3.008. TYPICAL DOS REGISTER USE**

<i>Register</i>	<i>Standard Usage</i>	<i># Bits</i>	<i>Comments</i>
AX	General purpose data register	16	Passes MS-DOS parameters, returns error
AH	Function request register	8	Contains function number on call (INT 21H)
AL	Error return register	8	Returns error if carry flag set
BX	Data segment base register	16	Also returns data (e.g. handle number)
CX	Loop counter	16	Sometimes used for data passing
DX	General purpose data register	16	Often used as offset to DS for pointer to data
SP	Stack register	16	
IP	Instruction pointer register	16	
BP	Stack segment base register	16	
DS	Data segment of pointer	16	Normally used with DX
SS	Stack segment of pointer	16	Normally used with BX or CX
SI	Source index in string operations	16	
DI	Destination index in string ops	16	
Flags	Carry flag set=error; carry flag clear=no error	1	Used primarily by DOS 2.1 and later

**Source:** IBM DOS 3.3 Technical Reference, pages 6-8 to 6-9

**3.009. FUNCTION 00H -- TERMINATE PROGRAM**

*Prior to Calling Function*

	High	Low
AX	00H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS	Segment address of PSP*	
DS		
SS		
ES		

*Upon Return From Function*

Function does not return:  
 •File buffers flushed  
 •Termination handler address restored from PSP:000AH  
 •Ctrl-C exit address restored from PSP:000EH  
 •Critical error handler address restored from PSP:0012H\*\*  
 •Control passes to termination handler address

**Notes:** •Obsolete function; in DOS 2.x or later use function 31H or 4CH instead  
 •\*See 3.136. Program Segment Prefix Layout  
 •\*\*DOS versions 2.x and later only

**Source:** IBM DOS 3.3 Technical Reference, page 6-51

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.053. Function 31H -- Keep Process  
 3.095. Function 4CH -- End Process

**3.010. FUNCTION 01H -- READ KEYBOARD AND ECHO**

*Prior to Calling Function*

	High	Low
AX	01H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX		8-bit char code*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** •Function echoes characters to display; Control-C is enabled; waits for character to be input from standard input device  
 •Function is obsolete; in DOS 2.x or later use function 3FH instead  
 •\*Either 8-bit IBM ASCII code, or one of two bytes of an IBM Extended ASCII code

**Source:** MS-DOS 3.3 Programmer's Reference, page 6-52

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 1.21. ASCII Character Set  
 1.22. IBM ASCII Character Set  
 1.23. IBM Extended Character Codes  
 3.015. Function 06H -- Direct Console I/O  
 3.016. Function 07H -- Direct Console Input Without Echo  
 3.017. Function 08H -- Read Keyboard Without Echo  
 3.019. Function 0AH -- Buffered Keyboard Input  
 3.021. Function 0CH -- Flush Buffer, Read Keyboard  
 3.065. Function 3FH -- Read Using Handle

**3.011. FUNCTION 02H -- DISPLAY CHARACTER**

**Prior to Calling Function**

	High	Low
AX	02H	
BX		
CX		
DX		8-bit char to display
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

Function does not return any values

**Notes:**

- Obsolete function; in DOS 2.x or later use function 40H instead
- Cursor position updated; if character is a backspace (08H), the cursor is moved to the left one position, but the character there is not erased

**Source:** MS-DOS 3.3 Programmer's Reference, page 6-53

**See Also:**

- 1.22. IBM ASCII Character Set
- 1.23. IBM Extended Character Set
- 3.001. INT 21H Functions by DOS Version Summary
- 3.015. Function 06H -- Direct Console I/O
- 3.018. Function 09H -- Display String
- 3.066. Function 40H -- Write Using Handle

**3.012. FUNCTION 03H -- AUXILIARY INPUT**

**Prior to Calling Function**

	High	Low
AX	03H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		8-bit char from AUX
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:**

- This function does not check status of AUX port, buffer input, or return error codes
- Obsolete function; in DOS 2.x or later use function 3FH instead
- DOS initializes the standard auxiliary device to 2400 baud, no parity, one stop bit, and 8-bit words

**Source:** IBM DOS 3.3 Technical Reference, page 6-54

**See Also:**

- 1.21. ASCII Character Set
- 3.001. INT 21H Functions by DOS Version Summary
- 3.013. Function 04H -- Auxiliary Output
- 3.065. Function 3FH -- Read Using Handle

**3.013. FUNCTION 04H -- AUXILIARY OUTPUT**

**Prior to Calling Function**

	High	Low
AX	04H	
BX		
CX		
DX		8-bit char to AUX
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

Function does not return any values

- Notes:**
- This function does not check status of AUX port, buffer output, or return error codes
  - Obsolete function; in DOS 2.x or later use function 40H instead
- Source:** IBM DOS 3.3 Technical Reference, page 6-55
- See Also:**
- 3.001. INT 21H Functions by DOS Version Summary
  - 3.012. Function 03H -- Auxiliary Input
  - 3.066. Function 40H -- Write Using Handle

**3.014. FUNCTION 05H -- PRINT CHARACTER**

**Prior to Calling Function**

	High	Low
AX	05H	
BX		
CX		
DX		8-bit char to print
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

Function returns no values

- Notes:**
- This function does not check status of printer port, buffer output, or return error codes
  - Obsolete function; in DOS 2.x or later use function 40H instead
- Source:** IBM DOS 3.3 Technical Reference, page 6-56
- See Also:**
- 3.001. INT 21H Functions by DOS Version Summary
  - 3.066. Function 40H -- Write Using Handle

**3.015. FUNCTION 06H -- DIRECT CONSOLE I/O**

**Prior to Calling Function**

	High	Low
AX	06H	
BX		
CX		
DX		8-bit char or FFH*
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		8-bit char or 00H**
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	ZeroFlag set	
CS		
DS		
SS		
ES		

- Notes:**
- Obsolete function; in DOS 2.x and later use functions 3FH and 40H
  - \*If DL=FFH, console input is performed; otherwise DL is sent to console
  - \*\*If ZeroFlag is clear, AL contains character from console; otherwise AL = 0

**Source:** IBM DOS 3.3 Technical Reference, pages 6-57 to 6-58

- See Also:**
- 3.001. INT 21H Functions by DOS Version Summary
  - 3.002. INT 21H Keyboard Functions Summary
  - 3.010. Function 01H -- Read Keyboard and Echo
  - 3.011. Function 02H -- Display Character
  - 3.016. Function 07H -- Direct Console Input Without Echo
  - 3.017. Function 08H -- Read Keyboard Without Echo
  - 3.018. Function 09H -- Display String
  - 3.019. Function 0AH -- Buffered Keyboard Input
  - 3.021. Function 0CH -- Flush Buffer, Read Keyboard
  - 3.065. Function 3FH -- Read Using Handle
  - 3.066. Function 40H -- Write Using Handle

**3.016. FUNCTION 07H -- DIRECT CONSOLE INPUT WITHOUT ECHO***Prior to Calling Function*

	High	Low
AX	07H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX		8-bit char from CON
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:**

- Function does not echo character or check for Control-C
- Obsolete function; in DOS 2.x and later use function 3FH instead

**Source:** IBM DOS 3.3 Technical Reference, page 6-59

**See Also:**

- 3.001. INT 21H Functions by DOS Version Summary
- 3.002. INT 21H Keyboard Functions Summary
- 3.010. Function 01H -- Read Keyboard and Echo
- 3.015. Function 06H -- Direct Console I/O
- 3.017. Function 08H -- Read Keyboard Without Echo
- 3.019. Function 0AH -- Buffered Keyboard Input
- 3.021. Function 0CH -- Flush Buffer, Read Keyboard
- 3.065. Function 3FH -- Read Using Handle

**3.017. FUNCTION 08H -- READ KEYBOARD WITHOUT ECHO***Prior to Calling Function*

	High	Low
AX	08H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX		8-bit char from CON
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:**

- Function waits for and does not echo character
- Obsolete function; in DOS 2.x and later use function 3FH instead

**Source:** IBM DOS 3.3 Technical Reference, page 6-60

**See Also:**

- 3.001. INT 21H Functions by DOS Version Summary
- 3.002. INT 21H Keyboard Functions Summary
- 3.010. Function 01H -- Read Keyboard and Echo
- 3.015. Function 06H -- Direct Console I/O
- 3.016. Function 07H -- Direct Console Input Without Echo
- 3.019. Function 0AH -- Buffered Keyboard Input
- 3.021. Function 0CH -- Flush Buffer, Read Keyboard
- 3.065. Function 3FH -- Read Using Handle

**3.018. FUNCTION 09H -- DISPLAY STRING**

**Prior to Calling Function**

	High	Low
AX	09H	
BX		
CX		
DX	Offset of pointer to \$-terminated string	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to \$-terminated string	
SS		
ES		

**Upon Return From Function**

Function does not return a value

**Notes:** Obsolete function; in DOS 2.x and later use function 40H instead

**Source:** IBM DOS 3.3 Technical Reference, page 6-61

**See Also:** 1.17. Common String Formats  
 3.001. INT 21H Functions by DOS Version Summary  
 3.011. Function 02H -- Display Character  
 3.066. Function 40H -- Write Using Handle

**3.019. FUNCTION 0AH -- BUFFERED KEYBOARD INPUT**

**Prior to Calling Function**

	High	Low
AX	0AH	
BX		
CX		
DX	Offset of pointer to input buffer	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to input buffer	
SS		
ES		

**Upon Return From Function**

	High	Low
AX		
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Buffer** Max. length byte (non-zero), empty string

**Buffer** Contains max. length, actual length, string type

**Notes:** Obsolete function; in DOS 2.x or later use function 3FH instead

**Source:** IBM DOS 3.3 Technical Reference, page 6-62

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.010. Function 01H -- Read Keyboard and Echo  
 3.015. Function 06H -- Direct Console I/O  
 3.016. Function 07H -- Direct Console Input Without Echo  
 3.017. Function 08H -- Read Keyboard Without Echo  
 3.019. Function 0AH -- Buffered Keyboard Input  
 3.021. Function 0CH -- Flush Buffer, Read Keyboard  
 3.065. Function 3FH -- Read Using Handle

**3.020. FUNCTION 0BH -- CHECK KEYBOARD STATUS**

**Prior to Calling Function**

	High	Low
AX	0BH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Buffer status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:**           \*Obsolete function; in DOS 2.x and later use function 44H,6H instead  
                   \*\*00=no character in buffer; FFH=character pending in buffer

**Source:**           IBM DOS 3.3 Technical Reference, page 6-63

**See Also:**        3.001. INT 21H Functions by DOS Version Summary  
                   3.002. INT 21H Keyboard Functions Summary  
                   3.077. Function 44H, 06H -- IOCTL Get input Status

**3.021. FUNCTION 0CH -- FLUSH BUFFER, READ KEYBOARD**

**Prior to Calling Function**

	High	Low
AX	0CH	Keyboard function*
BX		
CX		
DX	Offset of pointer to buffer (if AL=0AH)	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to buffer (if AL=0AH)	
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Varies**
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Buffer**   Max. length, empty string (if AL=0AH)

**Buffer**   Max. length, actual length, string (if AL=0AH)

**Notes:**           \*Obsolete function; in DOS 2.x or later use function 3FH instead  
                   \*\*1, 6, 7, 8, or A are allowable keyboard functions and act just as do the INT 21H functions with the same number  
                   \*\*\*0=buffer was flushed, but no other processing was done. Otherwise, will be the same as for the INT21H function called by value in AL.

**Source:**           IBM DOS 3.3 Technical Reference, page 6-64

**See Also:**        3.001. INT 21H Functions by DOS Version Summary  
                   3.002. INT 21H Keyboard Functions Summary  
                   3.01C. Function 01H -- Read Keyboard and Echo  
                   3.015. Function 06H -- Direct Console I/O  
                   3.016. Function 07H -- Direct Console input Without Echo  
                   3.017. Function 08H -- Read Keyboard Without Echo  
                   3.019. Function 0AH -- Buffered Keyboard Input  
                   3.065. Function 3FH -- Read Using Handle

**3.022. FUNCTION 0DH -- RESET DISK**

*Prior to Calling Function*

	High	Low
AX	0DH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

Function returns no values

**Notes:** •Obsolete function; in DOS 2.x and later, effects on default drive and DTA are undocumented  
 •Function flushes all file buffers to disk  
 •Close all files first to update directory

**Source:** IBM DOS 3.3 Technical Reference, page 6-65

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.025. Function 10H -- Close File With FCB  
 3.064. Function 3EH -- Close File

**3.023. FUNCTION 0EH -- SELECT DISK**

*Prior to Calling Function*

	High	Low
AX	0EH	
BX		
CX		
DX		Drive number*
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX		# Logical drives**
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** •Note that the value returned in AL does not mean that all of the indicated logical drives are valid drives  
 •\*0=A, 1=B, and so on. Note that this is different than logical drive number  
 •\*\*Same value as LASTDRIVE= in CONFIG.SYS, or total number of devices, whichever is greater

**Source:** IBM DOS 3.3 Technical Reference, page 6-66

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.033. Function 19H -- Get Current Disk  
 3.137. Logical Drive Numbers

## 3.024. FUNCTION 0FH -- OPEN FILE WITH FCB

*Prior to Calling Function*

	High	Low
AX	0FH	
BX		
CX		
DX	Offset of pointer to unopened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to unopened FCB	
SS		
ES		

FCB	Drive Number	Logical drive number
	File Name	ASCII file name
	File Type	ASCII file extension
	Current Block	0
	Record Size	0
	File Size	0
	File Date	0
	File Time	0
	RESERVED	0
	Current Record	0
	Random Record #	0

*Upon Return From Function*

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

FCB	Drive Number	Actual drive number
	File Name	ASCII file name
	File Type	ASCII file extension
	Current Block	0
	Record Size	80H (128)
	File Size	Actual file size
	File Date	Last change date
	File Time	Last change time
	RESERVED	RESERVED
	Current Record	0
	Random Record #	0

**Version Info:** On networks file is opened in compatibility mode only

**Notes:**

- Obsolete function; in DOS 2.x or later use function 3DH instead
- '00=directory entry was found and opened; FFH=directory entry wasn't found

**Source:** IBM DOS 3.3 Technical Reference, pages 6-67 to 6-68

**See Also:**

- 3.001. INT 21H Functions by DOS Version Summary
- 3.003. INT 21H FCB-oriented Functions Summary
- 3.063. Function 3DH -- Open File
- 3.123. Unopened FCB Format
- 3.124. Opened FCB Format

**3.025. FUNCTION 10H -- CLOSE FILE WITH FCB**

**Prior to Calling Function**

	High	Low
AX	10H	
BX		
CX		
DX	Offset of pointer to opened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment address of pointer to opened FCB	
SS		
ES		

FCB	Drive Number	Do not change
	File Name	Do not change
	File Type	Do not change
	Current Block	Do not change
	Record Size	Do not change
	File Size	Do not change
	File Date	Do not change
	File Time	Do not change
	RESERVED	Do not change
	Current Record	Do not change
	Random Record #	Do not change

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

FCB

**Notes:** •Obsolete function, in DOS 2.x or later use function 3EH instead  
 \*00=directory entry found and closed; FFH=entry not found

**Source:** IBM DOS 3.3 Technical Reference, page 6-69

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.003. INT 21H FCB-oriented Functions Summary  
 3.064. Function 3EH -- Close File  
 3.124. Opened FCB Format

**3.026. FUNCTION 11H -- FIND FIRST ENTRY WITH FCB**

**Prior to Calling Function**

	High	Low
AX	11H	
BX		
CX		
DX	Offset of pointer to unopened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to unopened FCB	
SS		
ES		
DTA	Empty	

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		
DTA	Contains unopened FCB for file found	

FCB	Drive Number	Logical drive number
	File Name	ASCII file name**
	File Type	ASCII file type **
	Current Block	0
	Record Size	0
	File Size	0
	File Date	0
	File Time	0
	RESERVED	0
	Current Record	0
	Random Record #	0

FCB	Drive Number	Actual drive number
	File Name	ASCII file name**
	File Type	ASCII file type **
	Current Block	0
	Record Size	0
	File Size	0
	File Date	0
	File Time	0
	RESERVED	0
	Current Record	0
	Random Record #	0

**Version Info:** \*\*May contain ? wildcard character; may contain \* wildcard character in DOS 3.x

**Notes:**  
 •Obsolete function; with DOS 2.x or later use function 4EH instead  
 •You may use an extended FCB (unopened) to find files with a certain attribute  
 •\*00=directory entry found; FFH=entry not found

**Source:** IBM DOS 3.3 Technical Reference, pages 6-70 to 6-71

**See Also:**  
 3.001. INT 21H Functions by DOS Version Summary  
 3.003. INT 21H FCB-oriented Functions Summary  
 3.027. Function 12H -- Find Next Entry With FCB  
 3.097. Function 4EH -- Find First File  
 3.098. Function 4FH -- Find Next File  
 3.123. Unopened FCB Format  
 3.125. Extended FCB Format

**3.027. FUNCTION 12H -- FIND NEXT ENTRY WITH FCB**

**Prior to Calling Function**

	High	Low
AX	12H	
BX		
CX		
DX	Offset of pointer to unopened FCB**	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to unopened FCB**	
SS		
ES		
DTA	Empty	

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		
DTA	Unopened FCB of file found, if any	

FCB	Drive Number	Logical drive number
	File Name	ASCII file name***
	File Type	ASCII file type***
	Current Block	0
	Record Size	0
	File Size	0
	File Date	0
	File Time	0
	RESERVED	0
	Current Record	0
	Random Record #	0

FCB	Drive Number	Actual drive number
	File Name	ASCII file name***
	File Type	ASCII file type***
	Current Block	0
	Record Size	0
	File Size	0
	File Date	0
	File Time	0
	RESERVED	0
	Current Record	0
	Random Record #	0

**Version Info:**      \*\*\*May contain ? wildcard characters; in DOS 3.x may also contain \* wildcard characters

**Notes:**

- You may use extended FCBs (unopened) to search for file with a certain attribute
- Obsolete function; with DOS 2.x or later use function 4FH instead
- \*00=directory entry found; FFH=entry not found
- \*\*Must be unchanged FCB used previously with function 11H or function 12H

IBM DOS 3.3 Technical Reference, pages 6-72 to 6-73

**Source:**

**See Also:**

- 3.001. INT 21H Functions by DOS Version Summary
- 3.003. INT 21H FCB-oriented Functions Summary
- 3.026. Function 11H -- Find First Entry With FCB
- 3.097. Function 4EH -- Find First File
- 3.098. Function 4FH -- Find Next File
- 3.123. Unopened FCB Format
- 3.125. Extended FCB Format

**3.028. FUNCTION 13H -- DELETE FILE WITH FCB**

**Prior to Calling Function**

**Upon Return From Function**

	High	Low
AX	13H	
BX		
CX		
DX	Offset of pointer to unopened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to unopened FCB	
SS		
ES		

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

FCB Drive Number	Logical drive number
File Name	ASCII file name**
File Type	ASCII file extension**
Current Block	0
Record Size	0
File Size	0
File Date	0
File Time	0
RESERVED	0
Current Record	0
Random Record #	0

FCB No longer valid

- Version Info:** Requires create access rights on networks
- Notes:**
- Obsolete function; in DOS 2.x or later use function 41H instead
  - \*00=at least one matching file found and deleted;
  - FFH=no matching files found
  - \*\*May contain ? wildcard characters
- Source:** IBM DOS 3.3 Technical Reference, page 6-74
- See Also:**
- 3.001. INT 21H Functions by DOS Version Summary
  - 3.003. INT 21H FCB-oriented Functions Summary
  - 3.060. Function 3AH -- Remove Subdirectory
  - 3.067. Function 41H -- Delete File
  - 3.123. Unopened FCB Format

**3.029. FUNCTION 14H -- SEQUENTIAL READ WITH FCB**

**Prior to Calling Function**

	High	Low
AX	14H	
BX		
CX		
DX	Offset of pointer to opened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to opened FCB	
SS		
ES		

DTA 

Blank (size=one record of data)
---------------------------------

FCB	Drive Number	Actual drive number
	File Name	ASCII file name
	File Type	ASCII file extension
	Current Block	Current block**
	Record Size	128**
	File Size	Actual file size
	File Date	Last changed date
	File Time	Last changed time
	RESERVED	RESERVED
	Current Record	Current record**
	Random Record #	Not used

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

DTA 

One record of data (size=record size)
---------------------------------------

FCB	Drive Number	Unchanged
	File Name	Unchanged
	File Type	Unchanged
	Current Block	Incremented
	Record Size	Unchanged
	File Size	Unchanged
	File Date	Unchanged
	File Time	Unchanged
	RESERVED	RESERVED
	Current Record	Incremented
	Random Record #	Unchanged

**Version Info:** Requires read access rights on networks

**Notes:**  
 •Obsolete function; with DOS 2.x or later use function 3FH instead  
 \*\*0=successful read; 1=end of file; 2=DTA too small; 3=partial record read  
 (See 3.127. FCB Error Codes)  
 \*\*\*You may change these fields prior to calling function

**Source:** IBM DOS 3.3 Technical Reference, page 6-75

**See Also:**  
 3.001. INT 21H Functions by DOS Version Summary  
 3.003. INT 21H FCB-oriented Functions Summary  
 3.037. Function 21H -- Random Read With FCB  
 3.043. Function 27H -- Random Block Read With FCB  
 3.065. Function 3FH -- Read Using Handle  
 3.124. Opened FCB Format

**3.030. FUNCTION 15H -- SEQUENTIAL WRITE WITH FCB**

**Prior to Calling Function**

	High	Low
AX	15H	
BX		
CX		
DX	Offset of pointer to opened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to opened FCB	
SS		
ES		
DTA	Record of data (size must match record size)	

FCB Drive Number	Actual drive number
File Name	ASCII file name
File Type	ASCII file extension
Current Block	May be set to new record**
Record Size	128**
File Size	Actual file size
File Date	Date last changed
File Time	Time last changed
RESERVED	RESERVED
Current Record	May be set to new record**
Random Record #	Not used

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		
DTA	Unchanged data	

FCB Drive Number	Unchanged
File Name	Unchanged
File Type	Unchanged
Current Block	Incremented by call
Record Size	Unchanged
File Size	Unchanged
File Date	Unchanged
File Time	Unchanged
RESERVED	RESERVED
Current Record	Incremented by call
Random Record #	Unchanged

**Version Info:** Requires write access rights on networks

**Notes:** •Obsolete function; in DOS 2.x and later use function 40H instead  
 •\*0=successful write; 1=disk full; 2=DTA too small (See 3.127. FCB Error Codes)  
 •\*\*You may change these values prior to calling function

**Source:** IBM DOS 3.3 Technical Reference, page 6-76

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.003. INT 21H FCB-oriented Functions Summary  
 3.038. Function 22H -- Random Write With FCB  
 3.044. Function 28H -- Random Block Write With FCB  
 3.066. Function 40H -- Write Using Handle  
 3.124. Opened FCB Format

**3.031. FUNCTION 16H -- CREATE FILE WITH FCB**

**Prior to Calling Function**

	High	Low
AX	16H	
BX		
CX		
DX	Offset of pointer to unopened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to unopened FCB	
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

FCB	Drive Number	Logical drive number
	File Name	ASCII file name
	File Type	ASCII file extension
	Current Block	Must be 0
	Record Size	Must be 0
	File Size	Must be 0
	File Date	Must be 0
	File Time	Must be 0
	RESERVED	Must be 0
	Current Record	Must be 0
	Random Record #	Must be 0

FCB	Drive Number	Actual drive number
	File Name	Unchanged
	File Type	Unchanged
	Current Block	Set to 0
	Record Size	Set to 128
	File Size	Set to 0
	File Date	Set to current date
	File Time	Set to current time
	RESERVED	Set by call
	Current Record	Set to 0
	Random Record #	Set to 0

**Version Info:** Requires create access rights on networks

**Notes:** •Obsolete function; in DOS 2.x and later use function 3CH, 5AH, or 5BH  
 •\*00=file created; 0FFH=no more empty entries available  
 (See 3.127. FCB Error Codes)

**Source:** IBM DOS 3.3 Technical Reference, pages 6-77 to 6-78

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.003. INT 21H FCB-oriented Functions Summary  
 3.024. Function 0FH -- Open File With FCB  
 3.062. Function 3CH -- Create File  
 3.063. Function 3DH -- Open File  
 3.106. Function 5AH -- Create Temporary File  
 3.107. Function 5BH -- Create New File  
 3.123. Unopened FCB Format  
 3.124. Opened FCB Format

**3.032. FUNCTION 17H -- RENAME FILE WITH FCB**

**Prior to Calling Function**

	High	Low
AX	17H	
BX		
CX		
DX	Offset of pointer to rename FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to rename FCB	
SS		
ES		

FCB Drive Number	Logical drive number
First File Name	ASCII file name**
First File Type	ASCII file type**
Second File Name	ASCII file name**
Second File Type	ASCII file type**

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

FCB Drive Number	Actual drive number
First File Name	Unchanged
First File Type	Unchanged
Second File Name	Unchanged
Second File Type	Unchanged

**Version Info:** Requires create access rights on networks

**Notes:**  
 •Obsolete function; in DOS 2.x or later use function 56H instead.  
 \*GJ=at least one file renamed; FFH=no files renamed, or new name already exists  
 \*\*May contain ? wildcard characters

**Source:** IBM DOS 3.3 Technical Reference, pages 6-79 to 6-80

**See Also:**  
 3.001. INT 21H Functions by DOS Version Summary  
 3.003. INT 21H FCB-oriented Functions Summary  
 3.100. Function 56H -- Rename File  
 3.126. Rename FCB Format

**3.033. FUNCTION 19H -- GET CURRENT DISK**

**Prior to Calling Function**

	High	Low
AX	19H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Selected drive*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*0=A drive, 1=B drive, and so on

**Source:** IBM DOS 3.3 Technical Reference, page 6-81

**See Also:** 3.001. INT 21H Functions by DOS Version Summary

**3.034. FUNCTION 1AH -- SET DISK TRANSFER ADDRESS**

*Prior to Calling Function*

*Upon Return From Function*

	High	Low
AX	1AH	
BX		
CX		
DX	Offset of pointer to disk transfer address	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to disk transfer address	
SS		
ES		

Function returns no values

**Notes:** •DTA may not cross segment boundaries  
 •Default DTA is at 0080H in the PSP

**Source:** IBM DOS 3.3 Technical Reference, page 6-82

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.051. Function 2FH -- Get Disk Transfer Address

**3.035. FUNCTION 1BH -- GET DEFAULT DRIVE DATA**

*Prior to Calling Function*

*Upon Return From Function*

	High	Low
AX	1BH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX		Sectors per cluster
BX	Offset of pointer to FAT ID byte	
CX	Number of bytes per sector	
DX	Number of clusters per drive	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to FAT ID byte	
SS		
ES		

**Notes:** •The FAT ID byte is no longer adequate to identify the drive type (beginning DOS 2.x)  
 •Obsolete function; in DOS 2.x or later use function 36H instead

**Source:** IBM DOS 3.3 Technical Reference, page 6-83

**See Also:** 2.37. Disk ID Byte  
 3.001. INT 21H Functions by DOS Version Summary  
 3.036. Function 1CH -- Get Drive Data  
 3.056. Function 36H -- Get Disk Free Space  
 3.128. Extended Error Codes Returned from Function 59H

**3.036. FUNCTION 1CH -- GET DRIVE DATA**

**Prior to Calling Function**

	High	Low
AX	1CH	
BX		
CX		
DX		Logical drive number*
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Sectors per cluster**
BX		Offset of pointer to FAT ID byte
CX		Number of bytes per sector
DX		Number of clusters per drive
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		Segment of pointer to FAT ID byte
SS		
ES		

- Notes:**
- Obsolete function; in DOS 2.x or later use function 36H instead
  - The FAT ID byte is no longer adequate to identify the drive type (beginning DOS 2.x)
  - \*0=default, 1=A, 2=B, etc. (See 3.137. Logical Drive Numbers)
  - \*\*A value of FFH returned by call means the drive specified is invalid

**Source:** IBM DOS 3.3 Technical Reference, page 6-84

- See Also:**
- 2.37. FAT ID Byte
  - 3.001. INT 21H Functions by DOS Version Summary
  - 3.035. Function 1BH -- Get Default Drive Data
  - 3.056. Function 36H -- Get Disk Free Space
  - 3.137. Logical Drive Numbers

**3.037. FUNCTION 21H -- RANDOM READ WITH FCB**

**Prior to Calling Function**

	High	Low
AX	21H	
BX		
CX		
DX	Offset of pointer to opened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to opened FCB	
SS		
ES		

DTA **Blank memory to hold one record of data**

FCB Drive Number	Actual drive number
File Name	ASCII file name
File Type	ASCII file extension
Current Block	Will be set by call
Record Size	128**
File Size	As set by open file
File Date	As set by open file
File Time	As set by open file
RESERVED	As set by open file
Current Record	Will be set by call
Random Record #	Record to read

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

DTA **One record of data**

FCB Drive Number	Unchanged
File Name	Unchanged
File Type	Unchanged
Current Block	Set by call
Record Size	Unchanged
File Size	Unchanged
File Date	Unchanged
File Time	Unchanged
RESERVED	Unchanged
Current Record	Set by call
Random Record #	Incremented by call

**Version Info:** Requires read access rights on networks

**Notes:**

- Random record # is usually set by using function 24H
- Obsolete function; in DOS 2.x or later use function 3FH instead
- \*0=successful read; 1=end of file; 2=DTA too small; 3=partial record read (See 3.127. FCB Error Codes)
- \*\*You may change these fields prior to calling function

**Source:** IBM DOS 3.3 Technical Reference, page 6-85

**See Also:**

- 3.001. INT 21H Functions by DOS Version Summary
- 3.003. INT 21H FCB-oriented Functions Summary
- 3.029. Function 14H -- Sequential Read With FCB
- 3.040. Function 24H -- Set Relative Record With FCB
- 3.043. Function 27H -- Random Block Read With FCB
- 3.065. Function 3FH -- Read Using Handle
- 3.124. Opened FCB Format

**3.038. FUNCTION 22H -- RANDOM WRITE WITH FCB**

**Prior to Calling Function**

	High	Low
AX	22H	
BX		
CX		
DX	Offset of pointer to opened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to opened FCB	
SS		
ES		
DTA	One record of data to write to disk	

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		
DTA	Unchanged data	

FCB	Drive Number	Actual drive number
	File Name	ASCII file name
	File Type	ASCII file extension
	Current Block	Will be set by call
	Record Size	128**
	File Size	As set by open file
	File Date	As set by open file
	File Time	As set by open file
	RESERVED	As set by open file
	Current Record	Will be set by call
	Random Record #	Record to write**

FCB	Drive Number	Unchanged
	File Name	Unchanged
	File Type	Unchanged
	Current Block	Set by call
	Record Size	Unchanged
	File Size	Updated if size changes
	File Date	Updated to current date
	File Time	Updated to current time
	RESERVED	RESERVED
	Current Record	Set by call
	Random Record #	Incremented by call

**Version Info:** Requires write access rights on networks

**Notes:**

- Random record # is usually set with function 24H
- Obsolete function; in DOS 2.x or later use function 40H instead
- \*\*0=successful write; 1=disk full; 2=DTA too small (See 3.127. FCB Error Codes)
- \*\*\*You may change these fields prior to calling function

**Source:** IBM DOS 3.3 Technical Reference, page 6-86

**See Also:**

- 3.001. INT 21H Functions by DOS Version Summary
- 3.003. INT 21H FCB-oriented Functions Summary
- 3.030. Function 15H -- Sequential Write With FCB
- 3.040. Function 24H -- Set Relative Record With FCB
- 3.044. Function 28H -- Random Block Write With FCB
- 3.066. Function 40H -- Write Using Handle
- 3.124. Opened FCB Format

**3.039. FUNCTION 23H -- GET FILE SIZE WITH FCB**

**Prior to Calling Function**

	High	Low
AX	23H	
BX		
CX		
DX	Offset of pointer to unopened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to unopened FCB	
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

FCB Drive Number	Actual drive number
File Name	ASCII file name
File Type	ASCII file extension
Current Block	0
Record Size	Set to 1 or record size***
File Size	0
File Date	0
File Time	0
RESERVED	0
Current Record	0
Random Record #	0

FCB Drive Number	Unchanged
File Name	Unchanged
File Type	Unchanged
Current Block	Unchanged
Record Size	Unchanged
File Size	Unchanged
File Date	Unchanged
File Time	Unchanged
RESERVED	RESERVED
Current Record	Unchanged
Random Record #	Size of file in records**

**Notes:**

- Obsolete function; in DOS 2.x or later use function 42H instead
- \*0=file found; 0FFH=file not found
- \*\*Rounded up to next integer if partial record found
- \*\*\*Set to 1 to find file size in bytes

**Source:** IBM DOS 3.3 Technical Reference, page 6-87

**See Also:**

- 3.001. INT 21H Functions by DOS Version Summary
- 3.003. INT 21H FCB-oriented Functions Summary
- 3.068. Function 42H -- Move File Pointer
- 3.123. Unopened FCB Format

**3.040. FUNCTION 24H -- SET RELATIVE RECORD WITH FCB**

**Prior to Calling Function**

	High	Low
AX	24H	
BX		
CX		
DX	Offset of pointer to opened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to opened FCB	
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Always 00H
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

FCB Drive Number	Actual drive number
File Name	ASCII file name
File Type	ASCII file extension
Current Block	Set to block number*
Record Size	Set to record size*
File Size	Unchanged from open
File Date	Unchanged from open
File Time	Unchanged from open
RESERVED	Unchanged from open
Current Record	Set to record number*
Random Record #	Set to 0

FCB Drive Number	Unchanged
File Name	Unchanged
File Type	Unchanged
Current Block	Unchanged
Record Size	Unchanged
File Size	Unchanged
File Date	Unchanged
File Time	Unchanged
RESERVED	Unchanged
Current Record	Unchanged
Random Record #	Set to relative record

**Notes:** -Obsolete function; in DOS 2.x or later use function 42H instead  
 \*You must set these fields prior to calling function

**Source:** IBM DOS 3.3 Technical Reference, page 6-88

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.003. INT 21H FCB-oriented Functions Summary  
 3.068. Function 42H -- Move File Pointer  
 3.124. Opened FCB Format

**3.041. FUNCTION 25H -- SET INTERRUPT VECTOR**

*Prior to Calling Function*

*Upon Return From Function*

	<i>High</i>	<i>Low</i>
AX	25H	Interrupt number
BX		
CX		
DX	Offset of pointer to interrupt handler routine	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to interrupt handler routine	
SS		
ES		

Function returns no values

**Notes:** The four byte address of DS:DX is placed at appropriate place in the interrupt vector table

**Source:** IBM DOS 3.3 Technical Reference, page 6-89

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.055. Function 35H -- Get Interrupt Vector  
 7.04. PC Interrupt Usage

**3.042. FUNCTION 26H -- CREATE NEW PROGRAM SEGMENT**

*Prior to Calling Function*

*Upon Return From Function*

	<i>High</i>	<i>Low</i>
AX	26H	
BX		
CX		
DX	Segment address of new program segment	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Function returns no values

**Notes:** Obsolete function; in DOS 2.x or later use function 4BH instead

**Source:** IBM DOS 3.3 Technical Reference, page 6-90

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.093. Function 4BH. 00H -- Load and Execute Program

3.043. FUNCTION 27H -- RANDOM BLOCK READ WITH FCB

Prior to Calling Function

	High	Low
AX	27H	
BX		
CX	Number of blocks to read	
DX	Offset of pointer to opened FCB	
SP		
BP		
SI		
DI		
IP		
Flags		
CS		
DS	Segment of pointer to opened FCB	
SS		
ES		

DTA Blank memory to hold records of data

FCB	Drive Number	Actual drive number
	File Name	ASCII file name
	File Type	ASCII file extension
	Current Block	Will be set by call
	Record Size	128**
	File Size	As set by open file
	File Date	As set by open file
	File Time	As set by open file
	RESERVED	RESERVED
	Current Record	Will be set by call
	Random Record #	Starting record**

Upon Return From Function

	High	Low
AX		Status*
BX		
CX	Number of blocks actually read	
DX		
SP		
BP		
SI		
DI		
IP		
Flags		
CS		
DS		
SS		
ES		

DTA Data read

FCB	Drive Number	Unchanged
	File Name	Unchanged
	File Type	Unchanged
	Current Block	Set by call
	Record Size	Unchanged
	File Size	Unchanged
	File Date	Unchanged
	File Time	Unchanged
	RESERVED	RESERVED
	Current Record	Set by call
	Random Record #	Set to end block+1 by call

**Version Info:** Requires read access rights on networks

**Notes:**

- Obsolete function; in DOS 2.x or later use function 3FH instead
- Random record # is usually set by function 24H
- \*0=successful read; 1=end of file; 2=DTA too small; 3=partial record read (See 3.127. FCB Error Codes)
- \*\*You may change these fields prior to calling function

**Source:** IBM DOS 3.3 Technical Reference, pages 6-91 to 6-92

**See Also:**

- 3.001. INT 21H Functions by DOS Version Summary
- 3.003. INT 21H FCB-oriented Functions Summary
- 3.029. Function 14H -- Sequential Read With FCB
- 3.037. Function 21H -- Random Read With FCB
- 3.040. Function 24H -- Set Relative Record With FCB
- 3.044. Function 28H -- Random Block Write With FCB
- 3.065. Function 3FH -- Read Using Handle
- 3.124. Opened FCB Format

**3.044. FUNCTION 28H -- RANDOM BLOCK WRITE WITH FCB**

**Prior to Calling Function**

	High	Low
AX	28H	
BX		
CX	Number of blocks to write	
DX	Offset of pointer to opened FCB	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to opened FCB	
SS		
ES		
DTA	Data to be written to disk	
FCB	Drive Number	Actual drive number
	File Name	ASCII file name
	File Type	ASCII file extension
	Current Block	Will be set by call
	Record Size	128**
	File Size	As set by open file
	File Date	As set by open file
	File Time	As set by open file
	RESERVED	RESERVED
	Current Record	Will be set by call
	Random Record #	Starting record #**

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX	Number of blocks actually written	
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		
DTA	Unchanged	
FCB	Drive Number	Unchanged
	File Name	Unchanged
	File Type	Unchanged
	Current Block	Set by call
	Record Size	Unchanged
	File Size	Set if file size changes
	File Date	Set to current date
	File Time	Set to current time
	RESERVED	RESERVED
	Current Record	Set by call
	Random Record #	Set to end block+1 by call

**Version Info:** Requires write access rights on networks

**Notes:**

- Obsolete function; in DOS 2.x or later use function 40H instead
- If CX=0 prior to call, file size is truncated to value in random record # field
- Random record # is usually set with function 24H
- \*0=successful write; 1=disk full; 2=DTA too small (See 3.127. FCB Error Codes)
- \*\*You may change these fields prior to calling function

**Source:** IBM DOS 3.3 Technical Reference, pages 6-93 to 6-94

**See Also:**

- 3.001. INT 21H Functions by DOS Version Summary
- 3.003. INT 21H FCB-oriented Functions Summary
- 3.030. Function 15H -- Sequential Write With FCB
- 3.038. Function 22H -- Random Write With FCB
- 3.040. Function 24H -- Set Relative Record With FCB
- 3.043. Function 27H -- Random Block Read With FCB
- 3.066. Function 40H -- Write Using Handle
- 3.124. Opened FCB Format

3.045. FUNCTION 29H -- PARSE FILE NAME

**Prior to Calling Function**

	High	Low
AX	29H	Parse control byte
BX		
CX		
DX		
SP		
BP		
SI	Offset of pointer to string to parse	
DI	Offset of pointer to buffer to contain unopened FCB	
IP		
flags		
CS		
DS	Segment of pointer to string to parse	
SS		
ES	Segment of pointer to buffer for unopened FCB	
Buffer	Empty	

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI	Offset of pointer 1 byte past parsed string	
DI	Offset of pointer to unopened FCB	
IP		
flags		
CS		
DS	Segment of pointer 1 byte past parsed string	
SS		
ES	Segment of pointer to unopened FCB	
Buffer (FCB)	Drive Number	Logical drive number
	File Name	ASCII file name
	File Type	ASCII file type
	Current Block	0
	Record Size	0
	File Size	0
	File Date	0
	File Time	0
	RESERVED	0
	Current Record	0
	Random Record #	0

**Notes:** \*00=FCB created, no wildcard characters; 01=FCB created, wildcard characters used in file name; FFH=drive letter invalid

**Source:** IBM DOS 3.3 Technical Reference, pages 6-95 to 6-97

**See Also:** 2.51. Filename Separator Characters  
 3.001. INT 21H Functions by DOS Version Summary  
 3.123. Unopened FCB Format  
 3.142. Parse Control Byte

**3.046. FUNCTION 2AH -- GET SYSTEM DATE**

*Prior to Calling Function*

	High	Low
AX	2AH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX		Day of week*
BX		
CX		Year
DX	Month	Day
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*0=Sunday, 1=Monday, etc. (See 2.35. Date/Time Formats)

**Source:** IBM DOS 3.3 Technical Reference, page 6-98

**See Also:** 2.35. Date/Time Formats  
 3.001. INT 21H Functions by DOS Version Summary  
 3.047. Function 2BH -- Set System Date  
 3.048. Function 2CH -- Get System Time

**3.047. FUNCTION 2BH -- SET SYSTEM DATE**

**Prior to Calling Function**

	High	Low
AX	2BH	
BX		
CX	Year	
DX	Month	Day
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*00=valid date supplied; FFH=invalid date supplied

**Source:** IBM DOS 3.3 Technical Reference, page 6-99

**See Also:** 2.35. Date/Time Formats  
 3.001. INT 21H Functions by DOS Version Summary  
 3.046. Function 2AH -- Get System Date  
 3.049. Function 2DH -- Set System Time

**3.048. FUNCTION 2CH -- GET SYSTEM TIME**

**Prior to Calling Function**

	High	Low
AX	2CH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		
BX		
CX	Hour	Minutes
DX	Seconds	Hundredths
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** Hcur is in 24-hour clock format

**Source:** IBM DOS 3.3 Technical Reference, page 6-100

**See Also:** 2.35. Date/Time Formats  
 3.001. INT 21H Functions by DOS Version Summary  
 3.046. Function 2AH -- Get System Date  
 3.049. Function 2DH -- Set System Time

**3.049. FUNCTION 2DH -- SET SYSTEM TIME**

*Prior to Calling Function*

	High	Low
AX	2DH	
BX		
CX	Hour	Minutes
DX	Seconds	Hundredths
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*00=valid time supplied; FFH=invalid time supplied

**Source:** IBM DOS 3.3 Technical Reference, page 6-101

**See Also:** 2.35. Date/Time Formats  
 3.001. INT 21H Functions by DOS Version Summary  
 3.047. Function 2BH -- Set System Date  
 3.048. Function 2CH -- Get System Time

**3.050. FUNCTION 2EH -- SET/RESET VERIFY FLAG**

*Prior to Calling Function*

	High	Low
AX	2EH	Verify flag*
BX		
CX		
DX		00H**
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

Function returns no values

**Version Info:** Verification is not supported for network disk writes in DOS 3.x

**Notes:** \*00=do not verify after writes; 01=verify after writes  
 \*\*DOS 1.x and 2.x only

**Source:** IBM DOS 3.3 Technical Reference, page 6-102

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.099. Function 54H -- Get Verify State

**3.051. FUNCTION 2FH -- GET DISK TRANSFER ADDRESS**

**Prior to Calling Function**

	High	Low
AX	2FH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		
BX	Offset of pointer to disk transfer address	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to disk transfer address	

- Notes:** Default DTA is at 0080H in the PSP.
- Source:** IBM DOS 3.3 Technical Reference, page 6-103
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.034. Function 1AH -- Set Disk Transfer Address

**3.052. FUNCTION 30H -- GET DOS VERSION**

**Prior to Calling Function**

	High	Low
AX	30H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Minor version #	Major version #
BX	OEM number	High order serial #
CX	Low order word of 24-bit serial number	
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

- Version Info:** Applies only to versions of DOS 2.0 and later
- Notes:** \*OEM and serial numbers may not be present.(returns 0000H)  
\*If AL=0 on return, then version is assumed to be prior to 2.0
- Source:** IBM DOS 3.3 Technical Reference, page 6-104
- See Also:** 3.001. INT 21H Functions by DOS Version Summary

**3.053. FUNCTION 31H -- KEEP PROCESS**

**Prior to Calling Function**

	High	Low
AX	31H	Return code*
BX		
CX		
DX	# of paragraphs of memory to keep resident	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

Function returns no values

- Version Info:** Applies to all versions of DOS beginning with 2.0
- Notes:** \*Open files are not closed by this function  
\*\*You establish return codes. By convention 00=no error.
- Source:** IBM DOS 3.3 Technical Reference, pages 6-105 to 6-106
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.093. Function 4BH, 00H -- Load and Execute Program  
3.095. Function 4CH -- End Process  
3.096. Function 4DH -- Get Return Code

**3.054. FUNCTION 33H -- CONTROL-C CHECK**

**Prior to Calling Function**

	High	Low
AX	33H	0=get, 1=set state, 2=exchange state with DL
BX		
CX		
DX		0=OFF, 1=ON (if AL=1,2)
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		0=OFF, 1=ON (if AL=0,2)
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

- Version Info:** Applies to all versions of DOS beginning with 2.0
- Notes:** \*FFH=error (AL did not contain 0, 1, or 2 on call)
- Source:** IBM DOS 3.3 Technical Reference, page 6-107
- See Also:** 3.001. INT 21H Functions by DOS Version Summary

**3.055. FUNCTION 35H -- GET INTERRUPT VECTOR**

**Prior to Calling Function**

	High	Low
AX	35H	Interrupt number
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		
BX	Offset of pointer to interrupt routine*	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to interrupt routine*	

- Version Info:** Applies to all versions of DOS beginning with 2.0
- Notes:** \*If ES:BX = 0 then no handler is associated with this interrupt
- Source:** IBM DOS 3.3 Technical Reference, page 6-108
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.041. Function 25H -- Set Interrupt Vector  
7.04. PC Interrupt Usage

**3.056. FUNCTION 36H -- GET DISK FREE SPACE**

**Prior to Calling Function**

	High	Low
AX	36H	
BX		
CX		
DX		Logical drive number**
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Sectors per cluster*	
BX	Number of available clusters	
CX	Number of bytes per sector	
DX	Number of clusters per drive	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

- Version Info:** Applies to all versions of DOS beginning with 2.0
- Notes:** \*Or FFFFH if invalid drive was specified in DL  
\*\*0=default, 1=A, and so on
- Source:** IBM DOS 3.3 Technical Reference, page 6-109
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.035. Function 1BH -- Get Default Drive Data  
3.036. Function 1CH -- Get Drive Data  
3.137. Logical Drive Numbers

**3.057. FUNCTION 38H, 00H -- GET COUNTRY DATA**

*Prior to Calling Function*

	High	Low
AX	38H	0
BX		
CX		
DX	Offset of pointer to 32-byte buffer	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to 32-byte buffer	
SS		
ES		

Buffer

*Upon Return From Function*

	High	Low
AX	Error code (if carry flag set)	
BX	Country code (if carry flag clear)	
CX		
DX	Offset to country info buffer	
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS	Segment of country info buffer	
SS		
ES		

Buffer

- Version Info:** Applies to all versions of DOS beginning with 2.0
- Notes:** \*Carry flag set if error occurs
- Source:** IBM DOS 3.3 Technical Reference, pages 6-110 to 6-118
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.058. Function 38H, xxH -- Set Country Data  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.143. Country Code Buffer Layout  
 3.144. Country Codes

**3.058. FUNCTION 38H, xxH -- SET COUNTRY DATA**

*Prior to Calling Function*

	High	Low
AX	38H	Country code or FFH
BX	Country code if AL=FFH	
CX		
DX	FFFFH	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	FFFFH	
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry flag set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

- Version Info:** Applies to all versions of DOS beginning with 3.0
- Notes:** \*Carry flag set if error occurs
- Source:** IBM DOS 3.3 Technical Reference, pages 6-110 to 6-118
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.057. Function 38H, 00H -- Get Country Data  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.144. Country Codes

**3.059. FUNCTION 39H -- CREATE SUBDIRECTORY**

**Prior to Calling Function**

	<i>High</i>	<i>Low</i>
AX	39H	
BX		
CX		
DX	Offset of pointer to pathname string	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname string	
SS		
ES		

**Upon Return From Function**

	<i>High</i>	<i>Low</i>
AX	Error code (if carry flag set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:**     •Applies to all versions of DOS beginning with 2.0  
                           •Requires create access rights on networks

**Notes:**            •Pathname must be in ASCIIZ form  
                           •Carry flag set if error occurs

**Source:**            IBM DOS 3.3 Technical Reference, page 6-119

**See Also:**          3.001. INT 21H Functions by DOS Version Summary  
                           3.060. Function 3AH -- Remove Subdirectory  
                           3.061. Function 3BH -- Change Current Directory  
                           3.089. Function 47H -- Get Current Directory  
                           3.105. Function 59H -- Get Extended Error  
                           3.128. Extended Error Codes Returned from Function 59H

**3.060. FUNCTION 3AH -- REMOVE SUBDIRECTORY**

**Prior to Calling Function**

	High	Low
AX	3AH	
BX		
CX		
DX	Offset of pointer to pathname string	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname string	
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry flag set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** •Applies to all versions of DOS beginning with 2.0  
 •Requires create access rights on networks

**Notes:** •Pathname must be in ASCIIZ form  
 •\*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-120

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.059. Function 39H -- Create Subdirectory  
 3.061. Function 3BH -- Change Current Directory  
 3.089. Function 47H -- Get Current Directory  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.061. FUNCTION 3BH -- CHANGE CURRENT DIRECTORY**

**Prior to Calling Function**

	High	Low
AX	3BH	
BX		
CX		
DX	Offset of pointer to pathname string	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname string	
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry flag set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:**  
 \*Pathname must be in ASCIIZ form  
 \*Pathname string is limited to 64 characters and may not contain a network path  
 \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-121

**See Also:**  
 3.001. INT 21H Functions by DOS Version Summary  
 3.089. Function 47H -- Get Current Directory  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.062. FUNCTION 3CH -- CREATE FILE**

*Prior to Calling Function*

	High	Low
AX	3CH	
BX		
CX	0	File attribute byte
DX	Offset of pointer to pathname string	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname string	
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Handle or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** •Applies to all versions of DOS beginning with 2.0  
 •Requires create access rights on networks

**Notes:** •Pathname must be in ASCIIZ form  
 •File is truncated if it already exists  
 •Volume and subdirectory bits are ignored in attribute byte  
 •Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-122 to 6-123

**See Also:** 2.34. File Attribute Byte  
 3.001. INT 21H Functions by DOS Version Summary  
 3.031. Function 15H -- Create File With FCB  
 3.069. Function 43H, 00H -- Get File Attributes  
 3.070. Function 43H, 01H -- Set File Attributes  
 3.105. Function 59H -- Get Extended Error  
 3.106. Function 5AH -- Create Temporary File  
 3.107. Function 5BH -- Create New File  
 3.128. Extended Error Codes Returned from Function 59H

**3.063. FUNCTION 3DH -- OPEN FILE**

*Prior to Calling Function*

	High	Low
AX	3DH	Access code**
BX	Handle	
CX		
DX	Offset of pointer to pathname string	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname string	
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Handle or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:**  
 •Pathname must be in ASCIIZ form  
 \*\*Carry flag set if error occurs  
 \*\*AL=0 read only, AL=1 write only, AL=2 read/write

**Source:** IBM DOS 3.3 Technical Reference, pages 6-124 to 6-125

**See Also:**  
 3.001. INT 21H Functions by DOS Version Summary  
 3.024. Function 0FH -- Open File With FCB  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.129. Handle Access Byte

**3.064. FUNCTION 3EH -- CLOSE FILE**

*Prior to Calling Function*

	High	Low
AX	3EH	
BX	Handle	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry flag set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-136

**See Also:**  
 3.001. INT 21H Functions by DOS Version Summary  
 3.025. Function 10H -- Close File With FCB  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.130. Predefined Handles

**3.065. FUNCTION 3FH -- READ USING HANDLE**

**Prior to Calling Function**

	High	Low
AX	3FH	
BX	Handle	
CX	Number of bytes to read	
DX	Offset of pointer to empty buffer for data	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to empty buffer for data	
SS		
ES		

Buffer

**Upon Return From Function**

	High	Low
AX	Bytes read** or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

Buffer

**Version Info:**      •Applies to all versions of DOS beginning with 2.0  
                           •Requires read access rights on networks

**Notes:**             •\*Carry flag set if error occurs  
                           •\*\*A value of 0 indicates attempt to read at EOF

**Source:**            IBM DOS 3.3 Technical Reference, pages 6-137 to 6-138

**See Also:**           3.001. INT 21H Functions by DOS Version Summary  
                           3.029. Function 14H -- Sequential Read With FCB  
                           3.037. Function 21H -- Random Read With FCB  
                           3.043. Function 27H -- Random Block Read With FCB  
                           3.105. Function 59H -- Get Extended Error  
                           3.128. Extended Error Codes Returned from Function 59H

**3.066. FUNCTION 40H -- WRITE USING HANDLE**

*Prior to Calling Function*

	High	Low
AX	40H	
BX	Handle	
CX	Number of bytes to write***	
DX	Offset of pointer to buffer containing data	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to buffer containing data	
SS		
ES		
Buffer	Data to write	

*Upon Return From Function*

	High	Low
AX	Bytes written** or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		
Buffer	Unchanged data	

**Version Info:**      •Applies to all versions of DOS beginning with 2.0  
                              •Requires write access rights on networks

**Notes:**                •\*Carry flag set if error occurs  
                              •\*\*A value of 0 indicates disk is full  
                              •\*\*\*If 0, file is truncated at the pointer position

**Source:**                IBM DOS 3.3 Technical Reference, pages 6-139 to 6-140

**See Also:**              3.001. INT 21H Functions by DOS Version Summary  
                              3.030. Function 15H -- Sequential Write With FCB  
                              3.038. Function 22H -- Random Write With FCB  
                              3.044. Function 28H -- Random Block Write With FCB  
                              3.105. Function 59H -- Get Extended Error  
                              3.128. Extended Error Codes Returned from Function 59H

**3.067. FUNCTION 41H -- DELETE FILE**

**Prior to Calling Function**

	High	Low
AX	41H	
BX		
CX		
DX	Offset of pointer to pathname string	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname string	
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version info:**      •Applies to all versions of DOS beginning with 2.0  
                           •Requires create access rights on networks

**Notes:**             •Pathname must be in ASCIIZ format  
                           •\*Carry flag set if error occurs

**Source:**            IBM DOS 3.3 Technical Reference, pages 6-141 to 6-142

**See Also:**         1.17. Common String Formats  
                           3.001. INT 21H Functions by DOS Version Summary  
                           3.028. Function 13H -- Delete File with FCB  
                           3.060. Function 3AH -- Remove Subdirectory  
                           3.105. Function 59H -- Get Extended Error  
                           3.128. Extended Error Codes Returned from Function 59H

**3.068. FUNCTION 42H -- MOVE FILE POINTER**

**Prior to Calling Function**

	High	Low
AX	42H	Movement method**
BX	Handle	
CX	High order of offset to move pointer (in bytes)	
DX	Low order of offset to move pointer	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	LO position, or error code (if carry set)	
BX		
CX		
DX	High order position of pointer in file	
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

- Version Info:** Applies to all versions of DOS beginning with 2.0
- Notes:**
- \*You can find the size of a file by setting AL=2 and CX:DX=0
  - \*\*Carry flag set if error occurs
  - \*\*\*0=move pointer to record CX:DX; 1=move pointer to current plus CX:DX; 2=move pointer to EOF plus CX:DX
- Source:** IBM DOS 3.3 Technical Reference, pages 6-143 to 6-144
- See Also:**
- 3.001. INT 21H Functions by DOS Version Summary
  - 3.040. Function 24H -- Set Relative Record With FCB
  - 3.105. Function 59H -- Get Extended Error
  - 3.128. Extended Error Codes Returned from Function 59H
  - 3.131. Handle Pointer Movement Methods

**3.069. FUNCTION 43H,00H -- GET FILE ATTRIBUTES**

**Prior to Calling Function**

	High	Low
AX	43H	0
BX		
CX		
DX	Offset of pointer to pathname string	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname string	
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX	0	Attribute byte
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

- Version Info:** Applies to all versions of DOS beginning with 2.0
- Notes:**
- \*Pathname must be in ASCIIZ format
  - \*\*Carry flag set if error occurs
- Source:** IBM DOS 3.3 Technical Reference, pages 6-145 to 6-146
- See Also:**
- 1.17. Common String Formats
  - 2.34. File Attribute Byte
  - 3.001. INT 21H Functions by DOS Version Summary
  - 3.105. Function 59H -- Get Extended Error
  - 3.128. Extended Error Codes Returned from Function 59H

**3.070. FUNCTION 43H, 01H -- SET FILE ATTRIBUTES**

**Prior to Calling Function**

	High	Low
AX	43H	1
BX		
CX	0	Attribute byte
DX	Offset of pointer to pathname string	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname string	
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** •Applies to all versions of DOS beginning with 2.0  
 •Requires Create access rights on networks to change any bit other than the archive bit (bit 5)

**Notes:** •Pathname must be in ASCIIZ format  
 •You can't change the volume or directory bits of an Attribute Byte  
 •Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-145 to 6-146

**See Also:** 1.17. Common String Formats  
 2.34. File Attribute Byte  
 3.001. INT 21H Functions by DOS Version Summary  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.071. FUNCTION 44H,00H -- GET IOCTL DATA**

**Prior to Calling Function**

	High	Low
AX	44H	0
BX	Handle	
CX		
DX	0	0
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX	Device data word (if carry clear)	
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-148 to 6-150

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.072. Function 44H, 01H -- Set IOCTL Data  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.133. Device Data Word

**3.072. FUNCTION 44H, 01H -- SET IOCTL DATA**

*Prior to Calling Function*

	High	Low
AX	44H	1
BX	Handle	
CX		
DX	0	Device data
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-148 to 6-150

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.071. Function 44H, 00H -- Get IOCTL Data  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.133. Device Data Word

**3.073. FUNCTION 44H, 02H -- IOCTL READ STRING**

*Prior to Calling Function*

	High	Low
AX	44H	2
BX	Handle	
CX	Number of bytes to read from handle	
DX	Offset of pointer to empty buffer	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to empty buffer	
SS		
ES		
Buffer	Empty	

*Upon Return From Function*

	High	Low
AX	Bytes read or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		
Buffer	Data read from device	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-151

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.074. Function 44H, 03H -- IOCTL Write String  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.074. FUNCTION 44H, 03H -- IOCTL WRITE STRING**

*Prior to Calling Function*

	High	Low
AX	44H	3
BX	Handle	
CX	Number of bytes to write to handle	
DX	Offset of pointer to buffer of data to write	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to buffer of data to write	
SS		
ES		
Buffer	Data to write	

*Upon Return From Function*

	High	Low
AX	Bytes written or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		
Buffer	Unchanged data	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-151

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.073. Function 44H,02H -- IOCTL Read String  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.075. FUNCTION 44H,04H -- IOCTL READ BLOCK**

*Prior to Calling Function*

	High	Low
AX	44H	4
BX	Logical drive number**	
CX	Number of bytes to read from drive	
DX	Offset of pointer to empty buffer	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to empty buffer	
SS		
ES		
Buffer	Empty	

*Upon Return From Function*

	High	Low
AX	Bytes read or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		
Buffer	Data read from drive	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*\*Carry flag set if error occurs  
 \*\*Drive 0=default, drive 1=A, and so on

**Source:** IBM DOS 3.3 Technical Reference, page 152

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.076. Function 44H,05H -- IOCTL Write Block  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.137. Logical Drive Numbers

**3.076. FUNCTION 44H, 05H -- IOCTL WRITE BLOCK**

*Prior to Calling Function*

	High	Low
AX	44H	5
BX	Logical drive number**	
CX	Number of bytes to write to drive	
DX	Offset of pointer to buffer of data to write	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to buffer of data to write	
SS		
ES		
Buffer	Data to write	

*Upon Return From Function*

	High	Low
AX	Bytes written or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		
Buffer	Unchanged data	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs  
 \*\*Drive 0=default, drive 1=A, and so on

**Source:** IBM DOS 3.3 Technical Reference, page 6-152

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.075. Function 44H,04H -- IOCTL Read Block  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.137. Logical Drive Numbers

**3.077. FUNCTION 44H, 06H -- IOCTL GET INPUT STATUS**

*Prior to Calling Function*

	High	Low
AX	44H	6
BX	Handle	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*For character devices: 00=not ready, FF=ready  
 For block devices: 00=pointer at EOF, FF=ready

**Source:** IBM DOS 3.3 Technical Reference, page 6-153

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.078. Function 44H, 07H -- IOCTL Get Output Status  
 3.105. Function: 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.078. FUNCTION 44H, 07H -- IOCTL GET OUTPUT STATUS**

**Prior to Calling Function**

	High	Low
AX	44H	7
BX	Handle	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

- Version Info:** Applies to all versions of DOS beginning with 2.0
- Notes:** \*For character devices: 00=not ready, FF=ready  
For block devices: 00=not ready, FF=ready
- Source:** IBM DOS 3.3 Technical Reference, page 6-153
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.077. Function 44H, 06H -- IOCTL Get Input Status  
3.105. Function 59H -- Get Extended Error  
3.128. Extended Error Codes Returned from Function 59H

**3.079. FUNCTION 44H, 08H -- IOCTL IS REMOVABLE?**

**Prior to Calling Function**

	High	Low
AX	44H	8
BX		Logical drive number
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Status** or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

- Version Info:** Applies to all versions of DOS beginning with 3.0
- Notes:** \*Carry flag set if error occurs  
\*\*00=removable media; 01=media not removable; 0FH = invalid device
- Source:** IBM DOS 3.3 Technical Reference, page 6-154
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.105. Function 59H -- Get Extended Error  
3.128. Extended Error Codes Returned from Function 59H  
3.137. Logical Drive Numbers

**3.080. FUNCTION 44H, 09H -- IOCTL IS REDIRECTED BLOCK?**

*Prior to Calling Function*

	High	Low
AX	44H	9
BX		Logical drive number
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX	Device attribute code**	
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 3.1

**Notes:** \*Carry flag set if error occurs  
\*\*Bit 12 set=remote device; bit 12 clear=local device

**Source:** IBM DOS 3.3 Technical Reference, page 6-155

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.081. Function 44H,0AH -- IOCTL Is Redirected Handle?  
3.105. Function 59H -- Get Extended Error  
3.128. Extended Error Codes Returned from Function 59H  
3.137. Logical Drive Numbers  
3.150. Device Attribute Codes

**3.081. FUNCTION 44H, 0AH -- IOCTL IS REDIRECTED HANDLE?**

*Prior to Calling Function*

	High	Low
AX	44H	0AH
BX		Handle
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX	Device attribute code**	
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 3.1

**Notes:** \*Carry flag set if error occurs  
\*\*Bit 15 set=remote device; bit 15 clear=local device

**Source:** IBM DOS 3.3 Technical Reference, page 6-156

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.080. Function 44H, 09H -- IOCTL Is Redirected Block?  
3.105. Function 59H -- Get Extended Error  
3.128. Extended Error Codes Returned from Function 59H  
3.137. Logical Drive Numbers  
3.150. Device Attribute Codes

**3.082. FUNCTION 44H, 0BH -- IOCTL CHANGE RETRY COUNT**

**Prior to Calling Function**

	High	Low
AX	44H	0BH
BX		
CX	Number of loops to wait between retries	
DX	Number of times to retry operation	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

**Version Info:** •Applies to all versions of DOS beginning with 3.0

**Notes:** •\*Carry flag set if error occurs  
 •A loop is 65,536 machine cycles, and is coded as follows:  
 xor cx, cx  
 loop \$ ;loop 64K times  
 •Default is 1 loop, 3 retries

**Source:** IBM DOS 3.3 Technical Reference, pages 6-157 to 6-158

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

3.083. FUNCTION 44H, 0CH -- GENERIC IOCTL FOR HANDLES

*Prior to Calling Function*

	High	Low
AX	44H	0CH
BX	Handle	
CX	Major code**	Minor code***
DX	Offset of pointer to data buffer	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to data buffer	
SS		
ES		

Buffer 

Code page parm block or iteration count
-----------------------------------------

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

Buffer 

Code page parm block or iteration count
-----------------------------------------

**Version Info:**  
 •Applies to all versions of DOS beginning with 3.2  
 •Code page settings apply to DOS 3.3 only

**Notes:**  
 •\*Carry flag set if error occurs  
 •\*\*Major code is one of: 0 = unknown  
 1 = COMx  
 3 = CON  
 5 = LPTx  
 •\*\*\*Minor code is one of: 45H = set iteration count  
 4AH = select  
 4CH = prepare start  
 4DH = prepare end  
 65H = get iteration count  
 6AH = query selected  
 6BH = query prepare list

**Source:** IBM DOS 3.3 Technical Reference, pages 6-158 to 6-166

**See Also:**  
 3.001. INT 21H Functions by DOS Version Summary  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.146. Code Page Parameter Blocks  
 3.151. Device Request Header Status Field & Error Codes

**3.084. FUNCTION 44H, 0DH -- GENERIC IOCTL FOR DEVICES**

**Prior to Calling Function**

	High	Low
AX	44H	0DH
BX		Logical drive number
CX	8	Function code**
DX	Offset of pointer to parameter block	

SP	
BP	
SI	
DI	

IP	
flags	

CS	
DS	Segment of pointer to parameter block
SS	
ES	

Buffer Parameter block (if CL=40H,41H,42H,62H)

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		

SP	
BP	
SI	
DI	

IP	
flags	Carry*

CS	
DS	
SS	
ES	

Buffer Parameter block (if CL=60H,61H)

**Version Info:** •Applies to all versions of DOS beginning with 3.2

**Notes:** •\*Carry flag set if error occurs  
 •\*\*Function code is one of: 40H =set device parameters  
 41H=write track on logical device  
 42H=format track on logical device  
 60H=get device parameters  
 61H=read track on logical device  
 62H=verify track on logical device

**Source:** IBM DOS 3.3 Technical Reference, pages 6-166 to 6-181

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.134. Block Device Function Codes  
 3.135. Device Parameter Blocks  
 3.167. Device BPB Layout

**3.085. FUNCTION 44H, 0EH -- GET LOGICAL DRIVE MAP**

*Prior to Calling Function*

	High	Low
AX	44H	0EH
BX		Logical drive number
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Drive** or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 3.2

**Notes:** \*Carry flag set if error occurs  
 \*\*AL returns physical drive data; 00=only one drive mapped to logical drive;  
 1-26(A-Z)=physical drive mapped to logical drive

**Source:** IBM DOS 3.3 Technical Reference, page 6-182

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.086. Function 44H, 0FH -- Set Logical Drive Map  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.086. FUNCTION 44H, 0FH -- SET LOGICAL DRIVE MAP**

*Prior to Calling Function*

	High	Low
AX	44H	0FH
BX		Logical drive number
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Logical drive used or error code** (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** \*Applies to all versions of DOS beginning with 3.2

**Notes:** \*Carry flag set if error occurs  
 \*\*AL returns physical drive data; 00=only one drive mapped to logical drive;  
 1-26(A-Z)=physical drive mapped to logical drive

**Source:** IBM DOS 3.3 Technical Reference, pages 6-183 to 6-184

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.085. Function 44H, 0EH -- Get Logical Drive Map  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.137. Logical Drive Numbers

**3.087. FUNCTION 45H -- DUPLICATE FILE HANDLE**

*Prior to Calling Function*

	High	Low
AX	45H	
BX	Handle	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	New handle or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-185

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.088. Function 46H -- Force Duplicate File Handle  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.088. FUNCTION 46H -- FORCE DUPLICATE FILE HANDLE**

*Prior to Calling Function*

	High	Low
AX	46H	
BX	Existing handle	
CX	Second handle	
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** •Almost always used immediately after Function 45H -- Duplicate File Handle  
 •Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-186 to 6-187

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.087. Function 45H -- Duplicate File Handle  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.089. FUNCTION 47H -- GET CURRENT DIRECTORY**

*Prior to Calling Function*

	High	Low
AX	47H	
BX		
CX		
DX		Logical drive number
SP		
BP		
SI	Offset of pointer to 64-byte buffer	
DI		
IP		
flags		
CS		
DS	Segment of pointer to 64-byte buffer	
SS		
ES		
Buffer	Empty	

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		
Buffer	ASCII pathname (if carry flag clear)	

- Version Info:** Applies to all versions of DOS beginning with 2.0
- Notes:**  
 \*Returned pathname does not begin with a backslash or drive ID  
 \*\*Carry flag set if error occurs
- Source:** IBM DOS 3.3 Technical Reference, pages 6-188 to 6-189
- See Also:**  
 3.001. INT 21H Functions by DOS Version Summary  
 3.061. Function 3BH -- Change Current Directory  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.090. FUNCTION 48H -- ALLOCATE MEMORY**

*Prior to Calling Function*

	High	Low
AX	48H	
BX	Number of paragraphs of memory	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Segment address** or error code (if carry set)	
BX	Paragraphs available (if carry set)	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

- Version Info:** Applies to all versions of DOS beginning with 2.0
- Notes:**  
 \*\*Carry flag set if error occurs  
 \*\*\*Segment address of allocated memory block
- Source:** IBM DOS 3.3 Technical Reference, pages 6-190 to 6-191
- See Also:**  
 3.001. INT 21H Functions by DOS Version Summary  
 3.091. Function 49H -- Free Allocated Memory  
 3.092. Function 4AH -- Set Block  
 3.103. Function 58H, 00H -- Get Allocation Strategy  
 3.104. Function 58H, 01H -- Set Allocation Strategy  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.140. Memory Allocation Strategies

**3.091. FUNCTION 49H -- FREE ALLOCATED MEMORY**

**Prior to Calling Function**

	High	Low
AX	49H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment address of allocated block to free	

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-192

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.090. Function 48H -- Allocate Memory  
 3.092. Function 4AH -- Set Block  
 3.103. Function 58H, 00H -- Get Allocation Strategy  
 3.104. Function 58H, 01H -- Set Allocation Strategy  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.140. Memory Allocation Strategies

**3.092. FUNCTION 4AH -- SET BLOCK**

**Prior to Calling Function**

	High	Low
AX	4AH	
BX	Paragraphs of memory requested	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment address of memory block to allocate	

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX	Paragraphs available (if carry set)	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-193 to 6-194

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.090. Function 48H -- Allocate Memory  
 3.091. Function 49H -- Free Allocated Memory  
 3.103. Function 58H, 00H -- Get Allocation Strategy  
 3.104. Function 58H, 01H -- Set Allocation Strategy  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.140. Memory Allocation Strategies

**3.093. FUNCTION 4BH, 00H -- LOAD AND EXECUTE PROGRAM**

*Prior to Calling Function*

	High	Low
AX	4BH	0
BX	Offset of pointer to parameter block	
CX		
DX	Offset of pointer to pathname	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname	
SS		
ES	Segment of pointer to parameter block	

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX	Destroyed	Destroyed
CX	Destroyed	Destroyed
DX	Destroyed	Destroyed
SP	Destroyed	
BP	Destroyed	
SI	Destroyed	
DI	Destroyed	
IP		
flags	Carry*	
CS		
DS	Destroyed	
SS	Destroyed	
ES	Destroyed	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-195 to 6-199

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.053. Function 31H -- Keep Process  
 3.094. Function 4BH, 03H -- Load Overlay  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.138. Execute Program Parameter Block

**3.094. FUNCTION 4BH, 03H -- LOAD OVERLAY**

*Prior to Calling Function*

	High	Low
AX	4BH	3
BX	Offset of pointer to parameter block	
CX		
DX	Offset of pointer to pathname	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname	
SS		
ES	Segment of pointer to parameter block	

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX	Destroyed	Destroyed
CX	Destroyed	Destroyed
DX	Destroyed	Destroyed
SP	Destroyed	
BP	Destroyed	
SI	Destroyed	
DI	Destroyed	
IP		
flags	Carry*	
CS		
DS	Destroyed	
SS	Destroyed	
ES	Destroyed	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-195 to 6-199

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.053. Function 31H -- Keep Process  
 3.093. Function 4BH, 00H -- Load and Execute Program  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.139. Overlay Program Parameter Block

**3.095. FUNCTION 4CH -- END PROCESS**

*Prior to Calling Function*

	High	Low
AX	4CH	Return code
BX		
CX		
DX		

SP	
BP	
SI	
DI	

IP	
flags	

CS	
DS	
SS	
ES	

*Upon Return From Function*

Function does not return any values

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** All open files are closed by this function

**Source:** IBM DOS 3.3 Technical Reference, page 6-200

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.053. Function 31H -- Keep Process  
 3.096. Function 4DH -- Get Return Code

**3.096. FUNCTION 4DH -- GET RETURN CODE**

*Prior to Calling Function*

	High	Low
AX	4DH	
BX		
CX		
DX		

SP	
BP	
SI	
DI	

IP	
flags	

CS	
DS	
SS	
ES	

*Upon Return From Function*

	High	Low
AX	Termination code*	Return code
BX		
CX		
DX		

SP	
BP	
SI	
DI	

IP	
flags	

CS	
DS	
SS	
ES	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*0=normal 4CH terminate; 1=Control-C pressed; 2=critical device error; 3=normal 31H terminate

**Source:** IBM DOS 3.3 Technical Reference, page 6-201

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.053. Function 31H -- Keep Process  
 3.095. Function 4CH -- End Process

**3.097. FUNCTION 4EH -- FIND FIRST FILE**

**Prior to Calling Function**

	High	Low
AX	4EH	
BX		
CX	0	Attribute byte
DX	Offset of pointer to pathname.	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname	
SS		
ES		
DTA	Empty	
Pathname	ASCIIZ string	

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		
DTA	File info (See 3.132. Search First/Next Data Blocks)	
Pathname	Unchanged	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-202 to 6-203

**See Also:**

- 2.34. File Attribute Byte
- 2.35. Date/Time Formats
- 3.001. INT 21H Functions by DOS Version Summary
- 3.026. Function 11H -- Find First Entry With FCB
- 3.027. Function 12H -- Find Next Entry With FCB
- 3.098. Function 4FH -- Find Next File
- 3.105. Function 59H -- Get Extended Error
- 3.128. Extended Error Codes Returned from Function 59H
- 3.132. Search First/Next Data Blocks

**3.098. FUNCTION 4FH -- FIND NEXT FILE**

**Prior to Calling Function**

	High	Low
AX	4FH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

DTA 

Data about previously found file
----------------------------------

DTA 

Data about next found file (if carry clear)
---------------------------------------------

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** •Must be used after function 4EH  
 •\*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-204

**See Also:** 2.34. File Attribute Byte  
 2.35. Date/Time Formats  
 3.001. INT 21H Functions by DOS Version Summary  
 3.026. Function 11H -- Find First Entry With FCB  
 3.027. Function 12H -- Find Next Entry With FCB  
 3.097. Function 4EH -- Find First File  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.132. Search First/Next Data Blocks

**3.099. FUNCTION 54H -- GET VERIFY STATE**

**Prior to Calling Function**

	High	Low
AX	54H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		Verify state*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*0=no verify after write; 01=verify after write

**Source:** IBM DOS 3.3 Technical Reference, page 6-205

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.050. Function 2EH -- Set/Reset Verify Flag

**3.100. FUNCTION 56H -- RENAME FILE**

**Prior to Calling Function**

	High	Low
AX	56H	
BX		
CX		
DX	Offset of pointer to old pathname	
SP		
BP		
SI		
DI	Offset of pointer to new pathname	
IP		
flags		
CS		
DS	Segment of pointer to old pathname	
SS		
ES	Segment of pointer to new pathname	

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** •Applies to all versions of DOS beginning with 2.0  
•Requires create access rights on networks

**Notes:** •The ? wildcard character may not be used in the pathname  
•If the directory path is not the same, but the file name and type specified are, the file is "moved" to the new directory  
•\*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-206 to 6-207

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.032. Function 17H -- Rename File With FCB  
3.105. Function 59H -- Get Extended Error  
3.128. Extended Error Codes Returned from Function 59H

**3.101. FUNCTION 57H, 00H -- GET DATE/TIME OF FILE**

**Prior to Calling Function**

	High	Low
AX	57H	0
BX	Handle	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX	FCB format time file last changed	
DX	FCB format date file last changed	
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-208 to 6-209

**See Also:** 2.35. Date/Time Formats  
 3.001. INT 21H Functions by DOS Version Summary  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.102. FUNCTION 57H, 01H -- SET DATE/TIME OF FILE**

**Prior to Calling Function**

	High	Low
AX	57H	1
BX	Handle	
CX	FCB format time to be set	
DX	FCB format date to be set	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-208 to 6-209

**See Also:** 2.35. Date/Time Formats  
 3.001. INT 21H Functions by DOS Version Summary  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.103. FUNCTION 58H, 00H -- GET ALLOCATION STRATEGY**

**Prior to Calling Function**

	High	Low
AX	58H	0
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Strategy** or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 3.2

**Notes:** \*Carry flag set if error occurs  
 \*\*AH returns 00=first fit; 01=best fit; 02=last fit

**Source:** MS-DOS 3.2 Programmer's Reference, page 1-212  
 Missing from IBM DOS 3.3 Technical Reference!

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.090. Function 48H -- Allocate Memory  
 3.092. Function 4AH -- Set Block  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.140. Memory Allocation Strategies

**3.104. FUNCTION 58H, 01H -- SET ALLOCATION STRATEGY**

**Prior to Calling Function**

	High	Low
AX	58H	1
BX	Allocation strategy**	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 3.2

**Notes:** \*Carry flag set if error occurs  
 \*\*00=first fit; 01=best fit; 02=last fit

**Source:** MS-DOS 3.2 Programmer's Reference, page 1-212  
 Missing from IBM DOS 3.3 Technical Reference!

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.090. Function 48H -- Allocate Memory  
 3.092. Function 4AH -- Set Block  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H  
 3.140. Memory Allocation Strategies

**3.105. FUNCTION 59H -- GET EXTENDED ERROR**

*Prior to Calling Function*

	High	Low
AX	59H	
BX	0	0
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Extended error code (of last error)	
BX	Error class	Suggested action
CX	Location of error	Destroyed*
DX	Destroyed*	Destroyed*
SF		
BP		
SI	Destroyed*	
DI	Destroyed*	
IP		
flags		
CS		
DS	Destroyed*	
SS		
ES	Destroyed*	

- Version Info:** Applies to all versions of DOS beginning with 3.0
- Notes:** \*These registers are not preserved by DOS
- Source:** IBM DOS 3.3 Technical Reference, pages 6-210 to 6-212
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.128. Extended Error Codes Returned from Function 59H

**3.106. FUNCTION 5AH -- CREATE TEMPORARY FILE**

*Prior to Calling Function*

	High	Low
AX	5AH	
BX		
CX	0	Attribute byte
DX	Offset of pointer to special pathname**	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to special pathname**	
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Handle or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

Pathname Pathname

Pathname Pathname+filename

- Version Info:** \*Applies to all versions of DOS beginning with 3.0  
\*Requires create access rights on network
- Notes:** \*Carry flag set if error occurs  
\*\*Pathname, followed by backslash (\), followed by 14 bytes of 00H
- Source:** IBM DOS 3.3 Technical Reference, page 6-213
- See Also:** 2.34. File Attribute Byte  
3.001. INT 21H Functions by DOS Version Summary  
3.031. Function 16H -- Create File With FCB  
3.062. Function 3CH -- Create File  
3.105. Function 59H -- Get Extended Error  
3.107. Function 5BH -- Create New File  
3.128. Extended Error Codes Returned from Function 59H

**3.107. FUNCTION 5BH -- CREATE NEW FILE**

*Prior to Calling Function*

	High	Low
AX	5BH	
BX		
CX	0	Attribute byte
DX	Offset of pointer to pathname	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to pathname	
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Handle or error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** \*Applies to all versions of DOS beginning with 3.0  
 \*Requires create access rights on networks

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-215

**See Also:** 2.34. File Attribute Byte  
 3.001. INT 21H Functions by DOS Version Summary  
 3.031. Function 16H -- Create File With FCB  
 3.062. Function 3CH -- Create File  
 3.105. Function 59H -- Get Extended Error  
 3.106. Function 5AH -- Create Temporary File  
 3.128. Extended Error Codes Returned from Function 59H

**3.108. FUNCTION 5CH, 00H -- LOCK FILE**

*Prior to Calling Function*

	High	Low
AX	5CH	0
BX	Handle	
CX	High order of offset to region in file to lock	
DX	Low order of offset to region in file to lock	
SP		
BP		
SI	High order of length of region in file to lock	
DI	Low order of length of region in file to lock	
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 3.0

**Notes:** \*Should be used only if file was opened in deny read or deny none mode  
 \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-216 to 6-218

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.105. Function 59H -- Get Extended Error  
 3.128. Extended Error Codes Returned from Function 59H

**3.109. FUNCTION 5CH, 01H -- UNLOCK FILE**

*Prior to Calling Function*

	High	Low
AX	5CH	1
BX	Handle	
CX	High order of offset to region in file to unlock	
DX	Low order of offset to region in file to unlock	
SP		
BP		
SI	High order of length of region in file to unlock	
DI	Low order of length of region in file to unlock	
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		

- Version Info:** Applies to all versions of DOS beginning with 3.0
- Notes:** \*Region must be same as one locked with function 5CH,0  
\*\*Carry flag set if error occurs
- Source:** IBM DOS 3.3 Technical Reference, pages 6-216 to 6-218
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.105. Function 59H -- Get Extended Error  
3.108. Function 5CH,00H -- Lock File  
3.128. Extended Error Codes Returned from Function 59H

**3.110. FUNCTION 5EH, 00H -- GET MACHINE NAME**

*Prior to Calling Function*

	High	Low
AX	5EH	0
BX		
CX		
DX	Offset of pointer to 16-byte buffer	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to 16-byte buffer	
SS		
ES		
Buffer	Empty	

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX	Validity**	Netbios # for local
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry*	
CS		
DS		
SS		
ES		
Buffer	Network name	

- Version Info:** Applies to all versions of DOS beginning with 3.1
- Notes:** \*Carry flag set if error occurs  
\*\*0=invalid network device, 1=valid
- Source:** IBM DOS 3.3 Technical Reference, pages 6-219 to 6-220
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.105. Function 59H -- Get Extended Error  
3.128. Extended Error Codes Returned from Function 59H

**3.111. FUNCTION 5EH, 02H -- SET PRINTER STRING**

**Prior to Calling Function**

	High	Low
AX	5EH	2
BX	Assignment list index	
CX	Length of printer setup string	
DX		
SP		
BP		
SI	Offset of pointer to setup string	
DI		
IP		
Flags		
CS		
DS	Segment of pointer to setup string	
SS		
ES		
String	Printer setup string	

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
Flags	Carry*	
CS		
DS		
SS		
ES		
Buffer	Unchanged string	

- Version Info:** Applies to all versions of DOS beginning with 3.1
- Notes:** \*Printer setup string cannot be longer than 64 bytes  
\*Carry flag set if error occurs
- Source:** IBM DOS 3.3 Technical Reference, pages 6-221 to 6-222
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.105. Function 59H -- Get Extended Error  
3.112. Function 5EH, 03H -- Get Printer String  
3.128. Extended Error Codes Returned from Function 59H

**3.112. FUNCTION 5EH, 03H -- GET PRINTER STRING**

**Prior to Calling Function**

	High	Low
AX	5EH	3
BX	Assignment list index	
CX		
DX		
SP		
BP		
SI		
DI	Offset of pointer to 64-byte buffer	
IP		
Flags		
CS		
DS		
SS		
ES	Segment of pointer to 64-byte buffer	
Buffer	Empty	

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX	Length of printer string	
DX		
SP		
BP		
SI		
DI		
IP		
Flags	Carry*	
CS		
DS		
SS		
ES		
Buffer	Setup string	

- Version Info:** Applies to all versions of DOS beginning with 3.1
- Notes:** \*Carry flag set if error occurs
- Source:** IBM DOS 3.3 Technical Reference, pages 6-223 to 6-224
- See Also:** 3.001. INT 21H Functions by DOS Version Summary  
3.105. Function 59H -- Get Extended Error  
3.111. Function 5EH,02H -- Set Printer String  
3.128. Extended Error Codes Returned from Function 59H

3.113. FUNCTION 5FH, 02H -- GET ASSIGNMENT LIST ENTRY

**Prior to Calling Function**

	High	Low
AX	5FH	2
BX	Assignment list index	
CX		
DX		
SP		
BP		
SI	Offset of pointer to 16-byte local name buffer	
DI	Offset of pointer to 128-byte remote name buffer	
IP		
flags		
CS		
DS	Segment of pointer to 16-byte local name buffer	
SS		
ES	Segment of pointer to 128-byte remote name buffer	

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX	Status***	Code** (if carry clear)
CX	Stored user value	
DX	Destroyed	Destroyed
SP		
BP	Destroyed	
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

16-byte buffer 

Empty
-------

 16-byte buffer 

Local name (ASCII string)
---------------------------

128-byte buffer 

Empty
-------

 128-byte buffer 

Remote name (ASCII string)
----------------------------

**Version Info:** Applies to all versions of DOS beginning with 3.1

**Notes:** \*Carry flag set if error occurs  
 \*\*03=printer device; 04=drive device  
 \*\*\*0=valid network device, 1=invalid device

**Source:** IBM DOS 3.3 Technical Reference, pages 6-225 to 6-226  
 MS-DOS 3.3 Programmer's Reference, pages 287, 289

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.105. Function 59H -- Get Extended Error  
 3.110. Function 5EH,00H -- Get Machine Name  
 3.128. Extended Error Codes Returned from Function 59H

**3.114. FUNCTION 5FH, 03H -- MAKE ASSIGNMENT LIST ENTRY**

**Prior to Calling Function**

	High	Low
AX	5FH	3
BX		Code**
CX	User value***	
DX		
SP		
BP		
SI	Offset of pointer to 16-byte source device name string	
DI	Offset of pointer to 128-byte remote device name string	
IP		
flags		
CS		
DS	Segment of pointer to 16-byte source device name string	
SS		
ES	Segment of pointer to 128-byte remote device name string	

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 3.1

**Notes:**

- \*Strings should be in ASCIIZ format
- \*Carry flag set if error occurs
- \*\*03=printer device; 04=drive device
- \*\*\*Should be zero to retain compatibility with IBM local area networks

**Source:** IBM DOS 3.3 Technical Reference, pages 6-227 to 6-229

**See Also:**

- 3.001. INT 21H Functions by DOS Version Summary
- 3.105. Function 59H -- Get Extended Error
- 3.110. Function 5EH,00H -- Get Machine Name
- 3.128. Extended Error Codes Returned from Function 59H

**3.115. FUNCTION 5FH, 04H -- CANCEL ASSIGNMENT LIST ENTRY**

**Prior to Calling Function**

	High	Low
AX	5FH	4
BX		
CX		
DX		
SP		
BP		
SI	Offset of pointer to 16-byte source device name string	
DI		
IP		
flags		
CS		
DS	Segment of pointer to 16-byte source device name string	
SS		
ES		

**Upon Return From Function**

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 3.1

**Notes:** •Strings should be ASCIIZ format  
 •\*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-230 to 6-231

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.105. Function 59H -- Get Extended Error  
 3.110. Function 5EH,00H -- Get Machine Name  
 3.128. Extended Error Codes Returned from Function 59H

**3.116. FUNCTION 62H -- GET PROGRAM SEGMENT PREFIX**

**Prior to Calling Function**

	High	Low
AX	62H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return From Function**

	High	Low
AX		
BX	Segment address of PSP for current process	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Version Info:** Applies to all versions of DOS beginning with 3.0

**Source:** IBM DOS 3.3 Technical Reference, page 6-232

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 3.136. Program Segment Prefix Layout

**3.117. FUNCTION 63H -- GET LEAD BYTE TABLE**

*Prior to Calling Function*

	<i>High</i>	<i>Low</i>
AX	63H	Function*
BX		
CX		
DX		Flag** (if AL=1)
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	<i>High</i>	<i>Low</i>
AX		
BX		
CX		
DX		Flag (if AL=2)
SP		
BP		
SI		Offset of pointer to lead byte table
DI		
IP		
flags		
CS		
DS		Segment of pointer to lead byte table
SS		
ES		

**Version Info:** Function is available only in DOS 2.25

**Notes:** \*\*Function is one of: 0 = to get address of lead byte table  
1 = to set or clear interim console flag  
2 = to obtain interim console flag

\*\*Set/clear flag is one of: 0 = to clear interim console flag  
1 = to set interim console flag

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, page 385

**3.118. FUNCTION 65H -- GET EXTENDED COUNTRY INFO**

*Prior to Calling Function*

	<i>High</i>	<i>Low</i>
AX	65H	Info wanted**
BX	Code page of interest (-1=CON)	
CX	Number of bytes to return***	
DX	Country code	
SP		
BP		
SI		
DI		Offset of pointer to country info table
IP		
flags		
CS		
DS		
SS		
ES		Segment of pointer to ccountry info table

**Table** Empty

*Upon Return From Function*

	<i>High</i>	<i>Low</i>
AX	Error code (if CF set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Table** Country info

**Version Info:** Function is available only in DOS 3.3

**Notes:** \*Carry flag set if error occurs

\*\*Info wanted is one of: 1 = full country information table  
2 = pointer to uppercase table  
4 = pointer to filename uppercase table  
6 = pointer to collating sequence

\*\*\*Must be at least 5

**Source:** IBM DOS 3.3 Technical Reference, pages 6-223 to 6-236

**See Also:** 3.057. Function 38H, 00H -- Get Country Data  
3.058. Function 38H, xxH -- Set Country Data  
3.143. Country Code Buffer Layout  
3.144. Country Codes

**3.119. FUNCTION 66H, 01H -- GET GLOBAL CODE PAGE**

*Prior to Calling Function*

	High	Low
AX	66H	1
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX	Active code page (set by user)	
CX		
DX	System code page (boot time)	
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Function is available only in DOS 3.3

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-237 to 6-238

**See Also:** 3.120. Function 66H, 02H -- Set Global Code Page

**3.120. FUNCTION 66H, 02H -- SET GLOBAL CODE PAGE**

*Prior to Calling Function*

	High	Low
AX	66H	2
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Function is available only in DOS 3.3

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, pages 6-237 to 6-238

**See Also:** 3.119. Function 66H, 01H -- Get Global Code Page

**3.121. FUNCTION 67H -- SET HANDLE COUNT**

*Prior to Calling Function*

	High	Low
AX	67H	
BX	Number of open handles allowed	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX	Error code (if carry set)	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Function is available only in DOS 3.3

**Notes:**

- Maximum is actually controlled by CONFIG.SYS FILES= setting
- You must release memory to DOS for the extended handle list
- Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-239

**See Also:** 2.27. CONFIG.SYS Commands and Default Settings

**3.122. FUNCTION 68H -- COMMIT FILE**

*Prior to Calling Function*

	High	Low
AX	68H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
FLAGS		
CS		
DS		
SS		
ES		

*Upon Return From Function*

	High	Low
AX		
BX	File handle committed to disk	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
FLAGS		Carry*
CS		
DS		
SS		
ES		

**Version Info:** Function is available only in DOS 3.3

**Notes:** \*Carry flag set if error occurs

**Source:** IBM DOS 3.3 Technical Reference, page 6-240

**3.123. UNOPENED FCB FORMAT**

Offset	Length	Name	Contents
0 (0)	byte	Drive number	Logical drive number; 0=default, 1=A, 2=B, and so on
1 (1)	8 bytes	File name	ASCII characters, padded with spaces, if necessary
9 (9)	3 bytes	File type	ASCII characters, padded with spaces, if necessary
C (12)	25 bytes	RESERVED	(must be filled with zeros)

**Source:** IBM DOS 3.3 Technical Reference, pages 7-12 to 7-15

**See Also:** 3.003. INT 21H FCB-oriented Functions Summary  
 3.124. Opened FCB Format  
 3.125. Extended FCB Format  
 3.126. Rename FCB Format  
 3.137. Logical Drive Numbers

**3.124. OPENED FCB FORMAT**

Offset	Length	Name	Contents
0 (0)	byte	Drive number	Physical drive number; 0=A, 1=B, and so on
1 (1)	8 bytes	File name	ASCII characters, padded with spaces, if necessary
9 (9)	3 bytes	File type	ASCII characters, padded with spaces, if necessary
C (12)	word	Current block	Binary value indicating current block (set to 0 on File Open)
E (14)	word	Record size	Number of bytes per record (default=128)
10 (16)	dbl word	File size	Binary value indicating size of file, in bytes
14 (20)	word	File date	Packed word containing file last update date
16 (22)	word	File time	Packed word containing file last update time
18 (24)	8 bytes	RESERVED	Used internally by DOS
20 (32)	byte	Current record	Binary value indicating current record (set to 0 on File Open)
21 (33)	dbl word	Random record number	Binary value indicating next random block to read/write

**Notes:** In the PSP, an extended FCB starts 7 bytes prior to 5CH.  
 In your program (outside the PSP), your FCB pointer probably points directly to the FFH byte of an extended FCB, or to the drive number byte of a normal FCB. Thus, to insure that you address items in an FCB correctly, you must first know if it is extended or not (See 3.125. Extended FCB Format)

**Source:** IBM DOS 3.3 Technical Reference, pages 7-12 to 7-15

**See Also:** 3.003. INT 21H FCB-oriented Functions Summary  
 3.123. Unopened FCB Format  
 3.125. Extended FCB Format  
 3.126. Rename FCB Format

**3.125. EXTENDED FCB FORMAT**

Offset	Length	Name	Contents
0 (0)	byte	Extended FCB indicator	Always FF (255)
1 (1)	5 bytes	RESERVED	
6 (6)	byte	Attribute byte	See 2.34. File Attribute Byte
7 (7)	byte	Drive number	0=A, 1=B, and so on
8 (8)	8 bytes	File name	ASCII characters, padded with spaces, if necessary
10 (16)	3 bytes	File type	ASCII characters, padded with spaces, if necessary
13 (19)	word	Current block	Binary value indicating current block (set to 0 on File Open)
15 (21)	word	Record size	Number of bytes per record; default=80 (128)
17 (23)	dbl word	File size	Binary value indicating size of file, in bytes
1B (27)	word	File date	Packed word containing file last update date
1D (29)	word	File time	Packed word containing file last update time
1F (31)	8 bytes	RESERVED	Used internally by DOS
27 (39)	byte	Current record	Binary value indicating current record (set to 0 on File Open)
28 (40)	dbl word	Random record number	Binary value indicating next random block to read/write

**Notes:** •A value other than FFH in the first byte of an FCB indicates it is not an Extended FCB (See 3.124. Opened FCB Format)  
 •Values are in hexadecimal (decimal in parentheses)

**Source:** IBM DOS 3.3 Technical Reference, page 7-16

**See Also:** 2.34. File Attribute Byte  
 3.003. INT 21H FCB-oriented Functions Summary  
 3.123. Unopened FCB Format  
 3.124. Opened FCB Format  
 3.126. Rename FCB Format

**3.126. RENAME FCB FORMAT**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Contents</i>
0 (0)	byte	Drive number	Logical drive number; 0=default, 1=A, 2=B, and so on
1 (1)	8 bytes	Original file name	ASCII characters, padded with spaces, if necessary
9 (9)	3 bytes	Original file type	ASCII characters, padded with spaces, if necessary
C (12)	5 bytes	RESERVED	
11 (17)	8 bytes	New file name	ASCII characters, padded with spaces, if necessary
19 (25)	3 bytes	New file type	ASCII characters, padded with spaces, if necessary
1C (28)	9 bytes	RESERVED	Set to zeros

**Notes:** Both file name and typc fields may contain the DOS wildcard character ? (match any character)

**Source:** IBM DOS 3.3 Technical Reference, page 6-79

**See Also:** 3.003. INT 21H FCB-oriented Functions Summary  
 3.123. Unopened FCB Format  
 3.124. Opened FCB Format  
 3.125. Extended FCB Format  
 3.137. Logical Drive Numbers

**3.127. FCB ERROR CODES****For Read functions (14H, 21H, and 27H):**

<i>Code in AL</i>	<i>Meaning After Read</i>
0	Read operation was completed successfully
1	Read attempted at end of file; no data was transferred
2	Not enough room in the DTA for record(s); read canceled
3	Read encountered end of file; partial record read, remainder padded with 0's

**For Write functions (15H, 22H, and 28H):**

<i>Code in AL</i>	<i>Meaning After Write</i>
0	Write operation was completed successfully
1	Disk full; write canceled
2	DTA does not contain enough data to write record(s); write canceled

**Source:** MS-DOS 3.2 Programmer's Reference, pages 1-75 to 1-103

**See Also:** 3.003. INT 21H FCB-oriented Functions Summary  
 3.029. Function 14H -- Sequential Read With FCB  
 3.030. Function 15H -- Sequential Write With FCB  
 3.037. Function 21H -- Random Read With FCB  
 3.038. Function 22H -- Random Write With FCB  
 3.043. Function 27H -- Random Block Read With FCB  
 3.044. Function 28H -- Random Block Write With FCB

## 3.128. EXTENDED ERROR CODES RETURNED FROM FUNCTION 59H

**Error Class:**

Value in BH	Description of Class	Example
1 (1)	Out of a resource	Storage or channels
2 (2)	Temporary situation	Locked region of file
3 (3)	Authorization problem	User doesn't have access rights
4 (4)	Internal error in system software	
5 (5)	Hardware failure	
6 (6)	System software failure	Missing configuration file
7 (7)	Application program failure	
8 (8)	Item not found	File couldn't be found
9 (9)	Invalid format or type	File in wrong format
A (10)	Interlocked item	File is interlocked
B (11)	Media problem	Wrong disk, bad spot on disk
C (12)	Already exists	Declared machine name that exists
D (13)	Unknown	

**Suggested Action:**

Value in BL	Description of Suggested Action
1 (1)	Retry, then prompt user
2 (2)	Retry after a brief pause
3 (3)	If user entered item, prompt for it again
4 (4)	Terminate after closing files
5 (5)	Terminate immediately; don't close files
6 (6)	No action; error was informational only
7 (7)	Prompt the user to perform an action (e.g., change disk)

**Location:**

Value in CH	Probable Location of Error	Example
1	Unknown to DOS	
2	Random access device	Disk drive
3	Network	Network software, hardware
4	Character device	Printer, communications
5	Memory	RAM

**Error Code:**

Value in AX	Description
1 (1)	Invalid function code
2 (2)	File not found
3 (3)	Path not found
4 (4)	Too many open files
5 (5)	Access denied
6 (6)	Invalid handle
7 (7)	Memory control blocks destroyed
8 (8)	Insufficient memory
9 (9)	Invalid memory block address
A (10)	Invalid environment
B (11)	Invalid format
C (12)	Invalid access code
D (13)	Invalid data
E (14)	NOT USED
F (15)	Invalid drive
10 (16)	Attempt to remove the current directory
11 (17)	Not same device
12 (18)	No more files
13 (19)	Disk is write-protected
14 (20)	Bad disk unit
15 (21)	Drive not ready
16 (22)	Invalid disk command
17 (23)	CRC error
18 (24)	Invalid length in disk operation
19 (25)	Seek error
1A (26)	Not a DOS disk
1B (27)	Sector not found
1C (28)	Out of paper
1D (29)	Write fault
1E (30)	Read fault
1F (31)	General failure
20 (32)	Sharing violation
21 (33)	Lock violation
22 (34)	Wrong disk

(Continued)

Table 3.128. Continued

<b>Error Code:</b>	
<i>Value in AX</i>	<i>Description</i>
23 (35)	FCB unavailable
24 (36)	Sharing buffer overflow
25 (37)	RESERVED
26 (38)	RESERVED
27 (39)	RESERVED
28 (40)	RESERVED
29 (41)	RESERVED
3A (42)	RESERVED
3B (43)	RESERVED
3C (44)	RESERVED
3D (45)	RESERVED
3E (46)	RESERVED
3F (47)	RESERVED
40 (48)	RESERVED
41 (49)	RESERVED
42 (50)	Network request not supported
43 (51)	Remote computer not listening
44 (52)	Duplicate name on network
45 (53)	Network path not found
46 (54)	Network busy
47 (55)	Network device no longer exists
48 (56)	Net BIOS command limit exceeded
49 (57)	Network adapter hardware error
4A (58)	Incorrect response from network
4B (59)	Unexpected network error
4C (60)	Incompatible remote adapter
4D (61)	Print queue full
4E (62)	Not enough space for print file
4F (63)	Print file was canceled
50 (64)	Network name was deleted
51 (65)	Access denied
52 (66)	Network device type incorrect
53 (67)	Network name not found
54 (68)	Network name limit exceeded
55 (69)	Net BIOS session limit exceeded
56 (70)	Temporarily paused
57 (71)	Network request not accepted
58 (72)	Print or disk redirection is paused
59 (73)	RESERVED
5A (74)	RESERVED
5B (75)	RESERVED
5C (76)	RESERVED
5D (77)	RESERVED
5E (78)	RESERVED
5F (79)	RESERVED
60 (80)	File exists
61 (81)	NOT USED
62 (82)	Cannot make
63 (83)	Interrupt 24H failure
64 (84)	Out of structures
65 (85)	Already assigned
66 (86)	Invalid password
67 (87)	Invalid parameter
68 (88)	Net write fault

**Version Info:** •Error codes apply to all versions of DOS beginning with 2.0  
 •Error class, action, and location apply to all versions of DOS beginning with 3.0

**Source:** IBM DOS 3.3 Technical Reference, pages 6-40 to 6-46

**See Also:** 3.105. Function 59H --- Get Extended Error  
 3.127. FCB Error Codes

**3.129. HANDLE ACCESS BYTE****Bit Numbers**

7	6	5	4	3	2	1	0	Use
X								Inherit bit
	X	X	X					Sharing mode code
				X				Reserved; set to 0
					X	X	X	Access code

7	6	5	4	3	2	1	0	Allowable Values	Meaning
X								0=child inherits 1=child doesn't inherit	If a child process is spawned, this file will be inherited If a child process is spawned, it will not inherit this file
	X	X	X					000=compatibility mode 001=deny read/write mode 010=deny write mode 011=deny read mode 100=deny none mode	Fails if file has been opened in any of the other sharing modes Fails if file has been opened in any but deny none sharing mode Fails if file has been opened in compatibility or write sharing mode Fails if file has been opened in compatibility or read sharing mode Fails only if file has been opened in compatibility sharing mode
				X	X	X	X	0000=read access allowed 0001=write access allowed 0010=read/write access	Fails if file has been opened in deny read or deny both sharing mode Fails if file has been opened in deny write or deny both sharing mode Fails if file has been opened in deny read, write, or both sharing mode

**Version Info:** •Applies to all versions of DOS beginning with 2.0  
•Fully implemented beginning with DOS 3.1. Normally access byte for all non-network workstations would be 02H (inherit, compatibility, read/write).

**Source:** IBM DOS 3.3 Technical Reference, pages 6-127 to 6-135

**See Also:** 3.063. Function 3DH -- Open File

**3.130. PREDEFINED HANDLES**

Handle Number	Device Assignment	Default Device
0	Standard input	Keyboard
1	Standard output	Display
2	Standard error	Display
3	Auxiliary device	COM1:
4	Printer output	LPT1:

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** •The auxiliary device handle assumes that the proper parameters have been assigned to COM1: prior to start of communication  
•Preopened handles may be redirected to devices other than the default by using DOS INT 21H functions 45H and 46H

**Source:** IBM DOS 3.3 Technical Reference, pages 4-8 to 4-9

**See Also:** 3.148. Reserved Device Names and Chain Order

**3.131. HANDLE POINTER MOVEMENT METHODS**

<i>Value</i>	<i>Starting Location</i>	<i>Pointer is Moved To</i>
0	From beginning	Offset bytes (in CX:DX) from beginning of the file
1	From current pointer	Offset bytes (in CX:DX) from current location
2	From end of file	Offset bytes (in CX:DX) from end of file

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** CX:DX is considered a signed 32-bit integer, allowing offset values from -2,147,483,648 to 2,147,483,647

**Source:** IBM DOS 3.3 Technical Reference, page 6-144

**See Also:** 3.068. Function 42H -- Move File Pointer

**3.132. SEARCH FIRST/NEXT DATA BLOCKS**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Description</i>
0 (0)	21 bytes	RESERVED	Used by subsequent Search Next Functions
15 (21)	byte	Attribute byte	See 2.34. File Attribute Byte
16 (22)	word	File last update time	See 2.35. Date/Time Formats
18 (24)	word	File last update date	See 2.35. Date/Time Formats
1A (26)	word	Low word of file size	
1C (28)	word	High word of file size	
1E (30)	13-byte ASCIIZ string	Full file name and type*	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Data block is stored in DTA  
\*Filename string includes a period if a file type is present

**Source:** IBM DOS 3.3 Technical Reference, page 6-203

**See Also:** 3.097. Function 4EH -- Find First File  
3.098. Function 4FH -- Find Next File

**3.133. DEVICE DATA WORD**

**For Devices (Bit 7=1):**

Bit Number																Function	Allowable Values
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
X			X		X	X	X				X					RESERVED*	
	X															Process control strings**	0=cannot process control strings 1=can process control strings
		X														Output until busy**	0=no support for output until busy 1=supports output until busy
			X													Understand open/close**	0=doesn't understand open/close 1=understands open/close
								X								Device Type	1=device
									X							End of File	0=end of file on input 1=not at end of file
										X						Control Char Check	0=check for control characters 1=don't check for control chars
												X				Clock Device	0=is not clock device 1=is a clock device
													X			Null Device	0=is not a null device 1=is a null device
														X		Console Output Device	0=is not console output device 1=is console output device
															X	Console Input Device	0=is not console input device 1=is console input device

**For Files (bit 7=0):**

Bit Number																Function	Allowable Values
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
X	X	X	X	X	X	X	X									RESERVED	
								X								Device type	0=file
									X							File has been written	0=file has been written 1=file has not been written
										X	X	X	X	X	X	Drive number	000000=A 000001=B and so on

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:**  
 •Bit 14 may be read only; it cannot be set  
 •RESERVED bits should be set to 0 when setting device data  
 •DH must be 0, see page 6-147 of source

**Source:** IBM DOS 3.3 Technical Reference, pages 6-149 to 6-150

**See Also:** 3.071. Function 44H, 00H -- Get IOCTL Data  
 3.072. Function 44H, 01H -- Set IOCTL Data

**3.134. BLOCK DEVICE FUNCTION CODES**

Code	Function
40 (64)	Set device parameters
41 (65)	Write track on logical device
42 (66)	Format track on logical device
60 (96)	Get device parameters
61 (97)	Read track on logical device
62 (98)	Verify track on logical device

**Version Info:** Applies to all versions of DOS beginning with 3.0

**Source:** IBM DOS 3.3 Technical Reference, page 6-168

**See Also:** 3.084. Function 44H, 0DH -- Generic IOCTL For Devices

3.135. DEVICE PARAMETER BLOCKS

For Set Device (CL=40H):

Offset	Length	Name	Bit Numbers								Allowable Settings			
			7	6	5	4	3	2	1	0				
0 (0)	byte	Special functions	X	X	X	X	X							Must be set to 0 0=sectors different sizes 1=sectors same size 0=read all fields 1=read only track layout field 0=build new BPB 1=use device BPR 7=other device 6=tape drive 5=hard disk 4=8" double density floppy 3=8" single density floppy 2=720K microfloppy 1=1.2MB floppy 0=320/360K floppy
1 (1)	byte	Device type	0	0	0	0	0	1	1	1				0=sectors different sizes 1=sectors same size 0=read all fields 1=read only track layout field 0=build new BPB 1=use device BPR 7=other device 6=tape drive 5=hard disk 4=8" double density floppy 3=8" single density floppy 2=720K microfloppy 1=1.2MB floppy 0=320/360K floppy
2 (2)	word	Device attributes	X	X	X	X	X	X						Must be set to 0, RESERVED 0=disk changeline not supported 1=disk changeline supported 0=media is removable 1=media not removable Maximum # cylinders device supports
4 (4)	word	Number cylinders												0=1.2MB quad density 1=320/360K dbl density See 3.167. Device BPB
6 (6)	byte	Media type											X	Word total # of sectors Word sector 1 sector # Word sector 1 sector size Word sector 2 sector # Word sector 2 sector size ... and so on, up to... Word sector n sector # Word sector n sector size
7 (7)	varies	Device BPB												
varies	varies	Track layout												

For Get Device (CL=60H):

Offset	Length	Name	Bit Numbers								Allowable Settings			
			7	6	5	4	3	2	1	0				
0 (0)	byte	Special functions	X	X	X	X	X	X	X				X	Must be set to 0 0=return default BPB 1=return BUILD BPB 7=other device 6=tape drive 5=hard disk 4=8" double density floppy 3=8" single density floppy 2=720K microfloppy 1=1.2MB floppy 0=320/360K floppy
1 (1)	byte	Device type	0	0	0	0	0	1	1	1				Must be set to 0 0=disk changeline not supported 1=disk changeline supported 0=media is removable 1=media not removable Maximum # cylinders device supports
2 (2)	word	Device attributes	X	X	X	X	X	X						0=1.2MB quad density 1=320/360K dbl density See 3.167. Device BPB
4 (4)	word	Number cylinders												
6 (6)	byte	Media type											X	
7 (7)	varies	Device BPB												

For Read/Write Track (CL=61/41H):

Offset	Length	Name	Bit Numbers								Allowable Settings			
			7	6	5	4	3	2	1	0				
0 (0)	byte	Special functions	X	X	X	X	X	X	X	X				Must be set to 0 Head number to read/write Cylinder number to read/write First sector # to read/write Total # of sectors
1 (1)	word	Head												
3 (3)	word	Cylinder												
5 (5)	word	First sector												
7 (7)	word	Number of sectors												

(Continued)

Table 3.135. Continued

**For Read/Write Track (CL=61/41H):**

Offset	Length	Name	Bit Numbers								Allowable Settings	
			7	6	5	4	3	2	1	0		
9 (9)	dbl word	Transfer address										Segment:Offset of transfer buffer

**For Format/Verify Track (CL=42/62H):**

Offset	Length	Name	Bit Numbers								Allowable Settings	
			7	6	5	4	3	2	1	0		
0 (0)	byte	Special functions										
1 (1)	word	Head										Head number to format/verify
3 (3)	word	Cylinder										Cylinder number to format/verify

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Source:** IBM DOS 3.3 Technical Reference, pages 6-169 to 6-180

**See Also:** 3.084. Function 44H, 0DH -- Generic IOCTL For Devices  
 3.134. Block Device Function Codes  
 3.167. Device BPB Layout

**3.136. PROGRAM SEGMENT PREFIX LAYOUT**

Offset	Length	Usual Contents	Description	Comments
0 (0)	word	CD20H	Int 20H termination address	
2 (2)	word		End of memory allocation block	Is a segment address
4 (4)	byte	00H	RESERVED	
5 (5)	5 bytes		CALL FAR to DOS function dispatcher	Obsolete
A (10)	dbl word		Int 22H terminate handler address	Restored at exit of program; stored as IP:CS
E (14)	dbl word		Int 23H Ctrl-Break handler address	Stored as IP:CS
12 (18)	dbl word		Int 24H Critical Error handler address	Stored as IP:CS
16 (22)	word		Parent process's PSP	Is a segment address
18 (24)	20 bytes	FF=available	Handle table	One byte per handle, bit 7=not inherited
2C (44)	word		Environment block address	Is a segment address
2E (46)	dbl word		RESERVED	
32 (50)	word	14H,00H	Handle table size	DOS 3.3 allows larger tables
34 (52)	dbl word	12H,00H	Handle table address (if not at 12H)	DOS 3.3 allows table address
38 (56)	23 bytes		RESERVED	
50 (80)	word	CD21H	Int 21H DOS CALL	
52 (82)	byte	CBH	RET FAR	
53 (83)	9 bytes		RESERVED	
5C (92)	36 bytes		Default unopened file control block #1	
6C (108)	20 bytes		Default unopened file control block #2	Overlays FCB #1
80 (128)	byte		Length of command line parameters	Also start of default DTA
81 (129)	127 bytes		Command line parameters	Starts with blank, ends with a CR

**Notes:** FCB's only useful information is drive number and filename

**Sources:** IBM DOS 3.3 Technical Reference, pages 7-10 to 7-11

**See Also:** 3.002. INT 21H Keyboard Functions Summary  
 3.006. INT 21H System Functions Summary  
 3.042. Function 26H -- Create New Program Segment  
 3.116. Function 62H -- Get Program Segment Prefix  
 3.123. Unopened FCB Format

## 3.137. LOGICAL DRIVE NUMBERS

*In FCBs, Functions 1CH, 36H, some 44H subfunctions, and 47H:*

Value	Drive
0 (0)	Default
1 (1)	A
2 (2)	B
3 (3)	C
4 (4)	D
5 (5)	E
6 (6)	F
7 (7)	G
8 (8)	H
9 (9)	I
A (10)	J
B (11)	K
C (12)	L
D (13)	M
E (14)	N
F (15)	O
10 (16)	P
11 (17)	Q
12 (18)	R
13 (19)	S
14 (20)	T
15 (21)	U
16 (22)	V
17 (23)	W
18 (24)	X
19 (25)	Y
1A (26)	Z

*In Functions 0EH and 19H:*

Value	Drive
0 (0)	A
1 (1)	B
2 (2)	C
3 (3)	D
4 (4)	E
5 (5)	F
6 (6)	G
7 (7)	H
8 (8)	I
9 (9)	J
A (10)	K
B (11)	L
C (12)	M
D (13)	N
E (14)	O
F (15)	P
10 (16)	Q
11 (17)	R
12 (18)	S
13 (19)	T
14 (20)	U
15 (21)	V
16 (22)	W
17 (23)	X
18 (24)	Y
19 (25)	Z

**Source:** IBM DOS 3.3 Technical Reference, page 6-66

**See Also:** 3.124. Opened FCB Format

## 3.138. EXECUTE PROGRAM PARAMETER BLOCK

Offset	Length	Name	Function
0 (0)	word	Environment address	Segment address of environment to be passed, or 00H to use parent process's environment
2 (2)	dbl word*	Command line	Segment:Offset address of a command line to be placed at 80H in child process's PSP
6 (6)	dbl word*	First FCB	Segment:Offset address of a FCB to be placed at 5CH of child process's PSP
A (10)	dbl word*	Second FCB	Segment:Offset address of a second FCB to be placed at 6CH of child process's PSP

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*dbl words are in Offset:Segment format (i.e., least significant word first)

**Source:** IBM DOS 3.3 Technical Reference, page 6-197

**See Also:** 3.093. Function 4BH, 00H -- Load and Execute Program  
3.136. Program Segment Prefix Layout  
3.141. Environment Blocks

**3.139. OVERLAY PROGRAM PARAMETER BLOCK**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	word	Load address	Segment address where overlay is to be loaded
2 (2)	word	Relocation factor	Segment offset where overlay is to be loaded (normally same as load address, but may be increased to overlay only higher portion of a program)

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Source:** IBM DOS 3.3 Technical Reference, page 6-157

**See Also:** 3.094. Function 4BH, 03H -- Load Overlay  
3.138. Execute Program Parameter Block

**3.140. MEMORY ALLOCATION STRATEGIES**

<i>Value</i>	<i>Name</i>	<i>Description</i>
0	First fit	Search beginning at lowest available memory and allocate first block large enough to accommodate request (default)
1	Best fit	Search all blocks and allocate smallest block that accommodates request
2	Last fit	Search beginning at highest available memory and allocate first block large enough to accommodate request

**Version Info:** Applies to all versions of DOS beginning with 3.0

**Source:** MS-DOS Programmer's Reference Version 3.3, page 262  
Missing from the IBM DOS 3.3 Technical Reference!

**See Also:** 3.090. Function 48H -- Allocate Memory  
3.091. Function 49H -- Free Allocated Memory  
3.092. Function 4AH -- Set Block  
3.103. Function 58H, 00H -- Get Allocation Strategy  
3.104. Function 58H, 01H -- Set Allocation Strategy

**3.141. ENVIRONMENT BLOCKS**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Allowable Settings</i>
0 (0)	varies	Environment string 1	ASCII string, in form: PARAMETER=VALUE
varies	byte	String terminator	Must be a 0
varies	varies	Environment string 2	ASCII string in form: PARAMETER=VALUE
varies	byte	String terminator	Must be a 0

and so on, until last string:

varies	varies	Environment string n	ASCII string in form: PARAMETER=VALUE
varies	byte	String terminator	Must be a 0
varies	byte	String terminator	Must be a 0
varies	word	Count	Number of other ASCIIZ strings following
varies	varies	Initial argument string	ASCIIZ path and file name of current process

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** An environment may have no environment strings, in which case the first two bytes are 00,00

**Source:** IBM DOS 3.3 Technical Reference, pages 6-198 to 2-199

3.142. PARSE CONTROL BYTE

Bit Position								Function	Allowable Settings
7	6	5	4	3	2	1	0		
							X	Separator control	0=stop parsing if separator is encountered 1=ignore leading file separators
						X		Drive # control	0=set FCB drive number to 0 if no drive in string 1=leave FCB drive number unchanged if no drive in string
				X				File name control	0=set FCB filename to blanks if no name in string 1=leave FCB filename unchanged if no file name in string
			X					Extension control	0=set FCB filetype to blanks if no type in string 1=leave FCB filetype unchanged if nc type in string
X	X	X	X					UNUSED	Must be 0

**Notes:** Filename separators are . ; , = + / " [ ] \ < > | SPACE TAB

**Source:** IBM DOS 3.3 Technical Reference, pages 6-96 to 6-97

**See Also:** 2.51. File Separator Characters  
3.045. Function 29H -- Parse File Name

3.143. COUNTRY CODE BUFFER LAYOUT

Offset	Length	Name	Contents	USA Value
0 (0)	word	Date format	0 = American (mm/dd/yy) 1 = European (dd/mm/yy) 2 = Japanese (yy/mm/dd)	0
2 (2)	5 byte	Currency symbol	ASCII String	\$
7 (7)	2 byte	Thousands separator	ASCII String	.
9 (9)	2 byte	Decimal separator	ASCII String	.
B (11)	2 byte	Date separator*	ASCII String	/
D (13)	2 byte	Time separator*	ASCII String	.
F (15)	byte	Currency Code*	0 = currency symbol before amount, no spaces between 1 = currency symbol after amount, no spaces between 2 = currency symbol before amount, one space between 3 = currency symbol after amount, one space between 4 = currency symbol replaces decimal separator	0
10 (16)	byte	Currency places*	Binary value	2
11 (17)	byte	Time format*	0 = 12-hour clock 1 = 24-hour clock	1
12 (18)	dbl word	Case-Map call address*	Segment:offset address of FAR procedure that performs low:case to uppercase mapping on characters from 80H to FFH.	NA
16 (22)	2 bytes	Datalist separator*	ASCII String	NA
18 (24)	10 bytes	RESERVED		NA

**Version Info:** \*Applies to all versions of DOS beginning with 2.0  
\*DOS 3.x only

**Source:** IBM DOS 3.3 Technical Reference, page 6-115

**See Also:** 3.057. Function 38, 00H -- Get Country Data  
3.144. Country Codes

## 3.144. COUNTRY CODES

**Numerical Order**

Code	Country	Keyboard Code
001	United States	US
002	Canada (French)	CF
002	Canada (English)	US
003	Latin America	LA
031	Netherlands	NL
032	Belgium	BE
033	France	FR
034	Spain	SP
039	Italy	IT
041	Switzerland (French)	SF
041	Switzerland (German)	SG
044	Great Britain	UK
045	Denmark	DK
046	Sweden	SV
047	Norway	NO
049	West Germany	GR
061	Australia	US
351	Portugal	PO
358	Finland	SU
785	Middle East (Arabic)	-
972	Israel (Hebrew)	-

**Alphabetic Order**

Code	Country	Keyboard Code
061	Australia	US
032	Belgium	BE
002	Canada (English)	US
002	Canada (French)	CF
045	Denmark	DK
358	Finland	SU
033	France	FR
044	Great Britain	UK
972	Israel (Hebrew)	-
039	Italy	IT
003	Latin America	LA
785	Middle East (Arabic)	-
031	Netherlands	NL
047	Norway	NO
351	Portugal	PO
034	Spain	SP
046	Sweden	SV
041	Switzerland (French)	SF
041	Switzerland (German)	SG
001	United States	US
049	West Germany	GR

**Version Info:** Applies to all version of DOS beginning with 2.0

**Notes:** Country codes are usually the international telephone prefix number for the country

**Source:** IBM DOS 3.3 Reference, page B-2

**See Also:** 3.143. Country Code Buffer Layout

## 3.145. DOS MEMORY CONTROL BLOCKS

Offset	Length	Name	Contents
0	byte	Location	4DH (M) if not last block; 5AH (Z) if last block
1	word	Process ID	PSP segment address
3	word	Allocation amount	Number of paragraphs allocated
5	11 bytes	RESERVED	RESERVED

**Version Info:** Applies to all version of DOS beginning with 2.0

**Notes:** Memory control block and memory controlled are adjacent in memory

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, page 179

**See Also:** 3.092. Function 4AH -- Set Block

## 3.146. CODE PAGE PARAMETER BLOCKS

**When CL=4AH, 4DH, or 6BH**

Offset	Length	Name	Contents
0	word	Packet length	Must be 2, the length of the packet
2	word	Packet ID	Code page ID

**When CL=4CH**

Offset	Length	Name	Contents
0	word	Packet flags	0
2	word	Packet length	Number of bytes in remainder of packet
4	word	Number pages	Number of code pages in following list
6	word	Code page 1	
8	word	Code page 2	

and so on, until:

varies	word	Code page n	
--------	------	-------------	--

**When CL=6AH**

Offset	Length	Name	Contents
0	word	Packet length	$((n+1)+(m+1))*2$
2	word	Hrdw # pages	n
4	word	Hrdw page 1	
6	word	Hrdw page 2	

and so on, until:

varies	word	Hrdw page n	
varies	word	Prepd # pages	m
varies	word	Prepd page 1	
varies	word	Prepd page 2	

and so on, until:

varies	word	Prepd page m	
--------	------	--------------	--

**Version Info:** Applies only to DOS 3.3

**Source:** IBM DOS 3.3 Technical Reference, pages 6-160 to 6-162

**See Also:** 3.120. Function 66H, 02H -- Set Global Code Page

**3.147. CODE PAGE ASSIGNMENTS****Code Pages**

<i>Code Page</i>	<i>Language</i>
437	USA English
850	multilingual
860	Portuguese
863	Canadian French
865	Norwegian and Danish

<i>Use Code Page</i>	<i>Country</i>	<i>Prev Code Page</i>	<i>Keyboard Code</i>
850	Australia	437	US
850	Belgium	437	BE
850	Canada (English)	437	US
850	Canada (French)	863	CF
850	Denmark	865	DK
850	Finland	437	SU
850	France	437	FR
850	Germany	437	GR
850	Italy	437	IT
850	Latin America	437	LA
850	Netherlands	437	NL
850	Norway	865	NO
850	Portugal	860	PO
850	Spain	437	SP
850	Sweden	437	SV
850	Switzerland (French)	437	SF
850	Switzerland (German)	437	SG
850	United Kingdom	437	UK
850	United States	437	US

**Version Info:** Applies to DOS 3.3 only

**Source:** IBM DOS 3.3 Reference, pages 9-5 to 9-7

**See Also:** 3.120. Function 66H, 02H -- Set Global Code Page

**3.148. RESERVED DEVICE NAMES AND CHAIN ORDER**

<i>Name</i>	<i>Description</i>
NUL	Null device
---	Drivers established in CONFIG.SYS, in order encountered
CON	Console keyboard and display
AUX	Auxiliary device (COM1:)
PRN	Printer device (LPT1:)
CLOCK	Timer device (system clock 18.2 ticks/second)

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:**

- You may substitute your own device drivers for CON, AUX, PRN, and CLOCK (by redirecting their handles), but you may not redirect NUL
- Devices are "chained" in the order presented in the above table (i.e., NUL is the first entry in the device chain, the CONFIG.SYS drivers are next, and so on)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, page 254

**See Also:** 3.130. Predefined Handles

**3.149. DEVICE DRIVER HEADERS**

Offset	Length	Name	Function
0 (0)	dbl word	Next device pointer	Offset:segment* address of next device in file, or FFFF FFFF if last driver
4 (4)	word	Device attribute code	See 3.150. Device Attribute Codes
6 (6)	word	Device strategy pointer	Offset address to device strategy routine
8 (8)	word	Device interrupt pointer	Offset address to device interrupt routine
A (10)	8-bytes	Device name	ASCII device name; for block devices, first byte is number of units

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Note that first word is offset within segment, second word is segment address

**Source:** IBM DOS 3.3 Technical Reference, page 2-6

**See Also:** 3.150. Device Attribute Codes

**3.150. DEVICE ATTRIBUTE CODES**

*For Character-oriented Devices:*

Bit Numbers																Name	Allowable Settings
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
X																Device type	1=device is character oriented
	X															Control string support	0=doesn't support control strings 1=supports IOCTL control strings
		X														Output until busy support	0=doesn't support output until busy 1=supports output until busy
			X		X	X	X	X		X	X					RESERVED	
				X												Understands open/close	0=doesn't understand open/close 1=understands open/close
									X							Supports IOCTL functions	0=doesn't support IOCTL functions 1=supports IOCTL functions
												X				Clock device	0=is not a clock device 1=is a clock device
													X			Null device	0=is not a null device 1=is a null device
														X		Console output device	0=is not console output device 1=is console output device
															X	Console input device	0=is not console input device 1=is console input device

*For Block-oriented Devices:*

Bit Numbers																Name	Allowable Settings
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
X																Device type	0=block-oriented device
	X															Control string support	0=doesn't support control strings 1=supports IOCTL control strings
		X														Media type determiner	0=doesn't use FAT ID byte 1=uses FAT ID byte to find type*
			X		X	X	X	X		X	X	X	X	X	X	RESERVED	
				X												Understands open/close Removable media	0=doesn't understand open/close 1=understands open/close
									X							Supports IOCTL functions	0=doesn't support IOCTL functions 1=supports IOCTL functions

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*If FAT ID byte used, the first sector of the FAT must always be in the same physical location

**Source:** IBM DOS 3.3 Technical Reference, pages 2-7 to 2-10

**See Also:** 3.149. Device Driver Headers

**3.151. DEVICE REQUEST HEADER STATUS FIELD & ERROR CODES**

**Status Field**

*Bit Numbers*

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Name	Allowable Values
X																Error	0=no error 1=error
	X	X	X	X	X											RESERVED	
						X										Busy	0=not busy 1=busy
							X									Done	0=operation in progress 1=operation complete
								X	X	X	X	X	X	X	X	Error code	See table below

**Error Codes**

*Bit Numbers*

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Error Name
X																0=write-protect violation
X															X	1=unknown unit
X														X		2=drive not ready
X														X	X	3=unknown command
X													X			4=CRC error
X												X		X		5=bad drive request structure length
X													X	X		6=seek error
X													X	X	X	7=unknown media
X												X				8=sector not found
X												X			X	9=printer out of paper
X												X		X		A=write fault
X												X		X	X	B=read fault
X												X	X			C=general failure
X												X	X		X	D=RESERVED
X												X	X	X		E=RESERVED
X												X	X	X	X	F=invalid disk change

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Source:** IBM DOS 3.3 Technical Reference, pages 2-18 to 2-19

**See Also:** 3.152. Device Request Header

## 3.152. DEVICE REQUEST HEADER

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of record	Length, in bytes, of the entire request header (including code specific items)
1 (1)	byte	Unit code	Subunit (minor device within a block device) that request is intended for
2 (2)	byte	Command code	0 = init 1 = media check (block devices only) 2 = build BPB (block devices only) 3 = IOCTL input 4 = input (read from device) 5 = non-destructive input, no wait (character devices only) 6 = input status (character devices only) 7 = flush input (character devices only) 8 = output (write to device) 9 = output with verify (write to device) 10 = output status (character devices only) 11 = flush output (character devices only) 12 = IOCTL output 13 = open device 14 = close device 15 = removable media (block devices only) 16 = output until busy 19 = generic IOCTL request (block devices only) 23 = get drive map (block devices only) 24 = set drive map (block devices only)
3 (3)	word	Status	0 before call; set by device routine on return
5 (5)	8-bytes	RESERVED	

**Version, Info:** Applies to all versions of DOS beginning with 2:0

**Notes:**

- All unused command codes are reserved
- Many of the command codes require that the appropriate bit be set in the device attribute code

**Source:** IBM DOS 3.3 Technical Reference, pages 2-16 to 2-17

**See Also:**

- 3.150. Device Attribute Codes
- 3.153. Init Device Request
- 3.154. Media Check Request
- 3.155. Build BIOS Parameter Block Request
- 3.156. Read Device Request
- 3.157. Write Device Request
- 3.158. Non-Destructive Read with No Wait Request
- 3.159. Open or Close Request
- 3.160. Removable Media Request
- 3.161. Status Request
- 3.162. Flush Request

**3.153. INIT DEVICE REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 23
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	0 = INIT request
3 (3)	word	Status	See 3.152. Device Request Header
5 (5)	8-bytes	RESERVED	
D (13)	byte	Number of units	Number of units in block device
E (14)	dbl word	End address pointer	Segment:offset of resident portion of driver (returned by Init)
12 (18)	dbl word	BPB array pointer	Segment:offset of BPB for block devices (name returned by Init)*
16 (22)	byte	Block device number	Logical drive assignment for first unit (0=A, 1=B, etc.)

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** \*Note that double words are formatted as offset first, segment second  
\*On return, BPB array pointer will point to the first character following the equal sign (=) on the line of the CONFIG.SYS that created the device

**Source:** IBM DOS 3.3 Technical Reference, pages 2-21 to 2-22

**See Also:** 3.152. Device Request Header

**3.154. MEDIA CHECK REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 19
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	1 = media check
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	
D (13)	byte	Media descriptor	Type of drive
E (14)	byte	Check status	Returned by function 1=not changed, 0=don't know, -1=changed
10 (16)	dbl word	Previous volume ID	Returned by function if bit 11 of attributes set and media changed

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** Double words are formatted as offset first, segment second

**Source:** IBM DOS 3.3 Technical Reference, pages 2-23 to 2-25

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.155. BUILD BIOS PARAMETER BLOCK REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 22
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	2 = build BPB
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	
D (13)	byte	Media descriptor	Type of drive
E (14)	dbl word	Transfer address pointer	Offset:segment of buffer address
12 (18)	dbl word	BPB pointer	Offset:segment of BPB

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** Double words are formatted as offset first, segment second

**Source:** IBM DOS 3.3 Technical Reference, pages 2-29 to 2-30

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.156. READ DEVICE REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 26
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	3 = read device (IOCTL); 4 = read device
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	
D (13)	byte	Media descriptor	Type of drive
E (14)	dbl word	Transfer address pointer	Offset:segment pointer to blank area to transfer data to
12 (18)	word	Byte/sector count	Number of bytes (character) or sectors (block) to read
14 (20)	word	Starting sector number	First sector to read (block devices only)
16 (22)	dbl word	Volume ID pointer	Returned offset:segment pointer to volume ID if error 0FH

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** Double words are formatted as offset first, segment second

**Source:** IBM DOS 3.3 Technical Reference, pages 2-32 to 2-33

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.157. WRITE DEVICE REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 26
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	8=write, 9=write w/verify, 12=IOCTL write, 16=output til busy
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	
D (13)	byte	Media descriptor	Type of drive
E (14)	dbl word	Transfer address pointer	Offset:segment pointer to data area to transfer data from
12 (18)	word	Byte/sector count	Number of bytes (character) or sectors (block) to write
14 (20)	word	Starting sector number	First sector to write (block devices only)
16 (22)	dbl word	Volume ID pointer	Returned Offset:segment pointer to volume ID if error 0FH

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** Double words are formatted as offset first, segment second

**Source:** IBM DOS 3.3 Technical Reference, pages 2-32 to 2-33

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.158. NON-DESTRUCTIVE READ WITH NO WAIT REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 14
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	5 = non destructive read with no wait function
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	
D (13)	byte	Character	Returned character from device

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Source:** IBM DOS 3.3 Technical Reference, page 2-34

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.159. OPEN OR CLOSE REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 13
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	13 = open, 14 = close
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Source:** IBM DOS 3.3 Technical Reference, pages 2-37 to 2-38

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.160. REMOVABLE MEDIA REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 13
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	15 = removable media
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	

**Version Info:** DOS 3.x only, and only if the open/close/removable media bit is set in the device attribute code

**Source:** IBM DOS 3.3 Technical Reference, page 2-39

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.161. STATUS REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 13
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	6 = input status, 10 = output status
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** Character devices only. Sets status word.

**Source:** IBM DOS 3.3 Technical Reference, page 2-35

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.162. FLUSH REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 13
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	7 = flush input, 11 = flush output
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Notes:** Character devices only; sets the status word

**Source:** IBM DOS 3.3 Technical Reference, page 2-36

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.163. GENERIC IOCTL REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)		Length of request record	Number of bytes in request; should be 23
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	19 = generic IOCTRL request
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	
D (13)	byte	Category code	See 3.083. Function 44H, 0CH Generic IOCTL for Handles
E (14)	byte	Function code	See 3.083. Function 44H, 0CH Generic IOCTL for Handles
F (15)	word	SI contents	?
11 (17)	word	DI contents	?
13 (19)	dbl word	Data buffer pointer	Offset:segment of pointer to a data buffer

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Source:** IBM DOS 3.3 Technical Reference, page 2-40

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.164. LOGICAL DRIVE MAP REQUEST**

<i>Offset</i>	<i>Length</i>	<i>Name</i>	<i>Function</i>
0 (0)	byte	Length of request record	Number of bytes in request; should be 21
1 (1)	byte	Unit code	Subunit (for block devices)
2 (2)	byte	Command code	23 = get map, 24 = set map
3 (3)	word	Status	See 3.151. Device Request Header Status Field & Error Codes
5 (5)	8-bytes	RESERVED	
D (13)	byte	Unit code	Logical drive
E (14)	byte	Command code	See 3.134. Block Device Function Codes
F (15)	word	Status	
11 (17)	dbl word	RESERVED	

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Source:** IBM DOS 3.3 Technical Reference, page 2-41

**See Also:** 3.150. Device Attribute Codes  
3.152. Device Request Header

**3.165. MEDIA DESCRIPTOR TABLE LAYOUT**

<i>Offset</i>	<i>Length</i>	<i>Name</i>
0 (0)	3 bytes	JUMP to boot code
3 (3)	8 bytes	OEM name/version
B(11)	word	Number of bytes per sector
D(13)	byte	Number of sectors per allocation unit
E(14)	word	Number of reserved sectors
10(16)	byte	Number of FATs
11(17)	word	Number of root directory entries
13(19)	word	Number of sectors in logical image
15(21)	byte	Media descriptor
16(22)	word	Number of sectors in each FAT
18(24)	word	Number of sectors per track
1A(26)	word	Number of heads
1C(28)	word	Number of hidden sectors
1E(30)	word	High order number of hidden sectors
20(32)	dbl word	Total number of logical sectors

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Source:** IBM DOS 3.3 Technical Reference, page 2-31  
MS-DOS 3.3 Programmer's Reference, page 352

**See Also:** 3.167. Device BPB Layout

**3.166. CLOCK DEVICE TABLE LAYOUT**

<i>Offset</i>	<i>Length</i>	<i>Name</i>
0 (0)	word	Days since Jan. 1, 1980 (low byte, high byte)
2 (2)	byte	Minutes
3 (3)	byte	Hours
4 (4)	byte	Hundredths of seconds
5 (5)	byte	Seconds

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Source:** IBM DOS 3.3 Technical Reference, page 2-42

**See Also:** 2.35. Date/Time Formats

**3.167. DEVICE BPB LAYOUT**

<i>Offset</i>	<i>Length</i>	<i>Name</i>
0 (0)	word	Bytes per sector
2 (2)	byte	Sectors per cluster
3 (3)	word	Reserved sectors
5 (5)	byte	Number of FATs
6 (6)	word	Number of root directory entries
8 (8)	word	Total number of sectors
A (10)	byte	Media descriptor
B (11)	word	Sectors per FAT
D (13)	word	Sectors per track
F (15)	word	Number of heads
11 (17)	dbl word	Number of hidden sectors
15 (21)	dbl word	RESERVED-1
19 (25)	6 bytes	RESERVED-2

**Version Info:** Applies to all versions of DOS beginning with 2.0

**Source:** IBM DOS 3.3 Technical Reference, page 6-175

— SECTION —

# 4

DOS BIOS  
Calls and  
Support Tables

---

4.001. BIOS SERVICES SUMMARY

Interrupt	Function*	Description	Models Supporting Function										Comments	
			PC	XT	PCjr	AT	Conv.	PS/2-30	PS/2-50	PS/2-60	PS/2-80			
0	NA	Divide by zero trap	X	X	X	X	X	X	X	X	X	X		
1	NA	Single-step (Debug mode)	X	X	X	X	X	X	X	X	X	X		
2 (NMI)	NA	Parity check routine	X	X	X	X	X	X	X	X	X	X		
	NA	Coprocessor interrupt direct	X	X	X	X	X	X	X	X	X	X		
	NA	Coprocessor interrupt via int 75, IRQ 13	X	X	X	X	X	X	X	X	X	X		
	NA	Keyboard interrupt routine	X	X	X	X	X	X	X	X	X	X		
	NA	I/O channel check			X									
	NA	Disk controller power on request												
	NA	System suspend												
	NA	Real time clock (alarm interrupt)												
	NA	System watchdog timer (IRQ0 missed)												
	NA	System watchdog timer (IRQ0 missed)												
3	NA	Microchannel DMA timer time-out interrupt	X	X	X	X	X	X	X	X	X	X		
4	NA	Breakpoint (Debug mode)	X	X	X	X	X	X	X	X	X	X		
5	NA	Overflow trap	X	X	X	X	X	X	X	X	X	X		
6	NA	Print screen	X	X	X	X	X	X	X	X	X	X		Address 500 indicates status
7	RESERVED	RESERVED												
8 (IRQ 0)	NA	Timer interrupt handler	X	X	X	X	X	X	X	X	X	X		18.2 times per second
9 (IRQ 1)	NA	Keyboard interrupt handler	X	X	X	X	X	X	X	X	X	X		
0A (IRQ 2)	NA	Cascade IRQ8 to IRQ15	X	X	X	X	X	X	X	X	X	X		Also vertical retrace for EGA/VGA on PS/2 models
0B (IRQ 3)	NA	COM2 controller interrupt entry	X	X	X	X	X	X	X	X	X	X		
0C (IRQ 4)	NA	COM1 controller interrupt entry	X	X	X	X	X	X	X	X	X	X		
0D (IRQ 5)	NA	LPT2: controller interrupt entry	X	X	X	X	X	X	X	X	X	X		Also 80287 entry on AT, hard disk on XT, Model 30, vertical retrace on PCjr
0E (IRQ 6)	NA	Disk controller interrupt entry	X	X	X	X	X	X	X	X	X	X		
0F (IRQ 7)	NA	LPT1: controller interrupt entry	X	X	X	X	X	X	X	X	X	X		

(Continued)

Table 4.001. Continued

Interrupt	Function*	Description	Models Supporting Function										Comments	
			PC	XT	AT	Conv.	PS/2-30	PS/2-50	PS/2-60	PS/2-80				
10H	0	VIDEO set mode	X	X	X	X	X	X	X	X	X	X		
	1	VIDEO set cursor type	X	X	X	X	X	X	X	X	X	X		
	2	VIDEO set cursor position	X	X	X	X	X	X	X	X	X	X		
	3	VIDEO read cursor position	X	X	X	X	X	X	X	X	X	X		
	4	VIDEO read light pen position	X	X	X	X	X	X	X	X	X	X		
	5	VIDEO select display page	X	X	X	X	X	X	X	X	X	X		
	6	VIDEO init window, or scroll contents up	X	X	X	X	X	X	X	X	X	X		Not implemented on PS/2
	7	VIDEO init window, or scroll contents down	X	X	X	X	X	X	X	X	X	X		
	8	VIDEO read attribute and char at cursor	X	X	X	X	X	X	X	X	X	X		
	9	VIDEO write attribute and char at cursor	X	X	X	X	X	X	X	X	X	X		
	0A	VIDEO write character only at cursor	X	X	X	X	X	X	X	X	X	X		Valid only for mode 4 CGA, modes 6-8 and 0A on PCjr
	0B	VIDEO set color palette	X	X	X	X	X	X	X	X	X	X		Not valid for MDA
	0C	VIDEO write graphics pixel	X	X	X	X	X	X	X	X	X	X		Not valid for MDA
	0D	VIDEO read graphics pixel	X	X	X	X	X	X	X	X	X	X		
	0E	VIDEO write text in teletype mode	X	X	X	X	X	X	X	X	X	X		
	0F	VIDEO get mode	X	X	X	X	X	X	X	X	X	X		
	10	VIDEO set palette registers	X	X	X	X	X	X	X	X	X	X		
	11	VIDEO character generator	X	X	X	X	X	X	X	X	X	X		EGA and PCjr only
	12	VIDEO alternate select	X	X	X	X	X	X	X	X	X	X		EGA only
	13	VIDEO write character string	X	X	X	X	X	X	X	X	X	X		EGA and VGA only
	14	VIDEO load LCD char font	X	X	X	X	X	X	X	X	X	X		Convertible only
	15	VIDEO return physical parameters	X	X	X	X	X	X	X	X	X	X		Convertible only
	16	RESERVED												
	17	RESERVED												
	18	RESERVED												
	19	RESERVED												
	1A	VIDEO read/write display combo code												
	1B	VIDEO return state information												
	1C	VIDEO save/restore video state												
	1D-FF	RESERVED												
11H		EQUIPMENT LIST	X	X	X	X	X	X	X	X	X	X		Returns EQUIP_FLAG from BIOS data area (See 4.002.)
12H		MEMORY SIZE	X	X	X	X	X	X	X	X	X	X		

(Continued)

Table 4.001. Continued

		Models Supporting Function										Comments	
Interrupt	Function*	PC	XT	PCir	AT	Conv.	PS/2-30	PS/2-50	PS/2-60	PS/2-80			
13H	0	FLOPPY DISK reset system	X	X	X	X	X	X	X	X	X	X	Considered obsolete except on original XT Only model 319 and 339 ATs  Diagnostics only on PS/2s Diagnostics only on PS/2s Not on ESDI controllers Diagnostics only on PS/2s Diagnostics only on PS/2s  Diagnostics only on PS/2s Diagnostics only on PS/2s Diagnostics only on PS/2s  Added beginning with XT BIOS dated 1/10/86; only model 319/339 ATs Only on ESDI controllers
	1	FLOPPY DISK get system status	X	X	X	X	X	X	X	X	X	X	
	2	FLOPPY DISK read disk	X	X	X	X	X	X	X	X	X	X	
	3	FLOPPY DISK write disk	X	X	X	X	X	X	X	X	X	X	
	4	FLOPPY DISK verify disk sectors	X	X	X	X	X	X	X	X	X	X	
	5	FLOPPY DISK format diskette track	X	X	X	X	X	X	X	X	X	X	
	6	DISK format cylinder set bad sector flags	X	X	X	X	X	X	X	X	X	X	
	7	DISK format drive starting at cylinder	X	X	X	X	X	X	X	X	X	X	
	8	DISK get current drive parameters	X	X	X	X	X	X	X	X	X	X	
	9	DISK init drive pair characteristics	X	X	X	X	X	X	X	X	X	X	
	0A	DISK read long	X	X	X	X	X	X	X	X	X	X	
	0B	DISK write long	X	X	X	X	X	X	X	X	X	X	
	0C	DISK seek to cylinder	X	X	X	X	X	X	X	X	X	X	
	0D	DISK alternate disk reset	X	X	X	X	X	X	X	X	X	X	
	0E	DISK read sector buffer	X	X	X	X	X	X	X	X	X	X	
	0F	DISK write sector buffer	X	X	X	X	X	X	X	X	X	X	
	10	DISK test for drive ready status	X	X	X	X	X	X	X	X	X	X	
	11	DISK recalibrate drive	X	X	X	X	X	X	X	X	X	X	
12	DISK controller RAM diagnostic	X	X	X	X	X	X	X	X	X	X		
13	DISK drive diagnostic	X	X	X	X	X	X	X	X	X	X		
14	DISK controller diagnostics	X	X	X	X	X	X	X	X	X	X		
15	DISK get disk type	X	X	X	X	X	X	X	X	X	X		
16	FLOPPY DISK change disk status	X	X	X	X	X	X	X	X	X	X		
17	FLOPPY DISK set disk type	X	X	X	X	X	X	X	X	X	X		
18	FLOPPY DISK set media type	X	X	X	X	X	X	X	X	X	X		
19	DISK park heads	X	X	X	X	X	X	X	X	X	X		
1A	DISK format unit	X	X	X	X	X	X	X	X	X	X		
1B-FF	RESERVED												
14H	0	SERIAL init port	X	X	X	X	X	X	X	X	X	X	2 ports on PCs, 4 ports on PS/2s 2 ports on PCs, 4 ports on PS/2s 2 ports on PCs, 4 ports on PS/2s 2 ports on PCs, 4 ports on PS/2s 4 ports on PS/2s 4 ports on PS/2s
	1	SERIAL write character to port	X	X	X	X	X	X	X	X	X	X	
	2	SERIAL read character from port	X	X	X	X	X	X	X	X	X	X	
	3	SERIAL return port status	X	X	X	X	X	X	X	X	X	X	
	4	SERIAL extended initialize	X	X	X	X	X	X	X	X	X	X	
5	SERIAL extended port control	X	X	X	X	X	X	X	X	X	X		
6-FF	RESERVED												

(Continued)

Table 4.001. Continued

Interrupt	Models Supporting Function										Comments	
	Function*	Description	PC	XT	PCir	AT	Conv.	PS/2-30	PS/2-50	PS/2-60		PS/2-80
15H	0	CASSETTE motor ON	X		X							Original PC only, later models didn't have port
	1	CASSETTE motor OFF	X		X							Original PC only, later models didn't have port
	2	CASSETTE read data blocks	X		X							Original PC only, later models didn't have port
	3	CASSETTE write data blocks	X		X							Original PC only, later models didn't have port
	4-0E	RESERVED										
	0F	DISK format periodic interrupt						X				
	10-1F	RESERVED										
	20	AL=10 SYSREQ setup;						X				
	21	AL=11 SYSREQ completion			X							
	22-3F	DEVICE power-on self-test error log										
	40	RESERVED										
	41	DEVICE read/modify profiles					X					
	42	DEVICE wait for external event					X					
	43	DEVICE request system power OFF					X					
	44	DEVICE read system status					X					
	45-4E	DEVICE activate internal modem power					X					
	4F	RESERVED										
	50-7F	KEYBOARD intercept						X				Model 319/339 ATs only
	80	RESERVED										
	81	DEVICE open device			X			X				
	82	DEVICE close device			X			X				
	83	DEVICE program termination			X			X				
	84	DEVICE event wait			X			X				
	85	JOYSTICK										
	86	SYSTEM system request key press						X				
	87	DEVICE wait						X				
	88	DEVICE mcve block						X				
	89	MEMORY get extended memory size			X			X				
	90	MEMORY switch to protected mode			X			X				
	91	DEVICE busy loop			X			X				
	92-BF	DEVICE set flag and complete interrupt			X			X				
	C0	RESERVED										
	C1	DEVICE return system parameters						X				Model 319/339 ATs only
	C2	DEVICE return extended BIOS seg.addr.						X				
	C3	DEVICE pointing device BIOS interfacs						X				
	C4	DEVICE enable watchdog time-out						X				
	C5-FF	DEVICE programmable option select						X				
		RESERVED										

(Continued)

Table 4.001. Continued

Interrupt	Function*	Description	Models Supporting Function										Comments	
			PC	XT	PCjr	AT	Conv	PS/2-30	PS/2-50	PS/2-60	PS/2-80			
16H	0	KEYBOARD read char from keyboard	X	X	X	X	X	X	X	X	X	X	Model 339 ATs only XT after 1/10/86, AT after 6/10/85 XT after 1/10/86, AT after 6/10/85 XT after 1/10/86, AT after 6/10/85 XT after 1/10/86, AT after 6/10/85 3 ports on PCs, 2 on PS/2s 3 ports on PCs, 2 on PS/2s PC loads system from disk, PCjr from cartridge or disk, others from any disk	
	1	KEYBOARD read keyboard status	X	X	X	X	X	X	X	X	X	X		
	2	KEYBOARD return keyboard flags	X	X	X	X	X	X	X	X	X	X		
	3	KEYBOARD typematic and delay	X	X	X	X	X	X	X	X	X	X		
	4	KEYBOARD click ON/OFF												
	5	KEYBOARD write		X		X	X	X	X	X	X	X		
	6-0F	RESERVED												
	10	KEYBOARD extended keyboard read		X		X	X	X	X	X	X	X		
	11	KEYBOARD extended keystroke status		X		X	X	X	X	X	X	X		
	12	KEYBOARD extended shift status		X		X	X	X	X	X	X	X		
	13-FF	RESERVED												
	17H	0	PRINTER write char to printer	X	X	X	X	X	X	X	X	X		3 ports on PCs, 2 on PS/2s 3 ports on PCs, 2 on PS/2s 3 ports on PCs, 2 on PS/2s
		1	PRINTER init printer port	X	X	X	X	X	X	X	X	X		
2		PRINTER return printer status	X	X	X	X	X	X	X	X	X			
3-FF		RESERVED												
18H		BASIC load BASIC	X	X	X	X	X	X	X	X	X	PC loads system from disk, PCjr from cartridge or disk, others from any disk		
	19H	BOOTSTRAP loader	X	X	X	X	X	X	X	X	X			
1AH	0	TIME OF DAY read clock count	X	X	X	X	X	X	X	X	X	XT after 1/10/86 XT after 1/10/86		
	1	TIME OF DAY set clock count	X	X	X	X	X	X	X	X	X			
	2	TIME OF DAY read real time clock	X	X	X	X	X	X	X	X	X			
	3	TIME OF DAY set real time clock	X	X	X	X	X	X	X	X	X			
	4	TIME OF DAY read date from RT clock	X	X	X	X	X	X	X	X	X			
	5	TIME OF DAY set date in RT clock	X	X	X	X	X	X	X	X	X			
	6	TIME OF DAY set alarm	X	X	X	X	X	X	X	X	X			
	7	TIME OF DAY reset alarm	X	X	X	X	X	X	X	X	X			
	8	TIME OF DAY set RTC-activated power ON	X	X	X	X	X	X	X	X	X			
	9	TIME OF DAY read RTC alarm time & status	X	X	X	X	X	X	X	X	X			
	0A	TIME OF DAY read system timer day count	X	X	X	X	X	X	X	X	X			
	0B	TIME OF DAY set system timer day count	X	X	X	X	X	X	X	X	X			
	0C-7F	RESERVED												
	80	SOUND set up multiplexer			X									
	81-FF	RESERVED												

**Legend:** X = supported  
 O = obsolete (implemented but not normally used)  
 P = partial or peculiar support, see comments  
 D = diagnostic call only

**Notes:** \*Usually value in AH register, values in hexadecimal

**Source:** Programmer's Guide to the IBM PC (Microsoft Press), Peter Norton, chapters 8 to 13  
 IBM PC/XT Technical Reference BIOS Listings  
 IBM PC/AT Technical Reference BIOS Listings  
 IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-10 to 2-122

**See Also:** 5.01. DOS Interrupt Usage by Version  
 5.08. INT 33H Mouse Functions Summary  
 5.23. INT 67H Expanded Memory Manager Functions Summary  
 7.04. PC Interrupt Usage Summary

4.002. BIOS MEMORY USAGE SUMMARY

Location	Length	Description	Bit Numbers										Comments		
			7	6	5	4	3	2	1	0					
40:00	Word	COM1 base address													
40:02	Word	COM2 base address													
40:04	Word	COM3 base address													Supported only by PS/2 BIOS
40:06	Word	COM4 base address													Supported only by PS/2 BIOS
40:08	Word	LPT1 base address													
40:0A	Word	LPT2 base address													
40:0C	Word	LPT3 base address													
40:0E	Word	LPT4 base address													
40:10	Byte	Installed hardware 1	X	X				X	X						PC, XT, AT & Convertible only Number of floppy drives (0-based) Video mode (01=40x25 color, 10=80x25 color, 11=80x25 mono) RESERVED (old PC and PCjr bits 2-3 indicate memory installed) Pointing device installed (PS/2 only) Math coprocessor installed (not on FCjr or Convertible) Floppy drives installed
40:11	Byte	Installed hardware 2	X	X				X	X						Number of printer adapters Internal modem (Convertible only) Joystick installed Number of RS-232 Adapters RESERVED (PCjr=DMA device installed) Convertible only in KBytes (0 to 640)
40:12	Byte	Power-on self test status													
40:13	Word	Memory size													
40:15	Word	RESERVED													
40:17	Byte	Keyboard control 1	X												Insert mode active Caps lock mode active Num lock mode active Scroll lock mode active Alt key held down Ctrl key held down Left Shift key held down Right Shift key held down Insert key held down Caps Lock key held down Num Lock key held down Scroll Lock key held down Pause mode active System Request key held down Left Alt key held down Left Ctrl key held down
40:18	Byte	Keyboard control 2	X	X											Insert key held down Caps Lock key held down Num Lock key held down Scroll Lock key held down Pause mode active System Request key held down Left Alt key held down Left Ctrl key held down
40:19	Byte	Alternate keypad entry													
40:1A	Word	Keyboard buffer head pointer													Points to first character in typeahead buffer
40:1C	Word	Keyboard buffer tail pointer													Points to last character in typeahead buffer
40:1E	32 bytes	Keyboard buffer													

(Continued)

Table 4.002. Continued

Location	Length	Description	Bit Numbers								Comments		
			7	6	5	4	3	2	1	0			
40:3E	Byte	Floppy recalibrate status	X										Interrupt flag RESERVED Recalibrate drive 3 Recalibrate drive 2 Recalibrate drive 1 Recalibrate drive 0 Write/read operation RESERVED Drive selected (binary value equals drive number) Drive 3 motor ON status Drive 2 motor ON status Drive 1 motor ON status Drive 0 motor ON status
40:3F	Byte	Floppy motor status	X										
40:40	Byte	Motor off counter											
40:41	Byte	Floppy previous operation status	X	X									Drive not ready Seek operation failed General controller failure CRC error on diskette read DMA overrun on operation Requested sector not found Address mark not found Invalid drive parameter No error Write-protect error Disk changed DMA attempt across 64K segment boundary Media type not found
40:42	7 bytes	Floppy controller status bytes											
40:49	Byte	Display mode											
40:4A	Word	Number of columns											
40:4C	Word	Length of regen buffer in bytes											
40:4E	Word	Address of regen buffer											
40:50	Word	Cursor position page 1											
40:52	Word	Cursor position page 2											
40:54	Word	Cursor position page 3											
40:56	Word	Cursor position page 4											
40:58	Word	Cursor position page 5											
40:5A	Word	Cursor position page 6											
40:5C	Word	Cursor position page 7											
40:5E	Word	Cursor position page 8											
40:60	Word	Cursor type											
40:62	Byte	Current display page											
40:63	Word	Video controller base address											
40:65	Byte	Current 3x8 register setting											
40:66	Byte	Current 3x9 register setting											

(Continued)

Table 4.002. Continued

Location	Length	Description	Bit Numbers										Comments	
			7	6	5	4	3	2	1	0				
40:67	Dbl word	Pointer to reset code												PS/2 only (except Model 30)
40:6B	Byte	RESERVED												
40:6C	Dbl word	Timer counter												
40:70	Byte	Timer overflow flag												
40:71	Byte	Break key state												Non-zero means timer passed 24 hours
40:72	Word	Reset flag												1234H=bypass mem test; 4321H=preserve mem (PS/2) 5678H=system suspended (Convert.); 9ABCH=mtg test (Convert.) ABCDH=system post loop (Convertible only) See 4.041. INT 13H, Disk System Status Byte Layout (not used PS/2)
40:74	Byte	Fixed disk previous operation status												XT only
40:75	Byte	Number of fixed drives												XT only
40:76	Byte	Fixed disk drive control												
40:77	Byte	Fixed disk controller port												
40:78	Byte	Printer 1 time-out value												
40:79	Byte	Printer 2 time-out value												
40:7A	Byte	Printer 3 time-out value												
40:7B	Byte	Printer 4 time-out value												PC, XT, and AT only
40:7C	Byte	COM1 time-out value												
40:7D	Byte	COM2 time-out value												
40:7E	Byte	COM3 time-out value												
40:7F	Byte	COM4 time-out value												
40:80	Word	Keyboard buffer start offset pointer												
40:82	Word	Keyboard buffer end offset pointer												
40:84	Byte	Video rows (minus one)												
40:85	Word	Char height (bytes/char)												
40:87	Byte	Video control states 1												
40:88	Byte	Video control states 2												
40:89	Word	RESERVED												
40:8B	Byte	Media control	X	X										Last floppy drive data rate* (AT, XT after 1/10/85, PS/2) Last floppy drive step rate (AT, XT after 1/10/85, PS/2) RESERVED AT, XT after 1/10/85, PS/2 only AT, XT after 1/10/85, PS/2 only AT, XT after 1/10/85, PS/2 only
40:8C	Byte	Fixed disk controller status												
40:8D	Byte	Fixed disk controller error status												
40:8E	Byte	Fixed disk interrupt control												
40:8F	Byte	RESERVED												
40:90	Byte	Drive 0 media state	X	X										Drive data rate* (AT, XT after 1/10/85, PS/2) Double stepping required (AT, XT after 1/10/85, PS/2) Media established (AT, XT after 1/10/85, PS/2) RESERVED Drive/media state** (AT, XT after 1/10/85, PS/2)
40:91	Byte	Drive 1 media state	X	X										Drive data rate* (AT, XT after 1/10/85, PS/2) Double stepping required (AT, XT after 1/10/85, PS/2) Media established (AT, XT after 1/10/85, PS/2) RESERVED Drive/media state** (AT, XT after 1/10/85, PS/2)

(Continued)

Table 4.002. Continued

Location	Length	Description	Bit Numbers										Comments		
			7	6	5	4	3	2	1	0					
40:92	Word	RESERVED													
40:94	Byte	Drive 0 current cylinder													
40:95	Byte	Drive 1 current cylinder													
40:96	Byte	Keyboard mode state, type flags	X												Read ID in progress Last character was first ID character Force Num Lock if read ID and KBX 101/102-key keyboard installed Right Alt key held down Right Ctrl key held down Last code was E0 hidden code Last code was E1 hidden code
40:97	Byte	Keyboard LED flags	X												Keyboard transmit error flag Mode indicator update Resend receive flag Acknowledgment received RESERVED (must be 0) LED state bits
40:98	Word	Offset address to user wait complete flag													
40:9A	Word	Segment address to user wait complete													
40:9C	Word	User wait count (low word)													
40:9E	Word	User wait count (high word)													
40:A0	Byte	Wait active flag	X												In microseconds In milliseconds Wait time elapsed and post RESERVED Int 15H Function 86H (Wait) has occurred
40:A1	7 bytes	RESERVED													
40:A8	Dbl word	Video parameter table pointer													EGA and PS/2 only
40:AC	Dbl word	Dynamic save area pointer													EGA and PS/2 only
40:B0	Dbl word	Alpha mode aux char gen pointer													EGA and PS/2 only
40:B4	Dbl word	Graphics mode aux char gen pointer													PS/2 only (not Model 30)
40:B8	Dbl word	Secondary save pointer													Set to zeros only
40:BC	8 bytes	RESERVED													
40:C0	64 bytes	RESERVED													
50:00	Byte	Print screen status byte													

Version Info: PS/2 Extended BIOS uses space at top of memory for an Extended BIOS data area

Notes:

- \*Drive data notes: 00 = 500 KB/second  
01 = 300 KB/second  
10 = 250 KB/second  
11 = RESERVED

\*\*Drive media state values not currently documented in IBM BIOS references

Source:

IBM PS/2 and PC BIOS Interface Technical Reference, pages 3-3 to 3-15

See Also:

- 4.003. Extended BIOS Data Area Layout
- 7.02. PC, AT, and PS/2 Memory Use Summary

**4.003. EXTENDED BIOS DATA AREA LAYOUT**

<i>Location</i>	<i>Function</i>
40:13	KB value below 640KB limit at which extended BIOS data area begins

<i>Offset</i>	<i>Function</i>
0	Single byte containing length of extended BIOS data area in KB
1	Beginning of extended BIOS data area

**Source:** IBM PS/2 and PC BIOS Technical Reference, page 3-15

**See Also:** 4.090. INT 15H, AH=C0H -- Return System Config Parameters  
 4.092. INT 15H, AH=C1H -- Return Ext BIOS Segment Address

**4.004. MODEL NUMBER BYTES**

<i>Model Byte*</i>	<i>Submodel**</i>	<i>Revision**</i>	<i>BIOS Version</i>	<i>Machine</i>
FF (255)	Not used	Not used	All	IBM PC
FE (254)	Not used	Not used	11/8/82	IBM PC/XT and Portable PC
FD (253)	Not used	Not used	All	IBM PCjr
FC (252)	Not used	Not used	1/10/84	IBM PC/AT
	00	01	6/10/85	IBM PC/AT
	01	00	11/15/85	IBM PC/AT
	04	00	Initial	IBM PS/2 Model 50
	05	00	Initial	IBM PS/2 Model 60
	02	00	All	IBM PC/XT286
FB (251)	00	01	1/10/86	IBM PC/XT
	00	02	5/9/86	IBM PC/XT
FA (250)	00	00	9/2/86	IBM PS/2 Model 30
F9 (249)	00	00	9/13/85	IBM PC Convertible
F8 (248)	00	00	Initial	IBM PS/2 Model 80
	01	00	Initial	IBM PS/2 Model 80
FE (254)	Not supported	Not supported		Compaq DeskPro
2D (45)	Not supported	Not supported		Compaq Portable
9A (154)	Not supported	Not supported		Compaq Portable Plus
4B (75)	Not supported	Not supported		MegaBIOS ROM (Display Telecom)
B6 (182)	Not supported	Not supported		HP110 Portable (original model)

**Notes:**

- Many non-IBM machines use the same Machine ID Byte as the IBM machine they emulate
- \*The model number byte is located at F000:FFFE.
- \*\*Submodel and revision numbers are returned by BIOS service INT 15H, AH=C0H (Return System Config Parameters)

**Source:** IBM PS/2 and PC BIOS Technical Reference, page 4-18  
 Manufacturer's information (Compaq, et. al.)

**See Also:** 4.002. BIOS Memory Usage Summary

**4.005 INT 10H, AH=00H -- SET MODE**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	00H	Video mode*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

- Notes:**                   \*See 4.006. INT 10H, Display Modes
- Source:**                 IBM PS 2 and PC BIOS Interface Technical Reference, page 2-11
- See Also:**               4.001. BIOS Services Summary  
                               4.022. INT 10H, AH=0FH -- Get Current Display Mode

**4.006. INT 10H, DISPLAY MODES**

Mode Number	Type	Max Colors	Text Format	Max Pages	Buffer Start
0 (0)	Text	16	40x25	8	B8000
1 (1)	Text	16	40x25	8	B8000
2 (2)	Text	16	80x25	4* 8** 8***	B8000
3 (3)	Text	16	80x25	4* 8** 8***	B8000
4 (4)	Graphics	4	40x25	1	B8000
5 (5)	Graphics	4	40x25	1	B8000
6 (6)	Graphics	2	80x25	1	B8000
7 (7)	Text	Mono	80x25	1**** 8 ¥ 4 †	B0000
8 (8)	Graphics	16	20x25	1	B0000
9 (9)	Graphics	16	40x25	1	B0000
A (10)	Graphics	4	80x25	1	B0000
B (11)	RESERVED				
C (12)	RESERVED				
D (13)	Graphics	16	40x25	8 ¥	A0000
E (14)	Graphics	16	80x25	4 ¥	A0000
F (15)	Graphics	Mono	80x25	2 ¥	A0000
10 (16)	Graphics	16	80x25	2 ¥	A0000
11 (17)	Graphics	2	80x30	1***	A0000
12 (18)	Graphics	16	80x30	1***	A0000
13 (19)	Graphics	256	40x25	1***	A0000

- Notes:**                   \*\*CGA, PCJr, Convertible  
                               \*\*\*EGA  
                               \*\*\*\*PS/2  
                               \*\*\*\*\*MDA  
                               † Convertible  
                               ¥ EGA and PS/2 (except Model 30)
- Source:**                 IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-10 to 2-12
- See Also:**               4.005. INT 10H, AH=00H -- Set Mode  
                               4.022. INT 10H, AH=0FH -- Get Current Display Mode

**4.007. INT 10H, AH=01H -- SET CURSOR TYPE**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	01H	
BX		
CX	Starting scan line	Ending scan line
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

- Notes:**                   •CGA allowable scan lines=0 - 7; MDA = 0 -13  
                              •Note that setting bits 5 or 6 in CH may cause erratic behavior
- Source:**                 IBM PS/2 and PC BIOS Interface Technical Reference,  
                              pages 2-14 to 2-15
- See Also:**              4.001. BIOS Services Summary  
                              4.008. INT 10H, AH=02H -- Set Cursor Position  
                              4.009. INT 10H, AH=03H -- Read Cursor Position

**4.008. INT 10H, AH=02H -- SET CURSOR POSITION**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	02H	
BX	Display page	
CX		
DX	Row	Column
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

- Notes:**                   Page numbers, rows, and columns are 0-based  
                              (start with 0)
- Source:**                 IBM PS/2 and PC BIOS Interface Technical Reference,  
                              page 2-15
- See Also:**              4.001. BIOS Services Summary  
                              4.007. INT 10H, AH=01H -- Set Cursor Type  
                              4.009. INT 10H, AH=03H -- Read Cursor Position

**4.009. INT 10H, AH=03H -- READ CURSOR POSITION**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	03H	
BX	Display page	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX		
BX		
CX	Starting scan line	Ending scan line
DX	Row	Column
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:**                   •Page numbers, rows, and columns are 0-based (start with 0)  
                               •CX returns current cursor type

**Source:**                IBM PS/2 and PC BIOS Interface Technical Reference, page 2-15

**See Also:**             4.001. BIOS Services Summary  
                               4.007. INT 10H, AH=01H -- Set Cursor Type  
                               4.008. INT 10H, AH=02H -- Set Cursor Position

**4.010. INT 10H, AH=04H -- READ LIGHT PEN POSITION**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	04H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Pen trigger signal	
BX		Pixel column
CX	Pixel row*	
DX	Character row	Character column
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Version Info:**        Light pen is not supported for Convertible or PS/2 models

**Notes:**                \*May be extended to BX for some graphics modes

**Source:**             IBM PS/2 and PC BIOS Interface Technical Reference, page 2-15

**See Also:**            4.001. BIOS Services Summary

**4.011. INT 10H, AH=05H -- SELECT DISPLAY PAGE**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	05H	Page number*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX		
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*Page numbers are 0-based  
 \*\* Used by PCjr only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-16

**See Also:** 4.001. BIOS Services Summary

**4.012. INT 10H, AH=06H -- INIT WINDOW, SCROLL WINDOW UP**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	06H	Lines to scroll up*
BX	Blank line attribute	
CX	Upper row	Left column
DX	Lower row	Right column
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Notes.** -BH contains attribute to use for all new blank lines created by function  
 \*0=blank entire window (Init Window)

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-16

**See Also:** 4.001. BIOS Services Summary  
 4.013. INT 10H, AH=07H -- Init Window, Scroll Window Down



**4.015. INT 10H, AH=09H -- WRITE CHARACTER AND ATTRIBUTE**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	09H	Character
BX	Page number	Attribute
CX	Number of characters to write*	
DX		

Interrupt returns no values

SP	
BP	
SI	
DI	

IP	
flags	

CS	
DS	
SS	
ES	

**Notes:** \*Does not wrap to next line (i.e., characters all on same row, up to limit)

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-17

**See Also:** 4.001. BIOS Services Summary  
 4.014. INT 10H, AH=08H -- Read Character and Attribute  
 4.016. INT 10H, AH=0AH -- Write Character Only at Cursor  
 4.019. INT 10H, AH=0CH -- Write Pixel

**4.016. INT 10H, AH=0AH -- WRITE CHARACTER ONLY AT CURSOR**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	0AH	Character
BX	Page number	
CX	Number of characters to write*	
DX		

Interrupt returns no values

SP	
BP	
SI	
DI	

IP	
flags	

CS	
DS	
SS	
ES	

**Notes:** \*Does not wrap to next line (i.e., characters all on same row, up to limit)

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-17

**See Also:** 4.001. BIOS Services Summary  
 4.014. INT 10H, AH=08H -- Read Character and Attribute  
 4.015. INT 10H, AH=09H -- Write Character and Attribute  
 4.019. INT 10H, AH=0CH -- Write Pixel

4.017. INT 10H, AH=0BH -- SET COLOR PALETTE

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	<i>High</i>	<i>Low</i>
AX	0BH	
BX	Palette ID*	Color ID**
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

- Notes:**                   \*0=red/green/brown, 1=cyan/magenta/white on CGA  
                              \*\*See 4.018. INT 10H, Palette and Color Values
- Source:**                IBM PS/2 and PC BIOS Interface Technical Reference, page 2-18
- See Also:**             4.001. BIOS Services Summary

4.018. INT 10H, PALETTE AND COLOR VALUES

*If BH=0, then BL register contains two nibble color values (foreground, background) as follows:*

<i>Value</i>	<i>Color</i>
0 (0)	Black
1 (1)	Blue
2 (2)	Green
3 (3)	Cyan
4 (4)	Red
5 (5)	Magenta
6 (6)	Brown
7 (7)	White
8 (8)	Gray
9 (9)	Light blue
A (10)	Light green
B (11)	Light cyan
C (12)	Light red
D (13)	Light magenta
E (14)	Yellow
F (15)	Bright white

*if BH=1, then BL register contains palette number, as follows:*

<i>Value</i>	<i>Palette</i>
0	Green/red/brown
1	Cyan/magenta/white

- Source:**                IBM Technical Reference Options and Adapters, CGA 8  
                              Microsoft QuickBASIC, page 453
- See Also:**             4.017. INT 10H, AH=0BH -- Set Color Palette

**4.019. INT 10H, AH=0CH -- WRITE PIXEL**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	0CH	Color*
BX		
CX	Pixel column	
DX	Pixel row	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

- Notes:** \*If bit 7 is set, the color value is XORed with current contents (except display mode 13H)
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-18
- See Also:** 4.001. BIOS Services Summary  
 4.015. INT 10H, AH=09H -- Write Character and Attribute  
 4.016. INT 10H, AH=0AH -- Write Character Only at Cursor  
 4.020. INT 10H, AH=0DH -- Read Pixel

**4.020. INT 10H, AH=0DH -- READ PIXEL**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	0DH	
BX	Page number*	
CX	Pixel column	
DX	Pixel row	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX		Color
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

- Notes:** \*Only if display mode supports more than one page
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-19
- See Also:** 4.001. BIOS Services Summary  
 4.014. INT 10H, AH=08H -- Read Character and Attribute  
 4.019. INT 10H, AH=0CH -- Write Pixel

**4.021. INT 10H, AH=0EH -- WRITE TEXT IN TELETYPE MODE**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	0EH	Character**
BX	Page number***	Foreground color*
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CX		
DS		
SS		
ES		

Interrupt returns no values

- Notes:**
- \*If in a graphics display mode
  - \*\*Carriage Return, Linefeed, Backspace, and Bell are treated as commands instead of displayable characters
  - \*\*\*For PC BIOS dated 4/24/81 and 10/19/81 only
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-19
- See Also:**
- 4.001. BIOS Services Summary
  - 4.015. INT 10H, AH=09H -- Write Character and Attribute
  - 4.016. INT 10H, AH=0AH -- Write Character Only at Cursor
  - 4.019. INT 10H, AH=0CH -- Write Pixel

**4.022. INT 10H, AH=0FH -- GET CURRENT DISPLAY MODE**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	High	Low
AX	0FH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CX		
DS		
SS		
ES		

	High	Low
AX	Columns	Display mode
BX	Page number	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CX		
DS		
SS		
ES		

- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-19
- See Also:**
- 4.001. BIOS Services Summary
  - 4.005. INT 10H, AH=00H -- Set Mode
  - 4.006. INT 10H, Display Modes

**4.023. INT 10H, AH=10H -- SET PALETTE REGISTERS**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	<i>High</i>	<i>Low</i>
AX	10H	Command*
BX	Value**	Palette reg***
CX		
DX	Offset of pointer to 17-byte table****	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to 17-byte table****	

Interrupt returns no values

- Version Info:** •Applies to PCjr and EGA-equipped systems only (includes PS/2 emulating EGA)
- Notes:** •\*0=set individual palette register; 1=set overscan register; 2=set all registers; 3=toggle intensify/blinking bit  
 •\*\*only if AL=0 or 1  
 •\*\*\*only if AL=0  
 •\*\*\*\*only if AL=2; table contains 16=byte palette registers, 1 byte overscan register
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-20 to 2-24
- See Also:** 4.001. BIOS Services Summary

**4.024. INT 10H, AH=11H -- CHARACTER GENERATOR**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	<i>High</i>	<i>Low</i>
AX	11H	Command*
BX	# Bytes/character**	Block to load***
CX	Count to store**	
DX	Character offset into table**	
SP		
BP	Pointer to user table**	
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Pointer to user table**	

Interrupt returns no values

- Version Info:** Applies to EGA-equipped systems only (includes PS/2 emulating EGA)
- Notes:** •\*0=user alpha load; 1=ROM monochrome set; 2=ROM 8x8 double dot; 3=set block specifier; other commands available, see Tech Ref  
 •\*\*only if AL=0  
 •\*\*\*only if AL=0, 1 or 2; if AL=3 BL=character block selection
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-24 to 2-32
- See Also:** 4.001. BIOS Services Summary

4.025. INT 10H, AH=12H -- ALTERNATE SELECT

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	<i>High</i>	<i>Low</i>
AX	12H	Value**
BX	***	Command*
CX	***	***
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Varies, see Technical Reference manual

**Version Info:** Applies to EGA-equipped systems only (includes PS/2 emulating EGA)

**Notes:**

- \*10H = return EGA information
- 20H = select alternate print screen routine
- 30H = select scan lines for alphanumeric modes
- 31H = default palette loading during set mode
- 32H = enable/disable video
- 33H = summing to gray shades
- 34H = cursor emulation
- \*\*0=enable, 1=disable for commands 31H-34H
- \*\*\*Register used by some commands, see Technical Reference manual

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-24 to 2-32

**See Also:** 4.001. BIOS Services Summary  
4.024. INT 10H, AH=11H -- Character Geherator

**4.026. INT 10H, AH=13H -- WRITE STRING**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

	<i>High</i>	<i>Low</i>
AX	13H	Mode*
BX	Page number	Attribute*
CX	Character count	
DX	Start cursor position	
SP		
BP	Offset of pointer to string	
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to string	

Interrupt returns no values

**Version Info:** Applies to AT and PS/2 only

**Notes:**

- \*If AL=00 then BL contains attribute, cursor is not moved
- AL=01 then BL contains attribute, cursor is updated
- AL=02 then string contains alternating character and attribute bytes and cursor is not moved (alpha modes only)
- AL=03 then string contains alternating character and attribute bytes and cursor is updated (alpha modes only)
- CR, LF, Backspace, and Bell are treated as commands, not characters

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-36 to 2-37

**See Also:** 4.001. BIOS Services Summary

**4.027. INT 10H, AH=1AH, AL=00H -- READ DISPLAY CODES**

<i>Prior to Issuing INT 10H</i>		<i>Upon Return from INT 10H</i>		
	<i>High</i>	<i>Low</i>		
AX	1AH	00H	AX	Status*
BX			BX	Alternate disp code**
CX			CX	Active disp code**
DX			DX	
SP			SP	
BP			BP	
SI			SI	
DI			DI	
IP			IP	
flags			flags	
CS			CS	
DS			DS	
SS			SS	
ES			ES	

- Version Info:** Applies to PS/2 models only
- Notes:** \*1AH= function was supported (display codes are valid)  
 \*\*See 4.029. INT 10H, Display Codes
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-39
- See Also:** 4.001. BIOS Services Summary

**4.028. INT 10H, AH=1AH, AL=01H -- WRITE DISPLAY CODES**

<i>Prior to Issuing INT 10H</i>		<i>Upon Return from INT 10H</i>		
	<i>High</i>	<i>Low</i>		
AX	1AH	01H	AX	Status*
BX	Alternate disp code**	Active disp code**	BX	
CX			CX	
DX			DX	
SP			SP	
BP			BP	
SI			SI	
DI			DI	
IP			IP	
flags			flags	
CS			CS	
DS			DS	
SS			SS	
ES			ES	

- Version Info:** Applies to PS/2 models only
- Notes:** \*1AH= function was supported (display codes were changed)  
 \*\*See 4.029. INT 10H, Display Codes
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-39
- See Also:** 4.001. BIOS Services Summary  
 4.027. INT 10H, AH=1AH, AL=00H -- Read Display Codes

**4.029. INT 10H, DISPLAY CODES**

<i>Value</i>	<i>Function</i>
0 (0)	No display
1 (1)	Monochrome with 5151 (monochrome) monitor
2 (2)	CGA with 5153/4 (color) monitor
3 (3)	RESERVED
4 (4)	EGA with 5153/4 (color) monitor
5 (5)	EGA with 5151 (monochrome) monitor
6 (6)	*PGS with 5175 (color) monitor
7 (7)	VGA with analog monochrome monitor (except Model 30)
8 (8)	VGA with analog color monitor (except Model 30)
9 (9)- A(10)	RESERVED
B (11)	Model 30 with analog monochrome monitor (MCGA)
C (12)	Model 30 with analog color monitor (MCGA)
D (13)-FE(254)	RESERVED
FF (255)	Unknown monitor type

**Notes:** \*PGS refers to Professional Graphics System

**Source:** IBM PS/2 and PC BIOS Technical Reference, page 2-39

**See Also:** 4.027. INT 10H, AH=1AH, AL=00H -- Read Display Codes  
4.028. INT 10H, AH=1AH, AL=01H -- Write Display Codes

**4.030. INT 10H, AH=1BH -- RETURN STATE**

*Prior to Issuing INT 10H*

*Upon Return from INT 10H*

		<i>High</i>	<i>Low</i>			<i>High</i>	<i>Low</i>
AX	1BH			AX	Status*		
BX	Implementation type***			BX			
CX				CX			
DX				DX			
SP				SP			
BP				BP			
SI				SI			
DI	Offset of pointer to empty buffer			DI	Offset of pointer to video state buffer**		
IP				IP			
flags				flags			
CS				CS			
DS				DS			
SS				SS			
ES	Segment of pointer to empty buffer			ES	Segment of pointer to video state buffer**		

**Version Info:** Applies to PS/2 models only

**Notes:** \*\*1BH= function was supported (buffer contains valid info)  
\*\*\*See 4.031. INT 10H, Video State Buffer Layout  
\*\*\*Currently only 00 is supported

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-40 to 2-44

**See Also:** 4.001. BIOS Services Summary

## 4.031. INT 10H, VIDEO STATE BUFFER LAYOUT

Offset	Size	Function	Allowable Values
0 (0)	word	Offset to static functionality info	
2 (2)	word	Segment of static functionality info	
4 (4)	byte	Video mode	See 4.006. INT 10H, Display Modes
5 (5)	word	Character columns in display	
7 (7)	word	Length of regenerator buffer	In bytes
9 (9)	word	Start address in regeneration buffer	
8 (11)	word	Cursor position for page 0	Row, column
D (13)	word	Cursor position for page 1	Row, column
F (15)	word	Cursor position for page 2	Row, column
11 (17)	word	Cursor position for page 3	Row, column
13 (19)	word	Cursor position for page 4	Row, column
15 (21)	word	Cursor position for page 5	Row, column
17 (23)	word	Cursor position for page 6	Row, column
19 (25)	word	Cursor position for page 7	Row, column
1B (27)	word	Cursor type	Start, end values
1D (29)	byte	Active display page	
1E (30)	word	CRT controller address	e.g., 3Bx for monochrome, 3Dx for color
20 (32)	byte	3x8 register setting	
21 (33)	byte	3x9 register setting	
22 (34)	byte	Character rows in display	
23 (35)	word	Character height	In scan lines per character
25 (37)	byte	Active display combination code	
26 (38)	byte	Alternate display combination code	
27 (39)	word	# colors supported in current mode	
29 (41)	byte	# pages supported in current mode	
2A (42)	byte	# scan lines supported in current mode	0=200, 1=350, 2=400, 3=480, 4-255=RESERVED
2B (43)	byte	Primary character block	0=block 0, 1=block 1, and so on/(RESERVED on PS/2 Model 30)
2C (44)	byte	Secondary character block	0=block 0, 1=block 1, and so on/(RESERVED on PS/2 Model 30)
2D (45)	byte	Miscellaneous information	Bits 6,7=RESERVED Bit 5: 0=background intensity ON, 1=blinking Bit 4: 0=no emulation, 1=cursor emulation ON Bit 3: 1=mode set default palette loading DISABLED Bit 2: 1=monochrome display attached Bit 1: 1=summing is active Bit 0: 1=all modes on all displays are active
2E (46)	3 bytes	RESERVED	
31 (49)	byte	Amt of available video memory	0=64K, 1=128K, 2=132K, 3=256K, 4-255=RESERVED
32 (50)	byte	Save pointer state information	Bits 6,7=RESERVED Bit 5: 1=DCC extension is active Bit 4: 1=palette override is active Bit 3: 1=graphics font override is active Bit 2: 1=alpha font override is active Bit 1: 1=dynamic save area is active Bit 0: 1=512-character set is active
33 (51)	13 bytes	RESERVED	

**Source:** IBM PS/2 and PC BIOS Technical Reference, pages 2-40 to 2-42

**See Also:** 4.030. INT 10H, AH=1BH -- Return State

**4.032. INT 10H, AH=1CH, AL=00H -- RETURN SAVE/RESTORE**

Prior to Issuing INT 10H		Upon Return from INT 10H		
	High	Low		
AX	1CH	00H	AX	Status*
BX	Requested states**		BX	Number 64-byte blocks for state
CX			CX	
DX			DX	
SP			SP	
BP			BP	
SI			SI	
DI			DI	
IP			IP	
flags			flags	
CS			CS	
DS			DS	
SS			SS	
ES			ES	

**Version Info:** Applies to PS/2 Models 50, 60 and 80 only

**Notes:**

- \*\*1CH= function was supported (BX is valid value)
- \*\*Bit 0 set = save/restore video hardware state
- Bit 1 set = save/restore video BIOS data area
- Bit 2 set = save/restore video DAC state and color registers
- Bits 3-15 should be set to 0 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-44 to 2-45

**See Also:** 4.001. BIOS Services Summary

**4.033. INT 10H, AH=1CH, AL=01H -- SAVE STATE**

Prior to Issuing INT 10H		Upon Return from INT 10H		
	High	Low		
AX	1CH	01H	AX	Status*
BX	Offset of pointer to video state buffer		BX	
CX	Requested states**		CX	
DX			DX	
SP			SP	
BP			BP	
SI			SI	
DI			DI	
IP			IP	
flags			flags	
CS			CS	
DS			DS	
SS			SS	
ES	Segment of pointer to video state buffer		ES	

**Version Info:** Applies to PS/2 models 50, 60 and 80 only

**Notes:**

- \*\*1CH= function was supported (states were saved)
- \*\*Bit 0 set = save/restore video hardware state
- Bit 1 set = save/restore video BIOS data area
- Bit 2 set = save/restore video DAC state and color registers
- Bits 3-15 should be set to 0 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-44 to 2-45

**See Also:** 4.001. BIOS Services Summary  
4.031. INT 10H, Video State Buffer Layout

4.034. INT 10H, AH=1CH, AL=02H -- RESTORE STATE

Prior to Issuing INT 10H		Upon Return from INT 10H	
	High	Low	
AX	1CH	02H	AX
BX	Offset of pointer to video state buffer		BX
CX	Requested states**		CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES	Segment of pointer to video state buffer		ES

**Version Info:** Applies to PS/2 models 50, 60 and 80 only

**Notes:**

- \*1CH= function was supported (states were restored)
- \*\*Bit 0 set = save/restore video hardware state
- Bit 1 set = save/restore video BIOS data area
- Bit 2 set = save/restore video DAC state and color registers
- Bits 3-15 should be set to 0 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-44 to 2-45

**See Also:** 4.001. BIOS Services Summary  
4.031. INT 10H, Video State Buffer Layout

4.035. INT 10H, AH=FEH -- GET VIDEO BUFFER (TOPVIEW)

Prior to Issuing INT 10H		Upon Return from INT 10H	
	High	Low	
AX	FEH		AX
BX			BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI	Offset of physical video buffer		DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES	Segment of physical video buffer		ES

**Notes:**

- Physical address is B000:0000H for MDA  
B800:0000H for CGA and EGA
- Logical address is memory assigned to video buffer by Topview
- Function is ignored if Topview is not running

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 418 to 419

**See Also:** 4.001. BIOS Function Summary  
4.036. INT 10H, AH=FFH -- Update Video Buffer (Topview)

**4.036. INT 10H, AH=FFH -- UPDATE VIDEO BUFFER (TOPVIEW)**

	<i>Prior to Calling INT 10H</i>	<i>Upon Return from INT 10H</i>																														
	<table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td style="width: 50px; text-align: center;"><i>High</i></td> <td style="width: 50px; text-align: center;"><i>Low</i></td> </tr> <tr> <td>AX</td> <td>FFH</td> </tr> <tr> <td>BX</td> <td></td> </tr> <tr> <td>CX</td> <td>Number of chars modified*</td> </tr> <tr> <td>DX</td> <td></td> </tr> <tr> <td>SP</td> <td></td> </tr> <tr> <td>BP</td> <td></td> </tr> <tr> <td>SI</td> <td></td> </tr> <tr> <td>DI</td> <td>Offset to first char modified</td> </tr> <tr> <td>IP</td> <td></td> </tr> <tr> <td>FLAGS</td> <td></td> </tr> <tr> <td>CS</td> <td></td> </tr> <tr> <td>DS</td> <td></td> </tr> <tr> <td>SS</td> <td></td> </tr> <tr> <td>ES</td> <td>Segment of logical video buffer</td> </tr> </table>	<i>High</i>	<i>Low</i>	AX	FFH	BX		CX	Number of chars modified*	DX		SP		BP		SI		DI	Offset to first char modified	IP		FLAGS		CS		DS		SS		ES	Segment of logical video buffer	Function returns no values
<i>High</i>	<i>Low</i>																															
AX	FFH																															
BX																																
CX	Number of chars modified*																															
DX																																
SP																																
BP																																
SI																																
DI	Offset to first char modified																															
IP																																
FLAGS																																
CS																																
DS																																
SS																																
ES	Segment of logical video buffer																															

**Notes:**

- \*Logical video buffer is obtained using Function FEH
- \*Function is ignored if Topview is not running
- \*Characters must be in sequence (i.e., contiguous)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 419 to 420

**See Also:** 4.001. BIOS Services Summary  
4.035. INT 10H, AH=FEH -- Get Video Buffer (Topview)

**4.037. INT 11H: GET EQUIPMENT LIST SERVICE**

	<i>Prior to Issuing INT 11H</i>	<i>Upon Return from INT 11H</i>																																																												
	<table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td style="width: 50px; text-align: center;"><i>High</i></td> <td style="width: 50px; text-align: center;"><i>Low</i></td> </tr> <tr> <td>AX</td> <td></td> </tr> <tr> <td>BX</td> <td></td> </tr> <tr> <td>CX</td> <td></td> </tr> <tr> <td>DX</td> <td></td> </tr> <tr> <td>SP</td> <td></td> </tr> <tr> <td>BP</td> <td></td> </tr> <tr> <td>SI</td> <td></td> </tr> <tr> <td>DI</td> <td></td> </tr> <tr> <td>IP</td> <td></td> </tr> <tr> <td>flags</td> <td></td> </tr> <tr> <td>CS</td> <td></td> </tr> <tr> <td>DS</td> <td></td> </tr> <tr> <td>SS</td> <td></td> </tr> <tr> <td>ES</td> <td></td> </tr> </table>	<i>High</i>	<i>Low</i>	AX		BX		CX		DX		SP		BP		SI		DI		IP		flags		CS		DS		SS		ES		<table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td style="width: 50px; text-align: center;"><i>High</i></td> <td style="width: 50px; text-align: center;"><i>Low</i></td> </tr> <tr> <td>AX</td> <td>Equipment flag word*</td> </tr> <tr> <td>BX</td> <td></td> </tr> <tr> <td>CX</td> <td></td> </tr> <tr> <td>DX</td> <td></td> </tr> <tr> <td>SP</td> <td></td> </tr> <tr> <td>BP</td> <td></td> </tr> <tr> <td>SI</td> <td></td> </tr> <tr> <td>DI</td> <td></td> </tr> <tr> <td>IP</td> <td></td> </tr> <tr> <td>flags</td> <td></td> </tr> <tr> <td>CS</td> <td></td> </tr> <tr> <td>DS</td> <td></td> </tr> <tr> <td>SS</td> <td></td> </tr> <tr> <td>ES</td> <td></td> </tr> </table>	<i>High</i>	<i>Low</i>	AX	Equipment flag word*	BX		CX		DX		SP		BP		SI		DI		IP		flags		CS		DS		SS		ES	
<i>High</i>	<i>Low</i>																																																													
AX																																																														
BX																																																														
CX																																																														
DX																																																														
SP																																																														
BP																																																														
SI																																																														
DI																																																														
IP																																																														
flags																																																														
CS																																																														
DS																																																														
SS																																																														
ES																																																														
<i>High</i>	<i>Low</i>																																																													
AX	Equipment flag word*																																																													
BX																																																														
CX																																																														
DX																																																														
SP																																																														
BP																																																														
SI																																																														
DI																																																														
IP																																																														
flags																																																														
CS																																																														
DS																																																														
SS																																																														
ES																																																														

**Notes:**

- \*Bit 0 = floppy drive installed
- Bit 1 = math coprocessor installed
- Bits 2-3 = 16K blocks RAM installed on system board\*\*
- Bits 4-5 = video mode (1=40x25 color, 2=80x25 color, 3=80x25 mono)
- Bits 6-7 = number of floppy drives - 1
- Bit 8 = DMA present\*\*
- Bits 9-11 = number of RS-232 cards attached
- Bit 12 = game port adapter attached\*\*
- Bit 13 = serial printer attached (PCJr only)
- Bit 13 = internal modem installed for all others
- Bits 14-15 = number of printers attached
- \*\*These bits have different meanings for AT and PS/2

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-46

**See Also:** 4.001. BIOS Services Summary

**4.038. INT 12H: GET MEMORY SIZE SERVICE**

*Prior to Issuing INT 12H*

*Upon Return from INT 12H*

		High	Low			High	Low
AX				AX		Memory size*	
BX				BX			
CX				CX			
DX				DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags			
CS				CS			
DS				DS			
SS				SS			
ES				ES			

**Version Info:** On PS/2, value in AX is total memory minus that allocated to the Extended BIOS data area

**Notes:** •All memory is assumed to be functional  
•\*In 1K bytes

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-47

**See Also:** 4.001. BIOS Services Summary

**4.039. INT 13H, AH=00H -- RESET DISK SYSTEM**

*Prior to Issuing INT 13H*

*Upon Return from INT 13H*

		High	Low			High	Low
AX		00H		AX		Status**	
BX				BX			
CX				CX			
DX			Drive*	DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags		Carry set on error*	
CS				CS			
DS				DS			
SS				SS			
ES				ES			

**Version Info:** •\*On PS/2 only  
•\*\*On PS/2 only, see 4.041. INT 13H, Disk System Status Byte Layout

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-48 to 2-49

**See Also:** 4.001. BIOS Services Summary  
4.041. Disk System Status Byte Layout

**4.040. INT 13H, AH=01H -- GET DISK SYSTEM STATUS**

**Prior to Issuing INT 13H**

**Upon Return from INT 13H**

High		Low		High		Low	
AX	01H			AX	Status*		
BX				BX			
CX				CX			
DX			Drive**	DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags	Carry set on error**		
CS				CS			
DS				DS			
SS				SS			
ES				ES			

- Version Info:**        \*\*On PS/2 and Extended BIOS only
- Notes:**             \*See 4.041. INT 13H, Disk System Status Byte Layout
- Source:**            IBM PS/2 and PC BIOS Interface Technical Reference, page 2-49
- See Also:**          4.001. BIOS Services Summary  
                          4.041. Disk System Status Byte Layout

**4.041. INT 13H, DISK SYSTEM STATUS BYTE LAYOUT**

Value	Floppy/Fixed	Description
0 (0)	Both	No error
1 (1)	Both	Invalid diskette parameter (bad command)
2 (2)	Both	Address mark was not found
3 (3)	Floppy	Attempted write on protected diskette
4 (4)	Both	Sector was not found
5 (5)	Fixed	Reset failed
6 (6)	Floppy	Diskette was removed
7 (7)	Fixed	Bad parameter table
8 (8)	Floppy	DMA overrun on previous operation
9 (9)	Both	Attempted to cross 64k segment boundary on DMA operation
A (10)	Fixed	Bad sector flag
B (11)	Fixed	Bad cylinder detected*
C (12)	Floppy	Media type requested was not found*
D (13)	Fixed	Invalid number of sectors in format*
E (14)	Fixed	Control data address mark detected*
F (15)	Fixed	DMA arbitration level out of allowable range*
10 (16)	Both	CRC or ECC error on disk read
11 (17)	Fixed	ECC corrected data error
20 (32)	Both	Controller failed
40 (64)	Both	Seek operation failed
80 (128)	Both	Drive timed out, assumed not ready
AA (170)	Fixed	Drive not ready
BB (187)	Fixed	Undefined error
CC (204)	Fixed	Write fault
EO (224)	Fixed	Status error
FF (255)	Fixed	Sense operation failed*

- Version Info:**        \*Documented for PS/2 and Extended BIOS only
- Notes:**             Fixed disk status byte applies to XT and AT hard disks; floppy applies to all models of IBM PCs
- Source:**            IBM PS/2 and PC BIOS interface Technical Reference, pages 2-49 and 2-59
- See Also:**          4.040. INT 13H, AH=01H -- Get Disk System Status

## 4.042. INT 13H, AH=02H -- READ DISK

*Prior to Issuing INT 13H*

	High	Low
AX	02H	# Sectors to read
BX	Offset of pointer to read buffer	
CX	Cylinder number	Sector number**
DX	Head number	Drive number***
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to read buffer	

*Upon Return from INT 13H*

	High	Low
AX	Status*	# Sectors read
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

- Notes:**
- Only value in DL is checked for an appropriate value
  - See 4.041. INT 13H, Disk System Status Byte Layout
  - \*\*For fixed drives, top 2 bits are HO bits of 10-bit cylinder number, bottom 6 bits are sector number
  - \*\*\*Bit 7=0 for floppy drive, 1 for fixed drive

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-50 and 2-60

**See Also:** 4.001. BIOS Services Summary  
4.041. Disk System Status Byte Layout  
4.043. INT 13H, AH=03H -- Write Disk

## 4.043. INT 13H, AH=03H -- WRITE DISK

*Prior to Issuing INT 13H*

	High	Low
AX	03H	# Sectors to write
BX	Offset of pointer to buffer with data	
CX	Cylinder number	Sector number**
DX	Head number	Drive number***
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to buffer with data	

*Upon Return from INT 13H*

	High	Low
AX	Status*	# Sectors written
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

- Notes:**
- Only value in DL is checked for an appropriate value
  - See 4.041. INT 13H, Disk System Status Byte Layout
  - \*\*For fixed drives, top 2 bits are HO bits of 10-bit cylinder number, bottom 6 bits are sector number
  - \*\*\*bit 7=0 for floppy drive, 1 for fixed drive

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-50 and 2-61

**See Also:** 4.001. BIOS Services Summary  
4.041. Disk System Status Byte Layout  
4.042. INT 13H, AH=02H -- Read Disk

**4.044. INT 13H, AH=04H -- VERIFY SECTORS**

*Prior to Issuing INT 13H*

	High	Low
AX	04H	# Sectors to verify
BX	Offset of pointer to data buffer****	
CX	Cylinder number	Sector number**
DX	Head number	Drive number***
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to buffer with data****	

*Upon Return from INT 13H*

	High	Low
AX	Status*	# Sectors verified
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** \*\*\*\*Not required for AT BIOS after 11/15/85, or for XT286, Convertible, or PS/2

**Notes:**

- Only value in DL is checked for an appropriate value
- \*See 4.041. INT 13H, Disk System Status Byte Layout
- \*\*For fixed drives, top 2 bits are HO bits of 10-bit cylinder number, bottom 6 bits are sector number
- \*\*\*Bit 7=0 for floppy drive, 1 for fixed drive

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-51 and 2-61 to 2-62

**See Also:**

- 4.001. BIOS Services Summary
- 4.041. Disk System Status Byte Layout
- 4.042. INT 13H, AH=02H -- Read Disk

**4.045. INT 13H, AH=05H -- FORMAT CYLINDER**

*Prior to Issuing INT 13H*

*Upon Return from INT 13H*

	High	Low
AX	05H	Number of sectors
BX	Offset of pointer to 4-byte address field****	
CX	Cylinder number	Sector number**
DX	Head number	Drive number***
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to 4-byte address field****	

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Notes:**

- \*Only value in DL is checked for an appropriate value
- \*\*See 4.041. INT 13H, Disk System Status Byte Layout
- \*\*\*For fixed drives, top 2 bits are HO bits of 10-bit cylinder number, bottom 6 bits are sector number
- \*\*\*\*Bit 7=0 for floppy drive, 1 for fixed drive
- \*\*\*\*\*Address field:

Byte	Meaning	Allowable Values
1	Cylinder number	
2	Head number	
3	Sector number	
4	Number bytes/sector	0=128, 1=256, 2=512, 3=1024

**Source:**

IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-51 to 2-52 and 2-62 to 2-63

**See Also:**

- 4.001. BIOS Services Summary
- 4.041. Disk System Status Byte Layout
- 4.046. INT 13H, AH=06H -- Format Cylinder Set Bad Sector Flags
- 4.047. INT 13H, AH=07H -- Format Drive Starting at Cylinder

**4.046. INT 13H, AH=06H -- FORMAT CYLINDER SET BAD SECTOR FLAGS**

*Prior to Issuing INT 13H*

*Upon Return from INT 13H*

	High	Low
AX	06H	Interleave
BX		
CX	Cylinder number	Sector number**
DX	Head number	Drive number***
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** Applies to XT, AT, XT286 and PS/2 with fixed disk drives only

**Notes:**

- \*Only value in DL is checked for an appropriate value
- \*See 4.041. INT 13H, Disk System Status Byte Layout
- \*\*Top 2 bits are HO bits of 10-bit cylinder number, bottom 6 bits are sector number
- \*\*\*Bit 7= 1 for fixed drive

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-63

**See Also:**

- 4.001. BIOS Services Summary
- 4.041. Disk System Status Byte Layout
- 4.045. INT 13H, AH=05H -- Format Cylinder
- 4.047. INT 13H, AH=07H -- Format Drive Starting at Cylinder

**4.047. INT 13H, AH=07H -- FORMAT DRIVE STARTING AT CYLINDER***Prior to Issuing INT 13H*

	High	Low
AX	07H	Interleave
BX		
CX	Cylinder number	Sector number**
DX	Head number	Drive number***
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return from INT 13H*

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** Applies to XT, AT, XT286 and PS/2 with fixed disk drives only

**Notes:**

- Only value in DL is checked for an appropriate value
- See 4.041. INT 13H, Disk System Status Byte Layout
- Top 2 bits are HO bits of 10-bit cylinder number, bottom 6 bits are sector number
- Bit 7= 1 for fixed drive

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-64

**See Also:**

- 4.001. BIOS Services Summary
- 4.041. Disk System Status Byte Layout
- 4.045. INT 13H, AH=05H -- Format Cylinder
- 4.046. INT 13H, AH=06H -- Format Cylinder Set Bad Sector Flags

**4.048. INT 13H, AH=08H -- READ DRIVE PARAMETERS***Prior to Issuing INT 13H*

	High	Low
AX	08H	
BX		
CX		
DX		Drive number*
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return from INT 13H*

	High	Low
AX	0	
BX	0	Drive type**
CX	Max cylinders	Max sectors/track***
DX	Max heads	Number drives
SP		
BP		
SI		
DI		Offset of pointer to 11-byte parm table
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		Segment of pointer to 11-byte parm table

**Version Info:** Applies to XT, AT and PS/2 only

**Notes:**

- C-based; bit 7=0 indicates floppy drive
- 01=360K, 02=1.2Mb, 03=720K, 04=1.44Mb
- Top 2 bits are HO bits of 10-bit max cylinders, bits 0-5 are max sectors per track

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-53 to 2-54

**See Also:** 4.001. BIOS Services Summary

**4.049. INT 13H, AH=09H -- INIT DRIVE PAIR CHARACTERISTICS**

<i>Prior to Issuing INT 13H</i>		<i>Upon Return from INT 13H</i>	
	<i>High</i>	<i>Low</i>	
AX	09H		AX
BX			BX
CX			CX
DX		Drive number*	DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
			Carry flag set if status is non-zero
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to XT, AT and PS/2 only

**Notes:** \*0-based; bit 7 indicates fixed drive  
 \*\*See 4.041. INT 13H, Disk System Status Byte Layout

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-65

**See Also:** 4.001. BIOS Services Summary  
 4.041. Disk System Status Byte Layout

**4.050. INT 13H, AH=0CH -- SEEK**

<i>Prior to Issuing INT 13H</i>		<i>Upon Return from INT 13H</i>	
	<i>High</i>	<i>Low</i>	
AX	0CH		AX
BX			BX
CX		Cylinder number***	CX
DX	Head number	Drive number*	DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
			Carry set if status is non-zero
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to XT, AT and PS/2 only

**Notes:** \*0-based; bit 7 set indicates fixed disk  
 \*\*See 4.041. INT 13H, Disk System Status Byte Layout  
 \*\*\*Bits 7-6 of CL are 2 HO bits of 10-bit cylinder number; CH=8 LO bits of 10-bit cylinder number

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-66

**See Also:** 4.001. BIOS Services Summary  
 4.041. Disk System Status Byte Layout

**4.051. INT 13H, AH=0DH -- ALTERNATE DISK RESET**

*Prior to Issuing INT 13H*

*Upon Return from INT 13H*

	High	Low
AX	0DH	
BX		
CX		
DX		Drive number*
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Status**	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set if status is non-zero	
CS		
DS		
SS		
ES		

**Version Info:** Applies to XT, AT and PS/2 only

**Notes:** \*\*0-based; bit 7 set indicates fixed disk  
 \*\*See 4.041. INT 13H, Disk System Status Byte Layout

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-66

**See Also:** 4.001. BIOS Services Summary  
 4.041. Disk System Status Byte Layout

**4.052. INT 13H, AH=10H -- TEST DRIVE READY**

*Prior to Issuing INT 13H*

*Upon Return from INT 13H*

	High	Low
AX	10H	
BX		
CX		
DX		Drive number*
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Status**	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set if status is non-zero	
CS		
DS		
SS		
ES		

**Version Info:** Applies to XT, AT and PS/2 only

**Notes:** \*\*0-based; bit 7 set indicates fixed drive  
 \*\*See 4.041. INT 13H, Disk System Status Byte Layout

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-66 to 2-67

**See Also:** 4.001. BIOS Services Summary  
 4.041. Disk System Status Byte Layout

**4.053. INT 13H, AH=11H -- RECALIBRATE DRIVE**

*Prior to Issuing INT 13H*

	High	Low
AX	11H	
BX		
CX		
DX		Drive number*
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return from INT 13H*

	High	Low
AX	Status**	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set if status is non-zero	
CS		
DS		
SS		
ES		

- Version Info:** Applies to XT, AT and PS/2 only
- Notes:** \*\*0-based; bit 7 set indicates fixed drive  
 \*\*\*See 4.041. INT 13H, Disk System Status Byte Layout
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-67
- See Also:** 4.001. BIOS Services Summary  
 4.041. Disk System Status Byte Layout

**4.054. INT 13H, AH=15H -- READ DASD TYPE**

*Prior to Issuing INT 13H*

	High	Low
AX	15H	
BX		
CX		
DX		Drive number*
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return from INT 13H*

	High	Low
AX	Type**	
BX		
CX	HO number	512-byte blocks
DX	LO number	512-byte blocks
SP		
BP		
SI		
DI		
IP		
flags	Carry set if operation unsuccessful	
CS		
DS		
SS		
ES		

- Version Info:** Applies to AT, Convertible, and PS/2 only
- Notes:** -DASD (Direct Access Storage Device)  
 \*\*0-based; bit 7 set indicates fixed disk  
 \*\*\*00=drive not present or invalid  
 01=no change line support  
 02=change line supported  
 03=fixed disk
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-67
- See Also:** 4.001. BIOS Services Summary

**4.055. INT 13H, AH=16H -- DISKETTE CHANGE LINE STATUS**

*Prior to Issuing INT 13H*

*Upon Return from INT 13H*

		High	Low			High	Low
AX		16H		AX		Status**	
BX				BX			
CX				CX			
DX			Drive number*	DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags		Carry set if status is non-zero	
CS				CS			
DS				DS			
SS				SS			
ES				ES			

**Version Info:** Applies to AT, Convertible, and PS/2 only

**Notes:**  
 \*0-based; bit 7 set indicates fixed disk  
 \*\*00=diskette change signal not active  
 01= invalid diskette parameter  
 06= diskette change signal active  
 80H=diskette drive not ready

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-55

**See Also:** 4.001. BIOS Services Summary

**4.056. INT 13H, AH=17H -- SET DASD TYPE FOR FORMAT**

*Prior to Issuing INT 13H*

*Upon Return from INT 13H*

		High	Low			High	Low
AX		17H	DASD Type*	AX		Status***	
BX				BX			
CX				CX			
DX			Drive number**	DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags		Carry set if status is non-zero	
CS				CS			
DS				DS			
SS				SS			
ES				ES			

**Version Info:** Applies to AT, Convertible, and PS/2 only

**Notes:**  
 \*00, 05-FFH=invalid request  
 01=320/360K diskette in 360K drive  
 02=360K diskette in 1.2Mb drive  
 03=1.2Mb diskette in 1.2Mb drive  
 04=720Kb disk in 720K drive (only for BIOS 6/10/85 and later)  
 \*\*0-based; bit 7 set indicates fixed drive  
 \*\*\*See 4.041. INT 13H, Disk System Status Byte Layout

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-55 to 2-56

**See Also:** 4.001. BIOS Services Summary  
 4.041. Disk System Status Byte Layout

**4.057. INT 13H, AH=18H -- SET MEDIA TYPE FOR FORMAT**

**Prior to Issuing INT 13H**

**Upon Return from INT 13H**

		High	Low			High	Low
AX		18H		AX		Status*	
BX				BX			
CX		Number of tracks	Number of sectors**	CX			
DX			Drive number***	DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI		Offset of pointer to 11-byte media parm table****	
IP				IP			
flags				flags		Carry set on error	
CS				CS			
DS				DS			
SS				SS			
ES				ES		Segment of pointer to 11-byte media parm table****	

**Version Info:** Applies to AT after 11/15/85, XT after 1/10/86, XT286, and PS/2

**Notes:**

- Only value in DL is checked for an appropriate value
- \*See 4.041. INT 13H, Disk System Status Byte Layout
- \*\*Top 2 bits are HO bits of 10-bit number of tracks, bottom 6 bits are number of sectors
- \*\*\*Bit 7=0 for disk drives
- \*\*\*\*See 4.058. INT 13H, Media Descriptor Table

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-56 to 2-57

**See Also:**

- 4.001. BIOS Services Summary
- 4.041. Disk System Status Byte Layout
- 4.045. INT 13H, AH=05H -- Format Cylinder
- 4.046. INT 13H, AH=06H --Format Cylinder Set Bad Sector Flags
- 4.058. Media Descriptor Table

**4.058. MEDIA DESCRIPTOR TABLE**

Offset	Length	Description	Allowable Values
0 (0)	Byte	First specify byte	
1 (1)	Byte	Second specify byte	
2 (2)	Byte	Timer ticks to wait until motor OFF	
3 (3)	Byte	Number of bytes/sector	0=128, 1=256, 2=512, 3=1024
4 (4)	Byte	Number of sectors/track	
5 (5)	Byte	Gap length, in bytes	
6 (6)	Byte	Data length, in bytes	
7 (7)	Byte	Gap length for format	
8 (8)	Byte	Fill byte for formatting	
9 (9)	Byte	Head settle time, in milliseconds	
A (10)	Byte	Motor startup time, in 1/8 seconds	

**Version Info:** Applies to AT after 11/15/85, XT after 1/10/86, XT286, and PS/2

**Notes:** Sometimes referred to as MPT (Media Parameter Table)

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 3-23

**See Also:** 4.057. INT 13H, AH=18H -- Set Media Type For Format

**4.059. INT 13H, AH=19H -- PARK HEADS**

<i>Prior to Issuing INT 13H</i>		<i>Upon Return from INT 13H</i>	
	High	Low	
AX	19H		AX
BX			BX
CX			CX
DX		Drive**	DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
			Carry set on error
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to AT, XT, XT286, and PS/2

**Notes:** \*\*See 4.041. INT 13H, Disk System Status Byte Layout  
 \*\*\*For PS/2 products only; bit 7=1 for fixed disk

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-68

**See Also:** 4.001. BIOS Services Summary  
 4.041. Disk System Status Byte Layout

**4.060. INT 13H, AH=1AH -- FORMAT UNIT**

<i>Prior to Issuing INT 13H</i>		<i>Upon Return from INT 13H</i>	
	High	Low	
AX	1AH	Defect table count*	Interrupt returns no values
BX	Offset of pointer to defect table		
CX		Modifier bits**	
DX		Drive***	
SP			
BP			
SI			
DI			
IP			
flags			
CS			
DS			
SS			
ES	Segment of pointer to defect table		

**Version Info:** Applies to PS/2 models 50, 60 and 80 only

**Notes:** \*0=no defect table used; >0 means use defect table.  
 Defect table consists of relative block addresses of defective sectors.  
 \*\*See 4.061. INT 13H, Format Unit Modifier Bits  
 \*\*\*Bit 7=1 for fixed disk

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-68 to 2-69

**See Also:** 4.001. BIOS Services Summary  
 4.061. Format Unit Modifier Bits

**4.061. INT 13H, FORMAT UNIT MODIFIER BITS**

Bit Number	Function
5-7	RESERVED
4	Periodic interrupt status (1=ON, 0=OFF)
3	Extended surface analysis (1=perform, 0=don't perform)
2	Secondary defect map (1=update, 0=don't update)
1	Use secondary defect map (1=ignore it, 0=use it)
0	Use primary defect map (1=ignore it, 0=use it)

**Source:** IBM PS/2 and PC BIOS Technical Reference, pages 2-68 to 2-69

**See Also:** 4.060. INT 13H, AH=1AH -- Format Unit

**4.062. INT 14H, AH=00H -- INIT COMMUNICATIONS PORT**

*Prior to Issuing INT 14H*

*Upon Return from INT 14H*

		High	Low			High	Low
AX		00H	Comm parm byte*	AX		Line status**	Modem status**
BX				BX			
CX				CX			
DX		Comm port number		DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags			
CS				CS			
DS				DS			
SS				SS			
ES				ES			

**Notes:** \*See 4.064. INT 14H, Com Port Parameter Byte  
 \*\*See 4.063. Modem Status Byte

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-70 to 2-71

**See Also:** 4.001. BIOS Services Summary  
 4.063. Modem Status Byte  
 4.064. Com Port Parameter Byte

**4.063. MODEM STATUS BYTE**

**Modem Status Byte:**

Bit Numbers								Description
7	6	5	4	3	2	1	0	
X								Received line signal detect
	X							Ring indicator
		X						Data set ready
			X					Clear to send
				X				Delta receive line signal detect
					X			Trailing edge ring detector
						X		Delta data set ready
							X	Delta clear to send

**Line Status Byte:**

Bit Numbers								Description
7	6	5	4	3	2	1	0	
X								Time-out*
	X							Transmitter shift register empty
		X						Transmitter holding register empty
			X					Break detect
				X				Framing error
					X			Parity error
						X		Overrun error
							X	Data ready

**Notes:** \*Unpredictable results in other bits when this bit is set

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-70 to 2-71

**See Also:** 4.062. INT 14H, AH=00H -- Init Communications Port  
 4.065. INT 14H, AH=01H -- Write Character  
 4.066. INT 14H, AH=02H -- Read Character  
 4.067. INT 14H, AH=03H -- Status Request

**4.064. COM PORT PARAMETER BYTE**

Bit Numbers								Description	Allowable Values
7	6	5	4	3	2	1	0		
X	X	X						Baud rate	000 = 110 baud 001 = 150 010 = 300 011 = 600 100 = 1200 (default) 101 = 2400 110 = 4800 111 = 9600
			X	X				Parity	00 = No parity 01 = Odd parity 10 = No parity 11 = Even parity
					X			Stop bits	0=1 stop bit, 1=2 stop bits
						X	X	Word length	10 = 7 bits 11 = 8 bits

**Notes:** On PS/2, baud rates higher than 9600 are set using functions 4 and 5

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-70 to 2-71

**See Also:** 4.062. INT 14H, AH=00H -- Init Communications Port

**4.065. INT 14H, AH=01H -- WRITE CHARACTER**

*Prior to Issuing INT 14H*

	High	Low
AX	01H	Character
BX		
CX		
DX	Comm port number	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return from INT 14H*

	High	Low
AX	Line status*	Character
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*See 4.063. Modem Status Byte

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-71

**See Also:** 4.001. BIOS Services Summary  
 4.063. Modem Status Byte  
 4.066. INT 14H, AH=02H -- Read Character

**4.066. INT 14H, AH=02H -- READ CHARACTER**

*Prior to Issuing INT 14H*

	High	Low
AX	02H	
BX		
CX		
DX	Comm port number	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return from INT 14H*

	High	Low
AX	Line status*	Character
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*See 4.063. Modem Status Byte

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-71

**See Also:** 4.001. BIOS Services Summary  
 4.063. Modem Status Byte  
 4.065. INT 14H, AH=01H -- Write Character

4.067. INT 14H, AH=03H -- STATUS REQUEST

Prior to Issuing INT 14H

Upon Return from INT 14H

	High	Low
AX	03H	
BX		
CX		
DX	Comm port number	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Line status*	Modem status*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Notes: \*See 4.063. Modem Status Byte

Source: IBM PS/2 and PC BIOS Interface Technical Reference, page 2-72

See Also: 4.001. BIOS Services Summary  
4.063. Modem Status Byte

4.068. INT 14H, AH=04H -- EXTENDED INIT

Prior to Issuing INT 14H

Upon Return from INT 14H

	High	Low
AX	04H	Break setting *
BX	Parity setting **	Stop bit setting ***
CX	Word length ****	Baud rate †
DX	Port number ¥	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Line status §	Modem status §
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Version Info: Applies to PS/2 models only

Notes: \* 00=no break, 01=break  
 \*\* 00=no parity, 01=odd parity, 02=even parity, 03=stick parity odd, 04=stick parity even  
 \*\*\* 00=one, 01=two (one and a half for 5-bit word lengths)  
 \*\*\*\* 00=5 bits, 01=6 bits, 02=7 bits, 03=8 bits  
 † 00=110 baud, 01=150 baud, 02=300 baud, 03=600 baud, 04=1200 baud, 05=2400 baud, 06=4800 baud, 07=9600 baud, 08=19,200 baud  
 ¥ Must be 0, 1, 2, or 3  
 § See 4.063. Modem Status Byte

Source: IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-72 to 2-73

See Also: 4.001. BIOS Services Summary  
4.062. INT 14H, AH=00H -- Init Communications Port  
4.063. Modem Status Byte

**4.069. INT 14H, AH=05H, AL=00H -- READ MODEM CONTROL REGISTER**

*Prior to Issuing INT 14H*

*Upon Return from INT 14H*

	High	Low
AX	05H	00H
BX		
CX		
DX	Port number**	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX		
BX		Modem control reg*
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Version Info:** Applies to PS/2 models only

**Notes:** \*Modem control register formatted as follows:

Bit	Meaning when set
5-7	RESERVED
4	Loop
3	Out2
2	Out1
1	Request to send
0	Data terminal ready

\*\*Serial port to use, must be 0, 1, 2, or 3

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-73

**See Also:** 4.001. BIOS Services Summary  
4.070. INT 14H, AH=05H, AL=01H -- Write Modem Control Register

**4.070. INT 14H, AH=05H, AL=01H -- WRITE MODEM CONTROL REGISTER**

*Prior to Issuing INT 14H*

*Upon Return from INT 14H*

	High	Low
AX	05H	01H
BX		
CX		
DX	Port number**	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Line status***	Modem status***
BX		Modem control reg*
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Version Info:** Applies to PS/2 models only

**Notes:** \*Modem control register formatted as follows:

Bit	Meaning when set
5-7	RESERVED
4	Loop
3	Out2
2	Out1
1	Request to send
0	Data terminal ready

\*\*\*Serial port to use, must be 0, 1, 2, or 3

\*\*\*\*See 4.063. Modem Status Byte

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-73

**See Also:** 4.001. BIOS Services Summary  
 4.063. Modem Status Byte  
 4.069. INT 14H, AH=05H, AL=00H -- Read Modem Control Register

**4.071. INT 15H, AH=00H -- CASSETTE MOTOR ON**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

	High	Low
AX	00H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	00H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry clear	
CS		
DS		
SS		
ES		

**Version Info:** Applies to PC and PCjr only, all others set Carry and return 86H in AH

**Notes:** Obsolete function, no longer supported

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-74 to 2-75

**See Also:** 4.001. BIOS Services Summary  
 4.072. INT 15H, AH=01H -- Cassette Motor OFF

**4.072. INT 15H, AH=01H -- CASSETTE MOTOR OFF**

<i>Prior to Issuing INT 15H</i>		<i>Upon Return from INT 15H</i>	
	<i>High</i>	<i>Low</i>	
AX	01H		AX
BX			BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to PC and PCjr only, all others set Carry and return 86H in AH

**Notes:** Obsolete function, no longer supported

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-75

**See Also:** 4.001. BIOS Services Summary  
4.071. INT 15H, AH=00H -- Cassette Motor ON

**4.073. INT 15H, AH=02H -- CASSETTE READ DATA BLOCKS**

<i>Prior to Issuing INT 15H</i>		<i>Upon Return from INT 15H</i>	
	<i>High</i>	<i>Low</i>	
AX	02H		AX
BX	Offset of pointer to data buffer		BX
CX	# Bytes to read		CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES	Segment of pointer to data buffer		ES

**Version Info:** \*PC and PCjr only, all others set Carry and return 86H in AH  
\*\*For PCjr, 1=CRC error, 2=lost data transitions, 4=no data found

**Notes:** Obsolete function, no longer supported

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-75

**See Also:** 4.001. BIOS Services Summary  
4.074. INT 15H, AH=03H -- Cassette Write Data Blocks

**4.074. INT 15H, AH=03H -- CASSETTE WRITE DATA BLOCKS**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

		High	Low			High	Low
AX		03H		AX			
BX		Offset of pointer to data buffer		BX		Offset of pointer to last byte written +1	
CX		# Bytes to write		CX		00H	00H
DX				DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags			
CS				CS			
DS				DS			
SS				SS			
ES		Segment of pointer to data buffer		ES		Segment of pointer to last byte written +1	

- Version Info:** PC and PCjr only, all others set Carry and return 86H in AH
- Notes:** Obsolete function, no longer supported
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-76
- See Also:** 4.001. BIOS Services Summary  
4.073. INT 15H, AH=02H -- Cassette Read Data Blocks

**4.075. INT 15H, AH=0FH -- FORMAT PERIODIC INTERRUPT**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

		High	Low			High	Low
AX		0FH	Phase code*	AX			
BX				BX			
CX				CX			
DX				DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags		Carry set if end formatting or scanning	
CS				CS			
DS				DS			
SS				SS			
ES				ES			

- Version Info:** Applies only to PS/2 machines using ESDI fixed disk drive adapter
- Notes:** \*00=reserved, 01=surface analysis, 02=formatting
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-76 to 2-77
- See Also:** 4.001. BIOS Services Summary

**4.076. INT 15H, AH=4FH -- KEYBOARD INTERCEPT**

**Prior to Issuing INT 15H**

	High	Low
AX	4FH	Scan code*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry must be set	
CS		
DS		
SS		
ES		

**Upon Return from INT 15H**

	High	Low
AX		Scan code**
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry clear if scan code to be ignored	
CS		
DS		
SS		
ES		

**Version Info:** Applies to AT, Convertible, and PS/2 only

**Notes:** \*See 7.06. AT 84-key Key Numbers and Scan Codes  
 7.07. AT 101/102-key Key Numbers and Scan Codes  
 7.08. PS/2 Key Numbers and Scan Codes  
 \*\*May be changed by interrupt handler

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-82

**See Also:** 4.001. BIOS Services Summary  
 7.06. AT 84-key Key Numbers and Scan Codes  
 7.07. AT 101/102-key Key Numbers and Scan Codes  
 7.08. PS/2 Key Numbers and Scan Codes

**4.077. INT 15H, AH=80H -- OPEN DEVICE**

**Prior to Issuing INT 15H**

	High	Low
AX	80H	
BX	Device ID	
CX	Process ID	
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return from INT 15H**

Interrupt returns no values

**Version Info:** Applies to AT and PS/2 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-83

**See Also:** 4.001. BIOS Services Summary  
 4.078. INT 15H, AH=81H -- Close Device

**4.078. INT 15H, AH=81H -- CLOSE DEVICE**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

	<i>High</i>	<i>Low</i>
AX	81H	
BX	Device ID	
CX	Process ID	
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Version Info:** Applies to AT and PS/2 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-83

**See Also:** 4.001. BIOS Services Summary  
4.077. INT 15H, AH=80H -- Open Device

**4.079. INT 15H, AH=82H -- PROGRAM TERMINATE**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

	<i>High</i>	<i>Low</i>
AX	82H	
BX	Device ID	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Version Info:** Applies to AT and PS/2 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-84

**See Also:** 4.001. BIOS Services Summary

**4.080. INT 15H, AH=83H -- EVENT WAIT**

**Prior to Issuing INT 15H**

	High	Low
AX	83H	0 or 1*
BX	Offset of pointer to byte	
CX	HO microseconds to posting	
DX	LO microseconds to posting	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to byte	

**Upon Return from INT 15H**

	High	Low
AX		
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set if operation unsuccessful	
CS		
DS		
SS		
ES		

- Version Info:** Applies to AT, Convertible, and PS/2 only
- Notes:** \*Carry always set on PS/2 model 30  
\*\*0=set interval, 1=cancel set interval; for all except AT BIOS 1/10/84
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-84 to 2-85
- See Also:** 4.001. BIOS Services Summary

**4.081. INT 15H, AH=84H -- JOYSTICK SUPPORT**

**Prior to Issuing INT 15H**

	High	Low
AX	84H	
BX		
CX		
DX		0 or 1**
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return from INT 15H**

	High	Low
AX	A(x) value***	switch settings*
BX	A(y) value***	
CX	B(x) value***	
DX	B(y) value***	
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

- Version Info:** Applies to AT and PS/2 only
- Notes:** \*Bits 7 - 4 are used to represent switches; returned only if DX was 0 prior to interrupt  
\*\*0=read switch settings, 1=read resistive inputs  
\*\*\*Returned only if DX was 1 prior to interrupt
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-85 to 2-86
- See Also:** 4.001. BIOS Services Summary

**4.082. INT 15H, AH=85H -- SYSTEM REQUEST KEY PRESSED**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

		High	Low			High	Low
AX		85H		AX			Value*
BX				BX			
CX				CX			
DX				DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags			
CS				CS			
DS				DS			
SS				SS			
ES				ES			

**Version Info:** Applies to AT, Convertible, and PS/2 only

**Notes:** \*0=key make, 1=key break

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-86

**See Also:** 4.001. BIOS Services Summary

**4.083. INT 15H, AH=86H -- WAIT**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

		High	Low			High	Low
AX		86H		AX			
BX				BX			
CX		HO microseconds before return		CX			
DX		LO microseconds before return		DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags		Carry flag set if wait already in progress	
CS				CS			
DS				DS			
SS				SS			
ES				ES			

**Version Info:** Applies to AT, Convertible, and PS/2 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-86 to 2-87

**See Also:** 4.001. BIOS Services Summary

**4.084. INT 15H, AH=87H -- MOVE BLOCK**

*Prior to Issuing INT 15H*

	High	Low
AX	87H	
BX		
CX	Word count of block to move*	
DX		
SP		
BP		
SI	Offset of pointer to global desc. table***	
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to global desc. table***	

*Upon Return from INT 15H*

	High	Low
AX	Status**	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry, zero flags set on some errors	
CS		
DS		
SS		
ES		

**Version Info:** Applies to AT and PS/2 only

**Notes:** \*\*Maximum of 8000H words (64K bytes)  
 \*\*\*00=successful, 01=RAM parity, 02=other exception error, 03=Gate address line 20H failed  
 \*\*\*Six 8-byte blocks: dummy, GDT location, source GDT, target GDT, BIOS CS, SS

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-87 to 2-89

**See Also:** 4.001. BIOS Services Summary

**4.085. INT 15H, AH=88H -- GET EXTENDED MEMORY SIZE**

*Prior to Issuing INT 15H*

	High	Low
AX	88H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return from INT 15H*

	High	Low
AX	1k blocks*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Version Info:** Applies to AT and PS/2 only

**Notes:** \*Contiguous memory beginning at 100000H (1 Mbyte)

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-89 to 2-90

**See Also:** 4.001. BIOS Services Summary

**4.086. INT 15H, AH=89H -- SWITCH TO PROTECTED MODE****Prior to Issuing INT 15H**

	High	Low
AX	89H	
BX	Index to Int Level 1	Index to Int Level 2
CX		
DX		

SP		
BP		
SI	Offset of pointer to global desc. table	
DI		

IP		
flags		

CS		
DS		
SS		
ES	Segment of pointer to global desc. table	

**Upon Return from INT 15H**

	High	Low
AX	00 if successful	
BX	Destroyed	
CX	Destroyed	
DX	Destroyed	

SP	Destroyed	
BP	Destroyed	
SI	Destroyed	
DI	Destroyed	

IP	Destroyed	
flags	Destroyed	

CS	Destroyed	
DS	Destroyed	
SS	Destroyed	
ES	Destroyed	

**Version Info:** Applies to AT and PS/2 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-90 to 2-92

**See Also:** 4.001. BIOS Services Summary  
4.087. INT 15H, Global Descriptor Table

**4.087. INT 15H, GLOBAL DESCRIPTOR TABLE**

Offset	Length	Pointer To
0	8 bytes	Dummy
8	8 bytes	Global descriptor table
10 (16)	8 bytes	Interrupt descriptor table
18 (24)	8 bytes	User data segment
20 (32)	8 bytes	User extra segment
28 (40)	8 bytes	User stack segment
30 (48)	8 bytes	User code segment
38 (56)	8 bytes	Temporary BIOS code segment

**Source:** IBM PS/2 BIOS Technical Reference, pages 2-91 to 2-92

**See Also:** 4.086. INT 15H, AH=89H -- Switch to Protected Mode

**4.088. INT 15H, AH=90H -- DEVICE BUSY**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

	<i>High</i>	<i>Low</i>
AX	90H	Type code*
BX	Offset of pointer to network control block**	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to network control block**	

	<i>High</i>	<i>Low</i>
AX		
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry flag set if min. wait time satisfied	
CS		
DS		
SS		
ES		

**Version Info:** Applies to AT, Convertible, and PS/2 only

**Notes:**

- \*\*Type codes are as follows:
- 00=fixed disk (time out)
- 01=floppy disk (time out)
- 02=keyboard (no time out)
- 03=pointing device (time out)
- 80H=network (no time out)
- FCH=fixed disk reset for PS/2 products (time out)
- FDH=floppy disk drive motor start (time out)
- FEH=printer (time-out)
- \*\*\*Only for type code of 80H

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-93 to 2-94

**See Also:** 4.001. BIOS Services Summary

**4.089. INT 15H, AH=91H -- INTERRUPT COMPLETE**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

	High	Low
AX	91H	Type code*
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

No values returned for this interrupt

**Version Info:** Applies to AT, Convertible, and PS/2 only

**Notes:** \*Type codes are as follows:  
 00=fixed disk (time-out)  
 01=floppy disk (time-out)  
 02=keyboard (no time-out)  
 03=pointing device (time-out)  
 80H=network (no time-out)  
 FCH=fixed disk reset for PS/2 products (time-out)  
 FDH=floppy disk motor start (time-out)  
 FEH=printer (time-out)

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-94 and 2-93

**See Also:** 4.001. BIOS Services Summary

**4.090. INT 15H, AH=C0H -- RETURN SYSTEM CONFIG PARAMETERS**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

	High	Low
AX	C0H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	0	
BX	Offset of pointer to system descriptor table*	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry clear	
CS		
DS		
SS		
ES	Segment of pointer to system descriptor table*	

**Version Info:** Applies to AT after 6/10/85, XT after 1/10/86, XT286, Convertible, and PS/2 only

**Notes:** \*See 4.091. INT 15H, System Descriptor Table

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-94 to 2-96

**See Also:** 4.001. BIOS Services Summary  
 4.091. System Descriptor Table

**4.091. INT 15H, SYSTEM DESCRIPTOR TABLE**

Offset	Length	Description	Allowable Values
0	Word	Number of bytes in table	Minimum of 8
2	Byte	Model byte	See "Machine ID Byte"
3	Byte	Submodel byte	
4	Byte	BIOS revision level	00=first release
5	Byte	Feature information	bit 7 = fixed disk BIOS use DMA 3 bit 6 = 2nd interrupt chip present bit 5 = real-time clock present bit 4 = keyboard intercept called bit 3 = wait for ext event supported bit 2 = extended BIOS area allocated bit 1 = PS/2-type I/O channel bit 0 = RESERVED
6	Byte	Feature information RESERVED	
7	Byte	Feature information RESERVED	
8	Byte	Feature information RESERVED	
9	Byte	Feature information RESERVED	

**Version Info:** Applies to AT after 11/15/85, XT after 1/10/86, XT286, PC Convertible, and PS/2

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-94 to 2-96

**See Also:** 4.090. INT 15H, AH=C0H -- Return System Config Parameters

**4.092. INT 15H, AH=C1H -- RETURN EXT BIOS SEGMENT ADDRESS**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

	High	Low
AX	C1H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX		
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES	Segment address of extended BIOS data area	

**Version Info:** Applies to PS/2 models only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-96 to 2-97

**See Also:** 4.001. BIOS Services Summary  
4.003. Extended BIOS Data Area Layout

**4.093. INT 15H, AH=C2H, AL=00H -- ENABLE/DISABLE POINTING DEVICE**

**Prior to Issuing INT 15H**

**Upon Return from INT 15H**

	High	Low
AX	C2H	00H
BX	Enable/disable*	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Mouse status**	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** Applies to PS/2 models only

**Notes:** \*00=disable, 01=enable  
\*\*See 4.101. Mouse Port Status Bytes

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-97

**See Also:** 4.001. BIOS Services Summary  
4.101. Mouse Port Status Bytes

**4.094. INT 15H, AH=C2H, AL=01H -- RESET POINTING DEVICE**

**Prior to Issuing INT 15H**

**Upon Return from INT 15H**

	High	Low
AX	C2H	01H
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Mouse status*	
BX	Device ID**	(Destroyed)
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** Applies to PS/2 models only

**Notes:** \*Pointing device state is set to: disabled, 100 reports/second sample rate, 4 count/mm resolution, 1 to 1 scaling, data package size unmodified  
\*\*See 4.101. Mouse Port Status Bytes  
\*\*Only if no error occurred; set to 00H

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-98

**See Also:** 4.001. BIOS Services Summary  
4.101. Mouse Port Status Bytes

**4.095. INT 15H, AH=C2H, AL=02H -- SET SAMPLE RATE**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

	High	Low
AX	C2H	02H
BX	Sample rate**	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Mouse status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** Applies to PS/2 models only

**Notes:** \*\*See 4.101. Mouse Port Status Bytes  
 \*\*00=10 reports/second, 01=20 rpts/sec, 02=40 rpts/sec, 03=60 rpts/sec,  
 04=80 rpts/sec, 05=100 rpts/sec (default), 06=200 rpts/sec

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-98

**See Also:** 4.001. BIOS Services Summary  
 4.101. Mouse Port Status Bytes

**4.096. INT 15H, AH=C2H, AL=03H -- SET RESOLUTION**

*Prior to Issuing INT 15H*

*Upon Return from INT 15H*

	High	Low
AX	C2H	03H
BX	Resolution**	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Mouse status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** Applies to PS/2 models only

**Notes:** \*\*See 4.101. Mouse Port Status Bytes  
 \*\*00=1 count/millimeter, 01=2 cnts/mm, 02=4 cnts/mm, 03=8 cnts/mm

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-98

**See Also:** 4.001. BIOS Services Summary  
 4.101. Mouse Port Status Bytes

**4.097. INT 15H, AH=C2H, AL=04H -- READ DEVICE TYPE**

<i>Prior to Issuing INT 15H</i>		<i>Upon Return from INT 15H</i>	
	<i>High</i>	<i>Low</i>	
AX	C2H	04H	AX
BX			BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to PS/2 models only

**Notes:** \*\*See 4.101. Mouse Port Status Bytes  
\*\*Only if operation successful; set to 0

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-98 to 2-99

**See Also:** 4.001. BIOS Services Summary  
4.101. Mouse Port Status Bytes

**4.098. INT 15H, AH=C2H, AL=05H -- INITIALIZE POINTING DEVICE**

<i>Prior to Issuing INT 15H</i>		<i>Upon Return from INT 15H</i>	
	<i>High</i>	<i>Low</i>	
AX	C2H	05H	AX
BX	Bytes in data package		BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to PS/2 models only

**Notes:** •Device is initialized as: disabled state, 100 reports/second sampling rate, 4 count/millimeter resolution, 1 to 1 scaling  
•See 4.101. Mouse Port Status Bytes

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-99

**See Also:** 4.001. BIOS Services Summary  
4.101. Mouse Port Status Bytes

**4.099. INT 15H, AH=C2H, AL=06H -- EXTENDED COMMANDS**

**Prior to Issuing INT 15H**

	High	Low
AX	C2H	06H
BX	Command**	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return from INT 15H**

	High	Low
AX	Mouse status*	
BX		Status byte 1***
CX		Status byte 2***
DX		Status byte 3***
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** Applies to PS/2 models only

**Notes:**  
 \*\*See 4.101. Mouse Port Status Bytes  
 \*\*0=get status, 1=set scaling to 1 to 1, 2=set scaling to 2 to 1  
 \*\*\*For BH=0 only, successful operation returns:

Status byte 1

Bit	Meaning
7	RESERVED
6	0=stream mode, 1=remote mode
5	0=disable, 1=enable
4	0=1:1 scaling, 1=2:1 scaling
3	RESERVED
2	Left button pressed
1	RESERVED
0	Right button pressed

Status byte 2

Value	Meaning
0	1 count per millimeter
1	2 counts per millimeter
2	4 counts per millimeter
3	8 counts per millimeter

Status byte 3

Value	Meaning
0A	10 reports per second
14	20 reports per second
28	40 reports per second
3C	60 reports per second
50	80 reports per second
64	100 reports per second
C8	200 reports per second

**Source:** IBM PS/2 and PC BIOS Technical Reference, pages 2-99 to 2-100

**See Also:** 4.001. BIOS Services Summary  
 4.101. Mouse Port Status Bytes

**4.100. INT 15H, AH=C2H, AL=07H -- DEVICE DRIVER INIT CALL**

*Prior to issuing INT 15H*

*Upon Return from INT 15H*

	High	Low
AX	C2H	07H
BX	Offset of pointer to device driver	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to device driver	

	High	Low
AX	Mouse status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** Applies to PS/2 models only

**Notes:** \*See 4.101. Mouse Port Status Bytes

**Source:** IBM PS/2 and PC BIOS Technical Reference, page 2-100

**See Also:** 4.001. BIOS Services Summary  
4.101. Mouse Port Status Bytes

**4.101. INT 15H MOUSE PORT STATUS BYTES**

Value	Meaning
0	No error occurred
1	Invalid function call attempted
2	Invalid input to function call
3	Interface error
4	Resend
5	No far call installed for device

**Source:** IBM PS/2 and PC BIOS Technical Reference, page 2-97

**See Also:** 4.093. INT 15H, AH=C2H, AL=00H -- Enable/Disable Pointing Device  
4.094. INT 15H, AH=C2H, AL=01H -- Reset Pointing Device  
4.095. INT 15H, AH=C2H, AL=02H -- Set Sample Rate  
4.096. INT 15H, AH=C2H, AL=03H -- Set Resolution  
4.097. INT 15H, AH=C2H, AL=04H -- Read Device Type  
4.098. INT 15H, AH=C2H, AL=05H -- Initialize Pointing Device  
4.099. INT 15H, AH=C2H, AL=06H -- Extended Commands  
4.100. INT 15H, AH=C2H, AL=07H -- Device Driver Init Call

**4.102. INT 15H, AH=C3H -- WATCHDOG TIMEOUT**

**Prior to Issuing INT 15H**

	High	Low
AX	C3H	1=enable, 0=disable
BX	Watchdog timer count (1-255)	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return from INT 15H**

	High	Low
AX		
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** Applies to PS/2 products only except Model 30  
**Source:** IBM PS/2 and PC BIOS Technical Reference, page 2-102  
**See Also:** 4.001. BIOS Services Summary

**4.103. INT 15H, AH=C4H -- PROG OPTION SELECT**

**Prior to Issuing INT 15H**

	High	Low
AX	C4H	Option*
BX		Slot number**
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return from INT 15H**

	High	Low
AX		Option*
BX		Slot number**
CX		
DX	Base POS adapter register address***	
SP		
BP		
SI		
DI		
IP		
flags	Carry set on error	
CS		
DS		
SS		
ES		

**Version Info:** Applies to PS/2 products only except Model 30  
**Notes:** \*\*0=get base POS adapter register address, 1=enable slot, 2=enable adapter  
 \*\*\*Only if AL=1  
 \*\*\*\*Only AL=0  
**Source:** IBM PS/2 and PC BIOS Technical Reference, pages 2-102 to 2-103  
**See Also:** 4.001. BIOS Services Summary

4.104. INT 16H, AH=00H -- READ CHARACTER

*Prior to Issuing INT 16H*

*Upon Return from INT 16H*

	High	Low
AX	00H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Scan code	ASCII character
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

- Notes:** Character is extracted from keyboard buffer
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-106
- See Also:**
- 1.21. ASCII Character Set
  - 1.22. IBM ASCII Character Set
  - 4.001. BIOS Services Summary
  - 7.05. PC Keyboard Key Numbers and Scan Codes
  - 7.06. AT 84-key Key Numbers and Scan Codes
  - 7.07. AT 101/102-key Key Numbers and Scan Codes
  - 7.08. PS/2 Key Numbers and Scan Codes
  - 7.09. PC & XT Typeahead Buffer Layout

4.105. INT 16H, AH=01H -- READ STATUS

*Prior to Issuing INT 16H*

*Upon Return from INT 16H*

	High	Low
AX	01H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Scan code (if zero flag clear)	ASCII char (if zero flag clear)
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags	Zero flag set if no character available	
CS		
DS		
SS		
ES		

- Notes:** Character is not removed from keyboard buffer
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-106
- See Also:**
- 1.21. ASCII Character Set
  - 1.22. IBM ASCII Character Set
  - 4.001. BIOS Services Summary
  - 7.05. PC Keyboard Key Numbers and Scan Codes
  - 7.06. AT 84-key Key Numbers and Scan Codes
  - 7.07. AT 101/102-key Key Numbers and Scan Codes
  - 7.08. PS/2 Key Numbers and Scan Codes
  - 7.09. PC & XT Typeahead Buffer Layout

**4.106. INT 16H, AH=02H -- READ FLAGS**

*Prior to Issuing INT 16H*

*Upon Return from INT 16H*

	High	Low		High	Low
AX	02H		AX	RESERVED	Shift status byte*
BX			BX		
CX			CX		
DX			DX		
SP			SP		
BP			BP		
SI			SI		
DI			DI		
IP			IP		
flags			flags		
CS			CS		
DS			DS		
SS			SS		
ES			ES		

- Notes:** \*See 4.107. Keyboard Flags Byte
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-107
- See Also:** 4.001. BIOS Services Summary  
4.107. Keyboard Flags Byte

**4.107. KEYBOARD FLAGS BYTE**

*Bit Numbers:*

7	6	5	4	3	2	1	0	Description
X								Insert state locked active
	X							Caps lock key active
		X						Num lock key active
			X					Scroll lock key active
				X				Alt key held down
					X			Ctrl key held down
						X		Left shift key held down
							X	Right shift key held down

- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-107
- See Also:** 4.106. INT 16H, AH=02H -- Read Flags  
4.112. INT 16H, Extended Keyboard Flags Byte

**4.108. INT 16H, AH=05H -- KEYBOARD WRITE**

<i>Prior to Issuing INT 16H</i>		<i>Upon Return from INT 16H</i>	
	<i>High</i>	<i>Low</i>	
AX	05H		AX
BX			BX
CX	Scan code	ASCII char	CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to AT after 11/15/85, XT after 1/10/86, XT286, and PS/2 only

**Notes:** \*Function places key in typeahead buffer as if typed from keyboard  
\*0=successful, 1=buffer full

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, pages 2-108 to 2-109

**See Also:** 4.001. BIOS Services Summary  
7.09. PC & XT Typeahead Buffer Layout

**4.109. INT 16H, AH=10H -- EXTENDED KEYBOARD READ**

<i>Prior to Issuing INT 16H</i>		<i>Upon Return from INT 16H</i>	
	<i>High</i>	<i>Low</i>	
AX	10H		AX
BX			BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to AT after 11/15/85, XT after 1/10/86, XT286, and PS/2 only

**Notes:** Key is removed from typeahead buffer

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-109

**See Also:** 4.001. BIOS Services Summary  
4.104. INT 16H, AH=00H -- Read Character  
7.09. PC & XT Typeahead Buffer Layout

**4.110. INT 16H, AH=11H -- EXTENDED KEYSTROKE STATUS**

<i>Prior to Issuing INT 16H</i>		<i>Upon Return from INT 16H</i>	
	<i>High</i>	<i>Low</i>	
AX	11H		AX
BX			BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to AT after 11/15/85, XT after 1/10/86, XT286, and PS/2 only

**Notes:** Key is NOT removed from typeahead buffer

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-109

**See Also:** 4.001. BIOS Services Summary  
 4.105. INT 16H, AH=01H -- Read Status  
 7.09. PC & XT Typeahead Buffer Layout

**4.111. INT 16H, AH=12H -- EXTENDED SHIFT STATUS**

<i>Prior to Issuing INT 16H</i>		<i>Upon Return from INT 16H</i>	
	<i>High</i>	<i>Low</i>	
AX	12H		AX
BX			BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to AT after 11/15/85, XT after 1/10/86, XT286, and PS/2 only

**Notes:** \*\*See 4.112. Extended Keyboard Flags Byte  
 \*\*\*See 4.107. Keyboard Flags Byte

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-110

**See Also:** 4.001. BIOS Services Summary  
 4.106. INT 16H, AH=02H -- Read Flags  
 7.09. PC & XT Typeahead Buffer Layout  
 4.112. Extended Keyboard Flags Byte  
 4.107. Keyboard Flags Byte

**4.112. INT 16H, EXTENDED KEYBOARD FLAGS BYTE**

*Bit Numbers:*

7	6	5	4	3	2	1	0	Description
X								SysRq key held down
	X							Caps Lock key held down
		X						Num Lock key held down
			X					Scroll Lock key held down
				X				Right Alt key held down
					X			Right Ctrl key held down
						X		Left Alt key held down
							X	Left Ctrl key held down

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-110

**See Also:** 4.107. INT 16H, Keyboard Flags Byte  
4.111. INT 16H, AH=12H -- Extended Shift Status

**4.113. INT 17H, AH=00H -- WRITE CHARACTER**

*Prior to Issuing INT 17H*

*Upon Return from INT 17H*

	High	Low		High	Low
AX	00H	Character	AX	Status*	
BX			BX		
CX			CX		
DX	Printer number		DX		
SP			SP		
BP			BP		
SI			SI		
DI			DI		
IP			IP		
flags			flags		
CS			CS		
DS			DS		
SS			SS		
ES			ES		

**Notes:** \*See 4.114. INT 17H, Printer Status Byte

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-111

**4.114. INT 17H, PRINTER STATUS BYTE**

*Bit Numbers:*

7	6	5	4	3	2	1	0	Description
X								Not Busy
	X							Acknowledge
		X						Out of Paper
			X					Selected
				X				I/O Error
					X			RESERVED
						X		RESERVED
							X	Time-Out

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-111

**See Also:** 4.113. INT 17H, AH=00H -- Write Character

**4.115. INT 17H, AH=01H -- INITIALIZE PRINTER PORT**

*Prior to Issuing INT 17H*

*Upon Return from INT 17H*

	High	Low
AX	01H	
BX		
CX		
DX	Printer number	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*See 4.114. INT 17H, Printer Status Byte

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-111

**4.116. INT 17H, AH=02H -- STATUS REQUEST**

*Prior to Issuing INT 17H*

*Upon Return from INT 17H*

	High	Low
AX	02H	
BX		
CX		
DX	Printer number	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*See 4.114. INT 17H, Printer Status Byte

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-112

**4.117. INT 18H: BASIC LOADER**

*Prior to Issuing INT 18H*

*Upon Return from INT 18H*

	High	Low
AX		
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt does not return

**Notes:**           •Interrupt switches control to ROM BASIC  
                   •Not documented in IBM BIOS reference

**Source:**           *Programmer's Guide to the IBM PC* (Microsoft Press),  
                   Peter Norton, page 239

**See Also:**         4.001. BIOS Services Summary

**4.118. INT 19H: BOOTSTRAP LOADER**

*Prior to Issuing INT 19H*

*Upon Return from INT 19H*

	High	Low
AX		
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt does not return

**Notes:**           Interrupt reboots computer by reading cylinder 0, sector 1 into  
                   segment 0, offset 7C00H. Control is transferred to that location.

**Source:**           IBM PS/2 and PC BIOS Interface Technical Reference,  
                   page 2-114

**See Also:**         4.001. BIOS Services Summary

**4.119. INT 1AH, AH=00H -- READ CLOCK COUNT**

*Prior to Issuing INT 1AH*

	High	Low
AX	00H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return from INT 1AH*

	High	Low
AX		24-hour check*
BX		
CX		HO Count
DX		LO Count
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:**                   •Timer overflow flag is reset to 0  
                               •\*0=hasn't been 24 hours since power-on; >0=has been 24 hours or more

**Source:**                 IBM PS/2 and PC BIOS Interface Technical Reference, page 2-115

**See Also:**             4.001. BIOS Services Summary  
                               4.002. BIOS Memory Usage Summary  
                               4.120. INT 1AH, AH=01H -- Set Clock Count

**4.120. INT 1AH, AH=01H -- SET CLOCK COUNT**

*Prior to Issuing INT 1AH*

	High	Low
AX	01H	
BX		
CX		HO Count
DX		LO Count
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return from INT 1AH*

Interrupt returns no values

**Notes:**                 Timer overflow flag is set to 0

**Source:**                 IBM PS/2 and PC BIOS Interface Technical Reference, page 2-116

**See Also:**             4.001. BIOS Services Summary  
                               4.002. BIOS Memory Usage Summary  
                               4.119. INT 1AH, AH=00H -- Read Clock Count

**4.121. INT 1AH, AH=02H -- READ REAL TIME CLOCK TIME**

<i>Prior to Issuing INT 1AH</i>		<i>Upon Return from INT 1AH</i>	
	<i>High</i>	<i>Low</i>	
AX	02H		AX
BX			BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
			Carry set if clock not operating
CS			CS
DS			DS
SS			SS
ES			ES

- Version Info:** Applies to AT with BIOS dated 6/10/85 and after, XT286, Convertible, and PS/2 products
- Notes:** \*Daylight savings time option, 0=not used 1=operative
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-116
- See Also:** 4.001. BIOS Services Summary  
4.122. INT 1AH, AH=03H -- Set Real Time Clock Time  
4.123. INT 1AH, AH=04H -- Read Real Time Clock Date

**4.122. INT 1AH, AH=03H -- SET REAL TIME CLOCK TIME**

<i>Prior to Issuing INT 1AH</i>		<i>Upon Return from INT 1AH</i>
	<i>High</i>	<i>Low</i>
AX	03H	
BX		
CX	BCD Hours	BCD Minutes
DX	BCD Seconds	DST Option*
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

- Version Info:** This option works only on AT with BIOS dated 6/10/85 and after, XT286, and PS/2 products
- Notes:** \*Daylight savings time option, 0=not used 1=operative
- Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-117
- See Also:** 4.001. BIOS Services Summary  
4.121. INT 1AH, AH=02H -- Read Real Time Clock Time  
4.124. INT 1AH, AH=05H -- Set Real Time Clock Date

**4.123. INT 1AH, AH=04H -- READ REAL TIME CLOCK DATE**

<i>Prior to Issuing INT 1AH</i>		<i>Upon Return from INT 1AH</i>	
	<i>High</i>	<i>Low</i>	
AX	04H		AX
BX			BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
			Carry set if clock not operating
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to AT, Convertible and PS/2 only

**Notes:** \*Century is binary coded decimal 19 or 20 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-117

**See Also:** 4.001. BIOS Services Summary  
 4.121. INT 1AH, AH=02H -- Read Real Time Clock Time  
 4.124. INT 1AH, AH=05H -- Set Real Time Clock Date

**4.124. INT 1AH, AH=05H -- SET REAL TIME CLOCK DATE**

<i>Prior to Issuing INT 1AH</i>		<i>Upon Return from INT 1AH</i>
	<i>High</i>	<i>Low</i>
AX	05H	
BX		
CX	BCD Century*	BCD Year
DX	BCD Month	BCD Day
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Version Info:** Applies to AT, Convertible and PS/2 only

**Notes:** \*Century is binary coded decimal 19 or 20 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-117

**See Also:** 4.001. BIOS Services Summary  
 4.122. INT 1AH, AH=03H -- Set Real Time Clock Time  
 4.123. INT 1AH, AH=04H -- Read Real Time Clock Date

**4.125. INT 1AH, AH=06H -- SET REAL TIME CLOCK ALARM**

*Prior to Issuing INT 1AH*

*Upon Return from INT 1AH*

		High	Low			High	Low
AX		06H		AX			
BX				BX			
CX		BCD Hours	BCD Minutes	CX			
DX		BCD Seconds		DX			
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags		Carry set if alarm not ready or no clock	
CS				CS			
DS				DS			
SS				SS			
ES				ES			

**Version Info:** Applies to AT, Convertible and PS/2 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-118

**See Also:** 4.001. BIOS Services Summary  
4.126. INT 1AH, AH=07H -- Turn Off Real Time Clock Alarm

**4.126. INT 1AH, AH=07H -- TURN OFF REAL TIME CLOCK ALARM**

*Prior to Issuing INT 1AH*

*Upon Return from INT 1AH*

		High	Low		
AX		07H		Interrupt returns no values	
BX					
CX					
DX					
SP					
BP					
SI					
DI					
IP					
flags					
CS					
DS					
SS					
ES					

**Version Info:** Applies to AT, Convertible and PS/2 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-118

**See Also:** 4.001. BIOS Services Summary  
4.125. INT 1AH, AH=06H -- Set Real Time Clock Alarm

**4.127. INT 1AH, AH=09H -- READ REAL TIME CLOCK ALARM**

<i>Prior to Issuing INT 1AH</i>		<i>Upon Return from INT 1AH</i>	
	<i>High</i>	<i>Low</i>	
AX	09H		AX
BX			BX
CX			CX
DX			DX
			BCD hours
			BCD minutes
			BCD seconds
			Alarm Status*
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies only to Model 30 and PC Convertible

**Notes:** \*0=alarm not enabled, 1=alarm enabled, no power on  
2=alarm enabled, will power on system (Convertible only)

**Source:** IBM PS/2 and PC BIOS Technical Reference, page 2-119

**See Also:** 4.001. BIOS Services Summary

**4.128. INT 1AH, AH=0AH -- READ SYSTEM TIMER DAY COUNT**

<i>Prior to Issuing INT 1AH</i>		<i>Upon Return from INT 1AH</i>	
	<i>High</i>	<i>Low</i>	
AX	0AH		AX
BX			BX
CX			CX
DX			DX
			Count of days after 1/1/80
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Version Info:** Applies to XT after 1/10/86 and PS/2 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-120

**See Also:** 4.001. BIOS Services Summary  
4.002. BIOS Memory Usage Summary  
4.129. INT 1AH, AH=0BH -- Set System Timer Day Count

4.129. INT 1AH, AH=0BH -- SET SYSTEM TIMER DAY COUNT

*Prior to Issuing INT 1AH*

*Upon Return from INT 1AH*

	<i>High</i>	<i>Low</i>
AX	0BH	
BX		
CX	Count of days after 1/1/80	
DX		

Interrupt returns no values

SP	
BP	
SI	
DI	

IP	
flags	

CS	
DS	
SS	
ES	

**Version Info:** Applies to XT after 1/10/86 and PS/2 only

**Source:** IBM PS/2 and PC BIOS Interface Technical Reference, page 2-120

**See Also:**

- 4.001. BIOS Services Summary
- 4.002. BIOS Memory Usage Summary
- 4.128. INT 1AH, AH=0AH -- Read System Timer Day Count

— SECTION —

# 5

Other Interrupts,  
Mouse, and  
EMS Support

---

## 5.01. DOS INTERRUPT USAGE BY VERSION

*DOS Versions that Support Interrupt*

<i>Int. Number</i>	<i>Interrupt Name</i>	<i>1</i>	<i>1.1</i>	<i>2</i>	<i>2.1</i>	<i>3</i>	<i>3.1</i>	<i>3.2</i>	<i>3.3</i>
20 (32)	Program terminate	X	X	O	O	O	O	O	O
21 (33)	Function request	X	X	X	X	X	X	X	X
22 (34)	Terminate address	X	X	X	X	X	X	X	X
23 (35)	Control-Break exit address	X	X	X	X	X	X	X	X
24 (36)	Critical error handler vector	X	X	X	X	X	X	X	X
25 (37)	Absolute disk read	X	X	X	X	X	X	X	X
26 (38)	Absolute disk write	X	X	X	X	X	X	X	X
27 (39)	Terminate & stay resident	X	X	O	O	O	O	O	O
28 (40)	RESERVED	R	R	R	R	R	R	R	R
29 (41)	RESERVED	R	R	R	R	R	R	R	R
2A (42)	MS-Net access						X	X	X
2B (43)	RESERVED	R	R	R	R	R	R	R	R
2C (44)	RESERVED	R	R	R	R	R	R	R	R
2D (45)	RESERVED	R	R	R	R	R	R	R	R
2E (46)	RESERVED	R	R	R	R	R	R	R	R
2F (47)	Printer					X			
2F (47)	Multiplex						X	X	X
30 (48)	RESERVED	R	R	R	R	R	R	R	R
31 (49)	RESERVED	R	R	R	R	R	R	R	R
32 (50)	RESERVED	R	R	R	R	R	R	R	R
33 (51)	RESERVED	R	R	R	R	R	R	R	R
34 (52)	RESERVED	R	R	R	R	R	R	R	R
35 (53)	RESERVED	R	R	R	R	R	R	R	R
36 (54)	RESERVED	R	R	R	R	R	R	R	R
37 (55)	RESERVED	R	R	R	R	R	R	R	R
38 (56)	RESERVED	R	R	R	R	R	R	R	R
39 (57)	RESERVED	R	R	R	R	R	R	R	R
3A (58)	RESERVED	R	R	R	R	R	R	R	R
3B (59)	RESERVED	R	R	R	R	R	R	R	R
3C (60)	RESERVED	R	R	R	R	R	R	R	R
3D (61)	RESERVED	R	R	R	R	R	R	R	R
3E (62)	RESERVED	R	R	R	R	R	R	R	R
3F (63)	RESERVED	R	R	R	R	R	R	R	R

**Legend:** X=supported, O=supported but considered obsolete, R=reserved for future use

**Notes:** Interrupt 2FH changed name beginning with DOS 3.1.

**Source:** IBM DOS 3.3 Technical Reference, pages 6-1 to 6-33

**See Also:** 3.001. INT 21H Functions by DOS Version Summary  
 5.02. INT 24H Error Codes  
 5.03. INT 25H Absolute Disk Read  
 5.04. INT 26H Absolute Disk Write  
 5.06. INT 2FH Multiplex  
 7.04. PC Interrupt Usage Summary

**5.02. INT 24H ERROR CODES**

**For Error Codes Returned in AH Register:**

Bit Numbers							Name	Allowable Values	
7	6	5	4	3	2	1	0		
					X	X		Type of operation	0=read operation; 1=write operation
								Location of error	00 = DOS Area 01 = FAT 10 = directory 11 = data area
			X					Fail response	0 = fail not allowed, 1 = fail allowed
			X					Retry response	0 = retry not allowed, 1 = retry allowed
	X							Ignore response	0 = can't be ignored, 1 = can be ignored
	X							NOT USED	NOT USED
X								Device type	0 = disk drive device,** 1 = other device type*

**Notes:** \*If bit 7=1, then either the memory image of the FAT is bad, or the error occurred on a character device. To determine the type of error, examine bit 15 of the fifth byte in the device header (attribute bits). If it is 0, the error is a bad memory image of the FAT. Otherwise, bits 0-3 will tell you what character device failed, as follows:

Bit Number				Character Device that Failed
3	2	1	0	
			X	Current standard input
		X		Current standard output
	X			Current NULL device
X				Current clock device

\*\*If bit 7=0, then AL contains the failing drive number.

**Error Code Returned in Low Byte of DI Register:**

Error Code	Error Name	DOS versions		
		1.x	2.x	3.x
0 (0)	Write attempt on write-protected media	X	X	X
1 (1)	Unknown unit		X	X
2 (2)	Drive not ready	X	X	X
3 (3)	Unknown command		X	X
4 (4)	Data error (CRC error)	X	X	X
5 (5)	Bad request structure length		X	X
6 (6)	Seek error	X	X	X
7 (7)	Unknown media type		X	X
8 (8)	Sector not found	X	X	X
9 (9)	Printer is out of paper		X	X
A (10)	Write fault	X	X	X
B (11)	Read fault		X	X
C (12)	General failure	X	X	X
D (13)	UNDEFINED	R	R	R
E (14)	UNDEFINED	R	R	R
F (15)	Invalid disk change			X

**Legend:** X=supported, R=reserved

**Notes:** These are the same error codes returned by a device driver in its request header

**Source:** IBM DOS 3.3 Technical Reference, pages 6-15 to 6-16, 6-19 to 6-23

**See Also:** 5.01. DOS interrupt Usage by Version

**5.03. INT 25H ABSOLUTE DISK READ***Prior to Interrupt*

	High	Low
AX		Drive number*
BX	Offset of transfer address	
CX	Number of sectors to read	
DX	Beginning logical sector #	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of transfer address	
SS		
ES		

*Upon Return from Interrupt*

	High	Low
AX	Destroyed	Destroyed
BX	Destroyed	Destroyed
CX	Destroyed	Destroyed
DX	Destroyed	Destroyed
SP	Destroyed	
BP	Destroyed	
SI	Destroyed	
DI	Destroyed	
IP	Destroyed	
flags	Destroyed	
CS		
DS		
SS		
ES		

**Notes:** \*0=A, 1=B, and so on  
 \*\*On error CF=1 and AX contains error data

**Source:** IBM DOS 3.3 Technical Reference, pages 6-24 to 6-25

**See Also:** 5.04. INT 26H Absolute Disk Write  
 5.05. INT 25H and 26H Error Codes

**5.04. INT 26H ABSOLUTE DISK WRITE***Prior to Interrupt*

	High	Low
AX		Drive number*
BX	Offset of transfer address	
CX	Number of sectors to write	
DX	Beginning logical sector #	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of transfer address	
SS		
ES		

*Upon Return from Interrupt*

	High	Low
AX	Destroyed	Destroyed
BX	Destroyed	Destroyed
CX	Destroyed	Destroyed
DX	Destroyed	Destroyed
SP	Destroyed	
BP	Destroyed	
SI	Destroyed	
DI	Destroyed	
IP	Destroyed	
flags	Destroyed	
CS		
DS		
SS		
ES		

**Notes:** \*0=A, 1=B, and so on  
 \*\*On error CF=1 and AX contains error data

**Source:** IBM DOS 3.3 Technical Reference, page 6-25

**See Also:** 5.03. INT 25H Absolute Disk Read  
 5.05. INT 25H and 26H Error Codes

**5.05. INT 25H AND 26H ERROR CODES**

Error Code	Error Name	1.x	2.x	3.x
02 (2)	Error (other than those listed below)	X	X	X
03 (3)	Write attempt on write-protected device	X	X	X
04 (4)	Requested sector not found	X	X	X
08 (8)	Bad CRC on disk read	X	X	X
40 (64)	SEEK operation failed	X	X	X
80 (128)	Attachment failed to respond	X	X	X

**Legend:** X=supported

**Source:** IBM DOS 3.3 Technical Reference, page 6-25

**See Also:** 5.03. INT 25H Absolute Disk Read  
5.04. INT 26H Absolute Disk Write

**5.06. INT 2FH MULTIPLEX**

*Prior to Interrupt*

	High	Low
AX	Process*	Function**
BX		
CX		
DX	Offset of pointer to ASCIIZ string***	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS	Segment of pointer to ASCIIZ string***	
SS		
ES		

*Upon Return from Interrupt*

	High	Low
AX	Print error codes†	State****
BX		
CX		
DX	Error count†	
SP		
BP		
SI	Offset of pointer to queue†	
DI		
IP		
flags		
CS		
DS	Segment of pointer to queue†	
SS		
ES		

**Version Info:** Interrupt used in DOS 3.x only

**Notes:**

- \*\*Process is one of the following:
  - 1 = resident portion of PRINT
  - 2 = resident portion of ASSIGN
  - 10H = resident portion of SHARE
  - B7H = resident portion of APPEND
  - C0H-FFH = reserved for user applications
- \*\*Function is one of the following:
  - 0 = get installed state
  - 1 = submit file
  - 2 = cancel file
  - 3 = cancel all files
  - 4 = status
  - 5 = end of status
- \*\*\*\*Functions 1 and 2 only
- \*\*\*\*\*Function 0 only; one of the following:
  - 0 = not installed, OK to install
  - 1 = not installed, do not install
  - FFH = installed
- †Function 4 only
- ‡Function 5 only (See 5.07. INT 2FH Error Codes)

**Source:** IBM DOS 3.3 Technical Reference, pages 6-28 to 6-33

**See Also:** 5.07. INT 2FH Error Codes

## 5.07. INT 2FH ERROR CODES

<i>Error Code</i>	<i>Error Name</i>	<i>1.x</i>	<i>2.x</i>	<i>3.x</i>
1	Invalid function			X
2	File not found			X
3	Path not found			X
4	Too many open files			X
5	Access denied			X
8	Queue full			X
9	Busy			X
12	Name too long			X

**Legend:** X=supported

**Source:** IBM DOS 3.3 Technical Reference, page 6-29

**See Also:** 5.06. INT 2FH Multiplex

## 5.08. INT 33H: MOUSE FUNCTIONS SUMMARY

<i>Interrupt</i>	<i>Function*</i>	<i>Description</i>	<i>Comments</i>
33H	00H	Mouse installed flag	Also resets mouse to default driver values  Restricts mouse movement to window Restricts mouse movement to window
	01H	Show cursor	
	02H	Hide cursor	
	03H	Get mouse position and button status	
	04H	Set mouse cursor position	
	05H	Get button press information	
	06H	Get button release information	
	07H	Set min/max horizontal position	
	08H	Set min/max vertical position	
	09H	Set graphics cursor block	
	0AH	Set text cursor	
	0BH	Read mouse motion counters	
	0CH	Set user-defined subroutine input mask	
	0DH	Light pen emulation ON	
0EH	Light pen emulation OFF		
0FH	Set mickey/pixel ratio		
10H	Conditional OFF		
13H	Set doublespeed threshold		

**Notes:** \*Value entered in AX register

**Source:** Microsoft Mouse User's Guide, page 175

**5.09. INT 33H, AX=00H -- MOUSE INSTALLED FLAG**

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	<i>High</i>	<i>Low</i>
AX	00H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	<i>High</i>	<i>Low</i>
AX	Status*	
BX	Buttons**	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:**                   \*Function also resets mouse driver to default parameters  
                               \*\*0=mouse not installed; -1=mouse installed  
                               \*\*\*Always 2 for Microsoft Mouse

**Source:**                   Microsoft Mouse User's Guide, pages 176 to 177

**See Also:**                5.28. INT 33H, Mouse Driver Default Parameters

**5.10. INT 33H, AX=01H -- SHOW CURSOR**

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	<i>High</i>	<i>Low</i>
AX	01H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Notes:**                   Cursor flag is incremented by this function; cursor is displayed if the cursor flag has a value of 0 (default is -1)

**Source:**                   Microsoft Mouse User's Guide, page 178

**See Also:**                5.28. INT 33H, Mouse Driver Default Parameters

**5.11. INT 33H, AX=02H -- HIDE CURSOR**

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	High	Low
AX	02H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Notes:** Cursor flag is decremented by this function;  
cursor is removed from screen

**Source:** Microsoft Mouse User's Guide, pages 178 to 179

**See Also:** 5.28. INT 33H, Mouse Driver Default Parameters

**5.12. INT 33H, AX=03H -- GET POSITION AND BUTTON STATUS**

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	High	Low
AX	03H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Button status*	
BX	Horiz position	
CX	Vert position	
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** •A bit value of 1 represents a button held down (0=button up)  
•Bit 0 represents left button, bit 1 represents right button

**Source:** Microsoft Mouse User's Guide, page 179

**See Also:** 5.13. INT 33H, AX=04H -- Set Mouse Cursor Position  
5.14. INT 33H, AX=05H -- Get Button Press Information  
5.15. INT 33H, AX=06H -- Get Button Release Information

**5.13. INT 33H, AX=04H -- SET MOUSE CURSOR POSITION**

<i>Prior to Issuing INT 33H</i>		<i>Upon Return from INT 33H</i>
	High                      Low	
AX	04H	Interrupt returns no values
BX		
CX	Horz position	
DX	Vert position	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:**                      •Position may be rounded to nearest values if screen is not in high resolution mode  
                                     •Position must be within range for current video mode

**Source:**                      Microsoft Mouse User's Guide, page 180

**See Also:**                    5.12. INT 33H, AX=03H -- Get Position and Button Status  
                                     5.14. INT 33H, AX=05H -- Get Button Press Information  
                                     5.15. INT 33H, AX=06H -- Get Button Release Information

**5.14. INT 33H, AX=05H -- GET BUTTON PRESS INFORMATION**

<i>Prior to Issuing INT 33H</i>		<i>Upon Return from INT 33H</i>	
	High                      Low	High                      Low	
AX	05H	AX	Status**
BX	Button*	BX	Count***
CX		CX	Horz position at last press
DX		DX	Vert position at last press
SP		SP	
BP		BP	
SI		SI	
DI		DI	
IP		IP	
flags		flags	
CS		CS	
DS		DS	
SS		SS	
ES		ES	

**Notes:**                      •\*0=left button, 1=right button  
                                     •\*\*Bit 0 represents left button, bit 1 is right button; 1=button down, 0=button up  
                                     •\*\*\*Count of button presses, in range of 0 to 32767, set to 0 after call

**Source:**                      Microsoft Mouse User's Guide, page 181

**See Also:**                    5.12. INT 33H, AX=03H -- Get Position and Button Status  
                                     5.13. INT 33H, AX=04H -- Set Mouse Cursor Position  
                                     5.15. INT 33H, AX=06H -- Get Button Release Information

**5.15. INT 33H, AX=06H -- GET BUTTON RELEASE INFORMATION**

<i>Prior to Issuing INT 33H</i>		<i>Upon Return from INT 33H</i>	
	<i>High</i>	<i>Low</i>	
AX	06H		AX
BX	Button*		BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Notes:**                   \*0=left button, 1=right button  
 \*\*Bit 0 represents left button, bit 1 is right button; 1=button down, 0=button up  
 \*\*\*Count of button releases, in range of 0 to 32767, set to 0 after call

**Source:**                   Microsoft Mouse User's Guide, page 182

**See Also:**               5.12. INT 33H, AX=03H -- Get Position and Button Status  
 5.13. INT 33H, AX=04H -- Set Mouse Cursor Position  
 5.14. INT 33H, AX=05H -- Get Button Press Information

**5.16. INT 33H, AX=07H -- SET MIN AND MAX HORIZONTAL POSITION**

<i>Prior to Issuing INT 33H</i>		<i>Upon Return from INT 33H</i>
	<i>High</i>	<i>Low</i>
AX	07H	
BX		
CX	Minimum position	
DX	Maximum position	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Notes:**                   \*Function restricts mouse movement to horizontal coordinates specified  
 \*If min value is greater than max, the two values are swapped

**Source:**                   Microsoft Mouse User's Guide, page 183

**See Also:**               5.17. INT 33H, AX=08H -- Set Min and Max Vertical Position



5.19. INT 33H, AX=0AH -- SET TEXT CURSOR

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	High	Low
AX	0AH	
BX	Cursor type*	
CX	Screen mask**	
DX	Cursor mask***	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Notes:**

- \*0=software cursor, 1=hardware cursor
- \*\*Screen mask if software cursor, otherwise scan line start for hardware cursor
- \*\*\*Cursor mask if software cursor, otherwise scan line end for hardware cursor

**Source:** Microsoft Mouse User's Guide, page 187

**See Also:** 5.18. INT 33H, AX=09H -- Set Graphics Cursor Block  
5.27. INT 33H, Screen and Cursor Masks

5.20. INT 33H, AX=0BH -- READ MOUSE MOTION COUNTERS

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	High	Low
AX	0BH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX		
BX		
CX	Horizontal count	
DX	Vertical count	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:**

- Count values returned are the number of mickeys moved since the last call to this function. A mickey is 1/200 of an inch.
- Count values are in range -32768 to 32767

**Source:** Microsoft Mouse User's Guide, page 188

**5.21. INT 33H, AX=0CH -- SET USER-DEFINED SUBROUTINE INPUT MASK**

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	<i>High</i>	<i>Low</i>
AX	0CH	
BX		
CX	Call mask*	
DX	Offset of pointer to subroutine	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to subroutine	

Interrupt returns no values

**Notes:** •Subroutine is called when any of the conditions whose bit is 1 is met:

Bit	Condition
0	Cursor position changes
1	Left button pressed
2	Left button released
3	Right button pressed
4	Right button released
5-15	NOT USED

•Subroutine is passed information as follows:

Reg	Information
AX	Mask with condition bit set that triggered call
BX	Button state (bit 0=left, 1=right)
CX	Horizontal cursor position
DX	Vertical cursor position

**Source:** Microsoft Mouse User's Guide, pages 189 to 190

**5.22. INT 33H, AX=0DH -- SET LIGHT PEN EMULATION ON**

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	<i>High</i>	<i>Low</i>
AX	0DH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Notes:** Function causes mouse to emulate light pen, as follows:  
 Pen is down when both buttons are down  
 Pen is off screen when both buttons are up

**Source:** Microsoft Mouse User's Guide, page 191

**See Also:** 5.23. INT 33H, AX=0EH -- Set Light Pen Emulation OFF

**5.23. INT 33H, AX=0EH -- SET LIGHT PEN EMULATION OFF**

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	High	Low
AX	0EH	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

- Notes:** Function disables light pen emulation
- Source:** Microsoft Mouse User's Guide, page 192
- See Also:** 5.22. INT 33H, AX=0DH -- Set Light Pen Emulation ON

**5.24. INT 33H, AX=0FH -- SET MICKEY TO PIXEL RATIO**

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	High	Low
AX	0FH	
BX		
CX	Horizontal ratio	
DX	Vertical ratio	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

- Notes:**
- Ratio values must be in range 1 to 32767
  - Default horizontal value is 8
  - Default vertical value is 16
- Source:** Microsoft Mouse User's Guide, page 193

**5.25. INT 33H, AX=10H -- CONDITIONAL OFF**

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	<i>High</i>	<i>Low</i>
AX	10H	
BX		
CX	Upper x screen coord	
DX	Upper y screen coord	
SP		
BP		
SI	Lower x screen coord	
DI	Lower y screen coord	
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Notes:** Function defines region for updating; mouse cursor hidden when in this region, and you must use INT 33H, AX=01H to turn it back on

**Source:** Microsoft Mouse User's Guide, page 193

**See Also:** 5.10. INT 33H, AX=01H -- Show Cursor

**5.26. INT 33H, AX=13H -- SET DOUBLE SPEED THRESHOLD**

*Prior to Issuing INT 33H*

*Upon Return from INT 33H*

	<i>High</i>	<i>Low</i>
AX	13H	
BX		
CX		
DX	Threshold speed*	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

Interrupt returns no values

**Notes:** \*Speed defined in Mickeys per second; default is 64

**Source:** Microsoft Mouse User's Guide, page 194

## 5.27. INT 33H, SCREEN AND CURSOR MASKS

**Effect of Screen and Cursor Mask Combinations:**

Screen mask bit	Cursor mask bit	Resulting screen bit
0	0	0
0	1	1
1	0	Unchanged
1	1	Inverted

**Screen Data for Character:**

Bit Number*	Description	Comments
15	Blink control	1=blinking character
12-14	Background color	
11	Intensity control	1=high intensity
8-10	Foreground color	
0-7	Character	

**Notes:** \*Bytes are stored in reverse order

**Source:** Microsoft Mouse User's Guide, pages 165 to 166

**See Also:** 7.25. CGA Character Attributes

## 5.28. INT 33H, MOUSE DRIVER DEFAULT PARAMETERS

Function	Parameter	Comments
Cursor position	Screen center	e.g., 100,320 for CGA in 640x200 mono mode
Internal cursor flag	-1	Means not displayed
Graphics cursor	-1,-1	Arrow
Text cursor		Inverting box
Interrupt call mask	All 0	No interrupts
Light pen emulation mode	Enabled	
Mickey/pixel ratio (horz)	8 to 8	
Mickey/pixel ratio (vert)	16 to 8	
Min/max cursor pos (horz)	Varies	Set to maximum width of video mode
Min/max cursor pos (vert)	Varies	Set to maximum height of video mode

**Source:** Microsoft Mouse User's Guide, pages 176 to 177

**See Also:** 5.09. INT 33H, AX=00H -- Mouse Installed Flag

## 5.29. INT 67H: EXPANDED MEMORY MANAGER FUNCTIONS SUMMARY

Interrupt	Function*	Description	Comments
67H	40H	Get status	
	41H	Get page frame address	
	42H	Get page count	
	43H	Allocate pages	
	44H	Map memory	
	45H	Deallocate pages	
	46H	Get version	
	47H	Save page map	
	48H	Restore page map	
	4BH	Get handle count	
	4CH	Get page count for a handle	
	4DH	Get page counts for all handles	
	4EH,0	Get map	
	4EH,1	Set map	
	4EH,2	Swap map	
	4EH,3	Get size	
	60H	Get physical window array	EEMS only
	68H	Get system physical window array	EEMS only
	69H	Map page into window	EEMS only
	6AH,0	Get system map	EEMS only
	6AH,1	Set system map	EEMS only
	6AH,2	Swap system map	EEMS only
	6AH,3	Get map size	EEMS only
	6AH,4	Set standard mapping	EEMS only
	6AH,5	Set alternate mapping	EEMS only
	6AH,6	Deallocate initial pages	EEMS only

**Notes:** \*These functions work only if an Expanded Memory Manager (EMM) is active in the system. To check for EMM, see *Advanced MS-DOS*, pages 182 to 185.

\*First number is AH, second number (if any) is AL

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 442 to 443  
AST Rampage Technical Reference

**5.30. INT 67H, AH=40H -- GET STATUS**

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

	High	Low		High	Low
AX	40H		AX	Status*	
BX			BX		
CX			CX		
DX			DX		
SP			SP		
BP			BP		
SI			SI		
DI			DI		
IP			IP		
flags			flags		
CS			CS		
DS			DS		
SS			SS		
ES			ES		

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 441 to 442

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
5.56. INT 67H, Expanded Memory Manager Error Codes

**5.31. INT 67H, AH=41H -- GET PAGE FRAME ADDRESS**

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

	High	Low		High	Low
AX	41H		AX	Status*	
BX			BX	Segment address of page frame	
CX			CX		
DX			DX		
SP			SP		
BP			BP		
SI			SI		
DI			DI		
IP			IP		
flags			flags		
CS			CS		
DS			DS		
SS			SS		
ES			ES		

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 442 to 443

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
5.56. INT 67H, Expanded Memory Manager Error Codes

**5.32. INT 67H, AH=42H -- GET PAGE COUNT**

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

		High	Low			High	Low
AX		42H		AX		Status*	
BX				BX		Unallocated pages	
CX				CX			
DX				DX		Total page count	
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags			
CS				CS			
DS				DS			
SS				SS			
ES				ES			

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, page 443

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
5.56. INT 67H, Expanded Memory Manager Error Codes

**5.33. INT 67H, AH=43H -- ALLOCATE PAGES**

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

		High	Low			High	Low
AX		43H		AX		Status*	
BX		Pages to allocate		BX			
CX				CX			
DX				DX		EMM page handle	
SP				SP			
BP				BP			
SI				SI			
DI				DI			
IP				IP			
flags				flags			
CS				CS			
DS				DS			
SS				SS			
ES				ES			

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 444 to 445

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
5.56. INT 67H, Expanded Memory Manager Error Codes

**5.34. INT 67H, AH=44H -- MAP MEMORY**

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

	High	Low
AX	44H	Phys Page #**
BX	Logical page #	
CX		
DX	EMM page handle	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)  
 \*\*Must be in range 0-3

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 445 to 446

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
 5.33. INT 67H, AH=43H -- Allocate Pages  
 5.56. INT 67H, Expanded Memory Manager Error Codes

**5.35. INT 67H, AH=45H -- DEALLOCATE PAGES**

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

	High	Low
AX	45H	
BX		
CX		
DX	EMM page handle	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 446 to 447

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
 5.33. INT 67H, AH=43H -- Allocate Pages  
 5.56. INT 67H, Expanded Memory Manager Error Codes

**5.36. INT 67H, AH=46H -- GET EMM VERSION**

**Prior to Issuing INT 67H**

**Upon Return from INT 67H**

	High	Low
AX	46H	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Status*	Version**
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)  
 \*\*HO nibble is BCD-coded major version number, LO nibble is BCD-coded minor version number

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 447 to 448

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
 5.56. INT 67H, Expanded Memory Manager Error Codes

**5.37. INT 67H, AH=47H -- SAVE PAGE MAP**

**Prior to Issuing INT 67H**

**Upon Return from INT 67H**

	High	Low
AX	47H	
BX		
CX		
DX	EMM Page Handle	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 448 to 449

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
 5.33. INT 67H, AH=43H -- Allocate Pages  
 5.56. INT 67H, Expanded Memory Manager Error Codes

## 5.38. INT 67H, AH=48H -- RESTORE PAGE MAP

Prior to Issuing INT 67H		Upon Return from INT 67H	
	High	Low	
AX	48H		AX
BX			BX
CX			CX
DX	EMM page handle		DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Notes:**            •Function is used after an INT 67H, AH=47H call  
                       •\*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:**            *Advanced MS-DOS* (Microsoft Press), Ray Duncan, page 449

**See Also:**         5.29. INT 67H: Expanded Memory Manager Functions Summary  
                       5.33. INT 67H, AH=43H -- Allocate Pages  
                       5.37. INT 67H, AH=47H -- Save Page Map  
                       5.56. INT 67H, Expanded Memory Manager Error Codes

## 5.39. INT 67H, AH=4BH -- GET HANDLE COUNT

Prior to Issuing INT 67H		Upon Return from INT 67H	
	High	Low	
AX	4BH		AX
BX			BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Notes:**            \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:**            *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 450 to 451

**See Also:**         5.29. INT 67H: Expanded Memory Manager Functions Summary  
                       5.56. INT 67H, Expanded Memory Manager Error Codes

**5.40. INT 67H, AH=4CH -- GET PAGE COUNT FOR HANDLE**

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

	High	Low
AX	4CH	
BX		
CX		
DX	EMM page handle	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

	High	Low
AX	Status*	
BX	Number of pages**	
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)  
 \*\*Logical pages in range of 1 to 512

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 451 to 452

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
 5.56. INT 67H, Expanded Memory Manager Error Codes

**5.41. INT 67H, AH=4DH -- GET PAGE COUNTS FOR ALL HANDLES**

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

	High	Low
AX	4DH	
BX		
CX		
DX		
SP		
BP		
SI		
DI	Offset of pointer to empty array	
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to empty array	

	High	Low
AX	Status*	
BX	Number of handles	
CX		
DX		
SP		
BP		
SI		
DI	Offset of pointer to filled array	
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to filled array	

**Notes:** \*Array is a 1024-byte area which will be filled with two words for each handle being used (first word is handle number, second is number of pages associated with it)  
 \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 452 to 453

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
 5.40. INT 67H, AH=4CH -- Get Page Count for Handle  
 5.56. INT 67H, Expanded Memory Manager Error Codes

5.42. INT 67H, AH=4EH, AL=00H -- GET PAGE MAP

**Prior to Issuing INT 67H**

	High	Low
AX	4EH	00H
BX		
CX		
DX		
SP		
BP		
SI		
DI	Offset of pointer to empty array	
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to empty array	

**Upon Return from INT 67H**

	High	Low
AX	Status*	
BX	Number of handles	
CX		
DX		
SP		
BP		
SI		
DI	Offset of pointer to filled array	
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to filled array	

**Notes:** •Array is a 1024-byte area which will be filled with two words for each handle being used (first word is handle number, second is number of pages associated with it)  
 •\*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 453 to 454

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
 5.56. INT 67H, Expanded Memory Manager Error Codes

5.43. INT 67H, AH=4EH, AL=01H -- SET PAGE MAP

**Prior to Issuing INT 67H**

	High	Low
AX	4EH	01H
BX		
CX		
DX		
SP		
BP		
SI	Offset of pointer to page map array	
DI		
IP		
flags		
CS		
DS	Segment of pointer to page map array	
SS		
ES		

**Upon Return from INT 67H**

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** •Array is a 1024-byte area which will be filled with two words for each handle being used (first word is handle number, second is number of pages associated with it)  
 •\*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 453 to 454

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
 5.56. INT 67H, Expanded Memory Manager Error Codes

**5.44. INT 67H, AH=4EH, AL=02H -- SWAP PAGE MAP**

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

	High	Low		High	Low
AX	4EH	02H	AX	Status*	
BX			BX		
CX			CX		
DX			DX		
SP			SP		
BP			BP		
SI	Offset of pointer to page map array		SI		
DI			DI	Offset of pointer to previous page map array	
IP			IP		
flags			flags		
CS			CS		
DS	Segment of pointer to page map array		DS		
SS			SS		
ES			ES	Segment of pointer to previous page map array	

**Notes:**                   •Array is a 1024-byte area which will be filled with two words for each handle being used (first word is handle number, second is number of pages associated with it)  
                               \*\*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:**                 *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 453 to 454

**See Also:**             5.29. INT 67H: Expanded Memory Manager Functions Summary  
                               5.56. INT 67H, Expanded Memory Manager Error Codes

**5.45. INT 67H, AH=4EH, AL=03H -- GET PAGE MAP ARRAY SIZE**

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

	High	Low		High	Low
AX	4EH	03H	AX	Status*	Size**
BX			BX		
CX			CX		
DX			DX		
SP			SP		
BP			BP		
SI			SI		
DI			DI		
IP			IP		
flags			flags		
CS			CS		
DS			DS		
SS			SS		
ES			ES		

**Notes:**                   •\*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)  
                               \*\*Size is in bytes and represents size of current page map array

**Source:**                 *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 453 to 454

**See Also:**             5.29. INT 67H: Expanded Memory Manager Functions Summary  
                               5.56. INT 67H, Expanded Memory Manager Error Codes

5.46. INT 67H, AH=60H -- GET PHYSICAL WINDOW ARRAY

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

	High	Low
AX	60H	
BX		
CX		
DX		
SP		
BP		
SI		
DI	Offset of pointer to empty array	
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to empty array	

	High	Low
AX	Status*	Number entries**
BX		
CX		
DX		
SP		
BP		
SI		
DI	Offset of pointer to filled array	
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to filled array	

- Notes:**                   \*\*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)  
                               \*\*\*Size is in entries (four bytes per entry in array)
- Source:**                 AST Rampage Technical Reference
- See Also:**              5.29. INT 67H: Expanded Memory Manager Functions Summary  
                               5.56. INT 67H, Expanded Memory Manager Error Codes

5.47. INT 67H, AH=68H -- GET SYSTEM PHYSICAL WINDOW ARRAY

*Prior to Issuing INT 67H*

*Upon Return from INT 67H*

	High	Low
AX	68H	
BX		
CX		
DX		
SP		
BP		
SI		
DI	Offset of pointer to empty array	
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to empty array	

	High	Low
AX	Status*	Number entries**
BX		
CX		
DX		
SP		
BP		
SI		
DI	Offset of pointer to filled array	
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to filled array	

- Notes:**                   \*\*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)  
                               \*\*\*Size is in entries (four bytes per entry in array)
- Source:**                 AST Rampage Technical Reference
- See Also:**              5.29. INT 67H: Expanded Memory Manager Functions Summary  
                               5.56. INT 67H, Expanded Memory Manager Error Codes

**5.48. INT 67H, AH=69H -- MAP PAGE TO WINDOW**

*Prior to Issuing INT 67H*

	High	Low
AX	69H	
BX	Page number	
CX		
DX	EMM page handle	
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

*Upon Return from INT 67H*

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** AST Rampage Technical Reference

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
5.56. INT 67H, Expanded Memory Manager Error Codes

**5.49. INT 67H, AH=6AH, AL=00H -- GET SYSTEM MAP**

*Prior to Issuing INT 67H*

	High	Low
AX	6AH	00H
BX		
CX	First window	Window count
DX		
SP		
BP		
SI		
DI	Offset of pointer to empty array	
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to empty array	

*Upon Return from INT 67H*

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI	Offset of pointer to saved page map array	
IP		
flags		
CS		
DS		
SS		
ES	Segment of pointer to saved page map array	

**Notes:** \*00=nc error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** AST Rampage Technical Reference

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
5.56. INT 67H, Expanded Memory Manager Error Codes

## 5.50. INT 67H, AH=6AH, AL=01H -- SET SYSTEM MAP

*Prior to Issuing INT 67H*

	High	Low
AX	6AH	01H
BX		
CX	1st window	Window count
DX		

SP	
BP	
SI	
DI	Offset of pointer to saved page map array

IP	
flags	

CS	
DS	
SS	
ES	Segment of pointer to saved page map array

*Upon Return from INT 67H*

	High	Low
AX	Status*	
BX		
CX		
DX		

SP	
BP	
SI	
DI	

IP	
flags	

CS	
DS	
SS	
ES	

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** AST Rampage Technical Reference

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
5.56. INT 67H, Expanded Memory Manager Error Codes

## 5.51. INT 67H, AH=6AH, AL=02H -- SWAP SYSTEM MAP

*Prior to Issuing INT 67H*

	High	Low
AX	6AH	02H
BX		
CX	1st window	Window count
DX		

SP	
BP	
SI	Offset of pointer to next page map
DI	Offset of pointer to empty array

IP	
flags	

CS	
DS	Segment of pointer to next page map
SS	
ES	Segment of pointer to empty array

*Upon Return from INT 67H*

	High	Low
AX	Status*	
BX		
CX		
DX		

SP	
BP	
SI	
DI	Offset of pointer to previous page map

IP	
flags	

CS	
DS	
SS	
ES	Segment of pointer to previous page map

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** AST Rampage Technical Reference

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
5.56. INT 67H, Expanded Memory Manager Error Codes

**5.52. INT 67H, AH=6AH, AL=03H -- GET MAP SIZE**

**Prior to Issuing INT 67H**

	High	Low
AX	6AH	03H
BX		
CX	1st window	Window count
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return from INT 67H**

	High	Low
AX	Status*	Size**
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)  
 \*\*Size of page map array in bytes

**Source:** AST Rampage Technical Reference

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
 5.56. INT 67H, Expanded Memory Manager Error Codes

**5.53. INT 67H, AH=6AH, AL=04H -- SET STANDARD MAPPING**

**Prior to Issuing INT 67H**

	High	Low
AX	6AH	04H
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Upon Return from INT 67H**

	High	Low
AX	Status*	
BX		
CX		
DX		
SP		
BP		
SI		
DI		
IP		
flags		
CS		
DS		
SS		
ES		

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** AST Rampage Technical Reference

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
 5.56. INT 67H, Expanded Memory Manager Error Codes

**5.54. INT 67H, AH=6AH, AL=05H -- SET ALTERNATE MAPPING**

<i>Prior to Issuing INT 67H</i>		<i>Upon Return from INT 67H</i>	
	<i>High</i>	<i>Low</i>	
AX	6AH	05H	AX
BX			BX
CX			CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** AST Rampage Technical Reference

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
5.56. INT 67H, Expanded Memory Manager Error Codes

**5.55. INT 67H, AH=6AH, AL=06H -- DEALLOCATE INITIAL SYSTEM PAGES**

<i>Prior to Issuing INT 67H</i>		<i>Upon Return from INT 67H</i>	
	<i>High</i>	<i>Low</i>	
AX	6AH	06H	AX
BX			BX
CX	1st window	Window count	CX
DX			DX
SP			SP
BP			BP
SI			SI
DI			DI
IP			IP
flags			flags
CS			CS
DS			DS
SS			SS
ES			ES

**Notes:** \*00=no error (Otherwise see 5.56. INT 67H, Expanded Memory Manager Error Codes)

**Source:** AST Rampage Technical Reference

**See Also:** 5.29. INT 67H: Expanded Memory Manager Functions Summary  
5.56. INT 67H, Expanded Memory Manager Error Codes

**5.56. INT 67H -- EXPANDED MEMORY MANAGER ERROR CODES**

<i>Code</i>	<i>Description</i>	<i>Comments</i>
00H	Normal return code	No error occurred
80H	Software error	
81H	Hardware error	
83H	Unallocated or invalid handle	
84H	Undefined function code	
85H	Out of handles	
87H	Page count error	> total pages
88H	Page count error	
89H	Requested zero pages	
8AH	No logical page for this handle	
8BH	Physical page outside valid range	
8CH	Context stack out of memory	
8DH	Handle already has context stack	
8EH	No context stack for that handle	
8FH	Undefined subfunction code	

**Source:** *Advanced MS-DOS* (Microsoft Press), Ray Duncan, pages 441 to 454



— SECTION —

# 6

Microsoft  
Windows

---

## 6.01. RESERVED SYSTEM KEYS

Key Code	Key Name	Windows Action	Never Redefine Used by System	Reserved for Use in Menus	Reserved for Use in Dialogs
No equivalent	Alt + Tab	Selects active window from top down	X		
No equivalent	Alt + Shift + Tab	Selects active window from bottom up	X		
No equivalent	Alt + Spacebar	Selects System menu of active window	X		
0,10H to 0,32H	Alt + letter	Selects menu from active menu bar			
0,6BH	Alt+F4**	Closes window	X		
0,6CH	Alt+F5**	Restores window	X		
0,6EH	Alt+F7**	Moves window	X		
0,6FH	Alt+F8**	Sizes window	X		
0,70H	Alt+F9**	Shrinks window	X		
0,71H	Alt+F10**	Enlarges window	X		
No equivalent	Alt+Escape**	Selects next application	X		
No equivalent	Ctrl+Escape**	RESERVED	X		
No equivalent	Shift+Escape**	Selects system menu of active window	X		
0,44H	F10**	Selects system menu of active window	X		
0,4BH	Left*	Selects menu to left of current one		X	
0,4DH	Right*	Selects menu to right of current one		X	
0,48H	Up*	Selects command above current one		X	
0,50H	Down*	Selects command below current one		X	
13H	Enter	Invokes selected command or action		X	X
1BH	Escape	Cancel menu or dialog box		X	X
09H	Tab	Selects active control from top down			X
No equivalent	Shift + Tab	Selects active control from bottom up			X
20H	Spacebar	Invokes default action (default push button)			X

**Version Info:** \*\*Applies only to versions of Windows beginning with 2.0

**Notes:** \*Any direction key of this type should not be redefined

**Source:** Microsoft Windows SDK Application Style Guide 2.0, pages 44 to 45

**See Also:** 1.23. IBM Extended Character Codes  
6.02. Recommended Keyboard Actions  
6.05. Recommended Mouse Usage

## 6.02. RECOMMENDED KEYBOARD ACTIONS

Key Code	Key Name	Recommended Windows Action	
		In General Selections	In Text/Graphics Selections
09H	Tab	Move to next item (left to right, top to bottom)	Move to next tab stop to the right
No equivalent	Shift+Tab	Move to previous item (right to left, bottom to top)	Move to next tab stop to the left
13H	Enter	Confirm or execute default or highlighted item	Create an empty line
Varies	Left*	Move left one item	Move left one character
Varies	Right*	Move right one item	Move right one character
Varies	Up*	Move up one item	Move up one line
Varies	Down*	Move down one item	Move down one line
0,49H	PgUp	Move up one screen	Move up one screen
0,51H	PgDn	Move down one screen	Move down one screen
0,52H	Insert	Insert contents of Clipboard at cursor position	
0,53H	Delete	Move selected item to Clipboard	
No equivalent	Shift + Up*	Extend selection up from current item	Extend current selection up
No equivalent	Shift + Down*	Extend selection down from current item	Extend current selection down
No equivalent	Shift + Left*	Extend selection left from current item	Extend current selection left
No equivalent	Shift + Right*	Extend selection right from current item	Extend current selection right
No equivalent	Shift + Delete	Delete selected item (do not move to clipboard)	Delete selected item
Varies	Control + Direction	Leave selection intact, move in indicated direction	
No equivalent	Control + Shift + Direction	Add to discontinuous selection moving in direction	
No equivalent	Shift + Backspace		Delete character to right
08H	Backspace		Delete character to left
0,3BH	F1**	Help	
0,40H	F6**	Next section (pane) within application	
0,59H	Shift+F6**	Previous section (pane) within application	
0,63H	Ctrl+F6**	Next child or document window within application	
No equivalent	Shift+Ctrl+F6**	Previous child or document window within application	
0,68H	Alt+F1**	F11	
0,69H	Alt+F2**	F12	
No equivalent	Shift+Insert**	Insert contents of clipboard	
0,84H	Ctrl+PgUp**	Move left one screen	
0,76H	Ctrl+PgDn**	Move right one screen	

(Continued)

Table 6.02. Continued

Key Code	Key Name	Recommended Windows Action	
		In General Selections	In Text Graphics Selections
No equivalent	Shift+PgUp**		Move selection up one screen
No equivalent	Shift+PgDn**		Move selection down one screen
No equivalent	Alt+Backspace**	Undo last action	
No equivalent	Ctrl+Delete**	Clear to end of line	
0,47H	Home		Move to top of current screen
0,4FH	End		Move to bottom of current screen

**Version Info:** \*\*Applies to versions of Windows beginning with 2.0 only

**Notes:** \*Any direction key of this type should not be redefined

**Source:** Microsoft Windows SDK Application Style Guide 2.0, pages 46 to 49

**See Also:** 1.23. IBM Extended Character Codes  
6.01. Reserved System Keys  
6.05. Recommended Mouse Usage

### 6.03. VIRTUAL KEYS

Key Name	Description
VK_ADD	Add key
VK_BACK	Backspace key
VK_CANCEL	Cancel key
VK_CAPITAL	Caps lock key
VK_CLEAR	Clear key
VK_CONTROL	Control key
VK_DECIMAL	Decimal point key (.)
VK_DELETE	Delete key
VK_DIVIDE	Divide key
VK_DOWN	Down arrow key
VK_END	End of document key (End)
VK_ESCAPE	Escape key (Esc)
VK_F1	Function key 1
VK_F2	Function key 2
VK_F3	Function key 3
VK_F4	Function key 4
VK_F5	Function key 5
VK_F6	Function key 6
VK_F7	Function key 7
VK_F8	Function key 8
VK_F9	Function key 9
VK_F10	Function key 10
VK_F11	Function key 11
VK_F12	Function key 12
VK_F13	Function key 13
VK_F14	Function key 14
VK_F15	Function key 15
VK_F16	Function key 16
VK_HELP	Help key
VK_HOME	Beginning of document key (Home)

Key Name	Description
VK_INSERT	Insert key
VK_LBUTTON	Left mouse button
VK_LEFT	Left arrow key
VK_MBUTTON	Middle mouse button
VK_MENU	Alt key
VK_MULTIPLY	Multiply key
VK_NEXT	Next screen key (PgDn)
VK_NUMPAD0	Numeric keypad 0 key
VK_NUMPAD1	Numeric keypad 1 key
VK_NUMPAD2	Numeric keypad 2 key
VK_NUMPAD3	Numeric keypad 3 key
VK_NUMPAD4	Numeric keypad 4 key
VK_NUMPAD5	Numeric keypad 5 key
VK_NUMPAD6	Numeric keypad 6 key
VK_NUMPAD7	Numeric keypad 7 key
VK_NUMPAD8	Numeric keypad 8 key
VK_NUMPAD9	Numeric keypad 9 key
VK_PAUSE	Pause key
VK_PRINT	Print key
VK_PRIOR	Prior screen key (PgUp)
VK_RBUTTON	Right mouse button
VK_RETURN	Carriage return key (Enter key)
VK_RIGHT	Right arrow key
VK_SELECT	Select key
VK_SEPARATOR	Separator key
VK_SHIFT	Shift key
VK_SPACE	Spacebar
VK_SUBTRACT	Subtract key
VK_TAB	Tab key
VK_UP	Up arrow key

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 280 to 281

**See Also:** 6.01. Reserved System Keys  
6.02. Recommended Keyboard Actions  
6.05. Recommended Mouse Usage

#### 6.04. WINDOWS TERMINAL -- VT52 KEY EMULATIONS

<i>ANSI VT52 Key</i>	<i>Windows Key Equivalent</i>	<i>Numlock Status</i>
0	Numeric keypad 0 (insert)	ON
1	Numeric keypad 1 (end)	ON
2	Numeric keypad 2 (down)	ON
3	Numeric keypad 3 (PgDn)	ON
4	Numeric keypad 4 (left)	ON
5	Numeric keypad 5	ON
6	Numeric keypad 6 (right)	ON
7	Numeric keypad 7 (home)	ON
8	Numeric keypad 8 (up)	ON
9	Numeric keypad 9 (PgUp)	ON
-	Numeric keypad -	ON
.	Numeric keypad * (prtscr)	ON
.	Numeric keypad . (delete)	ON
Enter	Numeric keypad plus	ON
Insert char mode	Insert	OFF
Insert line	End	OFF
Cursor down	Down arrow	OFF
Delete line	PgDn	OFF
Cursor left	Left arrow	OFF
Cursor right	Right arrow	OFF
Home	Home	OFF
Cursor up	Up arrow	OFF
Delete char	PgUp	OFF
PF1	F1	NA
PF2	F2	NA
PF3	F3	NA
PF4	F4	NA

**Notes:** Keys listed are for IBM PC compatible keyboards only

**Source:** Microsoft Windows Desktop Applications User's Guide 2.0, pages 89 to 90

**See Also:** 6.01. Reserved System Keys  
6.02. Recommended Keyboard Actions

#### 6.05. RECOMMENDED MOUSE USAGE

##### *Recommended Usage*

<i>Mouse Action</i>	<i>In Text Selection</i>	<i>In Item Selection</i>
Click	Move insertion point to mouse pointer	Select item at pointer position
Double-click	Select word at mouse pointer position	Confirm or execute item at pointer position
Drag	Extend selection from pointer to release point	Extend selection from pointer to release point
Shift + drag	Extend current selection to new position	Move left one character
Shift + click	Extend current selection to new release point	Extend current selection to new release point
Control + drag		Allow discontinuous selection; add additional selection
Control + click		Toggle: delete or restore selection

**Source:** Microsoft Windows SDK Application Style Guide 2.0, pages 53 to 55

**See Also:** 1.23. IBM Extended Character Codes  
6.01. Reserved System Keys  
6.02. Recommended Keyboard Actions

**6.06. WINDOWS OPERATING ENVIRONMENT FILES**

<i>File Name</i>	<i>Function</i>	<i>1</i>	<i>2</i>
MSDOS.EXE	DOS Executive	X	X
SPOOLER.EXE	Print spooler	X	X
WIN.COM	Windows loader file	X	X
WIN.INI	Windows initialization file	X	X
WIN#.BIN	Windows code file (for 2.0, #=200)	X	X
WIN#.OVL	Windows overlay file (for 2.0, #=200)	X	X
WINOLDAP.GRB	Windows old applications support	X	X
WINOLDAP.MOD	Windows old applications support	X	X

**Optional Files:**

<i>File Name</i>	<i>Function</i>	<i>1</i>	<i>2</i>
CALC.EXE	Windows calculator program	X	X
CALENDAR.EXE	Windows calendar program	X	X
CARDFILE.EXE	Windows cardfile program	X	X
CLIPBRD.EXE	Windows clipboard program	X	X
CLOCK.EXE	Windows clock program	X	X
CONTROL.EXE	Windows control panel program	X	X
COUR*.FON	Courier font file (* is letter)	X	X
HELV*.FON	Helvetica font file (* is letter)	X	X
*.DRV	Printer driver file (* is printer name)	X	X
*.PCL	Printer control file (* is port name)	X	X
NOTEPAD.EXE	Windows notepad program	X	X
PAINT.EXE	Windows paint program	X	X
REVERSI.EXE	Windows game program	X	X
TERMINAL.EXE	Windows terminal emulation program	X	X
TMSR*.FON	Times Roman font file (* is letter)	X	X
WRITE.EXE	Windows write program	X	X

**Source:** Microsoft Windows 2.03 disks

**See Also:** 6.07. Windows C Programming Library Files  
6.08. Windows Development Utilities

**6.07. WINDOWS C PROGRAMMING LIBRARY FILES**

<i>File Name</i>	<i>Function</i>	<i>1</i>	<i>2</i>
CLIBW.LIB	Standard library, compact memory model	X	X
CLIBC.LIB	Startup library, compact memory model	X	X
LLIBW.LIB	Standard library, large memory model	X	X
LLIBC.LIB	Startup library, large memory model	X	X
MLIBW.LIB	Standard library, medium memory model	X	X
MLIBC.LIB	Startup library, medium memory model	X	X
SLIBW.LIB	Standard library, small memory model	X	X
SLIBC.LIB	Startup library, small memory model	X	X
WIN87EM.LIB	8087, extended memory library		X
WINDOWS.H	Windows include file for C-language applications	X	X

**Source:** Microsoft Windows SDK Programming Tools 2.0, page 17

**See Also:** 6.06. Windows Operating Environment Files  
6.08. Windows Development Utilities

## 6.08. WINDOWS DEVELOPMENT UTILITIES

File Name	Function	1	2
DIALOG.EXE	Creates and edits Windows dialog boxes	X	
DLGEDIT.EXE	Creates and edits Windows dialog boxes		X
EXEHDR.EXE	Displays EXE file header information	X	
NEWFONT.EXE	Converts version 1.03 fonts to 2.01 or later style		X
FONTEDIT.EXE	Creates and edits Windows fonts	X	X
GDI.EXE	Debugging executable for GDI library	X	X
GDI.SYM	Symbolic debugging information for GDI library	X	X
HEAPWALK.EXE	Displays allocated blocks in Windows global heap	X	
ICONEDIT.EXE	Creates and edits Windows icons	X	X
IMPLIB.EXE	Creates linkable, dynamic library files	X	
KERNEL.EXE	Debugging executable for kernel library	X	X
KERNEL.SYM	Symbolic debugging information for kernel library	X	X
LIB.EXE	Creates and maintains library files	X	
LINK4.EXE	Creates executable Windows applications	X	
MAKE.EXE	Automated file maintenance utility	X	
MAPSYM.EXE	Creates symbol files for symbolic debugger	X	
RC.EXE	Resource compiler	X	X
RCPPEX.EXE	Preprocessor for resource compiler	X	X
SHAKER.EXE	Randomly allocates memory in global heap	X	X
WINTOOL.EXE			X
WIN87EM.EXE	80x87 support		X
SLAPJR.EXE	Sends screen to file or printer	X	
SYMDEB.EXE	Symbolic debugger for Windows applications	X	
USER.EXE	Debugging executable for user library	X	X
USER.SYM	Symbolic debugging information for user library	X	X
WINSTUB.EXE	Warning message for non-Windows environs.	X	X

**Notes:** Additional utilities are available directly from Microsoft and the Microsoft-supported conference on Genie

**Source:** Microsoft Windows SDK 2.0 disks

**See Also:** 6.06. Windows Operating Environment Files  
6.07. Windows C Programming Library Files

## 6.09. EXTENDED ANSI CHARACTER CODES

Dec	Hex	Octal	Binary	Name	Character
8	08	10	0000 1000	Backspace	
9	09	11	0000 1001	Tab	
13	0D	15	0000 1101	Carriage return	
32	20	40	0010 0000	Space	Space
33	21	41	0010 0001	Exclamation point	!
34	22	42	0010 0010	Quotation mark	"
35	23	43	0010 0011	Number sign	#
36	24	44	0010 0100	Dollar sign	\$
37	25	45	0010 0101	Percent sign	%
38	26	46	0010 0110	Ampersand	&
39	27	47	0010 0111	Apostrophe	'
40	28	50	0010 1000	Opening parentheses	(
41	29	51	0010 1001	Closing parentheses	)
42	2A	52	0010 1010	Asterisk	*
43	2B	53	0010 1011	Plus sign	+
44	2C	54	0010 1100	Comma	,
45	2D	55	0010 1101	Hyphen	-
46	2E	56	0010 1110	Period	.
47	2F	57	0010 1111	Forward slash	/
48	30	60	0011 0000	Zero	0
49	31	61	0011 0001	One	1
50	32	62	0011 0010	Two	2
51	33	63	0011 0011	Three	3
52	34	64	0011 0100	Four	4
53	35	65	0011 0101	Five	5
54	36	66	0011 0110	Six	6
55	37	67	0011 0111	Seven	7
56	38	70	0011 1000	Eight	8
57	39	71	0011 1001	Nine	9
58	3A	72	0011 1010	Colon	:

(Continued)

Table 6.09. Continued

Dec	Hex	Octal	Binary	Name	Character
59	3B	73	0011 1011	Semicolon	;
60	3C	74	0011 1100	Less than sign	<
61	3D	75	0011 1101	Equal sign	=
62	3E	76	0011 1110	Greater than sign	>
63	3F	77	0011 1111	Question mark	?
64	40	100	0100 0000	Commercial at sign	@
65	41	101	0100 0001	Capital A	A
66	42	102	0100 0010	Capital B	B
67	43	103	0100 0011	Capital C	C
68	44	104	0100 0100	Capital D	D
69	45	105	0100 0101	Capital E	E
70	46	106	0100 0110	Capital F	F
71	47	107	0100 0111	Capital G	G
72	48	110	0100 1000	Capital H	H
73	49	111	0100 1001	Capital I	I
74	4A	112	0100 1010	Capital J	J
75	4B	113	0100 1011	Capital K	K
76	4C	114	0100 1100	Capital L	L
77	4D	115	0100 1101	Capital M	M
78	4E	116	0100 1110	Capital N	N
79	4F	117	0100 1111	Capital O	O
80	50	120	0101 0000	Capital P	P
81	51	121	0101 0001	Capital Q	Q
82	52	122	0101 0010	Capital R	R
83	53	123	0101 0011	Capital S	S
84	54	124	0101 0100	Capital T	T
85	55	125	0101 0101	Capital U	U
86	56	126	0101 0110	Capital V	V
87	57	127	0101 0111	Capital W	W
88	58	130	0101 1000	Capital X	X
89	59	131	0101 1001	Capital Y	Y
90	5A	132	0101 1010	Capital Z	Z
91	5B	133	0101 1011	Opening bracket	[
92	5C	134	0101 1100	Backward slash	\
93	5D	135	0101 1101	Closing bracket	]
94	5E	136	0101 1110	Caret	^
95	5F	137	0101 1111	Underscore	_
96	60	140	0110 0000	Grave	`
97	61	141	0110 0001	Lowercase A	a
98	62	142	0110 0010	Lowercase B	b
99	63	143	0110 0011	Lowercase C	c
100	64	144	0110 0100	Lowercase D	d
101	65	145	0110 0101	Lowercase E	e
102	66	146	0110 0110	Lowercase F	f
103	67	147	0110 0111	Lowercase G	g
104	68	150	0110 1000	Lowercase H	h
105	69	151	0110 1001	Lowercase I	i
106	6A	152	0110 1010	Lowercase J	j
107	6B	153	0110 1011	Lowercase K	k
108	6C	154	0110 1100	Lowercase L	l
109	6D	155	0110 1101	Lowercase M	m
110	6E	156	0110 1110	Lowercase N	n
111	6F	157	0110 1111	Lowercase O	o
112	70	160	0111 0000	Lowercase P	p
113	71	161	0111 0001	Lowercase Q	q
114	72	162	0111 0010	Lowercase R	r
115	73	163	0111 0011	Lowercase S	s
116	74	164	0111 0100	Lowercase T	t
117	75	165	0111 0101	Lowercase U	u
118	76	166	0111 0110	Lowercase V	v
119	77	167	0111 0111	Lowercase W	w
120	78	170	0111 1000	Lowercase X	x
121	79	171	0111 1001	Lowercase Y	y
122	7A	172	0111 1010	Lowercase Z	z
123	7B	173	0111 1011	Opening brace	{
124	7C	174	0111 1100	Vertical line	
125	7D	175	0111 1101	Closing brace	}
126	7E	176	0111 1110	Tilde	~
127	7F	177	0111 1111	DEL	Delete
128	80	200	1000 0000	Box	
129	81	201	1000 0001	Box	

(Continued)

Table 6.09. Continued

Dec	Hex	Octal	Binary	Name	Character
130	82	202	1000 0010	Box	
131	83	203	1000 0011	Box	
132	84	204	1000 0100	Box	
133	85	205	1000 0101	Box	
134	86	206	1000 0110	Box	
135	87	207	1000 0111	Box	
136	88	210	1000 1000	Box	
137	89	211	1000 1001	Box	
138	8A	212	1000 1010	Box	
139	8B	213	1000 1011	Box	
140	8C	214	1000 1100	Box	
141	8D	215	1000 1101	Box	
142	8E	216	1000 1110	Box	
143	8F	217	1000 1111	Box	
144	90	220	1001 0000	Box	
145	91	221	1001 0001	Box	
146	92	222	1001 0010	Box	
147	93	223	1001 0011	Box	
148	94	224	1001 0100	Box	
149	95	225	1001 0101	Box	
150	96	226	1001 0110	Box	
151	97	227	1001 0111	Box	
152	98	230	1001 1000	Box	
153	99	231	1001 1001	Box	
154	9A	232	1001 1010	Box	
155	9B	233	1001 1011	Box	
156	9C	234	1001 1100	Box	
157	9D	235	1001 1101	Box	
158	9E	236	1001 1110	Box	
159	9F	237	1001 1111	Box	
160	A0	240	1010 0000	Blank	
161	A1	241	1010 0001	Opening exclamation	
162	A2	242	1010 0010	Cent sign	
163	A3	243	1010 0011	Pound sign	
164	A4	244	1010 0100		
165	A5	245	1010 0101	Yen sign	
166	A6	246	1010 0110	Vertical line	
167	A7	247	1010 0111	Section symbol	
168	A8	250	1010 1000	Diaeresis symbol	
169	A9	251	1010 1001	Copyright symbol	
170	AA	252	1010 1010	Underlined a	
171	AB	253	1010 1011	Much less than	
172	AC	254	1010 1100		
173	AD	255	1010 1101	Hyphen	
174	AE	256	1010 1110	Registered symbol	
175	AF	257	1010 1111	Macron symbol	
176	B0	260	1011 0000	Degree symbol	
177	B1	261	1011 0001	Plus/minus symbol	
178	B2	262	1011 0010	Superscript 2	
179	B3	263	1011 0011	Superscript 3	
180	B4	264	1011 0100	Acute accent	
181	B5	265	1011 0101	Mu	
182	B6	266	1011 0110	Paragraph symbol	
183	B7	267	1011 0111	1 to 2 upper right	
184	B8	270	1011 1000	Cedilla symbol	
185	B9	271	1011 1001	Superscript 1	
186	BA	272	1011 1010	Superscript 0	
187	BB	273	1011 1011	Much greater than	
188	BC	274	1011 1100	One-quarter	
189	BD	275	1011 1101	One-half	
190	BE	276	1011 1110	Three-quarters	
191	BF	277	1011 1111	Opening question mark	
192	C0	300	1100 0000	Grave A	
193	C1	301	1100 0001	Acute A	
194	C2	302	1100 0010	Circumflex A	
195	C3	303	1100 0011	Circumflex A	
196	C4	304	1100 0100	Umlaut A	
197	C5	305	1100 0101	A	
198	C6	306	1100 0110	Diphthong AE	
199	C7	307	1100 0111	C cedilla	

(Continued)

Table 6.09. Continued

Dec	Hex	Octal	Binary	Name	Character
200	C8	310	1100 1000	Grave E	
201	C9	311	1100 1001	Acute E	
202	CA	312	1100 1010	Circumflex E	
203	CB	313	1100 1011	Umlaut E	
204	CC	314	1100 1100	Grave I	
205	CD	315	1100 1101	Acute I	
206	CE	316	1100 1110	Circumflex I	
207	CF	317	1100 1111	Umlaut I	
208	D0	320	1101 0000		
209	D1	321	1101 0001	Circumflex N	
210	D2	322	1101 0010	Grave O	
211	D3	323	1101 0011	Acute O	
212	D4	324	1101 0100	Circumflex O	
213	D5	325	1101 0101	Circumflex O	
214	D6	326	1101 0110	Umlaut O	
215	D7	327	1101 0111	Box	
216	D8	330	1101 1000	Slashed zero (0)	
217	D9	331	1101 1001	Grave U	
218	DA	332	1101 1010	Acute U	
219	DB	333	1101 1011	Circumflex u	
220	DC	334	1101 1100	Umlaut U	
221	DD	335	1101 1101	Acute Y	
222	DE	336	1101 1110		
223	DF	337	1101 1111	Beta	
224	E0	340	1110 0000	Grave a	
225	E1	341	1110 0001	Acute a	
226	E2	342	1110 0010	Circumflex a	
227	E3	343	1110 0011	Circumflex a	
228	E4	344	1110 0100	Umlaut a	
229	E5	345	1110 0101	a	
230	E6	346	1110 0110	Diphthong ae	
231	E7	347	1110 0111	c cedilla	
232	E8	350	1110 1000	Grave e	
233	E9	351	1110 1001	Acute e	
234	EA	352	1110 1010	Circumflex e	
235	EB	353	1110 1011	Umlaut e	
236	EC	354	1110 1100	Grave i	
237	ED	355	1110 1101	Acute i	
238	EE	356	1110 1110	Circumflex i	
239	EF	357	1110 1111	Umlaut i	
240	F0	360	1111 0000		
241	F1	361	1111 0001	Circumflex n	
242	F2	362	1111 0010	Grave o	
243	F3	363	1111 0011	Acute o	
244	F4	364	1111 0100	Circumflex o	
245	F5	365	1111 0101	Circumflex o	
246	F6	366	1111 0110	Umlaut o	
247	F7	367	1111 0111	Box	
248	F8	370	1111 1000	Slashed zero (0)	
249	F9	371	1111 1001	Grave u	
250	FA	372	1111 1010	Acute u	
251	FB	373	1111 1011	Circumflex u	
252	FC	374	1111 1100	Umlaut U	
253	FD	375	1111 1101	Acute y	
254	FE	376	1111 1110		
255	FF	377	1111 1111	Umlaut y	

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 121

**See Also:** 1.21. ASCII Character Set  
1.22. IBM ASCII Character Set

## 6.10. WINDOWS EXE FILE FORMAT

**The Overall Layout of the File Looks Like This:**

Offset	Size	Function
0 (0)	32 bytes	Old-style EXE header info
20 (32)	29 bytes	RESERVED
3C (60)	4 bytes	New-style offset
40 (64)	Varies	Relocation table for DOS stub program
varies	Varies	New-style EXE information

**The Layout of the New-Style EXE Information Section Looks Like This:**

Offset	Size	Function	Allowable Values
0 (0)	Word	Signature word	"EN"
2 (2)	Byte	Version number of linker	
3 (3)	Byte	Revision number of linker	
4 (4)	Word	Offset of entry table	(Relative to beginning of this section of header)
6 (6)	Word	Number of bytes in entry table	
8 (8)	Dbl word	32-bit CRC of entire file	
C (12)	Word	Keyword	0000H = NOAUTODATA 0001H = SINGLEDATA (solo) 0002H = MULTIPLEDATA (instance) 2000H = Errors detected at link time 8000H = Library module
E (14)	Word	Segment # of automatic data segment	
10 (16)	Word	Initial size of dynamic heap added to DS	(In bytes) 0=no local allocation
12 (18)	Word	Initial size of stack added to DS	(In bytes) 0=SS does not equal DS
14 (20)	Dbl word	CS:IP	
18 (24)	Dbl word	SS:SP	
1C (28)	Word	# entries in segment table	
1E (30)	Word	# bytes in nonresident-name table	
20 (32)	Word	Offset of segment table	(Relative to beginning of this section of header)
22 (34)	Word	Offset of resource table	(Relative to beginning of this section of header)
24 (36)	Word	Offset of resident-name table	(Relative to beginning of this section of header)
26 (38)	Word	Offset of module-reference table	(Relative to beginning of this section of header)
28 (40)	Word	Offset of imported-names table	(Relative to beginning of this section of header)
2A (42)	Dbl word	Offset of nonresident-name table	(Relative to beginning of file)
2E (46)	Word	# of movable entry points	
30 (48)	Word	Shift count of logical sector alignment	(Log [base 2] of the segment sector size)
32 (50)	Word	# of reserved segments	
34 (52)	10 bytes	RESERVED	Must be 0

**Version Info:** Applies to Windows 2.0 and Windows 386

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 645 to 648

**See Also:** 2.42. EXE File Header  
2.43. COM Program Layout

## 6.11. TAG IMAGE FILE FORMAT (TIFF)

**Header and Directory Format:**

Offset	Size	Description	Field Size	Field Description	Comments
0 (0)	8 bytes	Header	Word Word Dbl word	Byte order Version Pointer to first IFD	4949H=least to most; 4D4DH=most to least 2AH (version 42)
A (10)	Varies	Image file directory	Word 12 bytes 12 bytes each Dbl word	Number of directory entries First directory entry Additional directory entries Pointer to next IFD	Must begin on word boundary See below for format
Varies	Varies	Values (tags)			See table below

**Directory Entry Format (in Image File Directory):**

Offset	Size	Description	Allowable Values, Comments
0 (0)	Word	Tag	See Tag table, below
2 (2)	Word	Type	1=bytes 2=ASCII string 3=short (16-bit unsigned integers) 4=long (32-bit unsigned integers) 5=rational (2 longs: first is numerator, second is denominator)
4 (4)	Word	Length	Specified in terms of the data type (1 short=2 bytes)
8 (8)	Dbl word	Pointer to value	If value fits in four bytes or less, it is stored here

(Continued)

Table 6.11. Continued

**Tags:**

Tag	Type	Name	Allowable Values, Comments
FF (255)	Short	Subfile type	1=full resolution image data (requires image width, image length, strip offset) 2=reduced resolution data (requires image width, image length, strip offset)
100 (256)	Short	Image width	Width of image, in pixels
101 (257)	Short	Image length	Length of image, in pixels (rows)
102 (258)	Short	Bits per sample	(default=1)
103 (259)	Short	Compression	1=no compression, but tightly packed (default) 2=CCITT Group 3 compression 3=1-dimensional modified Huffman run length encoding
106 (262)	Short	Photometric interp.	0=min sample value is white, max sample value is black, all other grey 1=min sample value is black, max sample value is white, all other grey 2=RGB; min and max sample values control intensity (planar configuration affects stored order) 3=hue, saturation, brightness
107 (263)	Short	Thresholding	1=bilevel 'line art' scan (default) 2='halftone' or 'dithered' scan (bits per sample must be 1)
108 (264)	Short	Cell width	If thresholding=2, this is width of dithering matrix in 1-bit samples
109 (265)	Short	Cell length	If thresholding=2, this is length of dithering matrix in 1-bit samples
10A (266)	Short	Order of data values	1=most significant bits of byte filled first (default) 2=least significant bits of byte filled first
10D (269)	ASCIIZ	Name of document	
10E (270)	ASCIIZ	Image description	
10F (271)	ASCIIZ	Maker of scanner	
110 (272)	ASCIIZ	Model # of scanner	
111 (273)	Long	Strip offset	For each strip, the byte offset of that strip
112 (274)	Short	Orientation	1=first row at top, first column at left (default) 2=first row at top, first column at right 3=first row at bottom, first column at right 4=first row at bottom, first column at left 5=first row at left, first column at top 6=first row at right, first column at top 7=first row at right, first column at bottom 8=first row at left, first column at bottom
115 (277)	Short	Samples per pixel	1=monochrome (default) 3=color (other values allowed)
116 (278)	Long	Rows per strip	Number of rows per data strip (default=2**32-1)
117 (279)	Long	Strip byte counts	For each strip, the number of bytes it contains
118 (280)	Short	Min sample value	(Default=0)
119 (281)	Short	Max sample value	(Default= 2**(bitspersample)-1)
11A (282)	Rational	Width resolution	Number of pixels per inch
11B (283)	Rational	Length resolution	Number of pixels per inch
11C (284)	Short	Planar configuration	1=samples stored contiguously; single image plane 2=samples stored in separate sample planes
11D (285)	ASCIIZ	Name of page	
11E (286)	Rational	X position	Offset to left side of image on page, in inches
11F (287)	Rational	Y position	Offset to top side of image on page, in inches
120 (288)	Long	Free offsets	For each 'free' block in file, pointer to it, in bytes
121 (289)	Long	Free byte count	For each 'free' block in file, number of bytes in block

**Notes:** •Tags with a value of 8000H (32768) or higher are reserved for user-defined information  
•The entries for image file directories must be sorted in ascending order by value of the tag

**Source:** Tag Image File Format Draft (22 October 86), pages 2 to 13

**See Also:** 6.13. Windows Paint File Format

## 6.12. DYNAMIC DATA EXCHANGE PROTOCOL

Message Type	Purpose	Parameters	
WM_DDE_INITIATE	Request start of conversation	sparam = not used lparam = aDDEServerID (atom specifying application class name) aDDETopicID (atom specifying desired topic)	LO HO
WM_DDE_TERMINATE	End conversation	None	
WM_DDE_ACK	Acceptance of prev. message	sparam = not used For WM_DDE_INITIATE: lparam = aDDEID (atom specifying data item or topic involved) wStatus (high bit set specifies acceptance) For WM_DDE_EXECUTE: lparam = hCommands (handle to data item containing commands) wStatus (high bit set specifies acceptance)	HO LO HO LO
WM_DDE_REQUEST	Request for data item	lparam = aDataID (atom identifying data item) cfFormat (valid clipboard format)	HO LO
WM_DDE_DATA	Publication of data	lparam = aDDEID (atom specifying data item) hDDEData (handle to shared memory containing data)*	HO LO
WM_DDE_POKE	Place data at destination	lparam = aDataID (destination for data item) hDDEData (handle to shared memory containing data)*	HO LO
WM_DDE_ADVISE	Request for data	lparam = aDDEID (atom specifying data item) hOptions (handle to shared memory object)**	HO LO
WM_DDE_UNADVISE	Cancel request for data	lparam = aDDEID (atom specifying data item no longer needed) (null atom cancels all requests)	HO LO
WM_DD_EXECUTE	Request to process commands	lparam = hCommands (handle to shared memory containing command string [as if typed from keyboard])	HO LO

**Notes:**

\*Data items are stored in shared memory in this format:  
 Word fACKRequired bit 15 set to 1 requires acknowledgement  
       fClientRelease bit 13 set to 1 client should free data object after examining  
 Word wFormat clipboard type of data object  
 Varies Data in clipboard format

\*\*Options are stored in a shared memory object in this format:  
 Word fACKRequired bit 15 set to 1 requires acknowledgement  
       fNoData bit 14 set to 1 indicates server should send null hDDEData 'alarms'  
 Word wFormat clipboard data type preferred by client

**Source:**

DDE-Protocol Definition (15 Oct 86) pages 1-8 to 8-8.  
*Microsoft Systems Journal*,  
 2 (5), page 16

## 6.13. WINDOWS PAINT FILE FORMAT

Offset	Length	Usual Contents	Description
0 (0)	Word	6144H	Key#1 (version of paint program used to create file)
2 (2)	Word	4D6EH	Key#2 (version of paint program used to create file)
4 (4)	Word		Width of bitmap (in pixels)
6 (6)	Word		Height of bitmap (in pixels)
8 (8)	Word		X aspect ratio of bitmap
A (10)	Word		Y aspect ratio of bitmap
C (12)	Word		X aspect ratio of printer at creation time
E (14)	Word		Y aspect ratio of printer at creation time
10 (16)	Word		Width of printer in pixels
12 (18)	Word		Height of printer in pixels
14 (20)	Word		Used for checksum calculations
16 (22)	Word		Used for checksum calculations
18 (24)	Word		Checksum of header
1A (26)	Word		RESERVED
1C (28)	Word		RESERVED
1E (30)	Word		RESERVED
20 (32)	Varies		Bitmap

**Notes:**

\*A paint file (version 1.01) consists of a 32-byte header, as described above, followed by bitmap organized as scan lines. The total size of the bitmap will be =WidthOfBitmap x HeightOfBitmap/8.  
 \*The third through tenth fields in the header are determined by calling GetDeviceCaps().  
 \*Paint files in Windows 2.03 use a different format

**Source:**

Unpublished document from Microsoft University Windows Seminar

**See Also:**

6.15. Clipboard Formats  
 6.52. METAFILEPICT Structure Format

## 6.14. FONT FILE FORMAT (VERSION 1)

Field	Size	Description	Allowable Values
dfVersion	Word	Version of the file	Currently must be 100 (256)
dfSize	Dbl word	Total file size (in bytes)	Unsigned 32-bit integer
dfCopyright	60 bytes	Copyright information	ASCIIZ string
dfType	Word	Font file type	LObit0=0 (raster type file) LObit0=1 (vector type file) LObit3=1 (bitmap in memory) HO=0 (GDI realized standard font)
dfPoints	Word	Nominal point size for best look	
dfVertRes	Word	Nominal vert resolution dots per inch	Size at which font was digitized
dfHorizRes	Word	Nominal horiz resolution dots per inch	Size at which font was digitized
dfAscent	Word	Dist from top of char to baseline	
dfInternalLeading	Word	Area inside dfPixHeight for accent marks	
dfExternalLeading	Word	Extra leading requested between rows	
dfItalic	Byte	Is font an italic font?	0=no, 1=yes
dfUnderline	Byte	Is font underlined?	0=no, 1=yes
dfStrikeOut	Byte	Is font over stricken?	0=no, 1=yes
dfWeight	Word	Weight of character	Value 1-1000 (200 is normal)
dfCharSet	Byte	Character set used	FF (255) = IBM PC char set
dfPixWidth	Word	Width of grid for vector fonts Width of all chars for raster fonts	Size at which font was digitized 0=variable width
dfPixHeight	Word	Height of grid for vector fonts Height of the char bitmap for raster fonts	Size at which font was digitized
dfPitchAndFamily	Byte	Pitch and family of font	LObit=1 (variable pitch) LObit=0 (fixed pitch) HO4bits=0000 (FF_DONTCARE) HO4bits=0001 (FF_ROMAN) HO4bits=0010 (FF_SWISS) HO4bits=0011 (FF_MODERN) HO4bits=0100 (FF_SCRIPT) HO4bits=0101 (FF_DECORATIVE)
dfAvgWidth	Word	Average width of chars in font	Usually 'X'
dfMaxWidth	Word	Maximum pixel width of any char in font	
dfFirstChar	Byte	Character code of first char defined	
dfLastChar	Byte	Character code of last char defined	
dfDefaultChar	Byte	Character to substitute for missing chars	
dfBreakChar	Byte	Character used to define word breaks	
dfWidthBytes	Word	# bytes in each row of bitmap	(Raster fonts only)
dfDevice	Dbl word	Offset in file to device name string	0=generic device
dfFace	Dbl word	Offset in file to face name string	
dfBitsPointer	Dbl word	Absolute address of bitmap	(Set by GDI at load time)
dfBitsOffset	Dbl word	Offset in file to beginning of bitmap	
dfCharOffset	Word each	Offset in bitmap rows to each char in set	For variable spaced raster fonts
	0 bytes	Not used	For fixed spaced raster fonts
	Word each	Offset in bitmap to string for each char in set	For fixed spaced vector fonts
	Word	Offset in bitmap to char strokes for each char	For variable spaced vector fonts
	Word	Pixel width of the character	
(facename)	String	Name of typeface	ASCIIZ string
(devicename)	String	Name of device font was designed for	ASCIIZ string
(bitmap)	Bytes	Bitmap containing font data	Each row must start on word boundary

Source: Microsoft Windows SDK Programmer's Reference 2.0, pages 639 to 645

## 6.15. CLIPBOARD FORMATS

Format Name	Description
CF_BITMAP	Bitmap
CF_DIF	Data interchange format
CF_DSPBITMAP	Bitmap display associated with a private format
CF_DSPMETAFILEPICT	Metafile picture display associated with a private format
CF_DSPTEXT	Text display associated with a private format
CF_METAFILEPICT	Metafile picture structure (See 6.52. METAFILEPICT Structure Format)
CF_OWNERDISPLAY	Owner display format (clipboard owner must display and update clipboard)
CF_PRIVATEFIRST	Private format begin with this value
CF_SYLK	Microsoft SYLK data interchange format
CF_TEXT	Null-terminated text (ASCIIZ string)

Source: Microsoft Windows SDK Programmer's Reference 2.0, page 423

See Also: 1.17. Common String Formats  
6.16. MetaFile Format

6.16. METAFILE FORMAT

**MetaFile Header:**

Field	Size	Description	Allowable Values
mtType	Dbl word	Location indicator	
mtHeaderSize	Dbl word	Header size	
mtVersion	Dbl word	Version number	
mtSize	Dbl word	Size	Size of the MetaFile in words
mtNoObjects	Dbl word	Total number of objects	
mtMaxRecord	Dbl word	Size of largest record	
mtNoParameters	Dbl word	Number of parameters	Field not currently used

**MetaFile GDI Function Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this Record	Size in words
rdFunction	Dbl word	Magic Number of Function	0817H Arc 0418H Ellipse 0415H ExcludeClipRect 0419H FloodFill 0416H IntersectClipRect 0213H LineTo 0214H MoveTo 0220H OffsetClipRgn 0211H OffsetViewportOrg 020FH OffsetWindowOrg 061DH PatBit 081AH Pie 041BH Rectangle 0127H RestoreDC 061CH RoundRect 001EH SaveDC 0201H SetBkColor 0102H SetBkMode 0103H SetMapMode 041FH SetPixel 0106H SetPolyFillMode 0105H SetRelAbs 0104H SetROP2 0107H SetStretchBitMode 0108H SetTextCharExtra 0209H SetTextColor 020AH SetTextJustification 020CH SetWindowExt 020BH SetWindowOrg 020EH SetViewportExt 020DH SetViewportOrg
rdParm.#	Var. words	Parameter(s) for function	Variable number of words, each containing a parameter

**MetaFile Object-Creation Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size in bytes
rdFunction	Dbl word	Object creation ID	012DH
Index	Varies	Index into table to location of object	

**MetaFile CreatePen Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	5 (size in words)
rdFunction	Dbl word	CreatePen ID	0230H
rdParm		LOGPEN structure	See 6.50. LOGPEN Structure Format

**MetaFile CreateFont Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	28 (size in words)
rdFunction	Dbl word	CreateFont ID	0231H
rdParm		LOGFONT structure	See 6.49. LOGFONT Structure Format

**MetaFile CreateBrush Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	7 (size in words)
rdFunction	Dbl word	CreateBrush ID	0232H
rdParm		LOGBRUSH structure	See 6.48. LOGBRUSH Structure Format

(Continued)

Table 6.16. Continued

**MetaFile CreatePatternBrush Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	CreatePatternBrush ID	012FH
rdParm	Varies	Bitmap	Bitmap consists of: bitmap header, 9 unused words, then bmType           Bitmap type bmWidth         Bitmap width bmHeight        Bitmap height bmWidthBytes    Bytes per raster line bmPlanes        Number of color planes bmBitsPixel     Number adjacent color bits per pixel bmBits          Pointer to bit values bits             Actual bits of pattern

**MetaFile CreateRegion Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	CreateRegion ID	0635H
rdParm		Region	

**MetaFile TextOut Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	TextOut ID	0521H
rdParm	Varies	TextOut info	TextOut info consists of: count           Length of string flstring        The string flylocation     The y value of string's starting point flxlocation     The x value of string's starting point

**MetaFile Polygon Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	Polygon ID	0324H
rdParm	Varies	Polygon info	Polygon info consists of: count           Number of points in polygon ptlist          A list of the individual points

**MetaFile Polyline Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	Polyline ID	0325H
rdParm	Varies	Polyline info	Polyline info consists of: count           Number of points in polygon ptlist          A list of the individual points

**MetaFile Escape Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	Escape ID	0626H
rdParm	Varies	Escape info	Escape info consists of: escape#         Number of escape count          Number of bytes of escape data escapedata

**MetaFile InvertRegion Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	InvertRegion ID	012AH
rdParm		Region	Index to region in metafile table

**MetaFile PaintRegion Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	PaintRegion ID	012BH
rdParm		Region	Index to region in metafile table

(Continued)

Table 6.16. Continued

**MetaFile FillRegion Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	FillRegion ID	0228H
rdParm		Region	Index to region in metafile table

**MetaFile FrameRegion Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	FrameRegion ID	0429H
rdParm		Region	Index to region in metafile table

**MetaFile BitBlt Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	BitBlt ID	0922H
rdParm	Varies	BitBlt info	BitBlt info consists of: raster op      LO word, HO word of raster operation SY                The y coordinate of source origin SX                The x coordinate of source origin DYE               The destination y extent DXE               The destination x extent DY                The y coordinate of the dest origin DX                The x coordinate of the dest origin bmWidth        The width of the bitmap, in pixels bmHeight        The height of the bitmap, in raster lines bmWidthBytes   The number of bytes per raster line bmPlanes        The number of color planes per raster line bmBitsPixel    The number of adjacent color bits/pixel bits              The actual bitmap

**MetaFile StretchBlt Records:**

Field	Size	Description	Allowable Values
rdSize	Dbl word	Size of this record	Size of this record in words
rdFunction	Dbl word	StretchBlt ID	0B23H
rdParm	Varies	StretchBlt info	StretchBlt info consists of: raster op      LO word, HO word of raster operation SYE              The source y extent SXE              The source x extent SY                The y coordinate of source origin SX                The x coordinate of source origin DYE               The destination y extent DXE               The destination x extent DY                The y coordinate of the dest origin DX                The x coordinate of the dest origin bmWidth        The width of the bitmap, in pixels bmHeight        The height of the bitmap, in raster lines bmWidthBytes   The number of bytes per raster line bmPlanes        The number of color planes per raster line bmBitsPixel    The number of adjacent color bits/pixel bits              The actual bitmap

- Notes:**
- The actual MetaFile format is comprised of:
    - A MetaFile header
    - A variable number of MetaFile GDI or other function records
    - A table of any objects referenced by function records

- Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 127 to 129  
Microsoft Windows Beta2 Documentation 2.0, pages 646 to 655

- See Also:**
- 6.48. LOGBRUSH Structure Format
  - 6.49. LOGFONT Structure Format
  - 6.50. LOGPEN Structure Format
  - 6.79. Binary Raster Operation Codes (ROP2)

6.17. RESOURCE SCRIPT FILE DIRECTIVES

Directive	Function	Syntax	Comments
#include	Copies contents of file into resource script	#include filename	Filename is a string (e.g., "windows.h")
#define	Assigns a value to a name	#define name value	Name=letters,digits,punc.;value=int,char,string
#undef	Removes definition assigned to name	#undef name	Name=letters,digits,punctuation
#ifdef	Compiles up to #endif if name is defined	#ifdef name STATEMENT(S)	See #endif (see example 1, below)
#ifndef	Compiles up to #endif if name not defined	#ifndef name STATEMENT(S)	See #endif (see example 1, below)
#if	Compiles up to #endif if constant is non-zero	#if constant STATEMENT(S)	See #endif
#elif	Compiles block within #if- if constant is non-zero	#elif constant STATEMENT(S)	Used within #if,#ifndef, & #ifdef (see example 2)
#else	Optional clause within #if- construct	#else STATEMENT(S)	Used within #if,#ifndef, & #ifdef (see example 3)
#endif	Ends conditional compilation	#endif	Ends #if, #ifndef, #ifdef compilation

**Example 1:** #ifdef Debug  
 errbox BITMAP errbox.bmp  
 #endif

**Example 2:** #if Version<3  
 errbox BITMAP errbox.bmp  
 #elif Version<7  
 errbox BITMAP userbox.bmp  
 #endif

**Example 3:** #ifdef Debug  
 errbox BITMAP errbox.bmp  
 #else  
 errbox BITMAP userbox.bmp  
 #endif

**Source:** Microsoft Windows SDK Programming Tools 2.0, pages 25 to 27

**See Also:** 6.18. Single-line Resource Statements (ICON, CURSOR, BITMAP, FONT)  
 6.19. Menu Resource Script Definitions  
 6.20. Dialog Resource Script Definitions  
 6.21. Dialog Box Control Definitions  
 6.22. Accelerator Resource Script Definitions  
 6.24. STRINGTABLE Resource Script Definitions

6.18. SINGLE-LINE RESOURCE STATEMENTS (ICON, CURSOR, BITMAP, FONT)

**General Single Statement Resource Script Format:**

nameID resourcetype [loadoption] [memoryoption] filespec

Item	Description	Allowable Values
nameID	Name or number used to identify resource	For FONT resource, must be an integer number
resourcetype	Type of resource being defined	One of: CURSOR ICON BITMAP FONT
loadoption	When the resource should be loaded	One of: PRELOAD (loaded immediately) LOADONCALL (loaded only when called)default
memoryoption	How resource should be handled in memory	One of: FIXED (always remains at fixed location) MOVEABLE (may be moved in memory) DISCARDABLE (may be discarded from memory)
filespec	Name and extension of file containing resource	ASCII string, which may contain path name

**Source:** Microsoft Windows SDK Programming Tools 2.0, pages 30 to 31

**See Also:** 6.17. Resource Script File Directives  
 6.19. Menu Resource Script Definitions  
 6.20. Dialog Resource Script Definitions  
 6.21. Dialog Box Control Definitions  
 6.22. Accelerator Resource Script Definitions  
 6.24. STRINGTABLE Resource Script Definitions

**6.19. MENU RESOURCE SCRIPT DEFINITIONS**

**General MENU Resource Script Format:**

```
menuID MENU [load-option] [mem-option]
BEGIN
menuitems
END
```

Item	Description	Allowable Values
menuID	Name or number used to identify the menu resource	
load-option	Specifies when the resource is to be loaded	PRELOAD (resource loaded immediately) LOADONCALL (default: resource loaded when called)
mem-option	Determines how resource is treated in memory	FIXED (remains in fixed location) MOVEABLE (may be moved to compact memory) DISCARDABLE (may be discarded when not needed)

**Allowable Menuitems:**

MenuItem Name	Syntax	Description
MENUITEM	MENUITEM text, result, optionlist1	Defines a menu item
POPUP	POPUP text, optionlist2 BEGIN definitions END	Defines a popup menu definition
MENUITEM SEPARATOR	MENUITEM SEPARATOR	Special 'dividing' menu item, usually a horiz. bar

- optionlist1:**
  - MENUBREAK      Item is immediately preceded by a new line
  - CHECKED          Item has a checkmark next to it
  - INACTIVE        Item is displayed, but cannot be selected
  - GRAYED          Item is inactive and displayed 'grayed' (disabled)
- optionlist2:**
  - MENUBREAK      Item is placed in new column
  - CHECKED          Item has a checkmark next to it
  - INACTIVE        Item is displayed, but cannot be selected
  - GRAYED          Item is inactive and displayed 'grayed' (disabled)
  - MENUBARBREAK   Item is placed in new column separated by vert. bar

**text:** ASCII string (in quotes)

**result:** Integer number of result to return when user selects item

**Source:** Microsoft Windows SDK Programming Tools 2.0, pages 36 to 40

**See Also:** 6.17. Resource Script File Directives  
 6.18. Single-line Resource Statements  
 6.21. Dialog Box Control Definitions  
 6.22. Accelerator Resource Script Definitions  
 6.24. STRINGTABLE Resource Script Definitions

**6.20. DIALOG RESOURCE SCRIPT DEFINITIONS**

**General DIALOG Resource Script Format:**

```
nameID DIALOG [loadoption] [memoryoption] x,y,width,height
optionstatements
BEGIN
controlstatements
END
```

Item	Description	Allowable Values
nameID	Name or number used to identify the dialog	
loadoption	Specifies when the resource is to be loaded	PRELOAD (resource loaded immediately) LOADONCALL (default: resource loaded when called)
memoryoption	Determines how resource is treated in memory	FIXED (remains in fixed location) MOVEABLE (may be moved to compact memory) DISCARDABLE (may be discarded when not needed)
optionstatements	Define special attributes of dialog box	STYLE (defines style of dialog box) CAPTION text (defines dialog box's title) MENU name (defines dialog box's menu) CLASS class (defines dialog box's class)
controlstatements	Define attributes of controls within dialog box	See 6.21. Dialog Box Control Definitions

**Notes:** Default STYLE is:  
 WS\_POPUP  
 WS\_BORDER  
 WS\_SYSTEMMENU

**Source:** Microsoft Windows SDK Programming Tools 2.0, pages 40 to 46

**See Also:** 6.21. Dialog Box Control Definitions

6.21. DIALOG BOX CONTROL DEFINITIONS

Resource Script Format:

general form: CONTROLNAME text, id, xposition, yposition, width, height, [style]

Control Name	Class	Appears As	Syntax	Default Style
LTEXT	Static	Left-justified text	LTEXT text, id, x, y, w, h, [style]	ES_LEFT, WS_GROUP
RTEXT	Static	Right-justified text	RTEXT text, id, x, y, w, h, [style]	ES_RIGHT, WS_GROUP
CTEXT	Static	Centered text	CTEXT text, id, x, y, w, h, [style]	ES_CENTER, WS_GROUP
CHECKBOX	Button	Check box with text	CHECKBOX text, id, x, y, w, h, [style]	BS_CHECKBOX, WS_TABSTOP
PUSHBUTTON	Button	Push button with text	PUSHBUTTON text, id, x, y, w, h, [style]	BS_PUSHBUTTON, WS_TABSTOP
LISTBOX	List box	Boxed list of strings	LISTBOX id, x, y, w, h, [style]	LBS_NOTIFY, LBS_SORT, WS_VSCROLL, WS_BORDER
GROUPBOX	Button	Group of buttons	GROUPBOX text, id, x, y, w, h, [style]	BS_GROUPBOX, WS_TABSTOP
DEFPUSHBUTTON	Button	Default push button	DEFPUSHBUTTON text, id, x, y, w, h, [style]	BS_DEFPUSHBUTTON, WS_TABSTOP
RADIOBUTTON	Button	Radio button with text	RADIOBUTTON text, id, x, y, w, h, [style]	BS_RADIOBUTTON, WS_TABSTOP
EDITTEXT	Edit	Boxed text	EDITTEXT id, x, y, w, h, [style]	WS_TABSTOP, ES_LEFT, WS_BORDER
ICON	Static	Icon	ICON iconname, id, x, y, 0, [style]	SS_ICON
CONTROL	Varies	User-defined window	CONTROL text, id, class, style, x, y, w, h	none

Control Styles:

Style Name	Class	Description
BS_PUSHBUTTON	Button	Same as PUSHBUTTON
BS_DEFPUSHBUTTON	Button	Same as DEFPUSHBUTTON
BS_CHECKBOX	Button	Same as CHECKBOX
BS_AUTOCHECKBOX	Button	Button automatically toggles state when user clicks on it
BS_AUTORADIOBUTTON*	Button	Button checked, application notified, all other radio buttons in group unchecked
BS_PUSHBOX*	Button	Same as PUSHBUTTON, but no border drawn
BS_LEFTTEXT*	Button	Causes text to appear to left of button, [used with CHECKBOX, 3STATE, or RADIOBUTTON]
BS_RADIOBUTTON	Button	Same as RADIOBUTTON
BS_3STATE	Button	Same as BS_CHECKBOX except button can be 'grayed'
BS_AUTO3STATE	Button	Same as BS_3STATE except that button automatically toggles state when user clicks on it
BS_GROUPBOX	Button	Same as GROUPBOX
BS_USERBUTTON	Button	User-defined button; parent notified when clicked
ES_LEFT	Edit	Left-justified text
ES_RIGHT	Edit	Right-justified text
ES_CENTER	Edit	Centered text
ES_MULTILINE	Edit	Multiline edit control
ES_AUTOVSCROLL	Edit	Text scrolled up one 'page' when user presses CR on last line
ES_AUTOHSCROLL	Edit	Text scrolled 10 chars right at end of line, to 0 when CR pressed
ES_NOHIDESEL	Edit	Overrides hiding and inverting of text as focus moves to and from text
SS_LEFT	Static	Same as LTEXT
SS_RIGHT	Static	Same as RTEXT
SS_CENTER	Static	Same as CTEXT
SS_ICON	Static	Same as ICON
SS_BLACKRECT	Static	Black filled rectangle
SS_GRAYRECT	Static	Gray filled rectangle
SS_WHITERECT	Static	White filled rectangle
SS_BLACKFRAME	Static	Box with black frame
SS_GRAYFRAME	Static	Box with gray frame
SS_WHITEFRAME	Static	Box with white frame
SS_USERITEM	Static	User-defined static item
LBS_NOTIFY	Listbox	Parent receives message when user clicks or double-clicks string

(Continued)

Table 6.21. Continued

Control Styles:	Style Name	Class	Description
	LBS_MULTIPLESEL	Listbox	String selection toggled when user clicks or double clicks
	LBS_SORT	Listbox	Strings are listed in box alphabetically
	LBS_NOREDRAW	Listbox	List box display not updated when changes are made
	SBS_VERT	Scrollbar	Vertical scroll bar
	SBS_RIGHTALIGN	Scrollbar	Used with SBS_VERT, right edge is right edge of rectangle
	SBS_LEFTALIGN	Scrollbar	Used with SBS_VERT, left edge is left edge of rectangle
	SBS_HORZ	Scrollbar	Horizontal scroll bar
	SBS_TOPALIGN	Scrollbar	Used with SBS_HORZ, top edge is top edge of rectangle
	SBS_BOTTOMALIGN	Scrollbar	Used with SBS_HORZ, bottom edge is bottom edge of rectangle
	SBS_SIZEBOX	Scrollbar	Size box
	SBS_SIZEBOXTOPLEFTALIGN	Scrollbar	Used with SBS_SIZEBOX, aligns sizebox to top left corner of rectangle
	SBS_SIZEBOXBOTTOMRIGHTALIGN	Scrollbar	Used with SBS_SIZEBOX, aligns sizebox to bottom right corner of rectangle
	WS_GROUP	All	First control of group in which user may move using cursor keys
	WS_Toplevel*	All	Creates top-level window
	WS_POPUP*	All	Creates pop-up window (cannot be used with WS_CHILD)
	WS_CHILD*	All	Creates child window (cannot be used with WS_POPUP)
	WS_ICONIC*	All	Creates window that is initially iconic (use with WS_Toplevel only)
	WS_IconicPopup*	All	Creates iconic pop-up window
	WS_MAXIMIZE*	All	Creates window of maximum size
	WS_BORDER*	All	Creates window that has a border
	WS_CAPTION*	All	Creates window that has a title bar (implies WS_BORDER)
	WS_DlgFrame*	All	Creates window with a double border but no title
	WS_SYSMENU*	All	Creates window that has a system menu box in its title bar
	WS_SIZEBOX*	All	Creates window that has a size box (must have title bar or scroll bars)
	WS_VSCROLL*	All	Creates window with vertical scroll bar
	WS_HSCROLL*	All	Creates window with horizontal scroll bar
	WS_CLIPCHILDREN*	All	Excludes the area occupied by child window when drawing parent window
	WS_CLIPSIBLINGS*	All	Clips child windows relative to each other
	WS_VISIBLE*	All	Creates window that is initially visible (applies to toplevel and popup windows)
	WS_DISABLED*	All	Creates window that is initially disabled
	WS_ToplevelWindow*	All	Creates window with WS_Toplevel, WS_Caption, WS_SystemMenu, WS_SizeBox
	WS_PopupWindow*	All	Creates window with WS_Popup, WS_Border, WS_SystemMenu
	WS_ChildWindow*	All	Creates child window
	WS_TabStop	All	Control in which user may move using Tab key
	WS_Overlapped	All	Creates overlapping window
	WS_OverlappedWindow	All	Creates overlapped window having the styles WS_Overlapped, WS_Caption, WS_SystemMenu, and WS_SizeBox
	WS_Minimize	All	Creates window of minimum size
	WS_MinimizeBox	All	Creates window that has a Minimize box
	WS_MaximizeBox	All	Creates window that has a Maximize box

**Version Info:** \*First defined in Windows 2.0

**Source:** Microsoft Windows SDK Programming Tools 2.0, pages 44 to 65.

**See Also:**

- 6.17. Resource Script File Directives
- 6.18. Single-line Resource Statements
- 6.19. Menu Resource Script Definitions
- 6.22. Accelerator Resource Script Definitions
- 6.24. STRINGTABLE Resource Script Definitions

**6.22. ACCELERATOR RESOURCE SCRIPT DEFINITIONS****General ACCELERATOR Resource Script Format:**

tablename ACCELERATORS

BEGIN

event, idvalue [,type][,NOINVERT][,SHIFT][,CONTROL]

END

Item	Description	Allowable Values
tablename	Name of the accelerator table	
event	Keystroke to be used as accelerator	"char" or "a:char" (single character, control char) ASCII character code Virtual key character
idvalue	ID of accelerator keystroke	Integer value
type	Defines keytype of accelerator	Not used if using quoted chars (e.g., "AC") ASCII (if ASCII character code) VIRTKEY (if Virtual key character)
NOINVERT	Defines whether top-level menu is highlighted on key	If omitted, top-level menu is highlighted If included, top-level menu is not highlighted
SHIFT	Defines if accelerator requires shift key down	If omitted, shift key need not be down If included, shift key must be down
CONTROL	Defines if accelerator requires control key down	If omitted, control key shouldn't be down If included, control key must also be down

**Notes:** More than one key may be defined at once by including additional 'event' statements between the BEGIN and END statements

**Source:** Microsoft Windows SDK Programming Tools 2.0, pages 35 to 36

**See Also:** 6.17. Resource Script File Directives  
6.18. Single-line Resource Statements  
6.19. Menu Resource Script Definitions  
6.21. Dialog Box Control Definitions  
6.24. STRINGTABLE Resource Script Definitions

**6.23. COMMON EDIT MENU ACCELERATOR KEY DEFINITIONS**

Key Name	Action Performed in Windows 1	Action Performed in Windows 2
Shift + Escape	Invokes the Edit menu's Undo command	Selects system menu of active window
Alt+Backspace	Not defined	Invokes the Edit menu's Undo command
Delete	Invokes the Edit menu's Cut command	Invokes the Edit menu's Clear command
F2	Invokes the Edit menu's Copy command	Not defined
Insert + Control	Invokes the Edit menu's Paste command	Invokes the Edit menu's Copy command
Shift + Delete	Invokes the Edit menu's Clear command	Invokes the Edit menu's Cut command
Shift + Insert	Not defined	Invokes the Edit menu's Paste command

**Source:** Microsoft Windows SDK Application Style Guide 2.0, page 30

**See Also:** 6.01. Reserved System Keys  
6.02. Recommended Keyboard Actions  
6.22. Accelerator Resource Script Definitions

#### 6.24. STRINGTABLE RESOURCE SCRIPT DEFINITIONS

##### General STRINGTABLE Resource Script Format:

```
STRINGTABLE [loadoption] [memoryoption]
BEGIN
ID string
END
```

Item	Description	Allowable Values
loadoption	Specifies when the resource is to be loaded	PRELOAD (resource loaded immediately) LOADONCALL (default: resource loaded when called)
memoryoption	Determines how resource is treated in memory	FIXED (remains in fixed location) MOVEABLE (may be moved to compact memory) DISCARDABLE (may be discarded when not needed)
ID	Identifier used to name string	Must be an integer value
string	Text comprising string	ASCII string in quotes

**Notes:** Multiple strings may be defined at once by including multiple ID string statements between the BEGIN and END statements

**Source:** Microsoft Windows SDK Programming Tools 2.0, pages 34 to 35

**See Also:** 6.17. Resource Script File Directives  
6.18. Single-line Resource Statements  
6.19. Menu Resource Script Definitions  
6.21. Dialog Box Control Definitions  
6.22. Accelerator Resource Script Definitions

#### 6.25. WIN.INI EXTENSION SETTINGS

##### Section Header: [extensions]

Option	Function	Syntax	Allowable values
Extension setting	Associates extension with application	ext = apname.typ ^ .ext	'ext' is the extension to associate with application

**Source:** Microsoft Windows User's Guide 2.0, page 207

**See Also:** 6.26. WIN.INI Windows Settings  
6.27. WIN.INI Devices Settings  
6.28. WIN.INI Colors Settings  
6.29. WIN.INI PIF Settings  
6.31. WIN.INI Ports Settings  
6.32. WIN.INI International Settings  
6.33. WIN.INI Fonts Settings

#### 6.26. WIN.INI WINDOWS SETTINGS

##### Section Header: [windows]

Option	Function	Syntax	Example
Beep	Defines whether system beeps on errors	Beep=boolean	Beep=yes
BorderWidth	Sets area to display outside window	BorderWidth=integer	BorderWidth=5
CursorBlinkRate	Sets system's cursor blink rate	CursorBlinkRate=milliseconds	CursorBlinkRate=817
Device	Defines default output device	Device=name.drivermodule.portname	Device=PCL/LaserJet.HPPCL.LPT1:
DeviceNotSelectedTimeout	Sets device timeout value	DeviceNotSelectedTimeout=seconds	DeviceNotSelectedTimeout=15
DoubleClickSpeed	Sets system's double click speed	DoubleClickSpeed=milliseconds	DoubleClickSpeed=500
Load	Programs made into icons at startup	Load=list	Load clock notepad
MouseSpeed	Sets mouse acceleration rate	MouseSpeed=integer	MouseSpeed=1
NullPort	Defines null port	NullPort=portname	NullPort=none
Programs	Programs listed by MS-DOS Executive	Programs=list	Programs=com.exe.bat
Run	Programs run at startup	Run=list	Run excel
Spooler	Defines whether spooler is used	Spooler=boolean	Spooler=yes
SwapMouseButton	Allows mouse buttons to be reversed	SwapMouseButton=boolean	SwapMouseButton=no
TransmissionRetryTimeout	Sets timeout value for communications	TransmissionRetryTimeout=seconds	TransmissionRetryTimeout=45
xMouseThreshold	Sets horizontal mouse threshold level	xMouseThreshold=integer	xMouseThreshold=2
yMouseThreshold	Sets vertical mouse threshold level	yMouseThreshold=integer	yMouseThreshold=2

**Notes:** Values in lists may be separated by commas or white space

**Source:** Microsoft Windows User's Guide 2.0, pages 201 to 202

**See Also:** 6.25. WIN.INI Extension Settings  
6.27. WIN.INI Devices Settings  
6.28. WIN.INI Colors Settings  
6.29. WIN.INI PIF Settings  
6.31. WIN.INI Ports Settings  
6.32. WIN.INI International Settings

6.27. WIN.INI DEVICES SETTINGS

**Section Header:** [devices]

Option	Function	Syntax	Allowable values
devicename	Names output devices and their port	devicename=drivername.portname	Portname: See 6.31. WIN.INI Ports Settings

**Notes:**

- Additional port names may be specified (separated by commas)
- If device not connected, 'portname' should be the NullPort device defined in the Ports section

**Source:** Microsoft Windows User's Guide 2.0, page 214

**See Also:**

- 6.25. WIN.INI Extension Settings
- 6.26. WIN.INI Windows Settings
- 6.28. WIN.INI Colors Settings
- 6.29. WIN.INI PIF Settings
- 6.31. WIN.INI Ports Settings
- 6.32. WIN.INI International Settings

6.28. WIN.INI COLORS SETTINGS

**Section Header:** [colors]

Option	Function	Syntax	Allowable values
Component	Defines Windows background colors	Component = redval greenval blueval	Component is one of: ActiveBorder (active window border) ActiveTitle (active caption bar) AppWorkSpace (application work space) Background (icon area, screen back) InactiveTitle (inactive caption bar) InactiveBorder (inactive window border) Menu (menu background) MenuText (menu text) Scrollbar (scroll bars) TitleText (title text) Window (Window client area back) WindowFrame (Title back, frame) WindowText (window text) Color vals: 0 (black) to 255 (white);integer only;

**Notes:** Windows expects a solid color for MenuText, WindowText, Title Text and Window

**Source:** Microsoft Windows User's Guide 2.0, pages 207 to 208

**See Also:**

- 6.25. WIN.INI Extension Settings
- 6.26. WIN.INI Windows Settings
- 6.27. WIN.INI Devices Settings
- 6.29. WIN.INI PIF Settings
- 6.31. WIN.INI Ports Settings
- 6.32. WIN.INI International Settings

6.29. WIN.INI PIF SETTINGS

**Section Header:** [pif]

Option	Function	Syntax	Allowable values
Program Setting*	Sets memory setting for program	pgmname.typ=value	Value=amount of memory in KBytes
SwapDisk	Sets swap area for applications	SwapDisk=value	Value=? (swap to first fixed disk) Value=letter (swap to that letter drive) Value=0 (do not swap)
SwapSize	Sets amount of memory to swap	SwapSize=value	Value=min amt of memory in KBytes or 0 (set swap to first app size)

**Notes:**

- All disk swapping is done to the root directory unless the [environment] section specifies a temporary directory
- Multiple Program Settings may appear in [pif] section

**Source:** Microsoft Windows User's Guide 2.0, pages 208 to 211

**See Also:**

- 6.25. WIN.INI Extension Settings
- 6.26. WIN.INI Windows Settings
- 6.27. WIN.INI Devices Settings
- 6.30. Default PIF Settings
- 6.31. WIN.INI Ports Settings
- 6.32. WIN.INI International Settings
- 6.33. WIN.INI Fonts Settings

**6.30. DEFAULT PIF SETTINGS**

Item	Default Setting
Program title	Ignored
Initial directory	Ignored
Memory required	52KBytes
Memory desired	All available memory
Directly modifies	Screen
Program switch	Prevent program switch
Screen exchange	Text only
Close window on exit	Does not close

**Notes:** These settings are only used if no PIF file exists for the application

**Source:** Microsoft Windows User's Guide 2.0, page 188

**See Also:** 6.29. WIN.INI PIF Settings

**6.31. WIN.INI PORTS SETTINGS**

**Section Header:** [ports]

Option	Function	Syntax	Allowable values
Portname	Defines port settings	Portname:=baud,parity,wordlen,stopbits	Baud: actual baud rate (e.g. 300) Parity: o, e, n (odd, even, none) Wordlen: # of bits (e.g. 8) Stopbits: # of bits (e.g. 2)

**Notes:** 'Portname' must be one of the recognized DOS ports (e.g. COM1). Alternatively, 'portname' may be a filename, in which case output may be sent directly to a file.

**Source:** Microsoft Windows User's Guide 2.0, pages 212 to 213

**See Also:** 6.25. WIN.INI Extension Settings  
6.26. WIN.INI Windows Settings  
6.27. WIN.INI Devices Settings  
6.28. WIN.INI Colors Settings  
6.29. WIN.INI PIF Settings  
6.32. WIN.INI International Settings

**6.32. WIN.INI INTERNATIONAL SETTINGS**

**Section Header:** [intl]

Option	Function	Syntax	Allowable values
Country	Sets country code	iCountry=country code	See 3.144. Country Codes
Date format	Sets format for date	iDate=value	Value of 0=month-day-year Value of 1=day-month-year Value of 2=year-month-day
Currency format	Sets format for currency	iCurrency=value	Value of 0=currency prefix, no space Value of 1=currency suffix, no space Value of 2=currency prefix, 1 space Value of 3=currency suffix, 1 space
Decimal digits	Sets # of decimal digits in currency	iDigits=value	Value=# of significant digits
Time format	Sets format of time	iTime=value	Value of 0=12 hour clock Value of 1=24 hour clock
Leading zeros	Allows for leading zeros in currency	iLzero=value	0=none, 1=use leading zeroes
AM string	Sets trailing string for morning times	s1159=string	
PM string	Sets trailing string for afternoon times	s2359=string	
Currency symbol	Defines currency symbol	sCurrency=string	
Thousands separator	Defines thousands separator symbol	sThousands=string	
Decimal separator	Defines decimal separator symbol	sDecimal=string	
Date separator	Defines date separator symbol	sDate=string	
Time separator	Defines time separator symbol	sTime=string	
List separator	Defines list separator symbol	sList=string	
Preferences menu	Defines if Country Settings appear	dialog=yes	Always set to yes

**Notes:** The US version of Windows does not require the intl section

**See Also:** 6.25. WIN.INI Extension Settings  
6.26. WIN.INI Windows Settings  
6.27. WIN.INI Devices Settings  
6.28. WIN.INI Colors Settings  
6.29. WIN.INI PIF Settings  
6.31. WIN.INI Ports Settings  
6.33. WIN.INI Fonts Settings

**Source:** Microsoft Windows User's Guide 2.0, pages 211 to 212

**6.33. WIN.INI FONTS SETTINGS**

**Section Header:** [fonts]

Option	Function	Syntax	Allowable values
Fontname	Names font files to load at startup	Fontname psize(s) (set #number) =fontfile	Fontname=description font name psize=1 or more point sizes to load Number=set number Fontfile=filename, no extension

**Notes:** Windows 1.xx used the FNT extension for fontfiles, while Windows 2.xx uses the FON extension. The file formats are different.

**Source:** Microsoft Windows User's Guide 2.0, page 214

**See Also:** 6.25. WIN.INI Extension Settings  
6.26. WIN.INI Windows Settings  
6.27. WIN.INI Devices Settings  
6.28. WIN.INI Colors Settings  
6.29. WIN.INI PIF Settings  
6.31. WIN.INI Ports Settings  
6.32. WIN.INI International Settings

**6.34. DATA TYPES USED IN WINDOWS ARGUMENT NAMES**

Prefix Used	Meaning	Size	Comments
<i>c</i>	Character	Byte	See 6.09. Extended ANSI Character Codes
<i>b</i>	Boolean value	Word	0=false; non-zero=true
<i>f</i>	Bit flag value	Word	16 individual flags
<i>n</i>	Short integer value	Word	Signed values
<i>l</i>	Long integer value	Dbl word	Signed values
<i>w</i>	Short unsigned integer value	Word	Unsigned values
<i>dw</i>	Long unsigned integer value	Dbl word	Unsigned values
<i>h</i>	Handle	Word	Handle is an index into a table
<i>p</i>	Short pointer	Word	Near pointer
<i>lp</i>	Long pointer	Dbl word	Far pointer
<i>pt</i>	x,y coordinate point	Dbl word	Unsigned, 2 word values
<i>rgb</i>	RGB color value	Dbl word	Unsigned

**Notes:** The letters in the lefthand column are used as prefixes to an argument name, as in lpMinPos (e.g., MinPos is a long pointer argument).

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 9

**See Also:** 1.16. Common Numeric Data Formats  
6.09. Extended ANSI Character Codes  
6.35. Data Types Available as C Keywords

**6.35. DATA TYPES AVAILABLE AS C KEYWORDS**

Keyword	Meaning	Size	Signed	Comments
<i>char</i>	ASCII character	Byte	Y	See 6.09. Extended ANSI Character Codes
<i>BYTE</i>	Unsigned byte integer	Byte	N	
<i>int</i>	Signed word integer	Word	Y	
<i>short</i>	Signed word integer	Word	Y	
<i>WORD</i>	Unsigned word integer	Word	N	
<i>long</i>	Signed dbl word integer	Dbl word	Y	
<i>LONG</i>	Signed dbl word integer	Dbl word	Y	
<i>DWORD</i>	Unsigned dbl word integer	Dbl word	N	May also be Segment:Offset address
<i>BOOL</i>	Unsigned word	Word	N	0=false, non-zero=true
<i>void</i>	Empty value		N	
<i>PSTR</i>	Pointer to character string	Word	N	Data is assumed within current segment
<i>PINT</i>	Pointer to integer	Word	N	Data is assumed within current segment
<i>LPSTR</i>	Long pointer to char string	Dbl word	N	Data may be in another segment
<i>LPINT</i>	Long pointer to integer	Dbl word	N	Data may be in another segment
<i>LPRECT</i>	Long pointer to RECT struct.	Dbl word	N	Data may be in another segment
<i>LPMSG</i>	Long pointer to MSG struct.	Dbl word	N	Data may be in another segment
<i>FARPROC</i>	Long pointer to function	Dbl word	N	Function may be in another segment
<i>FAR</i>	Pointer	Word	N	Cast as a long pointer (data in any segment)
<i>NEAR</i>	Pointer	Word	N	Cast as a short pointer (data in current segment)
<i>HANDLE</i>	General handle	Word	N	

(Continued)

Table 6.35. Continued

<i>Keyword</i>	<i>Meaning</i>	<i>Size</i>	<i>Signed</i>	<i>Comments</i>
<i>HSTR</i>	String resource handle	Word	N	
<i>HCURSOR</i>	Cursor resource handle	Word	N	
<i>HICON</i>	Icon resource handle	Word	N	
<i>HMENU</i>	Menu resource handle	Word	N	
<i>HDC</i>	Display context handle	Word	N	
<i>HPEN</i>	Physical pen handle	Word	N	
<i>HFONT</i>	Physical font handle	Word	N	
<i>HBRUSH</i>	Physical brush handle	Word	N	
<i>HBITMAP</i>	Physical bitmap handle	Word	N	
<i>HRGN</i>	Physical region handle	Word	N	
<i>GLOBALHANDLE</i>	Global memory handle	Word	N	
<i>LOCALHANDLE</i>	Local memory handle	Word	N	

**Notes:** Microsoft C is case sensitive

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 607 to 608

**See Also:** 1.16. Common Numeric Data Formats  
6.09. Extended ANSI Character Codes  
6.34. Data Types Used in Windows Argument Names

### 6.36. WINDOWS HANDLE AND POINTER TYPES

<i>Name</i>	<i>Function</i>
<i>FAR</i>	Data type attribute that can be used to create a long pointer
<i>FARPROC</i>	Long pointer to a function
<i>GLOBALHANDLE</i>	Global memory handle: index to memory block in system's global heap
<i>HANDLE</i>	General handle: index to table entry identifying program data
<i>HBITMAP</i>	Physical bitmap handle: index to GDI's physical drawing objects
<i>HBRUSH</i>	Physical brush handle: index to GDI's physical drawing objects
<i>HCURSOR</i>	Cursor resource handle: index to a resource table entry
<i>HDC</i>	Display context handle: index to GDI's display context tables
<i>HFONT</i>	Physical font handle: index to GDI's physical drawing objects
<i>HICON</i>	Icon resource handle: index to a resource table entry
<i>HMENU</i>	Menu resource handle: index to a resource table entry
<i>HPEN</i>	Physical pen handle: index to GDI's physical drawing objects
<i>HRGN</i>	Physical region handle: index to GDI's physical drawing objects
<i>HSTR</i>	String resource handle: index to a resource table entry
<i>LOCALHANDLE</i>	Local memory handle: index to memory block in application's local heap
<i>LPINT</i>	Long pointer to a signed 16-bit integer
<i>LPMSG</i>	Long pointer to MSG data structure
<i>LPRECT</i>	Long pointer to RECT data structure
<i>LPSTR</i>	Long pointer to a character string
<i>NEAR</i>	Data type attribute that can be used to create a short pointer
<i>PINT</i>	Pointer to a signed 16-bit integer
<i>PSTR</i>	Pointer to a character string

**Notes:** All handles are 16-bit values.

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 607 to 608

**See Also:** 6.34. Data Types Used in Windows Argument Names  
6.35. Data Types Available as C Keywords  
6.53. MSG Structure Format  
6.57. RECT Structure Format

## 6.37. INCLUDE FILE CONSTANTS DEFINITIONS BY NAME

Defined Name	Used As	Hex Value	Decimal Value	Comments
ABORTDOC	GDI escape	2	2	
ABSOLUTE	GDI coordinate mode	1	1	
ALTERNATE	Polyfill mode	1	1	
ANSI_CHARSET	Logical font constant	0	0	
ANSI_FIXED_FONT	Stock logical object	B	11	
ANSI_VAR_FONT	Stock logical object	C	12	
ASPECT_FILTERING		1	1	
ASPECTX	Getdevicecaps device parameter	28	40	
ASPECTXY	Getdevicecaps device parameter	2C	44	
ASPECTY	Getdevicecaps device parameter	2A	42	
BANDINFO*	GDI escape code	18	24	
BITSPIXEL	Getdevicecaps device parameter	C	12	
BLACKNESS	Ternary raster op	0000 0042H	66	Dest = BLACK
BLACKONWHITE	Stretchbit mode	1	1	
BLACK_BRUSH	Stock logical object	4	4	
BLACK PEN	Stock logical object	7	7	
BM_GETCHECK*	Control message	400	1024	
BM_GETSTATE*	Control message	402	1026	
BM_SETCHECK*	Control message	401	1025	
BM_SETSTATE*	Control message	403	1027	
BM_SETSTYLE*	Control message	404	1208	
BN_CLICKED	User button notification code	0	0	
BN_DISABLE	User button notification code	4	4	
BN_DOUBLECLICKED*	Control message	5	5	
BN_HILITE	User button notification code	2	2	
BN_PAINT	User button notification code	1	1	
BN_UNHILITE	User button notification code	3	3	
BS_3STATE	Button control style	5	5	
BS_AUTO3STATE	Button control style	6	6	
BS_AUTOCHECKBOX	Button control style	3	3	
BS_AUTORADIOBUTTON*	Button style	9	9	
BS_CHECKBOX	Button control style	2	2	
BS_DEFPUSHBUTTON	Button control style	1	1	
BS_GROUPBOX	Button control style	7	7	
BS_HATCHED	Brush style	2	2	
BS_HOLLOW	Brush style	1	1	Defined as BS_NULL
BS_INDEXED*	Button control style	4	4	
BS_LEFTTEXT*	Button style	20	32	
BS_NULL	Brush style	1	1	
BS_PATTERN	Brush style	3	3	
BS_PUSHBOX*	Button style	A	10	
BS_PUSHBUTTON	Button control style	0	0	
BS_RADIOBUTTON	Button control style	4	4	
BS_SOLID	Brush style	0	0	
BS_USERBUTTON	Button control style	8	8	
CC_CHORD	Device capability mask	4	4	
CC_CIRCLES	Device capability mask	1	1	
CC_ELLIPSES	Device capability mask	8	8	
CC_INTERIORS	Device capability mask	80	128	
CC_NONE	Device capability mask	0	0	
CC_PIE	Device capability mask	2	2	
CC_STYLED	Device capability mask	20	32	
CC_WIDE	Device capability mask	10	16	
CC_WIDESTYLED	Device capability mask	40	64	
CE_BREAK	Comm device driver error	10	16	
CE_CTSTO	Comm device driver error	20	32	
CE_DNS	Comm device driver error	800	2048	
CE_DSRTO	Comm device driver error	40	64	
CE_FRAME	Comm device driver error	8	8	
CE_IOE	Comm device driver error	400	1024	
CE_MODE	Comm device driver error	8000	32768	
CE_OOP	Comm device driver error	1000	4096	
CE_OVERRUN	Comm device driver error	2	2	
CE_PTO	Comm device driver error	200	512	
CE_RLSDTO	Comm device driver error	80	128	
CE_RXOVER	Comm device driver error	1	1	
CE_RXPARITY	Comm device driver error	4	4	
CE_TXFULL	Comm device driver error	100	256	
CF_BITMAP	Clipboard format	2	2	
CF_DIF	Clipboard format	5	5	
CF_DSPBITMAP	Clipboard format	82	130	
CF_DSPMETAFILEPICT	Clipboard format	83	131	
CF_DSPTEXT	Clipboard format	81	129	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
CF_GDIOBJFIRST	Clipboard format	300	768	
CF_GDIOBJLAST	Clipboard format	3FF	1023	
CF_METAFILEPICT	Clipboard format	3	3	
CF_OEMTEXT*	Clipboard format	7	7	
CF_OWNERDISPLAY	Clipboard format	80	128	
CF_PRIVATEFIRST	Clipboard format	200	512	
CF_PRIVATELAST	Clipboard format	2FF	767	
CF_SYLK	Clipboard format	4	4	
CF_TEXT	Clipboard format	1	1	
CF_TIFF*	Clipboard format	6	6	
CLIPCAPS	Getdevicecaps device parameter	24	36	
CLIP_CHARACTER_PRECIS	Logical font constant	1	1	
CLIP_DEFAULT_PRECIS	Logical font constant	0	0	
CLIP_STROKE_PRECIS	Logical font constant	2	2	
CLRDTR	Comm escape function	6	6	
CLRRTS	Comm escape function	4	4	
COLORONCOLOR	Stretchbit mode	3	3	
COLOR_ACTIVEBORDER*	Color type index	A	10	
COLOR_ACTIVECAPTION	Color type index	2	2	
COLOR_APPWORKSPACE*	Color type index	C	12	
COLOR_BACKGROUND	Color type index	1	1	
COLOR_CAPTIONTEXT	Color type index	9	9	
COLOR_INACTIVEBORDER*	Color type index	B	11	
COLOR_INACTIVECAPTION	Color type index	3	3	
COLOR_MENU	Color type index	4	4	
COLOR_MENUTEXT	Color type index	7	7	
COLOR_SCROLLBAR	Color type index	0	0	
COLOR_WINDOW	Color type index	5	5	
COLOR_WINDOWFRAME	Color type index	6	6	
COLOR_WINDOWTEXT	Color type index	8	8	
COMPLEXREGION	Region flag	3	3	
CP_DIRECT*	Device capability mode	2	2	
CP_GETBEEP*	Control panel info	1	1	
CP_GETBORDER*	Control panel info	5	5	
CP_GETMOUSE*	Control panel info	3	3	
CP_HWND*	Device capability mode	0	0	
CP_KANJIMENU*	Control panel info	8	8	
CP_NONE	Device capability mask	0	0	
CP_OPEN*	Device capability mode	1	1	
CP_RECTANGLE	Device capability mask	1	1	
CP_SETBEEP*	Control panel info	2	2	
CP_SETBORDER*	Control panel info	6	6	
CP_SETMOUSE*	Control panel info	4	4	
CP_TIMEOUTS*	Control panel info	7	7	
CS_KEYCUTWINDOW	Class style	4	4	
CS_BYTEALIGNCLIENT*	Class style	1000	4096	
CS_BYTEALIGNWINDOW*	Class style	2000	8192	
CS_CLASSDC	Class style	40	64	
CS_DBLCLKS	Class style	8	8	
CS_HREDRAW	Class style	2	2	
CS_MENUPOPUP	Class style	80	128	
CS_NOCLOSE*	Class style	200	512	
CS_NOKEYCUT	Class style	100	512	
CS_OEMCHARS	Class style	10	16	
CS_OWINDC	Class style	20	32	
CS_PARENTDC*	Class style	80	128	
CS_SAVEBITS*	Class style	800	2048	
CS_VREDRAW	Class style	1	1	
CTLCOLOR_BTN	Color type index	3	3	
CTLCOLOR_DLG	Color type index	4	4	
CTLCOLOR_EDIT	Color type index	1	1	
CTLCOLOR_LISTBOX	Color type index	2	2	
CTLCOLOR_MAX	Color type index	8	8	
CTLCOLOR_MSGBOX	Color type index	0	0	
CTLCOLOR_SCROLLBAR	Color type index	5	5	
CTLCOLOR_STATIC	Color type index	6	6	
CURVECAPS	Getdevicecaps device parameter	1C	28	
DEFAULT_PITCH	Logical font constant	0	0	
DEFAULT_QUALITY	Logical font constant	0	0	
DEVICEDATA	MetaFile comment esc.	13	19	
DEVICEDEFAULT_FONT	Stock logical object	E	14	
DEVICE_FONTTYPE	Enumfont mask	2	2	
DF_ACTIVEBORDER*	DrawFrame index			COLOR_ACTIVEBORDER+1<<3
DF_ACTIVECAPTION*	DrawFrame index			COLOR_ACTIVECAPTION+1<<3
DF_APPWORKSPACE*	DrawFrame index			COLOR_APPWORKSPACE+1<<3
DF_BACKGROUND*	DrawFrame index			COLOR_BACKGROUND+1<<3
DF_CAPTIONTEXT*	DrawFrame index			COLOR_CAPTIONTEXT+1<<3

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
DF GRAY*	DrawFrame index			COLOR_APPWORKSPACE+(1<<3)
DF_INACTIVEBORDER*	DrawFrame index			COLOR_INACTIVEBORDER+1<<3
DF_INACTIVECAPTION*	DrawFrame index			COLOR_INACTIVECAPTION+1<<3
DF_MENU*	DrawFrame index			COLOR_MENU+1<<3
DF_MENUTEXT*	DrawFrame index			COLOR_MENUTEXT+1<<3
DF_PATCOPY*	DrawFrame index	0	0	
DF_PATINVERT*	DrawFrame index	4	4	
DF_SCROLLBAR*	DrawFrame index			COLOR_SCROLLBAR+1<<3
DF_SHIFT0*	DrawFrame index	0	0	
DF_SHIFT1*	DrawFrame index	1	1	
DF_SHIFT2*	DrawFrame index	2	2	
DF_SHIFT3*	DrawFrame index	3	3	
DF_WINDOW*	DrawFrame index			COLOR_WINDOW+1<<3
DF_WINDOWFRAME*	DrawFrame index			COLOR_WINDOWFRAME+1<<3
DF_WINDOWTEXT*	DrawFrame index			COLOR_WINDOWTEXT+1<<3
DKGRAY_BRUSH	Stock logical object	3	3	
DLGC_BUTTON*	Dialog code	2000	8192	
DLGC_DEFPUSHBUTTON*	Dialog code	10	16	
DLGC_HASSETSEL	Dialog code	8	8	
DLGC_RADIOBUTTON*	Dialog code	40	64	
DLGC_STATIC*	Dialog code	100	256	
DLGC_UNDEFPUSHBUTTON*	Dialog code	20	32	
DLGC_WANTALLKEYS	Dialog code	4	4	
DLGC_WANTARROWS	Dialog code	1	1	
DLGC_WANTCHARS*	Dialog code	80	128	
DLGC_WANTMESSAGE*	Dialog code	4	4	
DLGC_WANTTAB	Dialog code	2	2	
DM_GETDEFID	Dialog style bits	400	1024	WM_USER+0
DM_SETDEFID	Dialog style bits	401	1025	WM_USER+1
DM_HASDEFID	Dialog style bits	534B	21323	
DRAFTMODE	GDI escape	7	7	
DRAFT_QUALITY	Logical font constant	1	1	
DRAWPATTERNRECT*	GDI escape code	19	25	
DRIVERVERSION	Getdevicecaps device parameter	0	0	
DSTINVERT	Ternary raster op	0055 0009H	5570569	Dest = (not dest)
DS_ABSALIGN	Dialog style	1	1	
DS_LOCALEDT*	Dialog style	20	32	
DS_SYSMODAL	Dialog style	2	2	
DT_BOTTOM	DrawText format flag	8	8	
DT_CALCRECT*	DrawText format flag	400	1024	
DT_CENTER	DrawText format flag	1	1	
DT_CHARSTREAM	Device capability mask	4	4	
DT_DISPFIL	Device capability mask	6	6	
DT_EXPANDTABS	DrawText format flag	40	64	
DT_EXTERNALLEADING	DrawText format flag	200	512	
DT_INTERNAL	DrawText format flag	1000	4096	
DT_LEFT	DrawText format flag	0	0	
DT_METAFILE	Device capability mask	5	5	
DT_NOCLIP	DrawText format flag	100	256	
DT_NOPREFIX*	DrawText format flag	800	2048	
DT_PLOTTER	Device capability mask	0	0	
DT_RASCAMERA	Device capability mask	3	3	
DT_RASDISPLAY	Device capability mask	1	1	
DT_RASPRINTER	Device capability mask	2	2	
DT_RIGHT	DrawText format flag	2	2	
DT_SINGLELINE	DrawText format flag	20	32	
DT_TABSTOP	DrawText format flag	80	128	
DT_TOP	DrawText format flag	0	0	
DT_VCENTER	DrawText format flag	4	4	
DT_WORDBREAK	DrawText format flag	10	16	
EM_CANUNDO*	Edit control message	413	1043	
EM_FMTLINES*	Edit control message	415	1045	
EM_GETHANDLE*	Edit control message	40C	1036	
EM_GETLINE*	Edit control message	411	1041	
EM_GETLINECOUNT*	Edit control message	409	1033	
EM_GETMODIFY*	Edit control message	407	1031	
EM_GETRECT*	Edit control message	402	1026	
EM_GETSEL*	Edit control message	400	1024	
EM_GETTHUMB*	Edit control message	40D	1037	
EM_LIMITTEXT*	Edit control message	412	1042	
EM_LINEFROMCHAR*	Edit control message	416	1046	
EM_LINEINDEX*	Edit control message	40A	1034	
EM_LINELength*	Edit control message	40E	1038	
EM_LINESCROLL*	Edit control message	406	1030	
EM_REPLACESEL*	Edit control message	40F	1039	
EM_SCROLL*	Edit control message	405	1029	
EM_SETFONT*	Edit control message	410	1040	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
EM_SETHANDLE*	Edit control message	40B	1035	
EM_SETMODIFY*	Edit control message	408	1032	
EM_SETRECT*	Edit control message	403	1027	
EM_SETRECTNP*	Edit control message	404	1028	
EM_SETSEL*	Edit control message	401	1025	
EM_SETWORDBREAK*	Edit control message	417	1047	
EM_UNDO*	Edit control message	414	1044	
ENABLEDUPLEX*	GDI escape code	1C	28	
ENABLEMANUALFEED*	GDI escape code	1D	29	
ENABLEPAIRKERNING*	GDI escape code	301	769	
ENABLERELATIVewidths*	GDI escape code	300	768	
ENDDOC	GDI escape	8	11	
EN_CHANGE	Edit control notification code	300	768	
EN_ERRSPACE	Edit control notification code	500	1280	
EN_HSCROLL	Edit control notification code	601	1537	
EN_KILLFOCUS	Edit control notification code	200	512	
EN_SETFOCUS	Edit control notification code	100	256	
EN_UPDATE*	Edit control notification code	400	1024	
EN_VSCROLL	Edit control notification code	602	1538	
ERROR	Region flag	0	0	
ES_AUTOHSCROLL	Edit control style	80	128	
ES_AUTOVSCROLL	Edit control style	40	64	
ES_CENTER	Edit control style	1	1	
ES_LEFT	Edit control style	0	0	
ES_MULTILINE	Edit control style	4	4	
ES_NOHIDESEL	Edit control style	100	256	
ES_RIGHT	Edit control style	2	2	
ETO_CLIPPED*	Edit text option	4	4	
ETO_GRAYED*	Edit text option	1	1	
ETO_OPAQUE*	Edit text option	2	2	
EVENPARITY	Dcb field definition	2	2	
EV_BREAK	Comm event definition	40	64	
EV_CTS	Comm event definition	8	8	
EV_DSR	Comm event definition	10	16	
EV_ERR	Comm event definition	80	128	
EV_PERR	Comm event definition	200	512	
EV_RING	Comm event definition	100	256	
EV_RLSD	Comm event definition	20	32	
EV_RXCHAR	Comm event definition	1	1	
EV_RXFLAG	Comm event definition	2	2	
EV_TXEMPTY	Comm event definition	4	4	
EXTTEXTOUT*	GDI escape code	200	512	
FALSE	Standard definitions	0	0	
FF_DECORATIVE	Font family ID	5*	5*	*Shifted left four bits
FF_DONTCARE	Font family ID	0*	0*	*Shifted left four bits
FF_MODERN	Font family ID	3*	3*	*Shifted left four bits
FF_ROMAN	Font family ID	1*	1*	*Shifted left four bits
FF_SCRIPT	Font family ID	4*	4*	*Shifted left four bits
FF_SWISS	Font family ID	2*	2*	*Shifted left four bits
FIXED_PITCH	Logical font constant	1	1	
FLUSHOUTPUT	GDI escape	6	6	
FW_BLACK	Font weight constant	384	900	Defined as FW_HEAVY
FW_BOLD	Font weight constant	26C	700	
FW_DEMIBOLD	Font weight constant	258	600	Defined as FW_SEMIBOLD
FW_DONTCARE	Font weight constant	0	0	
FW_EXTRABOLD	Font weight constant	320	800	
FW_EXTRALIGHT	Font weight constant	C8	200	
FW_HEAVY	Font weight constant	384	900	
FW_LIGHT	Font weight constant	12C	300	
FW_MEDIUM	Font weight constant	1F4	500	
FW_NORMAL	Font weight constant	190	400	
FW_REGULAR*	Font weight	190	400	
FW_SEMIBOLD	Font weight constant	258	600	
FW_THIN	Font weight constant	64	100	
FW_ULTRABOLD	Font weight constant	320	800	Defined as FW_EXTRABOLD
FW_ULTRALIGHT	Font weight constant	C8	200	Defined as FW_EXTRALIGHT
GCL_MENUNAME	Class field offset	FFF8	-8	
GCL_WNDPROC	Class field offset	FFEA	-24	
GCW_CBCLSEXTRA	Class field offset	FFEC	-22	
GCW_CBWNDEXTRA	Class field offset	FFEE	-20	
GCW_HBRBACKGROUND	Class field offset	FFF6	-10	
GCW_HCURSOR	Class field offset	FFF4	-12	
GCW_HICON	Class field offset	FFF2	-14	
GCW_HMODULE	Class field offset	FFF0	-16	
GCW_STYLE	Class field offset	FFE8	-26	
GETCOLORTABLE	GDI escape	5	5	
GETEXTENDEDTEXTMETRICS*	GDI escape code	100	256	
GETTEXTTABLE*	GDI escape code	101	257	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
GETPAIRKERNTABLE*	GDI escape code	102	258	
GETPENWIDTH*	GDI escape code	10	16	
GETPHYSPAGE SIZE	GDI escape	C	12	
GETPRINTINGOFFSET	GDI escape	D	13	
GETSCALINGFACTOR	GDI escape	E	14	
GETTECHNOLOGY*	GDI escape code	14	20	
GETTRACKERNTABLE*	GDI escape code	103	259	
GETVECTORBRUSH SIZE*	GDI escape code	1B	27	
GETVECTORPEN SIZE*	GDI escape code	1A	26	
GHND*	Global memory management	42	66	
GMEM_DDESHARE*	Global memory management	2000	8192	
GMEM_DISCARDABLE	Global memory management	F00	3840	
GMEM_DISCARDED	GlobalFlag flag	4000	16384	
GMEM_FIXED	Global memory management	0	0	
GMEM_LOCKCOUNT	GlobalFlag flag	FF	255	
GMEM_LOWER*	Global memory management	1000	4096	
GMEM_MODIFY	Global memory management	80	128	
GMEM_MOVEABLE	Global memory management	2	2	
GMEM_NOCOMPACT	Global memory management	10	16	
GMEM_NODISCARD	Global memory management	20	32	
GMEM_NOTBANKED*	Global memory management	1000	4096	
GMEM_NOTIFY*	Global memory management	4000	16384	
GMEM_SHARE*	Global memory management	2000	8196	
GMEM_SWAPPED	GlobalFlag flag	8000	32768	
GMEM_ZEROINIT	Global memory management	40	64	
GPTR*	Global memory management	2	2	
GRAY_BRUSH	Stock logical object	2	2	
GWL_STYLE	Window field offset	FFF0	-16	
GWL_WNDPROC	Window field offset	FFFC	-4	
GWW_HINSTANCE	Window field offset	FFFA	-6	
GWW_HWNDPARENT	Window field offset	FFF8	-8	
GWW_HWNDTEXT	Window field offset	FFF6	-10	
GWW_ID	Window field offset	FFF4	-12	
GW_CHILD*	GetWindow constant	5	5	
GW_HWNDFIRST*	GetWindow constant	0	0	
GW_HWNDLAST*	GetWindow constant	1	1	
GW_HWNDNEXT*	GetWindow constant	2	2	
GW_HWNDPREV*	GetWindow constant	3	3	
GW_OWNER*	GetWindow constant	4	4	
HCBT_MINMAX*	Hook code	1	1	
HCBT_MOVESIZE*	Hook code	0	0	
HCBT_QS	Hook code	2	2	
HC_ACTION*	Hook code	0	0	
HC_GETNEXT*	Hook code	1	1	
HC_LPFNNEXT*	Hook code	FFFF	-1	
HC_LPLPFNNEXT*	Hook code	FFFE	-2	
HC_NOREM*	Hook code	3	3	
HC_SKIP*	Hook code	2	2	
HIDE_WINDOW	Showwindow command	0	0	
HOLLOW_BRUSH	Stock logical object	5	5	Defined as NULL_BRUSH
HORZRES	Getdevicecaps device parameter	8	8	
HORZSIZE	Getdevicecaps device parameter	4	4	
HS_BDIAGON:\L	Hatch style	3	3	
HS_CROSS	Hatch style	4	4	
HS_DIAGCROSS	Hatch style	5	5	
HS_FDIAGONAL	Hatch style	2	2	
HS_HORIZONTAL	Hatch style	0	0	
HS_VERTICAL	Hatch style	1	1	
HTCAPTION	Winwhere area code	2	2	
HTCLIENT	Winwhere area code	1	1	
HTERROR	Winwhere area code	FFFE	-2	
HTGROWBOX	Winwhere area code	4	4	
HTHSCROLL	Winwhere area code	6	6	
HTMENU	Winwhere area code	5	5	
HTNOWHERE	Winwhere area code	0	0	
HTSYSTEMMENU	Winwhere area code	3	3	
HTTRANSPARENT	Winwhere area code	FFFF	-1	
HTVSCROLL	Winwhere area code	7	7	
HTBOTTOM*	Winwhere area code	F	15	
HTBOTTOMLEFT*	Winwhere area code	10	16	
HTBOTTOMRIGHT*	Winwhere area code	11	17	
HTLEFT*	Winwhere area code	A	10	
HTREDUCE*	Winwhere area code	8	8	
HTRIGHT*	Winwhere area code	B	11	
HTSIZE*	Winwhere area code	4	4	
HTSIZEFIRST*	Winwhere area code	A	10	
HTSIZELAST*	Winwhere area code	11	17	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
HTTOP*	Winwhere area code	C	12	
HTTOPLEFT*	Winwhere area code	D	13	
HTTOPRIGHT*	Winwhere area code	E	14	
HTZOOM*	Winwhere area code	9	9	
IDABORT	Dialog/message box command ID	3	3	
IDCANCEL	Dialog/message box command ID	2	2	
IDC_ARROW	Standard cursor ID	7F00	32512	MAKEINTRESOURCE(32512)
IDC_CROSS	Standard cursor ID	7F03	32515	MAKEINTRESOURCE(32515)
IDC_IBEAM	Standard cursor ID	7F01	32513	MAKEINTRESOURCE(32513)
IDC_ICON	Standard cursor ID	7F81	32641	MAKEINTRESOURCE(32641)
IDC_SIZENWSE	Standard cursor ID	7F82	32642	
IDC_SIZENESW	Standard cursor ID	7F83	32643	
IDC_SIZELW	Standard cursor ID	7F84	32644	
IDC_SIZENS	Standard cursor ID	7F85	32645	
IDC_SIZE	Standard cursor ID	7F80	32640	MAKEINTRESOURCE(32640)
IDC_UPARROW	Standard cursor ID	7F04	32516	MAKEINTRESOURCE(32516)
IDC_WAIT	Standard cursor ID	7F02	32514	MAKEINTRESOURCE(32514)
IDIGNORE	Dialog/message box command ID	5	5	
IDI_APPLICATION	Standard icon ID	7F00	32512	MAKEINTRESOURCE(32512)
IDI_ASTERISK	Standard icon ID	7F04	32516	MAKEINTRESOURCE(32516)
IDI_EXCLAMATION	Standard icon ID	7F03	32515	MAKEINTRESOURCE(32515)
IDI_HAND	Standard icon ID	7F01	32513	MAKEINTRESOURCE(32513)
IDI_QUESTION	Standard icon ID	7F02	32514	MAKEINTRESOURCE(32514)
IDNO	Dialog/message box command ID	7	7	
IDOK	Dialog/message box command ID	1	1	
IDRETRY	Dialog/message box command ID	4	4	
IDYES	Dialog/message box command ID	6	6	
IE_BADID	Comm init error	FFFF	-1	
IE_BAUDRATE	Comm init error	FFF4	-12	
IE_BYTESIZE	Comm init error	FFF5	-11	
IE_DEFAULT	Comm init error	FFFB	-5	
IE_HARDWARE	Comm init error	FFF6	-10	
IE_MEMORY	Comm init error	FFFC	-4	
IE_NOPEN	Comm init error	FFFD	-3	
IE_OPEN	Comm init error	FFFE	-2	
IGNORE	Dcb field definition	0	0	
INFINITE	Dcb field definition	FFFF	-1	
KNJ_START	Conversion function	1	1	
KNJ_END	Conversion function	2	2	
KNJ_QUERY	Conversion function	3	3	
KNJ_LEARN_MODE	Conversion function	10	16	
KNJ_GETMODE	Conversion function	11	17	
KNJ_SETMODE	Conversion function	12	18	
KNJ_CODECONVERT	Conversion function	20	32	
KNJ_CONVERT	Conversion function	21	33	
KNJ_NEXT	Conversion function	22	34	
KNJ_PREVIOUS	Conversion function	23	35	
KNJ_ACCEPT	Conversion function	24	36	
KNJ_LEARN	Conversion function	30	48	
KNJ_REGISTER	Conversion function	31	49	
KNJ_REMOVE	Conversion function	32	50	
KNJ_CHANGE_UDIC	Conversion function	33	51	
KNJ_JIS1 to JIS1 KATAKANA	Conversion function	14	20	
KNJ_JIS1 to JIS2	Conversion function	13	19	
KNJ_JIS1 to JIS2 HIRAGANA	Conversion function	15	21	
KNJ_JIS1 to JIS2 KATAKANA	Conversion function	16	22	
KNJ_JIS1 to DEFAULT	Conversion function	10	16	
KNJ_JIS1 to JIS2 OEM	Conversion function	1F	31	
KNJ_JIS2 to JIS2	Conversion function	23	35	
KNJ_SJIS2 to JIS2	Conversion function	32	50	
KNJ_MD_ALPHA	Conversion function	1	1	
KNJ_MD_HIRAGANA	Conversion function	2	2	
KNJ_MD_HALF	Conversion function	4	4	
KNJ_MD_JIS	Conversion function	8	8	
KNJ_MD_SPECIAL	Conversion function	10	16	
KNJ_CUT_NEXT	Conversion function	1	1	
KNJ_CUT_PREV	Conversion function	2	2	
KNJ_CUT_KATAKANA	Conversion function	3	3	
KNJ_CUT_HIRAGANA	Conversion function	4	4	
KNJ_CUT_JIS1	Conversion function	5	5	
KNJ_CUT_JIS2	Conversion function	6	6	
KNJ_CUT_DEFAULT	Conversion function	7	7	
KNJ_CUT_TYPED	Conversion function	8	8	
LBN_DBLCLK	Listbox notification code	2	2	
LBN_ERRSPACE	Listbox notification code	FFFE	-2	
LBN_SELCHANGE	Listbox notification code	1	1	
LBS_MULTIPLESEL	Listbox style	8	8	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
LBS NOREDRAW	Listbox style	4	4	
LBS NOTIFY	Listbox style	1	1	
LBS SORT	Listbox style	2	2	
LBS STANDARD*	Listbox style	F	15	
LB_ADDSTRING*	Listbox message	400	1024	
LB_CTLCODE	Listbox control	0	0	
LB_DELETESTRING*	Listbox message	402	1	
LB_DIR*	Listbox message	40D	2	
LB_ERR	Listbox control	FFFF	-1	
LB_ERRSPACE	Listbox control	FFFE	-2	
LB_GETCOUNT*	Listbox message	40B	-1	
LB_GETCOURSEL*	Listbox message	409	0	
LB_GETSEL*	Listbox message	408	1	
LB_GETTEXT*	Listbox message	407	2	
LB_GETTEXTLEN*	Listbox message	40A	3	
LB_GETTOPINDEX*	Listbox message	40E	4	
LB_INSERTSTRING*	Listbox message	401	5	
LB_MSGMAX*	Listbox message	40F	6	
LB_OKAY	Listbox control	0	0	
LB_RESETCONTENT*	Listbox message	404	1	
LB_SELECTSTRING*	Listbox message	40C	2	
LB_SETCOURSEL*	Listbox message	406	3	
LB_SETSEL*	Listbox message	405	4	
LC_INTERIORS	Device capability mask	80	128	
LC_MARKER	Device capability mask	4	4	
LC_NONE	Device capability mask	0	0	
LC_POLYLINE	Device capability mask	2	2	
LC_POLYMARKER	Device capability mask	8	8	
LC_STYLED	Device capability mask	20	32	
LC_WIDE	Device capability mask	10	16	
LC_WIDESTYLED	Device capability mask	40	64	
LF_FACEIZE	Logical font constant	20	32	
LHND*	Global memory management	42	66	
LINECAPS	Getdevicecaps device parameter	1E	30	
LMEM_DISCARDABLE	Local memory management	F00	3840	
LMEM_DISCARDED*	Local memory management	4000	16384	
LMEM_FIXED	Local memory management	0	0	
LMEM_LOCKCOUNT	Local memory management	FF	255	
LMEM_MODIFY	Local memory management	80	128	
LMEM_MOVEABLE	Local memory management	2	2	
LMEM_NOCOMPACT	Local memory management	10	16	
LMEM_NODISCARD	Local memory management	20	32	
LMEM_ZEROINIT	Local memory management	40	64	
LNOTIFY_DISCARD	Local memory management	2	2	
LNOTIFY_MOVE	Local memory management	1	1	
LNOTIFY_OUTOFMEM	Local memory management	0	0	
LOGPIXELSX	Getdevicecaps device parameter	58	88	
LOGPIXELSY	Getdevicecaps device parameter	5A	90	
LPTR*	Global memory management	2	2	
LPTx*	Device description	80	128	
LTGRAY_BRUSH	Stock logical object	1	1	
MARKPARITY	Dcb field definition	3	3	
MA_ACTIVATE*	Mouse activate return code	1	1	
MA_ACTIVATEANDDEAT*	Mouse activate return code	2	2	
MA_NOACTIVATE*	Mouse activate return code	3	3	
MB_ABORTRETRYIGNORE	MessageBox type flag	2	2	
MB_APPLMODAL	MessageBox type flag	0	0	
MB_DEFBUTTON1	MessageBox type flag	0	0	
MB_DEFBUTTON2	MessageBox type flag	100	256	
MB_DEFBUTTON3	MessageBox type flag	200	512	
MB_DEFMASK	MessageBox type flag	F00	3840	
MB_ICONASTERISK	MessageBox type flag	40	64	
MB_ICONEXCLAMATION	MessageBox type flag	30	48	
MB_ICONHAND	MessageBox type flag	10	16	
MB_ICONMASK	MessageBox type flag	F0	240	
MB_ICONQUESTION	MessageBox type flag	20	32	
MB_MISCMASK	MessageBox type flag	C000	49152	
MB_MODEMASK	MessageBox type flag	3000	12288	
MB_NOFOCUS	MessageBox type flag	8000	32768	
MB_OK	MessageBox type flag	0	0	
MB_OKCANCEL	MessageBox type flag	1	1	
MB_RETRYCANCEL	MessageBox type flag	5	5	
MB_SYSTEMMODAL	MessageBox type flag	1000	4096	
MB_TYPMASK	MessageBox type flag	F	15	
MB_YESNO	MessageBox type flag	4	4	
MB_YESNOCANCEL	MessageBox type flag	3	3	
MERGECOPY	Ternary raster op	00C0 00CA	12583114	Dest = (source AND pattern)

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
MERGEPAINT	Ternary raster op	00BB 0226	12255782	Dest = (not source) OR dest
META_ARC*	Metafile function	817	2071	
META_BITBLT*	Metafile function	922	2338	
META_CHORD*	Metafile function	630	1584	
META_CREATEBITMAP*	Metafile function	6FE	1790	
META_CREATEBITMAPINDIRECT*	Metafile function	2FD	765	
META_CREATEBRUSH*	Metafile function	F8	248	
META_CREATEBRUSHINDIRECT*	Metafile function	2FC	764	
META_CREATEFONTINDIRECT*	Metafile function	2FB	763	
META_CREATEPATTERNBRUSH*	Metafile function	1F9	505	
META_CREATEPENDIRECT*	Metafile function	2FA	762	
META_CREATEREGION*	Metafile function	6FF	1791	
META_DRAWTEXT*	Metafile function	62F	1583	
META_ELLIPSE*	Metafile function	418	1048	
META_ESCAPE*	Metafile function	626	1574	
META_EXCLUDECLIPRECT*	Metafile function	415	1045	
META_FILLREGION*	Metafile function	228	552	
META_FLOODFILL*	Metafile function	419	1049	
META_FRAMEREGION*	Metafile function	429	1065	
META_INTERSECTCLIPRECT*	Metafile function	416	1046	
META_INVERTREGION*	Metafile function	12A	298	
META_LINETO*	Metafile function	213	531	
META_MOVETO*	Metafile function	214	532	
META_OFFSETCLIPRGN*	Metafile function	220	544	
META_OFFSETVIEWPORTORG*	Metafile function	211	529	
META_OFFSETWINDOWORG*	Metafile function	20F	527	
META_PAINTREGION*	Metafile function	12B	299	
META_PATBLT*	Metafile function	61D	1565	
META_PIE*	Metafile function	81A	2074	
META_POLYGON*	Metafile function	324	804	
META_POLYLINE*	Metafile function	325	805	
META_RECTANGLE*	Metafile function	41B	1051	
META_RESTOREDC*	Metafile function	127	295	
META_ROUNDRECT*	Metafile function	61C	1564	
META_SAVEDC*	Metafile function	1E	30	
META_SCALEVIEWPORTEXT*	Metafile function	412	1042	
META_SCALEWINDOWEXT*	Metafile function	400	1024	
META_SELECTCLIPREGION*	Metafile function	12C	300	
META_SELECTOBJECT*	Metafile function	12D	301	
META_SETBKCOLOR*	Metafile function	201	513	
META_SETBKMODE*	Metafile function	102	258	
META_SETMAPMODE*	Metafile function	103	259	
META_SETPIXEL*	Metafile function	41F	1055	
META_SETPOLYFILLMODE*	Metafile function	106	262	
META_SETRELABS*	Metafile function	105	261	
META_SETROP2*	Metafile function	104	260	
META_SETSTRECTCHBLTMODE*	Metafile function	107	263	
META_SETTEXTALIGN*	Metafile function	12E	302	
META_SETTEXTCHAREXTRA*	Metafile function	108	264	
META_SETTEXTCOLOR*	Metafile function	209	521	
META_SETTEXTJUSTIFICATION*	Metafile function	20A	522	
META_SETVIEWPORTEXT*	Metafile function	20E	526	
META_SETVIEWPORTORG*	Metafile function	20D	525	
META_SETWINDOWEXT*	Metafile function	20C	524	
META_SETWINDOWORG*	Metafile function	20B	523	
META_STRETCHBLT*	Metafile function	B23	2851	
META_TEXTOUT*	Metafile function	521	1313	
MFCOMMENT*	GDI escape code	F	15	
MF_APPEND	MenuItem menu flag	100	256	
MF_BITMAP	MenuItem menu flag	4	4	
MF_BYCOMMAND	MenuItem menu flag	0	0	
MF_BYPOSITION	MenuItem menu flag	400	1024	
MF_CHANGE	MenuItem menu flag	80	128	
MF_CHECKED	MenuItem menu flag	8	8	
MF_DELETE	MenuItem menu flag	200	512	
MF_DISABLED	MenuItem menu flag	2	2	
MF_ENABLED	MenuItem menu flag	0	0	
MF_GRAYED	MenuItem menu flag	1	1	
MF_HELP*	MenuItem menu flag	4000	16384	
MF_HILITE	MenuItem menu flag	80	128	
MF_INSERT	MenuItem menu flag	0	0	
MF_MENUBARBREAK	MenuItem menu flag	20	32	
MF_MENUBREAK	MenuItem menu flag	40	64	
MF_MOUSESELECT*	MenuItem menu flag	8000	32768	
MF_POPUP	MenuItem menu flag	10	16	
MF_REMOVE*	MenuItem menu flag	1000	4096	
MF_SEPARATOR	MenuItem menu flag	800	2048	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
MF STRING	Menuitem menu flag	0	0	
MF SYSMENU*	Menuitem menu flag	2000	8192	
MF UNCHECKED	Menuitem menu flag	0	0	
MF UNHILITE	Menuitem menu flag	0	0	
MK CONTROL	Key state mask f/mouse msg.	8	8	
MK LBUTTON	Key state mask f/mouse msg.	1	1	
MK MBUTTON	Key state mask f/mouse msg.	10	16	
MK RBUTTON	Key state mask f/mouse msg.	2	2	
MK SHIFT	Key state mask f/mouse msg.	4	4	
MM ANISOTROPIC	GDI map mode	8	8	
MM HIENGLISH	GDI map mode	5	5	
MM HIMETRIC	GDI map mode	3	3	
MM ISOTROPIC	GDI map mode	7	7	
MM LOENGLISH	GDI map mode	4	4	
MM LOMETRIC	GDI map mode	2	2	
MM TEXT	GDI map mode	1	1	
MM TWIPS	GDI map mode	6	6	
MSGF_DIALOGBOX	Filter procedure code	0	0	
MSGF_MENU	Filter procedure code	2	2	
MSGF_MESSAGEBOX	Filter procedure code	1	1	
MSGF_MOVE*	Filter procedure code	3	3	
MSGF_NEXTWINDOW*	Filter procedure code	6	6	
MSGF_SCROLLBAR*	Filter procedure code	5	5	
MSGF_SIZE*	Filter procedure code	4	4	
NEWFRAME	GDI escape	1	1	
NEXTBAND	GDI escape	3	3	
NONZEROLHND*	Global memory management	2	2	
NONZEROLPTR*	Global memory management	0	0	
NOPARITY	Dcb field definition	0	0	
NOTSRCOPY	Ternary raster op	0033 0008	3342344	Dest = (not source)
NOTSRCERASE	Ternary raster op	0011 00A6	1114278	Dest = (not source) AND (not dest)
NULL	Standard definitions	0	0	
NULLREGION	Region flag	1	1	
NULL_BRUSH	Stock logical object	5	5	
NULL_PEN	Stock logical object	8	8	
NUMBRUSHES	Getdevicecaps device parameter	10	16	
NUMCOLORS	Getdevicecaps device parameter	18	24	
NUMFONTS	Getdevicecaps device parameter	16	22	
NUMMARKERS	Getdevicecaps device parameter	14	20	
NUMPENS	Getdevicecaps device parameter	12	18	
OBJ_BRUSH	Object definition	2	2	
OBJ_PEN	Object definition	1	1	
OBM BTNCORNERS	OEM definition	7FF6	32758	
OBM BTSIZE	OEM definition	7FF9	32761	
OBM CHECK	OEM definition	7FF8	32760	
OBM CHECKBOXES	OEM definition	7FF7	32759	
OBM CLOSE	OEM definition	7FFF	32767	
OBM DNARROW	OEM definition	7FFC	32764	
OBM LFARROW	OEM definition	7FFA	32762	
OBM REDUCE*	OEM definition	7FF5	32757	
OBM RESTORE*	OEM definition	7FF3	32755	
OBM RGARROW	OEM definition	7FFB	32763	
OBM SIZE	OEM definition	7FFE	32766	
OBM UPARROW	OEM definition	7FFD	32765	
OBM ZOOM*	OEM definition	7FF4	32756	
OCR CROSS	OEM definition	7F03	32515	
OCR IBEAM	OEM definition	7F01	32513	
OCR ICON	OEM definition	7F81	32641	
OCR NORMAL	OEM definition	7F00	32512	
OCR SIZE	OEM definition	7F80	32640	
OCR SIZEALL*	OEM definition	7F86	32646	
OCR SIZENESW*	OEM definition	7F83	32643	
OCR SIZENS*	OEM definition	7F85	32645	
OCR SIZENWSE*	OEM definition	7F82	32642	
OCR SIZEWE*	OEM definition	7F84	32644	
OCR UP	OEM definition	7F04	32516	
OCR WAIT	OEM definition	7F02	32514	
ODDPARITY	Dcb field definition	1	1	
OEM_CHARSET	Logical font constant	FF	255	
OEM_FIXED_FONT	Stock logical object	A	10	
OF_CANCEL	OpenFile flag	800	2048	
OF_CREATE	OpenFile flag	1000	4096	
OF_DELETE	OpenFile flag	200	512	
OF_EXIST	OpenFile flag	4000	16384	
OF_PARSE	OpenFile flag	100	256	
OF_PROMPT	OpenFile flag	2000	8192	
OF_READ	OpenFile flag	0	0	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
OF READWRITE	OpenFile flag	2	2	
OF REOPEN	OpenFile flag	8000	32768	
OF VERIFY	OpenFile flag	400	1024	
OF WRITE	OpenFile flag	1	1	
OIC BANG	OEM definition	7F03	32515	
OIC HAND	OEM definition	7F01	32513	
OIC NOTE	OEM definition	7F04	32516	
OIC QUES	OEM definition	7F02	32514	
OIC SAMPLE	OEM definition	7F00	32512	
ONE5STOPBITS	Dcb field definition	1	1	
ONESTOPBIT	Dcb field definition	0	0	
OPAQUE	GDI background mode	2	2	
OUT CHARACTER PRECIS	Logical font constant	2	2	
OUT_DEFAULT PRECIS	Logical font constant	0	0	
OUT_STRING PRECIS	Logical font constant	1	1	
OUT_STROKE PRECIS	Logical font constant	3	3	
PASSTHROUGH*	GDI escape code	13	19	
PATCOPY	Ternary raster op	00F0 0021	15728673	Dest = pattern
PATINVERT	Ternary raster op	005A 0049	5898313	Dest = pattern XOR dest
PATPAINT	Ternary raster op	00FB 0A09	16452105	Dest = DPSnoo
PC INTERIORS	Device capability mask	80	128	
PC NONE	Device capability mask	0	0	
PC POLYGON	Device capability mask	1	1	
PC RECTANGLE	Device capability mask	2	2	
PC SCANLINE	Device capability mask	8	8	
PC STYLED	Device capability mask	20	32	
PC TRAPEZOID	Device capability mask	4	4	
PC WIDE	Device capability mask	10	16	
PC WIDESTYLED	Device capability mask	40	64	
PDEVICESIZE	Getdevicecaps device parameter	1A	26	
PLANES	Getdevicecaps device parameter	E	14	
PM NOREMOVE*	Peekmessage options	0	0	
PM NOYIELD*	Peekmessage options	2	2	
PM REMOVE*	Peekmessage options	1	1	
POLYGONALCAPS	Getdevicecaps device parameter	20	32	
PR_JOBSTATUS	Spooler wparm class	0	0	
PROOF_QUALITY	Logical font constant	2	2	
PS DASH	Pen style	1	1	
PS DASHDOT	Pen style	3	3	
PS DASHDOTDOT	Pen style	4	4	
PS DOT	Pen style	2	2	
PS NULL	Pen style	5	5	
PS SOLID	Pen style	0	0	
QUERYESCSUPPORT	GDI escape	8	8	
R2 BLACK	Binary raster op	1	1	O
R2 COPYPEN	Binary raster op	13	13	P
R2 MASKNOTPEN	Binary raster op	3	3	DPna
R2 MASKPEN	Binary raster op	9	9	DPa
R2 MASKPENNOT	Binary raster op	5	5	PDna
R2 MERGENOTPEN	Binary raster op	12	12	DPno
R2 MERGEPEN	Binary raster op	15	15	DPo
R2 MERGEPENNOT	Binary raster op	14	14	PDno
R2 NOP	Binary raster op	11	11	D
R2 NOT	Binary raster op	6	6	Dn
R2 NOTCOPYPEN	Binary raster op	4	4	PN
R2 NOTMASKPEN	Binary raster op	8	8	DPan
R2 NOTMERGEPEN	Binary raster op	2	2	DPon
R2 NOTXORPEN	Binary raster op	10	10	DPxn
R2 WHITE	Binary raster op	16	16	1
R2 XORPEN	Binary raster op	7	7	DPx
RASTERCAPS	Getdevicecaps device parameter	26	38	
RASTER_FONTTYPE	Enumfont mask	1	1	
RC BANDING	Device capability mask	2	2	
RC BITBLT	Device capability mask	1	1	
RC BITMAP64*	Device capability mask	8	8	
RC SCALING	Device capability mask	4	4	
RELATIVE	GDI coordinate mode	2	2	
RESETDEV	Comm escape function	7	7	
RGN_AND	Combinern style	1	1	
RGN_COPY	Combinern style	5	5	
RGN_DIFF	Combinern style	4	4	
RGN_OR	Combinern style	2	2	
RGN_XOR	Combinern style	3	3	
RT ACCELERATOR	Predefined resource type	9	9	MAKEINTRESOURCE (9)
RT BITMAP	Predefined resource type	2	2	MAKEINTRESOURCE (2)
RT CURSOR	Predefined resource type	1	1	MAKEINTRESOURCE (1)

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
RT_DIALOG	Predefined resource type	5	5	MAKEINTRESOURCE (5)
RT_FONT	Predefined resource type	8	8	MAKEINTRESOURCE (8)
RT_FONTDIR	Predefined resource type	7	7	MAKEINTRESOURCE (7)
RT_ICON	Predefined resource type	3	3	MAKEINTRESOURCE (3)
RT_MENU	Predefined resource type	4	4	MAKEINTRESOURCE (4)
RT_RCDATA*	Predefined resource type	A	10	MAKEINTRESOURCE (10)
RT_STRING	Predefined resource type	6	6	MAKEINTRESOURCE (6)
SBS_BOTTOMALIGN*	Scroll bar style	4	4	
SBS_HORZ*	Scroll bar style	0	0	
SBS_LEFTALIGN*	Scroll bar style	2	2	
SBS_RIGHTALIGN*	Scroll bar style	4	4	
SBS_SIZEBOX*	Scroll bar style	8	8	
SBS_SIZEBOXBOTTOMRIGHTALIGN*	Scroll bar style	4	4	
SBS_SIZEBOXTOPLEFTALIGN*	Scroll bar style	2	2	
SBS_TOPALIGN*	Scroll bar style	2	2	
SBS_VERT*	Scroll bar style	1	1	
SB_BOTH*	Scroll bar constant	3	3	
SB_BOTTOM	Scroll bar constant	7	7	
SB_CTL	Scroll bar constant	2	2	
SB_ENDSCROLL	Scroll bar constant	8	8	
SB_HORZ	Scroll bar constant	0	0	
SB_LINEDOWN	Scroll bar constant	1	1	
SB_LINEUP	Scroll bar constant	0	0	
SB_PAGEDOWN	Scroll bar constant	3	3	
SB_PAGEUP	Scroll bar constant	2	2	
SB_THUMBPOSITION	Scroll bar constant	4	4	
SB_THUMBTRACK	Scroll bar constant	5	5	
SB_TOP	Scroll bar constant	6	6	
SB_VERT	Scroll bar constant	1	1	
SC_ARRANGE*	System menu command	F110	61712	
SC_CLOSE	System menu command	F060	61536	
SC_HSCROLL	System menu command	F080	61568	
SC_ICON	System menu command	F020	61472	
SC_KEYMENU	System menu command	F100	61696	
SC_MAXIMIZE*	System menu command	F030	61488	
SC_MINIMIZE*	System menu command	F020	61472	
SC_MOUSEMENU	System menu command	F090	61584	
SC_MOVE	System menu command	F010	61456	
SC_NEXTWINDOW	System menu command	F040	61504	
SC_PREVWINDOW	System menu command	F050	61520	
SC_RESTORE*	System menu command	F120	61728	
SC_SIZE	System menu command	F000	61440	
SC_VSCROLL	System menu command	F070	61552	
SC_ZOOM	System menu command	F030	61488	
SELECTPAPERSOURCE*	GDI escape code	12	18	
SETABORTPROC	GDI escape	9	9	
SETCOLORTABLE	GDI escape	4	4	
SETCOPYCOUNT*	GDI escape code	11	17	
SETDTR	Comm escape function	5	5	
SETENDCAP	Metafile comment esc.	15	21	
SETKERNTTRACK*	GDI escape code	302	770	
SETLINEJOIN*	GDI escape code	16	22	
SETMITERLIMIT*	GDI escape code	17	23	
SETRTS	Comm escape function	3	3	
SETXOFF	Comm escape function	1	1	
SETXON	Comm escape function	2	2	
SHIFTJIS_CHARSET*	Logical font constant	80	128	
SHOW_FULLSCREEN	Showwindow command	3	3	
SHOW_ICONWINDOW	Showwindow command	2	2	
SHOW_OPENNOACTIVATE	Showwindow command	4	4	
SHOW_OPENWINDOW	Showwindow command	1	1	
SIMPLEREGION	Region flag	2	2	
SIZE_FULLSCREEN	Size message command	2	2	
SIZE_ICONIC	Size message command	1	1	
SIZE_NORMAL	Size message command	0	0	
SIZE_ZOOMHIDE	Size message command	4	4	
SIZE_ZOOMSHOW	Size message command	3	3	
SM_CMETRICS*	GetSystemMetrics code	24	36	
SM_CXBORDER	GetSystemMetrics code	5	5	
SM_CXCURSOR	GetSystemMetrics code	D	13	
SM_CXDLGFRAME	GetSystemMetrics code	7	7	
SM_CXFRAME*	GetSystemMetrics code	20	32	
SM_CXFULLSCREEN	GetSystemMetrics code	10	16	
SM_CXHSCROLL	GetSystemMetrics code	15	21	
SM_CXHTHUMB	GetSystemMetrics code	A	10	
SM_CXICON	GetSystemMetrics code	B	11	
SM_CXMIN*	GetSystemMetrics code	1C	28	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
SM CXMINTRACK*	GetSystemMetrics code	22	34	
SM CXSCREEN	GetSystemMetrics code	0	0	
SM CXSIZE*	GetSystemMetrics code	1E	30	
SM CXVSCROLL	GetSystemMetrics code	2	2	
SM CYBORDER	GetSystemMetrics code	6	6	
SM CYCAPTION	GetSystemMetrics code	4	4	
SM CYDLGFRAME	GetSystemMetrics code	8	8	
SM CYFRAME*	GetSystemMetrics code	21	33	
SM CYFULLSCREEN	GetSystemMetrics code	11	17	
SM CYHSCROLL	GetSystemMetrics code	3	3	
SM CYICON	GetSystemMetrics code	C	12	
SM CYICONSLOT*	GetSystemMetrics code	1B	27	
SM CYKANJIWINDOW	GetSystemMetrics code	12	18	
SM CYMENU	GetSystemMetrics code	F	15	
SM CYMIN*	GetSystemMetrics code	1D	29	
SM CYMINTRACK*	GetSystemMetrics code	23	35	
SM CYSCREEN	GetSystemMetrics code	1	1	
SM CYSIZE*	GetSystemMetrics code	1F	31	
SM CYVSCROLL	GetSystemMetrics code	14	20	
SM CYVTHUMB	GetSystemMetrics code	9	9	
SM DEBUG	GetSystemMetrics code	16	22	
SM_FULLSCREEN	GetSystemMetrics code	18	24	
SM_MOUSEPRESENT	GetSystemMetrics code	13	19	
SM_SWAPBUTTON	GetSystemMetrics code	17	23	
SM_CYCURSOR	GetSystemMetrics code	E	14	
SPACEPARITY	Dcb field definition	4	4	
SP_APPABORT	Spooler error code	FFFE	-2	
SP_ERROR	Spooler error code	FFFF	-1	
SP_NOTREPORTED	Spooler error code	4000	16384	
SP_OUTOFDISK	Spooler error code	FFFC	-4	
SP_OUTOFMEMORY	Spooler error code	FFFB	-5	
SP_USERABORT	Spooler error code	FFFD	-3	
SRCAND	Ternary raster op	0088 00C6	8913094	Dest = source AND dest
SRCOPY	Ternary raster op	00CC 0320	13369376	Dest=source
SRCERASE	Ternary raster op	0044 C328	4457256	Dest = source AND (not dest)
SRCINVERT	Ternary raster op	0066 0046	6684742	Dest = source XOR dest
SRCPAINT	Ternary raster op	00EE 0086	15597702	Dest=source OR dest
SS_BLACKFRAME	Static control constant	7	7	
SS_BLACKRECT	Static control constant	4	4	
SS_CENTER	Static control constant	1	1	
SS_GRAYFRAME	Static control constant	8	8	
SS_GRAYRECT	Static control constant	5	5	
SS_ICON	Static control constant	3	3	
SS_LEFT	Static control constant	0	0	
SS_NOPREFIX*	Static control constant	80	128	
SS_RIGHT	Static control constant	2	2	
SS_SIMPLE*	Static control constant	13	11	
SS_USERITEM	Static control constant	A	10	
SS_WHITEFRAME	Static control constant	9	9	
SS_WHITERECT	Static control constant	6	6	
STARTDOC	GDI escape	A	10	
STRETCHBLT*	GDI escape code	800	2048	
ST_BEGINSWP*		0	0	
ST_ENDSWP*		1	1	
SWP_DRAWFRAME*	SetWindow position flag	20	32	
SWP_HIDEWINDOW*	SetWindow position flag	80	128	
SWP_NOACTIVATE*	SetWindow position flag	10	16	
SWP_NOCOPYBITS*	SetWindow position flag	100	256	
SWP_NOMOVE*	SetWindow position flag	2	2	
SWP_NOREDRAW*	SetWindow position flag	8	8	
SWP_NOREPOSITION*	SetWindow position flag	200	512	
SWP_NOSIZE*	SetWindow position flag	1	1	
SWP_NOZORDER*	SetWindow position flag	4	4	
SWP_SHOWWINDOW*	SetWindow position flag	40	64	
SW_HIDE*	Showwindow message ID	0	0	
SW_MAXIMIZE*	Showwindow message ID	3	3	
SW_MINIMIZE*	Showwindow message ID	6	6	
SW_NORMAL*	Showwindow message ID	1	1	
SW_OTHERUNZOOM	Showwindow message ID	4	4	
SW_OTHERZOOM	Showwindow message ID	2	2	
SW_PARENTCLOSING	Showwindow message ID	1	1	
SW_PARENTOPENING	Showwindow message ID	3	3	
SW_RESTORE*	Showwindow message ID	1	1	
SW_SHOW*	Showwindow message ID	5	5	
SW_SHOWMAXIMIZED*	Showwindow message ID	3	3	
SW_SHOWMINIMIZED*	Showwindow message ID	2	2	
SW_SHOWMINNOACTIVE*	Showwindow message ID	7	7	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
SW_SHOWNA*	Showwindow message ID	8	8	
SW_SHOWNOACTIVE*	Showwindow message ID	4	4	
SW_SHOWNORMAL*	Showwindow message ID	1	1	
SYSTEM_FONT	Stock logical object	D	13	
S_ALLTHRESHOLD*	WaitSoundState constant	2	2	
S_LEGATO	Accent mode constant	1	1	
S_NORMAL	Accent mode constant	0	0	
S_PERIOD1024	SetSoundNoise source	1	1	
S_PERIOD2048	SetSoundNoise source	2	2	
S_PERIOD512	SetSoundNoise source	0	0	
S_PERIODVOICE	SetSoundNoise source	3	3	
S_QUEUEEMPTY	WaitSoundState constant	0	0	
S_SERBDNT	SetSoundNoise source	FFFB	-5	
S_SERDCC	SetSoundNoise source	FFF9	-7	
S_SERDDR	SetSoundNoise source	FFF2	-14	
S_SERDFQ	SetSoundNoise source	FFF3	-13	
S_SERDLN	SetSoundNoise source	FFFA	-6	
S_SERDMD	SetSoundNoise source	FFF6	-10	
S_SERDPT	SetSoundNoise source	FFF4	-12	
S_SERDSh	SetSoundNoise source	FFF5	-11	
S_SERDSR	SetSoundNoise source	FFF1	-15	
S_SERDST	SetSoundNoise source	FFF0	-16	
S_SERDTP	SetSoundNoise source	FFF8	-8	
S_SERDVL	SetSoundNoise source	FFF7	-9	
S_SERDVNA	SetSoundNoise source	FFFF	-1	
S_SERMACT	SetSoundNoise source	FFFD	-3	
S_SEROFM	SetSoundNoise source	FFFE	-2	
S_SERQFUL	SetSoundNoise source	FFFC	-4	
S_STACCATO	Accent mode constant	2	2	
S_THRESHOLD	WaitSoundState constant	1	1	
S_WHITE1024	SetSoundNoise source	5	5	
S_WHITE2048	SetSoundNoise source	6	6	
S_WHITE512	SetSoundNoise source	4	4	
S_WHITEVOICE	SetSoundNoise source	7	7	
TA_BASELINE*	Text alignment option	18	24	
TA_BOTTOM*	Text alignment option	8	8	
TA_CENTER*	Text alignment option	6	6	
TA_LEFT*	Text alignment option	0	0	
TA_NOUPDATECP*	Text alignment option	0	0	
TA_RIGHT*	Text alignment option	2	2	
TA_TOP*	Text alignment option	0	0	
TA_UPDATECP*	Text alignment option	1	1	
TC_CP_STROKE	Device capability mask	4	4	
TC_CR_90	Device capability mask	8	8	
TC_CR_ANY	Device capability mask	10	16	
TC_EA_DOUBLE	Device capability mask	200	512	
TC_IA_ABLE	Device capability mask	400	1024	
TC_OP_CHARACTER	Device capability mask	1	1	
TC_OP_STROKE	Device capability mask	2	2	
TC_RA_ABLE	Device capability mask	2000	8192	
TC_RESERVED	Device capability mask	8000	32768	
TC_SA_CONTIN	Device capability mask	100	256	
TC_SA_DOUBLE	Device capability mask	40	64	
TC_SA_INTEGER	Device capability mask	80	128	
TC_SF_X_YINDEP	Device capability mask	20	32	
TC_SO_ABLE	Device capability mask	1000	4096	
TC_UA_ABLE	Device capability mask	800	2048	
TC_VA_ABLE	Device capability mask	4000	16384	
TECHNOLOGY	Getdevicecaps device parameter	2	2	
TEXTCAPS	Getdevicecaps device parameter	22	34	
TRANSPARENT	GDI background mode	1	1	
TRUE	Standard definitions	1	1	
TWOSTOPBITS	Dcb field definition	2	2	
VARIABLE_PITCH	Logical font constant	2	2	
VERTRES	Getdevicecaps device parameter	A	10	
VERTSIZE	Getdevicecaps device parameter	6	6	
VK_ACCEPT*	Virtual key	1E	30	
VK_ADD	Standard set virtual key	6B	107	
VK_BACK	Standard set virtual key	8	8	
VK_CANCEL	Standard set virtual key	3	3	
VK_CAPITAL	Standard set virtual key	14	20	
VK_CLEAR	Standard set virtual key	C	12	
VK_CONTROL	Standard set virtual key	11	17	
VK_COPY	Standard set virtual key	2C	44	
VK_CONVERT*	Virtual key	1C	28	
VK_DECIMAL	Standard set virtual key	6E	110	
VK_DELETE	Standard set virtual key	2E	46	
VK_DIVIDE	Standard set virtual key	6F	111	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
VK_DOWN	Standard set virtual key	28	40	
VK_END	Standard set virtual key	23	35	
VK_ESCAPE	Standard set virtual key	1B	27	
VK_EXECUTE	Standard set virtual key	2B	43	
VK_F1	Standard set virtual key	70	112	
VK_F10	Standard set virtual key	79	121	
VK_F11	Standard set virtual key	7A	122	
VK_F12	Standard set virtual key	7B	123	
VK_F13	Standard set virtual key	7C	124	
VK_F14	Standard set virtual key	7D	125	
VK_F15	Standard set virtual key	7E	126	
VK_F16	Standard set virtual key	7F	127	
VK_F2	Standard set virtual key	71	113	
VK_F3	Standard set virtual key	72	114	
VK_F4	Standard set virtual key	73	115	
VK_F5	Standard set virtual key	74	116	
VK_F6	Standard set virtual key	75	117	
VK_F7	Standard set virtual key	76	118	
VK_F8	Standard set virtual key	77	119	
VK_F9	Standard set virtual key	78	120	
VK_HELP	Standard set virtual key	2F	47	
VK_HIRAGANA*	Virtual key	18	24	
VK_HOME	Standard set virtual key	24	36	
VK_INSERT	Standard set virtual key	2D	45	
VK_KANA*	Virtual key	15	21	
VK_KANJI*	Virtual key	19	25	
VK_LBUTTON	Standard set virtual key	1	1	
VK_LEFT	Standard set virtual key	25	37	
VK_MBUTTON	Standard set virtual key	4	4	
VK_MENU	Standard set virtual key	12	18	
VK_MODECHANGE*	Virtual key	1F	31	
VK_MULTIPLY	Standard set virtual key	6A	106	
VK_NEXT	Standard set virtual key	22	34	
VK_NONCONVERT*	Virtual key	1D	29	
VK_NUMLOCK	Standard set virtual key	90	144	
VK_NUMPAD0	Standard set virtual key	60	96	
VK_NUMPAD1	Standard set virtual key	61	97	
VK_NUMPAD2	Standard set virtual key	62	98	
VK_NUMPAD3	Standard set virtual key	63	99	
VK_NUMPAD4	Standard set virtual key	64	100	
VK_NUMPAD5	Standard set virtual key	65	101	
VK_NUMPAD6	Standard set virtual key	66	102	
VK_NUMPAD7	Standard set virtual key	67	103	
VK_NUMPAD8	Standard set virtual key	68	104	
VK_NUMPAD9	Standard set virtual key	69	105	
VK_PAUSE	Standard set virtual key	13	19	
VK_PRINT	Standard set virtual key	2A	42	
VK_PRIOR	Standard set virtual key	21	33	
VK_RBUTTON	Standard set virtual key	2	2	
VK_RETURN	Standard set virtual key	D	13	
VK_RIGHT	Standard set virtual key	27	39	
VK_ROMAJI*	Virtual key	16	22	
VK_SELECT	Standard set virtual key	29	41	
VK_SEPARATOR	Standard set virtual key	6C	108	
VK_SHIFT	Standard set virtual key	10	16	
VK_SPACE	Standard set virtual key	20	32	
VK_SUBTRACT	Standard set virtual key	6D	109	
VK_TAB	Standard set virtual key	9	9	
VK_UP	Standard set virtual key	26	38	
VK_ZENKAKU*	Virtual key	17	23	
WC_DEFWINDOWPROC*	Window manager hook code	3	3	
WC_DRAWCAPTION*	Window manager hook code	7	7	
WC_INIT*	Window manager hook code	1	1	
WC_MINMAX*	Window manager hook code	4	4	
WC_MOVE*	Window manager hook code	5	5	
WC_SIZE*	Window manager hook code	6	6	
WC_SWP*	Window manager hook code	2	2	
WHITENESS	Ternary raster op	00FF 0062	16711778	Dest = WHITE
WHITEONBLACK	Stretchbit mode	2	2	
WHITE_BRUSH	Stock logical object	0	0	
WHITE_PEN	Stock logical object	6	6	
WH_CALLWNDPROC	Setwindowshook code	4	4	
WH_CBT*	Window hook	5	5	
WH_GETMESSAGE	Setwindowshook code	3	3	
WH_JOURNALPLAYBACK	Setwindowshook code	1	1	
WH_JOURNALRECORD	Setwindowshook code	0	0	
WH_KEYBOARD	Setwindowshook code	2	2	
WH_MSGFILTER	Setwindowshook code	FFFF	-1	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
WH_SYMSGFILTER*	Window hook	6	6	
WH_WINDOWMGR*	Window hook	7	7	
WINDING	Polyfill mode	2	2	
WM_ACTIVATE	Window procedure message ID	6	6	
WM_ACTIVATEAPP	Window procedure message ID	1C	28	
WM_ASKCBFORMATNAME	Window procedure message ID	30C	780	
WM_CANCELMODE	Window procedure message ID	1F	31	
WM_CHANGECHAIN	Window procedure message ID	30D	781	
WM_CHAR	Window procedure message ID	102	258	
WM_CHILDACTIVATE*	Window procedure message ID	22	34	
WM_CLEAR	Window procedure message ID	303	771	
WM_CLOSE	Window procedure message ID	10	16	
WM_COMMAND	Window procedure message ID	111	273	
WM_CONVERTREQUEST	Window procedure message ID	10A	266	
WM_CONVERTRESULT	Window procedure message ID	10B	267	
WM_COPY	Window procedure message ID	301	769	
WM_CREATE	Window procedure message ID	1	1	
WM_CTLCOLOR	Window procedure message ID	19	25	
WM_CUT	Window procedure message ID	300	768	
WM_DEADCHAR	Window procedure message ID	103	259	
WM_DESTROY	Window procedure message ID	2	2	
WM_DESTROYCLIPBOARD	Window procedure message ID	307	775	
WM_DEVMODECHANGE	Window procedure message ID	1B	27	
WM_DRAWCLIPBOARD	Window procedure message ID	308	776	
WM_ENABLE	Window procedure message ID	0A	10	
WM_ENDSESSION	Window procedure message ID	16	22	
WM_ENTERIDLE	Window procedure message ID	121	289	
WM_ERASEBKGD	Window procedure message ID	14	20	
WM_FONTCHANGE	Window procedure message ID	1D	29	
WM_GETDLGCODE	Window procedure message ID	87	135	
WM_GETMINMAXINFO*	Window procedure message ID	24	36	
WM_GETTEXT	Window procedure message ID	D	13	
WM_GETTEXTLENGTH	Window procedure message ID	E	14	
WM_HSCROLL	Window procedure message ID	114	276	
WM_HSCROLLCLIPBOARD	Window procedure message ID	30E	782	
WM_ICONERASEBKGD*	Window procedure message ID	27	39	
WM_INITDIALOG	Window procedure message ID	110	272	
WM_INITMENU	Window procedure message ID	116	278	
WM_INITMENUPOPUP	Window procedure message ID	117	279	
WM_KANJIFIRST	Window procedure message ID	280	640	
WM_KANJILAST	Window procedure message ID	29F	671	
WM_KEYDOWN	Window procedure message ID	100	256	
WM_KEYFIRST	Window procedure message ID	100	256	
WM_KEYLAST	Window procedure message ID	107	263	
WM_KEYUP	Window procedure message ID	101	257	
WM_KILLFOCUS	Window procedure message ID	8	8	
WM_LBUTTONDOWNBLCK	Window procedure message ID	203	515	
WM_LBUTTONDOWNN	Window procedure message ID	201	513	
WM_LBUTTONUP	Window procedure message ID	202	514	
WM_MBUTTONDOWNBLCK	Window procedure message ID	209	521	
WM_MBUTTONDOWNN	Window procedure message ID	207	519	
WM_MBUTTONUP	Window procedure message ID	208	520	
WM_MENUCHAR*	Window procedure message ID	120	521	
WM_MENUELECT*	Window procedure message ID	11F	522	
WM_MOUSEACTIVATE*	Window procedure message ID	21	33	
WM_MOUSEFIRST	Window procedure message ID	200	512	
WM_MOUSELAST	Window procedure message ID	209	521	
WM_MOUSEMOVE	Window procedure message ID	200	512	
WM_MOVE	Window procedure message ID	3	3	
WM_NCACTIVATE	Window procedure message ID	86	134	
WM_NCCALCSIZE	Window procedure message ID	83	131	
WM_NCCREATE	Window procedure message ID	81	129	
WM_NCDESTROY	Window procedure message ID	82	130	
WM_NCHITTEST	Window procedure message ID	84	132	
WM_NCLBUTTONDOWNBLCK	Window procedure message ID	A3	163	
WM_NCLBUTTONDOWNN	Window procedure message ID	A1	161	
WM_NCLBUTTONUP	Window procedure message ID	A2	162	
WM_NCMBUTTONDBLCLK	Window procedure message ID	A9	169	
WM_NCMBUTTONDOWN	Window procedure message ID	A7	167	
WM_NCMBUTTONUP	Window procedure message ID	A8	168	
WM_NCMOUSEMOVE	Window procedure message ID	A0	160	
WM_NCPAINT	Window procedure message ID	85	133	
WM_NCRBUTTONDOWNBLCK	Window procedure message ID	A6	166	
WM_NCRBUTTONDOWNN	Window procedure message ID	A4	164	
WM_NCRBUTTONUP	Window procedure message ID	A5	165	
WM_NEXTDLGCTL*	Window procedure message ID	28	40	
WM_NULL	Window procedure message ID	0	0	
WM_PAINT	Window procedure message ID	F	15	

(Continued)

Table 6.37. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
WM_PAINTCLIPBOARD	Window procedure message ID	309	777	
WM_PAINTICON*	Window procedure message ID	26	38	
WM_PASTE	Window procedure message ID	302	770	
WM_QUERYENDSESSION	Window procedure message ID	11	17	
WM_QUERYOPEN	Window procedure message ID	13	19	
WM_QUEUESYNC*	Window procedure message ID	23	35	
WM_QUIT	Window procedure message ID	12	18	
WM_RBUTTONDBLCLK	Window procedure message ID	206	518	
WM_RBUTTONDOWN	Window procedure message ID	204	516	
WM_RBUTTONUP	Window procedure message ID	205	517	
WM_RENDERALLFORMATS	Window procedure message ID	306	774	
WM_RENDERFORMAT	Window procedure message ID	305	773	
WM_SETCURSOR*	Window procedure message ID	20	32	
WM_SETFOCUS	Window procedure message ID	7	7	
WM_SETREDRAW	Window procedure message ID	B	11	
WM_SETTEXT	Window procedure message ID	C	12	
WM_SETVISIBLE	Window procedure message ID	9	9	
WM_SHOWWINDOW	Window procedure message ID	18	24	
WM_SIZE	Window procedure message ID	5	5	
WM_SIZECLIPBOARD	Window procedure message ID	30B	779	
WM_SIZEWAIT	Window procedure message ID	4	4	
WM_SPOOLERSTATUS	Window procedure message ID	2A	42	
WM_SYNCPAINT*	Window procedure message ID	88	136	
WM_SYNCTASK*	Window procedure message ID	89	137	
WM_SYSCCHAR	Window procedure message ID	106	262	
WM_SYSCOLORCHANGE	Window procedure message ID	15	21	
WM_SYSCOMMAND	Window procedure message ID	112	274	
WM_SYSDEADCHAR	Window procedure message ID	107	263	
WM_SYSKEYDOWN	Window procedure message ID	104	260	
WM_SYSKEYUP	Window procedure message ID	105	261	
WM_SYSTEMERROR	Window procedure message ID	17	23	
WM_SYSTIMER	Window procedure message ID	118	280	
WM_TIMECHANGE	Window procedure message ID	1E	30	
WM_TIMER	Window procedure message ID	113	275	
WM_UNDO	Window procedure message ID	304	772	
WM_USER	Window procedure message ID	400	1024	First application window message
WM_VSCROLL	Window procedure message ID	115	277	
WM_VSCROLLCLIPBOARD	Window procedure message ID	30A	778	
WM_WININICHANGE	Window procedure message ID	1A	26	
WM_YOIMICHAR	Window procedure message ID	108	264	
WS_BORDER	Window style	0080 0000	8388608	
WS_CAPTION	Window style	00C0 0000	12582912	
WS_CHILD	Window style	4000 0000	1073741824	
WS_CHILDWINDOW*	Window style	4000 0000	1073741824	
WS_CLIPCHILDREN	Window style	0200 0000	33554432	
WS_CLIPSIBLINGS	Window style	0400 0000	67108864	
WS_DISABLED	Window style	0800 0000	134217728	
WS_DLGFRAME	Window style	0040 0000	4194304	
WS_GROUP	Window style	0002 0000	131072	
WS_HSCROLL	Window style	0010 0000	1048576	
WS_ICONIC	Window style	2000 0000	536870912	Defined as WS_MINIMIZE
WS_ICONICPOPUP*	Window style	C000 0000	3221225472	
WS_MAXIMIZE*	Window style	0100 0000	16777216	
WS_MAXIMIZEBOX*	Window style	0001 0000	65536	
WS_MINIMIZE	Window style	2000 0000	536870912	
WS_MINIMIZEBOX*	Window style	0002 0000	131072	
WS_OVERLAPPED*	Window style	0	0	
WS_OVERLAPPEDWINDOW*	Window style	00CC 0000	13369344	
WS_POPUP	Window style	8000 0000	-2147483648	
WS_POPUPWINDOW*	Window style	8088 0000	2156396544	
WS_SIZEBOX	Window style	0004 0000	262144	
WS_SYSMENU	Window style	0008 0000	524288	
WS_TABSTOP	Window style	0001 0000	65536	
WS_THICKFRAME*	Window style	0004 0000	262144	
WS_TILED	Window style	0	0	
WS_TILEDWINDOW*	Window style	00CC 0000	13369344	
WS_VISIBLE	Window style	1000 0000	268435456	
WS_VSCROLL	Window style	0020 0000	2097152	

**Version Info:** \*Applies to all versions of Windows beginning with 2.0

**Source:** WINDOWS.H file in development kit

**See Also:** 6.38. Include File Constants Definitions by Use

6.38. INCLUDE FILE CONSTANTS DEFINITIONS BY USE

Defined Name	Used As	Hex Value	Decimal Value	Comments
S LEGATO	Accent mode constant	1	1	
S NORMAL	Accent mode constant	0	0	
S STACCATO	Accent mode constant	2	2	
R2 BLACK	Binary raster op	1	1	O
R2 COPYPEN	Binary raster op	13	13	P
R2 MASKNOTPEN	Binary raster op	3	3	DPna
R2 MASKPEN	Binary raster op	9	9	DPa
R2 MASKPENNOT	Binary raster op	5	5	PDna
R2 MERGENOTPEN	Binary raster op	12	12	DPno
R2 MERGEPEN	Binary raster op	15	15	DPo
R2 MERGEPENNOT	Binary raster op	14	14	PDno
R2 NOP	Binary raster op	11	11	D
R2 NOT	Binary raster op	6	6	Dn
R2 NOTCOPYPEN	Binary raster op	4	4	PN
R2 NOTMASKPEN	Binary raster op	8	8	DPan
R2 NOTMERGEPEN	Binary raster op	2	2	DPon
R2 NOTXORPEN	Binary raster op	10	10	DPxn
R2 WHITE	Binary raster op	16	16	1
R2 XORPEN	Binary raster op	7	7	DPx
BS HATCHED	Brush style	2	2	
BS HOLLOW	Brush style	1	1	Defined as BS_NULL
BS NULL	Brush style	1	1	
BS PATTERN	Brush style	3	3	
BS SOLID	Brush style	0	0	
BS 3STATE	Button control style	5	5	
BS AUTO3STATE	Button control style	6	6	
BS AUTOCHECKBOX	Button control style	3	3	
BS CHECKBOX	Button control style	2	2	
BS DEFPUSHBUTTON	Button control style	1	1	
BS GROUPBOX	Button control style	7	7	
BS INDEXED*	Button control style	4	4	
BS PUSHBUTTON	Button control style	0	0	
BS RADIOBUTTON	Button control style	4	4	
BS USERBUTTON	Button control style	9	8	
BS AUTORADIOBUTTON*	Button style	9	9	
BS LEFTTEXT*	Button style	20	32	
BS PUSHBOX*	Button style	A	10	
GCL_MENUNAME	Class field offset	FFF8	-8	
GCL_WNDPROC	Class field offset	FFEA	-24	
GCW_CBCLSEXTRA	Class field offset	FFEC	-22	
GCW_CBWNDEXTRA	Class field offset	FFEE	-20	
GCW_HBRBACKGROUND	Class field offset	FFF6	-10	
GCW_HCURSOR	Class field offset	FFF4	-12	
GCW_HICON	Class field offset	FFF2	-14	
GCW_HMODULE	Class field offset	FFF0	-16	
GCW_STYLE	Class field offset	FFE8	-26	
CS_BYTEALIGNCLIENT*	Class style	1000	4096	
CS_BYTEALIGNWINDOW*	Class style	2000	8192	
CS_CLASSDC	Class style	40	64	
CS_DBLCLKS	Class style	8	8	
CS_HREDRAW	Class style	2	2	
CS_KEYCUTWINDOW	Class style	4	4	
CS_MENUPOPUP	Class style	80	128	
CS_NOCLOSE*	Class style	200	512	
CS_NOKEYCUT	Class style	100	512	
CS_OEMCHARS	Class style	10	16	
CS_OWINDC	Class style	20	32	
CS_PARENTDC*	Class style	80	128	
CS_SAVEBITS*	Class style	800	2048	
CS_VREDRAW	Class style	1	1	
CF_BITMAP	Clipboard format	2	2	
CF_DIF	Clipboard format	5	5	
CF_DSPBITMAP	Clipboard format	82	130	
CF_DSPMETAFILEPICT	Clipboard format	83	131	
CF_DSPTEXT	Clipboard format	81	129	
CF_GDIOBJFIRST	Clipboard format	300	768	
CF_GDIOBJLAST	Clipboard format	3FF	1023	
CF_METAFILEPICT	Clipboard format	3	3	
CF_OEMTEXT*	Clipboard format	7	7	
CF_OWNERDISPLAY	Clipboard format	80	128	
CF_PRIVATEFIRST	Clipboard format	200	512	
CF_PRIVATELAST	Clipboard format	2FF	767	
CF_SYLK	Clipboard format	4	4	
CF_TEXT	Clipboard format	1	1	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
CF TIFF*	Clipboard format	6	6	
COLOR_ACTIVEBORDER*	Color type index	A	10	
COLOR_ACTIVECAPTION	Color type index	2	2	
COLOR_APPWORKSPACE*	Color type index	C	12	
COLOR_BACKGROUND	Color type index	1	1	
COLOR_CAPTIONTEXT	Color type index	9	9	
COLOR_INACTIVEBORDER*	Color type index	B	11	
COLOR_INACTIVECAPTION	Color type index	3	3	
COLOR_MENU	Color type index	4	4	
COLOR_MENUTEXT	Color type index	7	7	
COLOR_SCROLLBAR	Color type index	0	0	
COLOR_WINDOW	Color type index	5	5	
COLOR_WINDOWFRAME	Color type index	6	6	
COLOR_WINDOWTEXT	Color type index	8	8	
CTLCOLOR_BTN	Color type index	3	3	
CTLCOLOR_DLG	Color type index	4	4	
CTLCOLOR_EDIT	Color type index	1	1	
CTLCOLOR_LISTBOX	Color type index	2	2	
CTLCOLOR_MAX	Color type index	8	8	
CTLCOLOR_MSGBOX	Color type index	0	0	
CTLCOLOR_SCROLLBAR	Color type index	5	5	
CTLCOLOR_STATIC	Color type index	6	6	
RGN_AND	Combinern style	1	1	
RGN_COPY	Combinern style	5	5	
RGN_DIFF	Combinern style	4	4	
RGN_OR	Combinern style	2	2	
RGN_XOR	Combinern style	3	3	
CE_BREAK	Comm device driver error	10	16	
CE_CTSTO	Comm device driver error	20	32	
CE_DNS	Comm device driver error	800	2048	
CE_DSRT0	Comm device driver error	40	64	
CE_FRAME	Comm device driver error	8	8	
CE_IOE	Comm device driver error	400	1024	
CE_MODE	Comm device driver error	8000	32768	
CE_OOP	Comm device driver error	1000	4096	
CE_OVERRUN	Comm device driver error	2	2	
CE_PTO	Comm device driver error	200	512	
CE_RLSDTO	Comm device driver error	80	128	
CE_RXOVER	Comm device driver error	1	1	
CE_RXPARITY	Comm device driver error	4	4	
CE_TXFULL	Comm device driver error	100	256	
CLRDTR	Comm escape function	6	6	
CLRRTS	Comm escape function	4	4	
RESETDEV	Comm escape function	7	7	
SETDTR	Comm escape function	5	5	
SETRTS	Comm escape function	3	3	
SETXOFF	Comm escape function	1	1	
SETXON	Comm escape function	2	2	
EV_BREAK	Comm event definition	40	64	
EV_CTS	Comm event definition	8	8	
EV_DSR	Comm event definition	10	16	
EV_ERR	Comm event definition	80	128	
EV_PERR	Comm event definition	200	512	
EV_RING	Comm event definition	100	256	
EV_RLSD	Comm event definition	20	32	
EV_RXCHAR	Comm event definition	1	1	
EV_RXFLAG	Comm event definition	2	2	
EV_TXEMPTY	Comm event definition	4	4	
IE_BADID	Comm init error	FFFF	-1	
IE_BAUDRATE	Comm init error	FFF4	-12	
IE_BYTESIZE	Comm init error	FFF5	-11	
IE_DEFAULT	Comm init error	FFFB	-5	
IE_HARDWARE	Comm init error	FFF6	-10	
IE_MEMORY	Comm init error	FFFC	-4	
IE_NOPEN	Comm init error	FFFD	-3	
IE_OPEN	Comm init error	FFFE	-2	
BM_GETCHECK*	Control message	400	1024	
BM_GETSTATE*	Control message	402	1026	
BM_SETCHECK*	Control message	401	1025	
BM_SETSTATE*	Control message	403	1027	
BM_SETSTYLE*	Control message	404	1208	
BN_DOUBLECLICKED*	Control message	5	5	
CP_GETBEEP*	Control panel info	1	1	
CP_GETBORDER*	Control panel info	5	5	
CP_GETMOUSE*	Control panel info	3	3	
CP_KANJIMENU*	Control panel info	8	8	
CP_SETBEEP*	Control panel info	2	2	

(Continued)

Table 6 38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
CP SETBORDER*	Control panel info	6	6	
CP SETMOUSE*	Control panel info	4	4	
CP TIMEOUTS*	Control panel info	7	7	
KNJ ACCEPT	Conversion function	24	36	
KNJ CHANGE UDIC	Conversion function	33	51	
KNJ CODECONVERT	Conversion function	20	32	
KNJ CONVERT	Conversion function	21	33	
KNJ CUT DEFAULT	Conversion function	7	7	
KNJ CUT HIRAGANA	Conversion function	4	4	
KNJ CUT JIS1	Conversion function	5	5	
KNJ CUT JIS2	Conversion function	6	6	
KNJ CUT KATAKANA	Conversion function	3	3	
KNJ CUT NEXT	Conversion function	1	1	
KNJ CUT PREV	Conversion function	2	2	
KNJ CUT TYPED	Conversion function	8	8	
KNJ END	Conversion function	2	2	
KNJ GETMODE	Conversion function	11	17	
KNJ JIS1 to DEFAULT	Conversion function	10	16	
KNJ JIS1 to JIS1 KATAKANA	Conversion function	14	20	
KNJ JIS1 to JIS2	Conversion function	13	19	
KNJ JIS1 to JIS2 HIRAGANA	Conversion function	15	21	
KNJ JIS1 to JIS2 KATAKANA	Conversion function	16	22	
KNJ JIS1 to JIS2 OEM	Conversion function	1F	31	
KNJ JIS2 to JIS2	Conversion function	23	35	
KNJ LEARN	Conversion function	30	48	
KNJ LEARN MODE	Conversion function	10	16	
KNJ MD ALPHA	Conversion function	1	1	
KNJ MD HALF	Conversion function	4	4	
KNJ MD HIRAGANA	Conversion function	2	2	
KNJ MD JIS	Conversion function	8	8	
KNJ MD SPECIAL	Conversion function	10	16	
KNJ NEXT	Conversion function	22	34	
KNJ PREVIOUS	Conversion function	23	35	
KNJ QUERY	Conversion function	3	3	
KNJ REGISTER	Conversion function	31	49	
KNJ REMOVE	Conversion function	32	50	
KNJ SETMODE	Conversion function	12	18	
KNJ SJIS2 to JIS2	Conversion function	32	50	
KNJ START	Conversion function	1	1	
EVENPARITY	Dcb field definition	2	2	
IGNORE	Dcb field definition	0	0	
INFINITE	Dcb field definition	FFFF	-1	
MARKPARITY	Dcb field definition	3	3	
NOPARITY	Dcb field definition	0	0	
ODDPARITY	Dcb field definition	1	1	
ONESTOPBITS	Dcb field definition	1	1	
ONESTOPBIT	Dcb field definition	0	0	
SPACEPARITY	Dcb field definition	4	4	
TWOSTOPBITS	Dcb field definition	2	2	
CC CHORD	Device capability mask	4	4	
CC CIRCLES	Device capability mask	1	1	
CC ELLIPSES	Device capability mask	3	8	
CC INTERIORS	Device capability mask	80	128	
CC NONE	Device capability mask	0	0	
CC PIE	Device capability mask	2	2	
CC STYLED	Device capability mask	20	32	
CC WIDE	Device capability mask	10	16	
CC WIDESTYLED	Device capability mask	40	64	
CP NONE	Device capability mask	0	0	
CP RECTANGLE	Device capability mask	1	1	
DT CHARSTREAM	Device capability mask	4	4	
DT DISPPFILE	Device capability mask	6	6	
DT METAFILE	Device capability mask	5	5	
DT PLOTTER	Device capability mask	0	0	
DT RASCAMERA	Device capability mask	3	3	
DT RASDISPLAY	Device capability mask	1	1	
DT RASPRINTER	Device capability mask	2	2	
LC INTERIORS	Device capability mask	80	128	
LC MARKER	Device capability mask	4	4	
LC NONE	Device capability mask	0	0	
LC POLYLINE	Device capability mask	2	2	
LC POLYMARKER	Device capability mask	8	8	
LC STYLED	Device capability mask	20	32	
LC WIDE	Device capability mask	10	16	
LC WIDESTYLED	Device capability mask	40	64	
PC INTERIORS	Device capability mask	80	128	
PC NONE	Device capability mask	0	0	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
PC POLYGON	Device capability mask	1	1	
PC RECTANGLE	Device capability mask	2	2	
PC SCANLINE	Device capability mask	8	8	
PC STYLED	Device capability mask	20	32	
PC TRAPEZOID	Device capability mask	4	4	
PC WIDE	Device capability mask	10	16	
PC WIDESTYLED	Device capability mask	40	64	
RC BANDING	Device capability mask	2	2	
RC BITBLT	Device capability mask	1	1	
RC BITMAP64*	Device capability mask	8	8	
RC SCALING	Device capability mask	4	4	
TC CP_STROKE	Device capability mask	4	4	
TC CR_90	Device capability mask	8	8	
TC CR_ANY	Device capability mask	10	16	
TC EA_DOUBLE	Device capability mask	200	512	
TC IA_ABLE	Device capability mask	400	1024	
TC OP_CHARACTER	Device capability mask	1	1	
TC OP_STROKE	Device capability mask	2	2	
TC RA_ABLE	Device capability mask	2000	8192	
TC RESERVED	Device capability mask	8000	32768	
TC SA_CONTIN	Device capability mask	100	256	
TC SA_DOUBLE	Device capability mask	40	64	
TC SA_INTEGER	Device capability mask	80	128	
TC SF_X_YINDEP	Device capability mask	20	32	
TC SO_ABLE	Device capability mask	1000	4096	
TC UA_ABLE	Device capability mask	800	2048	
TC VA_ABLE	Device capability mask	4000	16384	
CP DIRECT*	Device capability mode	2	2	
CP HWND*	Device capability mode	0	0	
CP_OPEN*	Device capability mode	1	1	
LPTx*	Device description	80	128	
DLGC_BUTTON*	Dialog code	2000	8192	
DLGC_DEFPUSHBUTTON*	Dialog code	10	16	
DLGC_HASSETSEL	Dialog code	8	8	
DLGC_RADIOBUTTON*	Dialog code	40	64	
DLGC_STATIC*	Dialog code	100	256	
DLGC_UNDEFPUSHBUTTON*	Dialog code	20	32	
DLGC_WANTALLKEYS	Dialog code	4	4	
DLGC_WANTARROWS	Dialog code	1	1	
DLGC_WANTCHARS*	Dialog code	80	128	
DLGC_WANTMESSAGE*	Dialog code	4	4	
DLGC_WANTTAB	Dialog code	2	2	
DS_ABSALIGN	Dialog style	1	1	
DS_LOCALEDIT*	Dialog style	20	32	
DS_SYSMODAL	Dialog style	2	2	
DM_GETDEFID	Dialog style bits	400	1024	WM_USER+0
DM_HASDEFID	Dialog style bits	534B	21323	
DM_SETDEFID	Dialog style bits	401	1025	WM_USER+1
IDABORT	Dialog/message box command ID	3	3	
IDCANCEL	Dialog/message box command ID	2	2	
IDIGNORE	Dialog/message box command ID	5	5	
IDNO	Dialog/message box command ID	7	7	
IDOK	Dialog/message box command ID	1	1	
IDRETRY	Dialog/message box command ID	4	4	
IDYES	Dialog/message box command ID	6	6	
DF_ACTIVEBORDER*	DrawFrame index			COLOR_ACTIVEBORDER+1<<3
DF_ACTIVECAPTION*	DrawFrame index			COLOR_ACTIVECAPTION+1<<3
DF_APPWORKSPACE*	DrawFrame index			COLOR_APPWORKSPACE+1<<3
DF_BACKGROUND*	DrawFrame index			COLOR_BACKGROUND+1<<3
DF_CAPTIONTEXT*	DrawFrame index			COLOR_CAPTIONTEXT+1<<3
DF_GRAY*	DrawFrame index			COLOR_APPWORKSPACE(+1<<3)
DF_INACTIVEBORDER*	DrawFrame index			COLOR_INACTIVEBORDER+1<<3
DF_INACTIVECAPTION*	DrawFrame index			COLOR_INACTIVECAPTION+1<<3
DF_MENU*	DrawFrame index			COLOR_MENU+1<<3
DF_MENUTEXT*	DrawFrame index			COLOR_MENUTEXT+1<<3
DF_PATCOPY*	DrawFrame index	0	0	
DF_PATINVERT*	DrawFrame index	4	4	
DF_SCROLLBAR*	DrawFrame index			COLOR_SCROLLBAR+1<<3
DF_SHIFT0*	DrawFrame index	0	0	
DF_SHIFT1*	DrawFrame index	1	1	
DF_SHIFT2*	DrawFrame index	2	2	
DF_SHIFT3*	DrawFrame index	3	3	
DF_WINDOW*	DrawFrame index			COLOR_WINDOW+1<<3
DF_WINDOWFRAME*	DrawFrame index			COLOR_WINDOWFRAME+1<<3
DF_WINDOWTEXT*	DrawFrame index			COLOR_WINDOWTEXT+1<<3
DT_BOTTOM	DrawText format flag	8	8	
DT_CENTER	DrawText format flag	1	1	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
DT_EXPANDTABS	DrawText format flag	40	64	
DT_EXTERNALLEADING	DrawText format flag	200	512	
DT_INTERNAL	DrawText format flag	1000	4096	
DT_LEFT	DrawText format flag	0	0	
DT_NOCLIP	DrawText format flag	100	256	
DT_RIGHT	DrawText format flag	2	2	
DT_SINGLELINE	DrawText format flag	20	32	
DT_TABSTOP	DrawText format flag	80	128	
DT_TOP	DrawText format flag	0	0	
DT_VCENTER	DrawText format flag	4	4	
DT_WORDBREAK	DrawText format flag	10	16	
DT_CALCRECT*	DrawText format flag	400	1024	
DT_NOPREFIX*	DrawText format flag	800	2048	
EM_CANUNDO*	Edit control message	413	1043	
EM_FMTLINES*	Edit control message	415	1045	
EM_GETHANDLE*	Edit control message	40C	1036	
EM_GETLINE*	Edit control message	411	1041	
EM_GETLINECOUNT*	Edit control message	409	1033	
EM_GETMODIFY*	Edit control message	407	1031	
EM_GETRECT*	Edit control message	402	1026	
EM_GETSEL*	Edit control message	400	1024	
EM_GETTHUMB*	Edit control message	40D	1037	
EM_LIMITTEXT*	Edit control message	412	1042	
EM_LINEFROMCHAR*	Edit control message	416	1046	
EM_LINEINDEX*	Edit control message	40A	1034	
EM_LINELENGTH*	Edit control message	40E	1038	
EM_LINESCROLL*	Edit control message	406	1030	
EM_REPLACESEL*	Edit control message	40F	1039	
EM_SCROLL*	Edit control message	405	1029	
EM_SETFONT*	Edit control message	410	1040	
EM_SETHANDLE*	Edit control message	40B	1035	
EM_SETMODIFY*	Edit control message	408	1032	
EM_SETRECT*	Edit control message	403	1027	
EM_SETRECTNP*	Edit control message	404	1028	
EM_SETSEL*	Edit control message	401	1025	
EM_SETWORDBREAK*	Edit control message	417	1047	
EM_UNDO*	Edit control message	414	1044	
EN_CHANGE	Edit control notification code	300	768	
EN_ERRSPACE	Edit control notification code	500	1280	
EN_HSCROLL	Edit control notification code	601	1537	
EN_KILLFOCUS	Edit control notification code	200	512	
EN_SETFOCUS	Edit control notification code	100	256	
EN_UPDATE*	Edit control notification code	400	1024	
EN_VSCROLL	Edit control notification code	602	1538	
ES_AUTOHSCROLL	Edit control style	80	128	
ES_AUTOVSCROLL	Edit control style	40	64	
ES_CENTER	Edit control style	1	1	
ES_LEFT	Edit control style	0	0	
ES_MULTILINE	Edit control style	4	4	
ES_NOHIDESEL	Edit control style	100	256	
ES_RIGHT	Edit control style	2	2	
ETO_CLIPPED*	Edit text option	4	4	
ETO_GRAYED*	Edit text option	1	1	
ETO_OPAQUE*	Edit text option	2	2	
DEVICE_FONTTYPE	Enumfont mask	2	2	
RASTER_FONTTYPE	Enumfont mask	1	1	
MSGF_DIALOGBOX	Filter procedure code	0	0	
MSGF_MENU	Filter procedure code	2	2	
MSGF_MESSAGEBOX	Filter procedure code	1	1	
MSGF_MOVE*	Filter procedure code	3	3	
MSGF_NEXTWINDOW*	Filter procedure code	6	6	
MSGF_SCROLLBAR*	Filter procedure code	5	5	
MSGF_SIZE*	Filter procedure code	4	4	
FF_DECORATIVE	Font family ID	5*	5*	*Shifted left four bits
FF_DONTCARE	Font family ID	0*	0*	*Shifted left four bits
FF_MODERN	Font family ID	3*	3*	*Shifted left four bits
FF_ROMAN	Font family ID	1*	1*	*Shifted left four bits
FF_SCRIPT	Font family ID	4*	4*	*Shifted left four bits
FF_SWISS	Font family ID	2*	2*	*Shifted left four bits
FW_REGULAR*	Font weight	190	400	
FW_BLACK	Font weight constant	384	900	Defined as FW_HEAVY
FW_BOLD	Font weight constant	26C	700	
FW_DEMIBOLD	Font weight constant	258	600	Defined as FW_SEMIBOLD
FW_DONTCARE	Font weight constant	0	0	
FW_EXTRABOLD	Font weight constant	320	800	
FW_EXTRALIGHT	Font weight constant	C8	200	
FW_HEAVY	Font weight constant	384	900	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
FW LIGHT	Font weight constant	12C	300	
FW MEDIUM	Font weight constant	1F4	500	
FW NORMAL	Font weight constant	190	400	
FW SEMIBOLD	Font weight constant	258	600	
FW THIN	Font weight constant	64	100	
FW ULTRABOLD	Font weight constant	320	800	Defined as FW EXTRABOLD
FW ULTRALIGHT	Font weight constant	C8	200	Defined as FW EXTRALIGHT
OPAQUE	GDI background mode	2	2	
TRANSPARENT	GDI background mode	1	1	
ABSOLUTE	GDI coordinate mode	1	1	
RELATIVE	GDI coordinate mode	2	2	
ABORTDOC	GDI escape	2	2	
DRAFTMODE	GDI escape	7	7	
ENDDOC	GDI escape	B	11	
FLUSHOUTPUT	GDI escape	6	6	
GETCOLORTABLE	GDI escape	5	5	
GETPHYSPAGESIZE	GDI escape	C	12	
GETPRINTINGOFFSET	GDI escape	D	13	
GETSCALINGFACTOR	GDI escape	E	14	
NEWFRAME	GDI escape	1	1	
NEXTBAND	GDI escape	3	3	
QUERYSCSUPPORT	GDI escape	8	8	
SETABORTPROC	GDI escape	9	9	
SETCOLORTABLE	GDI escape	4	4	
STARTDOC	GDI escape	A	10	
BANDINFO*	GDI escape code	18	24	
DRAWPATTERNRECT*	GDI escape code	19	25	
ENABLEDUPLEX*	GDI escape code	1C	28	
ENABLEMANUALFEED*	GDI escape code	1D	29	
ENABLEPAIRKERNING*	GDI escape code	301	769	
ENABLERELATIVEWIDTHS*	GDI escape code	300	768	
EXTTEXTOUT*	GDI escape code	200	512	
GETEXTENDEDTEXTMETRICS*	GDI escape code	100	256	
GETTEXTTABLE*	GDI escape code	101	257	
GETPAIRKERNTABLE*	GDI escape code	102	258	
GETPENWIDTH*	GDI escape code	10	16	
GETTECHNOLOGY*	GDI escape code	14	20	
GETTRACKKERNTABLE*	GDI escape code	103	259	
GETVECTORBRUSHSIZE*	GDI escape code	1B	27	
GETVECTORPENSIZE*	GDI escape code	1A	26	
MFCOMMENT*	GDI escape code	F	15	
PASSTHROUGH*	GDI escape code	13	19	
SELECTPAPERSOURCE*	GDI escape code	12	18	
SETCOPYCOUNT*	GDI escape code	11	17	
SETKERNTRACK*	GDI escape code	302	770	
SETLINEJOIN*	GDI escape code	16	22	
SETMITERLIMIT*	GDI escape code	17	23	
STRETCHBLT*	GDI escape code	800	2048	
MM ANISOTROPIC	GDI map mode	8	8	
MM HIENGLISH	GDI map mode	5	5	
MM HIMETRIC	GDI map mode	3	3	
MM ISOTROPIC	GDI map mode	7	7	
MM LOENGLISH	GDI map mode	4	4	
MM LOMETRIC	GDI map mode	2	2	
MM TEXT	GDI map mode	1	1	
MM TWIPS	GDI map mode	6	6	
ASPECTX	Getdevicecaps device parameter	28	40	
ASPECTY	Getdevicecaps device parameter	2C	44	
ASPECTY	Getdevicecaps device parameter	2A	42	
BITSPIXEL	Getdevicecaps device parameter	C	12	
CLIPCAPS	Getdevicecaps device parameter	24	36	
CURVECAPS	Getdevicecaps device parameter	1C	28	
DRIVERVERSION	Getdevicecaps device parameter	0	0	
HORZRES	Getdevicecaps device parameter	8	8	
HORZSIZE	Getdevicecaps device parameter	4	4	
LINECAPS	Getdevicecaps device parameter	1E	30	
LOGPIXELSX	Getdevicecaps device parameter	58	88	
LOGPIXELSY	Getdevicecaps device parameter	5A	90	
NUMBRUSHES	Getdevicecaps device parameter	10	16	
NUMCOLORS	Getdevicecaps device parameter	18	24	
NUMFONTS	Getdevicecaps device parameter	16	22	
NUMMARKERS	Getdevicecaps device parameter	14	20	
NUMPENS	Getdevicecaps device parameter	12	18	
PDEVICE SIZE	Getdevicecaps device parameter	1A	26	
PLANES	Getdevicecaps device parameter	E	14	
POLYGONALCAPS	Getdevicecaps device parameter	20	32	
RASTERCAPS	Getdevicecaps device parameter	26	38	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
TECHNOLOGY	GetDeviceCaps device parameter	2	2	
TEXTCAPS	GetDeviceCaps device parameter	22	34	
VERTRES	GetDeviceCaps device parameter	A	10	
VERTSIZE	GetDeviceCaps device parameter	6	6	
SM_CMETRICS*	GetSystemMetrics code	24	36	
SM_CXBORDER	GetSystemMetrics code	5	5	
SM_CXCURSOR	GetSystemMetrics code	D	13	
SM_CXDLGFRAME	GetSystemMetrics code	7	7	
SM_CXFRAME*	GetSystemMetrics code	20	32	
SM_CXFULLSCREEN	GetSystemMetrics code	10	16	
SM_CXHSCROLL	GetSystemMetrics code	15	21	
SM_CXHTHUMB	GetSystemMetrics code	A	10	
SM_CXICON	GetSystemMetrics code	B	11	
SM_CXMIN*	GetSystemMetrics code	1C	28	
SM_CXMINTRACK*	GetSystemMetrics code	22	34	
SM_CXSCREEN	GetSystemMetrics code	0	0	
SM_CXSIZE*	GetSystemMetrics code	1E	30	
SM_CXVSCROLL	GetSystemMetrics code	2	2	
SM_CYBORDER	GetSystemMetrics code	6	6	
SM_CYCAPTION	GetSystemMetrics code	4	4	
SM_CYCURSOR	GetSystemMetrics code	E	14	
SM_CYDLGFRAME	GetSystemMetrics code	8	8	
SM_CYFRAME*	GetSystemMetrics code	21	33	
SM_CYFULLSCREEN	GetSystemMetrics code	11	17	
SM_CYHSCROLL	GetSystemMetrics code	3	3	
SM_CYICON	GetSystemMetrics code	C	12	
SM_CYICONSLOT*	GetSystemMetrics code	1B	27	
SM_CYKANJIWINDOW	GetSystemMetrics code	12	18	
SM_CYMENU	GetSystemMetrics code	F	15	
SM_CYMIN*	GetSystemMetrics code	1D	29	
SM_CYMINTRACK*	GetSystemMetrics code	23	35	
SM_CYSCREEN	GetSystemMetrics code	1	1	
SM_CYSIZE*	GetSystemMetrics code	1F	31	
SM_CYVSCROLL	GetSystemMetrics code	14	20	
SM_CYVTHUMB	GetSystemMetrics code	9	9	
SM_DEBUG	GetSystemMetrics code	16	22	
SM_FULLSCREEN	GetSystemMetrics code	18	24	
SM_MOUSEPRESENT	GetSystemMetrics code	13	19	
SM_SWAPBUTTON	GetSystemMetrics code	17	23	
GW_CHILD*	GetWindow constant	5	5	
GW_HWNDFIRST*	GetWindow constant	0	0	
GW_HWNDLAST*	GetWindow constant	1	1	
GW_HWNDNEXT*	GetWindow constant	2	2	
GW_HWNDPREV*	GetWindow constant	3	3	
GW_OWNER*	GetWindow constant	4	4	
GHND*	Global memory management	42	66	
GMEM_DDESHARE*	Global memory management	2000	8192	
GMEM_DISCARDABLE	Global memory management	F00	3840	
GMEM_FIXED	Global memory management	0	0	
GMEM_LOWER*	Global memory management	1000	4096	
GMEM_MODIFY	Global memory management	80	128	
GMEM_MOVEABLE	Global memory management	2	2	
GMEM_NOCOMPACT	Global memory management	10	16	
GMEM_NODISCARD	Global memory management	20	32	
GMEM_NOTBANKED*	Global memory management	1000	4096	
GMEM_NOTIFY*	Global memory management	4000	16384	
GMEM_SHARE*	Global memory management	2000	8196	
GMEM_ZEROINIT	Global memory management	40	64	
GPTR*	Global memory management	2	2	
LHND*	Global memory management	42	66	
LPTR*	Global memory management	2	2	
NONZEROLHND*	Global memory management	2	2	
NONZEROLPTR*	Global memory management	0	0	
GMEM_DISCARDED	GlobalFlag flag	4000	16384	
GMEM_LOCKCOUNT	GlobalFlag flag	FF	255	
GMEM_SWAPPED	GlobalFlag flag	8000	32768	
HS_BDIAGONAL	Hatch style	3	3	
HS_CROSS	Hatch style	4	4	
HS_DIAGCROSS	Hatch style	5	5	
HS_FDIAGONAL	Hatch style	2	2	
HS_HORIZONTAL	Hatch style	0	0	
HS_VERTICAL	Hatch style	1	1	
HCBT_MINMAX*	Hook code	1	1	
HCBT_MOVESIZE*	Hook code	0	0	
HCBT_OS	Hook code	2	2	
HC_ACTION*	Hook code	0	0	
HC_GETNEXT*	Hook code	1	1	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
HC LPFNNEXT*	Hook code	FFFF	-1	
HC LPLPFNNEXT*	Hook code	FFFE	-2	
HC NOREM*	Hook code	3	3	
HC SKIP*	Hook code	2	2	
MK CONTROL	Key state mask f/mouse msg.	8	8	
MK LBUTTON	Key state mask f/mouse msg.	1	1	
MK MBUTTON	Key state mask f/mouse msg.	10	16	
MK RBUTTON	Key state mask f/mouse msg.	2	2	
MK SHIFT	Key state mask f/mouse msg.	4	4	
LB CTLCODE	Listbox control	0	0	
LB ERR	Listbox control	FFFF	-1	
LB ERRSPACE	Listbox control	FFFE	-2	
LB OKAY	Listbox control	0	0	
LB ADDSTRING*	Listbox message	400	1024	
LB DELETESTRING*	Listbox message	402	1025	
LB DIR*	Listbox message	40D	1026	
LB GETCOUNT*	Listbox message	40B	1027	
LB GETCURSEL*	Listbox message	409	1028	
LB GETSEL*	Listbox message	408	1029	
LB GETTEXT*	Listbox message	407	1030	
LB GETTEXTLEN*	Listbox message	40A	1031	
LB GETTOPINDEX*	Listbox message	40E	1032	
LB INSERTSTRING*	Listbox message	401	1033	
LB MSGMAX*	Listbox message	40F	1034	
LB RESETCONTENT*	Listbox message	404	1	
LB SELECTSTRING*	Listbox message	40C	2	
LB SETCURSEL*	Listbox message	406	3	
LB SETSEL*	Listbox message	405	4	
LBN DBLCLK	Listbox notification code	2	2	
LBN ERRSPACE	Listbox notification code	FFFE	-2	
LBN SELCHANGE	Listbox notification code	1	1	
LBS MULTIPLESEL	Listbox style	8	8	
LBS NOREDRAW	Listbox style	4	4	
LBS NOTIFY	Listbox style	1	1	
LBS SORT	Listbox style	2	2	
LBS STANDARD*	Listbox style	F	15	
LMEM DISCARDABLE	Local memory management	F00	3840	
LMEM DISCARDED*	Local memory management	4000	16384	
LMEM FIXED	Local memory management	0	0	
LMEM LOCKCOUNT	Local memory management	FF	255	
LMEM MODIFY	Local memory management	80	128	
LMEM MOVEABLE	Local memory management	2	2	
LMEM NOCOMPACT	Local memory management	10	16	
LMEM NODISCARD	Local memory management	20	32	
LMEM ZEROINIT	Local memory management	40	64	
LN NOTIFY DISCARD	Local memory management	2	2	
LN NOTIFY MOVE	Local memory management	1	1	
LN NOTIFY OUTOFMEM	Local memory management	0	0	
ANSI CHARSET	Logical font constant	0	0	
CLIP_CHARACTER_PRECIS	Logical font constant	1	1	
CLIP_DEFAULT_PRECIS	Logical font constant	0	0	
CLIP_STROKE_PRECIS	Logical font constant	2	2	
DEFAULT_PITCH	Logical font constant	0	0	
DEFAULT_QUALITY	Logical font constant	0	0	
DRAFT_QUALITY	Logical font constant	1	1	
FIXED_PITCH	Logical font constant	1	1	
LF_FACESIZE	Logical font constant	20	32	
OEM_CHARSET	Logical font constant	FF	255	
OUT_CHARACTER_PRECIS	Logical font constant	2	2	
OUT_DEFAULT_PRECIS	Logical font constant	0	0	
OUT_STRING_PRECIS	Logical font constant	1	1	
OUT_STROKE_PRECIS	Logical font constant	3	3	
PROOF_QUALITY	Logical font constant	2	2	
SHIFTJIS_CHARSET*	Logical font constant	80	128	
VARIABLE_PITCH	Logical font constant	2	2	
MF_APPEND	MenuItem menu flag	100	256	
MF_BITMAP	MenuItem menu flag	4	4	
MF_BYCOMMAND	MenuItem menu flag	0	0	
MF_BYPOSITION	MenuItem menu flag	400	1024	
MF_CHANGE	MenuItem menu flag	80	128	
MF_CHECKED	MenuItem menu flag	8	8	
MF_DELETE	MenuItem menu flag	200	512	
MF_DISABLED	MenuItem menu flag	2	2	
MF_ENABLED	MenuItem menu flag	0	0	
MF_GRAYED	MenuItem menu flag	1	1	
MF_HELP*	MenuItem menu flag	4000	16384	
MF_HILITE	MenuItem menu flag	80	128	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
MF INSERT	MenuItem menu flag	0	0	
MF_MENUBARBREAK	MenuItem menu flag	20	32	
MF_MENUBREAK	MenuItem menu flag	40	64	
MF_MOUSESELECT*	MenuItem menu flag	8000	32768	
MF_POPUP	MenuItem menu flag	10	16	
MF_REMOVE*	MenuItem menu flag	1000	4096	
MF_SEPARATOR	MenuItem menu flag	800	2048	
MF_STRING	MenuItem menu flag	0	0	
MF_SYSMENU*	MenuItem menu flag	2000	8192	
MF_UNCHECKED	MenuItem menu flag	0	0	
MF_UNHILITE	MenuItem menu flag	0	0	
MB_ABORTRETRYIGNORE	MessageBox type flag	2	2	
MB_APPLMODAL	MessageBox type flag	0	0	
MB_DEFBUTTON1	MessageBox type flag	0	0	
MB_DEFBUTTON2	MessageBox type flag	100	256	
MB_DEFBUTTON3	MessageBox type flag	200	512	
MB_DEFMASK	MessageBox type flag	F00	3840	
MB_ICONASTERISK	MessageBox type flag	40	64	
MB_ICONEXCLAMATION	MessageBox type flag	30	48	
MB_ICONHAND	MessageBox type flag	10	16	
MB_ICONMASK	MessageBox type flag	F0	240	
MB_ICONQUESTION	MessageBox type flag	20	32	
MB_MISCMASK	MessageBox type flag	C000	49152	
MB_MODEMASK	MessageBox type flag	3000	12288	
MB_NOFOCUS	MessageBox type flag	8000	32768	
MB_OK	MessageBox type flag	0	0	
MB_OKCANCEL	MessageBox type flag	1	1	
MB_RETRYCANCEL	MessageBox type flag	5	5	
MB_SYSTEMMODAL	MessageBox type flag	1000	4096	
MB_TYPMASK	MessageBox type flag	F	15	
MB_YESNO	MessageBox type flag	4	4	
MB_YESNOCANCEL	MessageBox type flag	3	3	
DEVICEDATA	Metafile comment esc.	13	19	
SETENDCAP	Metafile comment esc.	15	21	
META_ARC*	Metafile function	817	2071	
META_BITBLT*	Metafile function	922	2338	
META_CHORD*	Metafile function	630	1584	
META_CREATEBITMAP*	Metafile function	6FE	1790	
META_CREATEBITMAPINDIRECT*	Metafile function	2FD	765	
META_CREATEBRUSH*	Metafile function	F8	248	
META_CREATEBRUSHINDIRECT*	Metafile function	2FC	764	
META_CREATEFONTINDIRECT*	Metafile function	2FB	763	
META_CREATEPATTERNBRUSH*	Metafile function	1F9	505	
META_CREATEPENDIRECT*	Metafile function	2FA	762	
META_CREATEREGION*	Metafile function	6FF	1791	
META_DRAWTEXT*	Metafile function	62F	1583	
META_ELLIPSE*	Metafile function	418	1048	
META_ESCAPE*	Metafile function	626	1574	
META_EXCLUDECLIPRECT*	Metafile function	415	1045	
META_FILLREGION*	Metafile function	228	552	
META_FLOODFILL*	Metafile function	419	1049	
META_FRAMEREGION*	Metafile function	429	1065	
META_INTERSECTCLIPRECT*	Metafile function	416	1046	
META_INVERTREGION*	Metafile function	12A	298	
META_LINETO*	Metafile function	213	531	
META_MOVETO*	Metafile function	214	532	
META_OFFSETCLIPRGN*	Metafile function	220	544	
META_OFFSETVIEWPORTORG*	Metafile function	211	529	
META_OFFSETWINDOWORG*	Metafile function	20F	527	
META_PAINTREGION*	Metafile function	12B	299	
META_PATBLT*	Metafile function	61D	1565	
META_PIE*	Metafile function	81A	2074	
META_POLYGON*	Metafile function	324	804	
META_POLYLINE*	Metafile function	325	805	
META_RECTANGLE*	Metafile function	41B	1051	
META_RESTOREDC*	Metafile function	127	295	
META_ROUNDRECT*	Metafile function	61C	1564	
META_SAVEDC*	Metafile function	1E	30	
META_SCALEVIEWPORTTEXT*	Metafile function	412	1042	
META_SCALEWINDOWEXT*	Metafile function	400	1024	
META_SELECTCLIPREGION*	Metafile function	12C	300	
META_SELECTOBJECT*	Metafile function	12D	301	
META_SETBKCOLOR*	Metafile function	201	513	
META_SETBKMODE*	Metafile function	102	258	
META_SETMAPMODE*	Metafile function	103	259	
META_SETPIXEL*	Metafile function	41F	1055	
META_SETPOLYFILLMODE*	Metafile function	106	262	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
META SETRELABS*	Metafile function	105	261	
META SETROP2*	Metafile function	104	260	
META SETSTRECTCHBLT*MODE*	Metafile function	107	263	
META SETTEXTALIGN*	Metafile function	12E	302	
META SETTEXTCHAREXTRA*	Metafile function	108	264	
META SETTEXTCOLOR*	Metafile function	209	521	
META SETTEXTJUSTIFICATION*	Metafile function	20A	522	
META SETVIEWPORTEXT*	Metafile function	20E	526	
META SETVIEWPORTORG*	Metafile function	20D	525	
META SETWINDOWEXT*	Metafile function	20C	524	
META SETWINDOWORG*	Metafile function	20B	523	
META STRETCHBLT*	Metafile function	B23	2851	
META TEXTOUT*	Metafile function	521	1313	
MA ACTIVATE*	Mouse activate return code	1	1	
MA ACTIVATEANDEAT*	Mouse activate return code	2	2	
MA NOACTIVATE*	Mouse activate return code	3	3	
OBJ BRUSH	Object definition	2	2	
OBJ PEN	Object definition	1	1	
OBM BTNCORNERS	OEM definition	7FF6	32758	
OBM BSIZE	OEM definition	7FF9	32761	
OBM CHECK	OEM definition	7FF8	32760	
OBM CHECKBOXES	OEM definition	7FF7	32759	
OBM CLOSE	OEM definition	7FFF	32767	
OBM DNARROW	OEM definition	7FFC	32764	
OBM LFARROW	OEM definition	7FFA	32762	
OBM REDUCE*	OEM definition	7FF5	32757	
OBM RESTORE*	OEM definition	7FF3	32755	
OBM RGARROW	OEM definition	7FFB	32763	
OBM SIZE	OEM definition	7FFE	32766	
OBM UPARROW	OEM definition	7FFD	32765	
OBM ZOOM*	OEM definition	7FF4	32756	
OCR CROSS	OEM definition	7F03	32515	
OCR IBEAM	OEM definition	7F01	32513	
OCR ICON	OEM definition	7F81	32641	
OCR NORMAL	OEM definition	7F00	32512	
OCR SIZE	OEM definition	7F80	32640	
OCR SIZEALL*	OEM definition	7F86	32646	
OCR SIZESW*	OEM definition	7F83	32643	
OCR SIZES*	OEM definition	7F85	32645	
OCR SIZENW*	OEM definition	7F82	32642	
OCR SIZEWE*	OEM definition	7F84	32644	
OCR UP	OEM definition	7F04	32516	
OCR WAIT	OEM definition	7F02	32514	
OIC BANG	OEM definition	7F03	32515	
OIC HAND	OEM definition	7F01	32513	
OIC NOTE	OEM definition	7F04	32516	
OIC QUES	OEM definition	7F02	32514	
OIC SAMPLE	OEM definition	7F00	32512	
OF CANCEL	OpenFile flag	800	2048	
OF CREATE	OpenFile flag	1000	4096	
OF DELETE	OpenFile flag	200	512	
OF EXIST	OpenFile flag	4000	16384	
OF PARSE	OpenFile flag	100	256	
OF PROMPT	OpenFile flag	2000	8192	
OF READ	OpenFile flag	0	0	
OF READWRITE	OpenFile flag	2	2	
OF REOPEN	OpenFile flag	8000	32768	
OF VERIFY	OpenFile flag	400	1024	
OF WRITE	OpenFile flag	1	1	
PM NOREMOVE*	Peekmessage options	0	0	
PM NOYIELD*	Peekmessage options	2	2	
PM REMOVE*	Peekmessage options	1	1	
PS DASH	Pen style	1	1	
PS DASHDOT	Pen style	3	3	
PS DASHDOTDOT	Pen style	4	4	
PS DOT	Pen style	2	2	
PS NULL	Pen style	5	5	
PS SOLID	Pen style	0	0	
ALTERNATE	Polyfill mode	1	1	
WINDING	Polyfill mode	2	2	
RT ACCELERATOR	Predefined resource type	9	9	MAKEINTRESOURCE (9)
RT BITMAP	Predefined resource type	2	2	MAKEINTRESOURCE (2)
RT CURSOR	Predefined resource type	1	1	MAKEINTRESOURCE (1)
RT DIALOG	Predefined resource type	5	5	MAKEINTRESOURCE (5)
RT FONT	Predefined resource type	8	8	MAKEINTRESOURCE (8)
RT FONDIR	Predefined resource type	7	7	MAKEINTRESOURCE (7)
RT ICON	Predefined resource type	3	3	MAKEINTRESOURCE (3)

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
RT MENU	Predefined resource type	4	4	MAKEINTRESOURCE (4)
RT_RCDATA*	Predefined resource type	A	10	MAKEINTRESOURCE(10)
RT_STRING	Predefined resource type	6	6	MAKEINTRESOURCE (6)
COMPLEXREGION	Region flag	3	3	
ERROR	Region flag	0	0	
NULLREGION	Region flag	1	1	
SIMPLEREGION	Region flag	2	2	
SB_BOTH*	Scroll bar constant	3	3	
SB_BOTTOM	Scroll bar constant	7	7	
SB_CTL	Scroll bar constant	2	2	
SB_ENDSCROLL	Scroll bar constant	8	8	
SB_HORZ	Scroll bar constant	0	0	
SB_LINEDOWN	Scroll bar constant	1	1	
SB_LINEUP	Scroll bar constant	0	0	
SB_PAGEDOWN	Scroll bar constant	3	3	
SB_PAGEUP	Scroll bar constant	2	2	
SB_THUMBPOSITION	Scroll bar constant	4	4	
SB_THUMBTRACK	Scroll bar constant	5	5	
SB_TOP	Scroll bar constant	6	6	
SB_VERT	Scroll bar constant	1	1	
SBS_BOTTOMALIGN*	Scroll bar style	4	4	
SBS_HORZ*	Scroll bar style	0	0	
SBS_LEFTALIGN*	Scroll bar style	2	2	
SBS_RIGHTALIGN*	Scroll bar style	4	4	
SBS_SIZEBOX*	Scroll bar style	8	8	
SBS_SIZEBOXBOTTOMRIGHTALIGN*	Scroll bar style	4	4	
SBS_SIZEBOXTOPLEFTALIGN*	Scroll bar style	2	2	
SBS_TOPALIGN*	Scroll bar style	2	2	
SBS_VERT*	Scroll bar style	1	1	
S_PERIOD1024	SetSoundNoise source	1	1	
S_PERIOD2048	SetSoundNoise source	2	2	
S_PERIOD512	SetSoundNoise source	0	0	
S_PERIODVOICE	SetSoundNoise source	3	3	
S_SERBDNT	SetSoundNoise source	FFF8	-5	
S_SERDCC	SetSoundNoise source	FFF9	-7	
S_SERDDR	SetSoundNoise source	FFF2	-14	
S_SERDFO	SetSoundNoise source	FFF3	-13	
S_SERD!N	SetSoundNoise source	FFFA	-6	
S_SERDMD	SetSoundNoise source	FFF6	-10	
S_SERDPT	SetSoundNoise source	FFF4	-12	
S_SERDSH	SetSoundNoise source	FFF5	-11	
S_SERDSR	SetSoundNoise source	FFF1	-15	
S_SERDST	SetSoundNoise source	FFF0	-16	
S_SERDTP	SetSoundNoise source	FFF8	-8	
S_SERDVL	SetSoundNoise source	FFF7	-9	
S_SERDVNA	SetSoundNoise source	FFF4	-12	
S_SERMACT	SetSoundNoise source	FFF4	-12	
S_SEROFM	SetSoundNoise source	FFFE	-2	
S_SERQFUL	SetSoundNoise source	FFFC	-4	
S_WHITE1024	SetSoundNoise source	5	5	
S_WHITE2048	SetSoundNoise source	6	6	
S_WHITE512	SetSoundNoise source	4	4	
S_WHITEVOICE	SetSoundNoise source	7	7	
SWP_DRAWFRAME*	SetWindow position flag	20	32	
SWP_HIDEWINDOW*	SetWindow position flag	80	128	
SWP_NOACTIVATE*	SetWindow position flag	10	16	
SWP_NOCOPYBITS*	SetWindow position flag	100	256	
SWP_NOMOVE*	SetWindow position flag	2	2	
SWP_NOREDRAW*	SetWindow position flag	8	8	
SWP_NOREPOSITION*	SetWindow position flag	200	512	
SWP_NOSIZE*	SetWindow position flag	1	1	
SWP_NOZORDER*	SetWindow position flag	4	4	
SWP_SHOWWINDOW*	SetWindow position flag	40	64	
WH_CALLWNDPROC	Setwindowshook code	4	4	
WH_GETMESSAGE	Setwindowshook code	3	3	
WH_JOURNALPLAYBACK	Setwindowshook code	1	1	
WH_JOURNALRECORD	Setwindowshook code	0	0	
WH_KEYBOARD	Setwindowshook code	2	2	
WH_MSGFILTER	Setwindowshook code	FFFF	-1	
HIDE_WINDOW	Showwindow command	0	0	
SHOW_FULLSCREEN	Showwindow command	3	3	
SHOW_ICONWINDOW	Showwindow command	2	2	
SHOW_OPENNOACTIVATE	Showwindow command	4	4	
SHOW_OPENWINDOW	Showwindow command	1	1	
SW_HIDE*	Showwindow message ID	0	0	
SW_MAXIMIZE*	Showwindow message ID	3	3	
SW_MINIMIZE*	Showwindow message ID	6	6	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
SW_NORMAL*	Showwindow message ID	1	1	
SW_OTHERUNZOOM	Showwindow message ID	4	4	
SW_OTHERZOOM	Showwindow message ID	2	2	
SW_PARENTCLOSING	Showwindow message ID	1	1	
SW_PARENTOPENING	Showwindow message ID	3	3	
SW_RESTORE*	Showwindow message ID	1	1	
SW_SHOW*	Showwindow message ID	5	5	
SW_SHOWMAXIMIZED*	Showwindow message ID	3	3	
SW_SHOWMINIMIZED*	Showwindow message ID	2	2	
SW_SHOWMINNOACTIVE*	Showwindow message ID	7	7	
SW_SHOWNA*	Showwindow message ID	8	8	
SW_SHOWNOACTIVE*	Showwindow message ID	4	4	
SW_SHOWNORMAL*	Showwindow message ID	1	1	
SIZEFULLSCREEN	Size message command	2	2	
SIZEICONIC	Size message command	1	1	
SIZENORMAL	Size message command	0	0	
SIZEZOOMHIDE	Size message command	4	4	
SIZEZOOMSHOW	Size message command	3	3	
SP_APPABORT	Spooler error code	FFFE	-2	
SP_ERROR	Spooler error code	FFFF	-1	
SP_NOTREPORTED	Spooler error code	4000	16384	
SP_OUTOFDISK	Spooler error code	FFFC	-4	
SP_OUTOFMEMORY	Spooler error code	FFF8	-8	
SP_USERABORT	Spooler error code	FFFD	-3	
PR_JOBSTATUS	Spooler wparam class	0	0	
IDC_ARROW	Standard cursor ID	7F00	32512	MAKEINTRESOURCE(32512)
IDC_CROSS	Standard cursor ID	7F03	32515	MAKEINTRESOURCE(32515)
IDC_IBEAM	Standard cursor ID	7F01	32513	MAKEINTRESOURCE(32513)
IDC_ICON	Standard cursor ID	7F81	32641	MAKEINTRESOURCE(32641)
IDC_SIZE	Standard cursor ID	7F80	32640	MAKEINTRESOURCE(32640)
IDC_SIZESW	Standard cursor ID	7F83	32643	
IDC_SIZENS	Standard cursor ID	7F85	32645	
IDC_SIZENWSE	Standard cursor ID	7F82	32642	
IDC_SIZEW	Standard cursor ID	7F84	32644	
IDC_UPARROW	Standard cursor ID	7F04	32516	MAKEINTRESOURCE(32516)
IDC_WAIT	Standard cursor ID	7F02	32514	MAKEINTRESOURCE(32514)
NULL	Standard definitions	0	0	
FALSE	Standard definitions	0	0	
TRUE	Standard definitions	1	1	
IDI_APPLICATION	Standard icon ID	7F00	32512	MAKEINTRESOURCE(32512)
IDI_ASTERISK	Standard icon ID	7F04	32516	MAKEINTRESOURCE(32516)
IDI_EXCLAMATION	Standard icon ID	7F03	32515	MAKEINTRESOURCE(32515)
IDI_HAND	Standard icon ID	7F01	32513	MAKEINTRESOURCE(32513)
IDI_QUESTION	Standard icon ID	7F02	32514	MAKEINTRESOURCE(32514)
VK_ADD	Standard set virtual key	6B	107	
VK_BACK	Standard set virtual key	8	8	
VK_CANCEL	Standard set virtual key	3	3	
VK_CAPITAL	Standard set virtual key	14	20	
VK_CLEAR	Standard set virtual key	C	12	
VK_CONTROL	Standard set virtual key	11	17	
VK_COPY	Standard set virtual key	2C	44	
VK_DECIMAL	Standard set virtual key	6E	110	
VK_DELETE	Standard set virtual key	2E	46	
VK_DIVIDE	Standard set virtual key	6F	111	
VK_DOWN	Standard set virtual key	28	40	
VK_END	Standard set virtual key	23	35	
VK_ESCAPE	Standard set virtual key	1B	27	
VK_EXECUTE	Standard set virtual key	2B	43	
VK_F1	Standard set virtual key	70	112	
VK_F10	Standard set virtual key	79	121	
VK_F11	Standard set virtual key	7A	122	
VK_F12	Standard set virtual key	7B	123	
VK_F13	Standard set virtual key	7C	124	
VK_F14	Standard set virtual key	7D	125	
VK_F15	Standard set virtual key	7E	126	
VK_F16	Standard set virtual key	7F	127	
VK_F2	Standard set virtual key	71	113	
VK_F3	Standard set virtual key	72	114	
VK_F4	Standard set virtual key	73	115	
VK_F5	Standard set virtual key	74	116	
VK_F6	Standard set virtual key	75	117	
VK_F7	Standard set virtual key	76	118	
VK_F8	Standard set virtual key	77	119	
VK_F9	Standard set virtual key	78	120	
VK_HELP	Standard set virtual key	2F	47	
VK_HOME	Standard set virtual key	24	36	
VK_INSERT	Standard set virtual key	2D	45	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
VK_LBUTTON	Standard set virtual key	1	1	
VK_LEFT	Standard set virtual key	25	37	
VK_MBUTTON	Standard set virtual key	4	4	
VK_MENU	Standard set virtual key	12	18	
VK_MULTIPLY	Standard set virtual key	6A	106	
VK_NEXT	Standard set virtual key	22	34	
VK_NUMLOCK	Standard set virtual key	90	144	
VK_NUMPAD0	Standard set virtual key	60	96	
VK_NUMPAD1	Standard set virtual key	61	97	
VK_NUMPAD2	Standard set virtual key	62	98	
VK_NUMPAD3	Standard set virtual key	63	99	
VK_NUMPAD4	Standard set virtual key	64	100	
VK_NUMPAD5	Standard set virtual key	65	101	
VK_NUMPAD6	Standard set virtual key	66	102	
VK_NUMPAD7	Standard set virtual key	67	103	
VK_NUMPAD8	Standard set virtual key	68	104	
VK_NUMPAD9	Standard set virtual key	69	105	
VK_PAUSE	Standard set virtual key	13	19	
VK_PRINT	Standard set virtual key	2A	42	
VK_PRIOR	Standard set virtual key	21	33	
VK_RBUTTON	Standard set virtual key	2	2	
VK_RETURN	Standard set virtual key	D	13	
VK_RIGHT	Standard set virtual key	27	39	
VK_SELECT	Standard set virtual key	29	41	
VK_SEPARATOR	Standard set virtual key	6C	108	
VK_SHIFT	Standard set virtual key	10	16	
VK_SPACE	Standard set virtual key	20	32	
VK_SUBTRACT	Standard set virtual key	6D	109	
VK_TAB	Standard set virtual key	9	9	
VK_UP	Standard set virtual key	26	38	
SS_BLACKFRAME	Static control constant	7	7	
SS_BLACKRECT	Static control constant	4	4	
SS_CENTER	Static control constant	1	1	
SS_GRAYFRAME	Static control constant	8	8	
SS_GRAYRECT	Static control constant	5	5	
SS_ICON	Static control constant	3	3	
SS_LEFT	Static control constant	0	0	
SS_NOPREFIX*	Static control constant	80	128	
SS_RIGHT	Static control constant	2	2	
SS_SIMPLE*	Static control constant	13	11	
SS_USERITEM	Static control constant	A	10	
SS_WHITEFRAME	Static control constant	9	9	
SS_WHERECT	Static control constant	6	6	
ANSI_FIXED_FONT	Stock logical object	B	11	
ANSI_VAR_FONT	Stock logical object	C	12	
BLACK_BRUSH	Stock logical object	4	4	
BLACK_PEN	Stock logical object	7	7	
DEVICEDEFAULT_FONT	Stock logical object	E	14	
DKGRAY_BRUSH	Stock logical object	3	3	
GRAY_BRUSH	Stock logical object	2	2	
HOLLOW_BRUSH	Stock logical object	5	5	Defined as NULL_BRUSH
LTGRAY_BRUSH	Stock logical object	1	1	
NULL_BRUSH	Stock logical object	5	5	
NULL_PEN	Stock logical object	8	8	
OEM_FIXED_FONT	Stock logical object	A	10	
SYSTEM_FONT	Stock logical object	D	13	
WHITE_BRUSH	Stock logical object	0	0	
WHITE_PEN	Stock logical object	6	6	
BLACKONWHITE	Stretchblt mode	1	1	
COLORONCOLOR	Stretchblt mode	3	3	
WHITEONBLACK	Stretchblt mode	2	2	
SC_ARRANGE*	System menu command	F110	61712	
SC_CLOSE	System menu command	F060	61536	
SC_HSCROLL	System menu command	F080	61568	
SC_ICON	System menu command	F020	61472	
SC_KEYMENU	System menu command	F100	61696	
SC_MAXIMIZE*	System menu command	F030	61488	
SC_MINIMIZE*	System menu command	F020	61472	
SC_MOUSEMENU	System menu command	F090	61584	
SC_MOVE	System menu command	F010	61456	
SC_NEXTWINDOW	System menu command	F040	61504	
SC_PREVWINDOW	System menu command	F050	61520	
SC_RESTORE*	System menu command	F120	61728	
SC_SIZE	System menu command	F000	61440	
SC_VSCROLL	System menu command	F070	61552	
SC_ZOOM	System menu command	F030	61488	
BLACKNESS	Ternary raster op	0000 0042H	66	Dest = BLACK

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
DSTINVERT	Ternary raster op	0055 0009H	5570569	Dest = (not dest)
MERGECOPY	Ternary raster op	00C0 00CA	12583114	Dest = (source AND pattern)
MERGEPAINT	Ternary raster op	00BB 0226	12255782	Dest = (not source) OR dest
NOTSRCOCOPY	Ternary raster op	0033 0008	3342344	Dest = (not source)
NOTSRCERASE	Ternary raster op	0011 00A6	1114278	Dest = (not source) AND (not dest)
PATCOPY	Ternary raster op	00F0 0021	15728673	Dest = pattern
PATINVERT	Ternary raster op	005A 0049	5898313	Dest = pattern XOR dest
PATPAINT	Ternary raster op	00FB 0A09	16452105	Dest = DPSnoo
SRCAND	Ternary raster op	0088 00C6	8913094	Dest = source AND dest
SRCOCOPY	Ternary raster op	00CC 0020	13369376	Dest=source
SRCERASE	Ternary raster op	0044 0328	4457256	Dest = source AND (not dest)
SRCINVERT	Ternary raster op	0066 0046	6684742	Dest = source XOR dest
SRCPAINT	Ternary raster op	00EE 0086	15597702	Dest=source OR dest
WHITENESS	Ternary raster op	00FF 0062	16711778	Dest = WHITE
TA_BASELINE*	Text alignment option	18	24	
TA_BOTTOM*	Text alignment option	8	8	
TA_CENTER*	Text alignment option	6	6	
TA_LEFT*	Text alignment option	0	0	
TA_NOUPDATECP*	Text alignment option	0	0	
TA_RIGHT*	Text alignment option	2	2	
TA_TOP*	Text alignment option	0	0	
TA_UPDATECP*	Text alignment option	1	1	
BN_CLICKED	User button notification code	0	0	
BN_DISABLE	User button notification code	4	4	
BN_HILITE	User button notification code	2	2	
BN_PAINT	User button notification code	1	1	
BN_UNHILITE	User button notification code	3	3	
VK_ACCEPT*	Virtual key	1E	30	
VK_CONVERT*	Virtual key	1C	28	
VK_HIRAGANA*	Virtual key	18	24	
VK_KANA*	Virtual key	15	21	
VK_KANJI*	Virtual key	19	25	
VK_MODECHANGE*	Virtual key	1F	31	
VK_NONCONVERT*	Virtual key	1D	29	
VK_ROMAJI*	Virtual key	16	22	
VK_ZENKAKU*	Virtual key	17	23	
S_ALLTHRESHOLD*	WaitSoundState constant	2	2	
S_QUEUEEMPTY	WaitSoundState constant	0	0	
S_THRESHOLD	WaitSoundState constant	1	1	
GWL_STYLE	Window field offset	FFF0	-16	
GWL_WNDPROC	Window field offset	FFFC	-4	
GWW_HINSTANCE	Window field offset	FFFA	-6	
GWW_HWNDPARENT	Window field offset	FFF8	-8	
GWW_HWNDTEXT	Window field offset	FFF6	-10	
GWW_ID	Window field offset	FFF4	-12	
WH_SYMSGFILTER*	Window hook	6	6	
WH_WINDOWMGR*	Window hook	7	7	
WH_CBT*	Window hook	5	5	
WC_DEFWINDOWPROC*	Window manager hook code	3	3	
WC_DRAWCAPTION*	Window manager hook code	7	7	
WC_INIT*	Window manager hook code	1	1	
WC_MINMAX*	Window manager hook code	4	4	
WC_MOVE*	Window manager hook code	5	5	
WC_SIZE*	Window manager hook code	6	6	
WC_SWP*	Window manager hook code	2	2	
WM_ACTIVATE	Window procedure message ID	6	6	
WM_ACTIVATEAPP	Window procedure message ID	1C	28	
WM_ASKCBFORMATNAME	Window procedure message ID	30C	780	
WM_CANCELMODE	Window procedure message ID	1F	31	
WM_CHANGECHAIN	Window procedure message ID	30D	781	
WM_CHAR	Window procedure message ID	102	258	
WM_CHILDACTIVATE*	Window procedure message ID	22	34	
WM_CLEAR	Window procedure message ID	303	771	
WM_CLOSE	Window procedure message ID	10	16	
WM_COMMAND	Window procedure message ID	111	273	
WM_CONVERTREQUEST	Window procedure message ID	10A	266	
WM_CONVERTRESULT	Window procedure message ID	10B	267	
WM_COPY	Window procedure message ID	301	769	
WM_CREATE	Window procedure message ID	1	1	
WM_CTLCOLOR	Window procedure message ID	19	25	
WM_CUT	Window procedure message ID	300	768	
WM_DEADCHAR	Window procedure message ID	103	259	
WM_DESTROY	Window procedure message ID	2	2	
WM_DESTROYCLIPBOARD	Window procedure message ID	307	775	
WM_DEVMODECHANGE	Window procedure message ID	1B	27	
WM_DRAWCLIPBOARD	Window procedure message ID	308	776	
WM_ENABLE	Window procedure message ID	A	10	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
WM_ENDSESSION	Window procedure message ID	16	22	
WM_ENTERIDLE	Window procedure message ID	121	289	
WM_ERASEBKGD	Window procedure message ID	14	20	
WM_FONTCHANGE	Window procedure message ID	1D	29	
WM_GETDLGCODE	Window procedure message ID	87	135	
WM_GETMINMAXINFO*	Window procedure message ID	24	36	
WM_GETTEXT	Window procedure message ID	D	13	
WM_GETTEXTLENGTH	Window procedure message ID	E	14	
WM_HSCROLL	Window procedure message ID	114	276	
WM_HSCROLLCLIPBOARD	Window procedure message ID	30E	782	
WM_ICONERASEBKGD*	Window procedure message ID	27	39	
WM_INITDIALOG	Window procedure message ID	110	272	
WM_INITMENU	Window procedure message ID	116	278	
WM_INITMENUPOPUP	Window procedure message ID	117	279	
WM_KANJIFIRST	Window procedure message ID	280	640	
WM_KANJILAST	Window procedure message ID	29F	671	
WM_KEYDOWN	Window procedure message ID	100	256	
WM_KEYFIRST	Window procedure message ID	100	256	
WM_KEYLAST	Window procedure message ID	107	263	
WM_KEYUP	Window procedure message ID	101	257	
WM_KILLFOCUS	Window procedure message ID	8	8	
WM_LBUTTONDOWNLCLK	Window procedure message ID	203	515	
WM_LBUTTONDOWNN	Window procedure message ID	201	513	
WM_LBUTTONUP	Window procedure message ID	202	514	
WM_MBUTTONDOWNLCLK	Window procedure message ID	209	521	
WM_MBUTTONDOWNN	Window procedure message ID	207	519	
WM_MBUTTONUP	Window procedure message ID	208	520	
WM_MENUCLEAR*	Window procedure message ID	120	521	
WM_MENUSELECT*	Window procedure message ID	11F	522	
WM_MOUSEACTIVATE*	Window procedure message ID	21	33	
WM_MOUSEFIRST	Window procedure message ID	200	512	
WM_MOUSELAST	Window procedure message ID	209	521	
WM_MOUSEMOVE	Window procedure message ID	200	512	
WM_MOVE	Window procedure message ID	3	3	
WM_NCACTIVATE	Window procedure message ID	86	134	
WM_NCCALCSIZE	Window procedure message ID	83	131	
WM_NCCREATE	Window procedure message ID	81	129	
WM_NCDESTROY	Window procedure message ID	82	130	
WM_NCHITTEST	Window procedure message ID	84	132	
WM_NCLBUTTONDOWNLCLK	Window procedure message ID	A3	163	
WM_NCLBUTTONDOWNN	Window procedure message ID	A1	161	
WM_NCLBUTTONUP	Window procedure message ID	A2	162	
WM_NCMBUTTONDBLCLK	Window procedure message ID	A9	169	
WM_NCMBUTTONDOWN	Window procedure message ID	A7	167	
WM_NCMBUTTONUP	Window procedure message ID	A8	168	
WM_NCMOUSEMOVE	Window procedure message ID	A0	160	
WM_NCPAINT	Window procedure message ID	85	133	
WM_NCRBUTTONDOWNLCLK	Window procedure message ID	A6	166	
WM_NCRBUTTONDOWNN	Window procedure message ID	A4	164	
WM_NCRBUTTONUP	Window procedure message ID	A5	165	
WM_NEXTDLGCTL*	Window procedure message ID	28	40	
WM_NULL	Window procedure message ID	0	0	
WM_PAINT	Window procedure message ID	F	15	
WM_PAINTCLIPBOARD	Window procedure message ID	309	777	
WM_PAINTICON*	Window procedure message ID	26	38	
WM_PASTE	Window procedure message ID	302	770	
WM_QUERYENDSESSION	Window procedure message ID	11	17	
WM_QUERYOPEN	Window procedure message ID	13	19	
WM_QUEUESYNC*	Window procedure message ID	23	35	
WM_QUIT	Window procedure message ID	12	18	
WM_RBUTTONDOWNLCLK	Window procedure message ID	206	518	
WM_RBUTTONDOWNN	Window procedure message ID	204	516	
WM_RBUTTONUP	Window procedure message ID	205	517	
WM_RENDERALLFORMATS	Window procedure message ID	308	774	
WM_RENDERFORMAT	Window procedure message ID	305	773	
WM_SETCURSOR*	Window procedure message ID	20	32	
WM_SETFOCUS	Window procedure message ID	7	7	
WM_SETREDRAW	Window procedure message ID	B	11	
WM_SETTEXT	Window procedure message ID	C	12	
WM_SETVISIBLE	Window procedure message ID	9	9	
WM_SHOWWINDOW	Window procedure message ID	18	24	
WM_SIZE	Window procedure message ID	5	5	
WM_SIZECLIPBOARD	Window procedure message ID	30B	779	
WM_SIZEWAIT	Window procedure message ID	4	4	
WM_SPOOLERSTATUS	Window procedure message ID	2A	42	
WM_SYNCPAINT*	Window procedure message ID	88	136	
WM_SYNCTASK*	Window procedure message ID	89	137	

(Continued)

Table 6.38. Continued

Defined Name	Used As	Hex Value	Decimal Value	Comments
WM_SYSCHAR	Window procedure message ID	106	262	
WM_SYSCOLORCHANGE	Window procedure message ID	15	21	
WM_SYSCOMMAND	Window procedure message ID	112	274	
WM_SYSDEADCHAR	Window procedure message ID	107	263	
WM_SYSKEYDOWN	Window procedure message ID	104	260	
WM_SYSKEYUP	Window procedure message ID	105	261	
WM_SYSTEMERROR	Window procedure message ID	17	23	
WM_SYSTIMER	Window procedure message ID	118	280	
WM_TIMECHANGE	Window procedure message ID	1E	30	
WM_TIMER	Window procedure message ID	113	275	
WM_UNDO	Window procedure message ID	304	772	
WM_USER	Window procedure message ID	400	1024	First application window message
WM_VSCROLL	Window procedure message ID	115	277	
WM_VSCROLLCLIPBOARD	Window procedure message ID	30A	778	
WM_WININICHANGE	Window procedure message ID	1A	26	
WM_YOICHAR	Window procedure message ID	108	264	
WS_BORDER	Window style	0080 0000	8388608	
WS_CAPTION	Window style	00C0 0000	12582912	
WS_CHILD	Window style	4000 0000	1073741824	
WS_CHILDWINDOW*	Window style	4000 0000	1073741824	
WS_CLIPCHILDREN	Window style	0200 0000	33554432	
WS_CLIPSIBLINGS	Window style	0400 0000	67108864	
WS_DISABLED	Window style	0800 0000	13421728	
WS_DLGFRAE	Window style	0040 0000	4194304	
WS_GROUP	Window style	0002 0000	131072	
WS_HSCROLL	Window style	0010 0000	1048576	
WS_ICONIC	Window style	2000 0000	536870912	Defined as WS_MINIMIZE
WS_ICONICPOPUP*	Window style	C000 0000	3221225472	
WS_MAXIMIZE*	Window style	0100 0000	16777216	
WS_MAXIMIZEBOX*	Window style	0001 0000	65536	
WS_MINIMIZE	Window style	2000 0000	536870912	
WS_MINIMIZEBOX*	Window style	0002 0000	131072	
WS_OVERLAPPED*	Window style	0	0	
WS_OVERLAPPEDWINDOW*	Window style	00CC 0000	13369344	
WS_POPUP	Window style	8000 0000	-2147483648	
WS_POPUPWINDOW*	Window style	8088 0000	2156396544	
WS_SIZEBOX	Window style	0004 0000	262144	
WS_SYSMENU	Window style	0008 0000	524288	
WS_TABSTOP	Window style	0001 0000	65536	
WS_THICKFRAME*	Window style	0004 0000	262144	
WS_TILED	Window style	0	0	
WS_TILEDWINDOW*	Window style	00CC 0000	13369344	
WS_VISIBLE	Window style	1000 0000	268435456	
WS_VSCROLL	Window style	0020 0000	2097152	
HTBOTTOM*	Winwhere area code	F	15	
HTBOTTOMLEFT*	Winwhere area code	10	16	
HTBOTTOMRIGHT*	Winwhere area code	11	17	
HTCAPTION	Winwhere area code	2	2	
HTCLIENT	Winwhere area code	1	1	
HTERROR	Winwhere area code	FFFE	-2	
HTGROWBOX	Winwhere area code	4	4	
HTHSCROLL	Winwhere area code	6	6	
HTLEFT*	Winwhere area code	A	10	
HTMENU	Winwhere area code	5	5	
HTNOWHERE	Winwhere area code	0	0	
HTREDUCE*	Winwhere area code	8	8	
HTRIGHT*	Winwhere area code	B	11	
HTSIZE*	Winwhere area code	4	4	
HTSIZEFIRST*	Winwhere area code	A	10	
HTSIZELAST*	Winwhere area code	11	17	
HTSYSMENU	Winwhere area code	3	3	
HTTOP*	Winwhere area code	C	12	
HTTOPLEFT*	Winwhere area code	D	13	
HTTOPRIGHT*	Winwhere area code	E	14	
HTTRANSPARENT	Winwhere area code	FFFF	-1	
HTVSCROLL	Winwhere area code	7	7	
HTZOOM*	Winwhere area code	9	9	
ASPECT_FILTERING		1	1	
ST_BEGINSWP*		0	0	
ST_ENDSWP*		1	1	

**Version Info:** \*Applies to all versions of Windows beginning with 2.0

**Source:** WINDOWS.H file in development kit

**See Also:** 6.37. Include File Constants Definitions by Name

**6.39. BITMAP STRUCTURE FORMAT**

<i>Field Type</i>	<i>Argument Type</i>	<i>Description</i>	<i>Restrictions on Allowable Values</i>
Short	bmType	Bitmap type	Must be 0 for logical bitmaps
Short	bmWidth	Width of bitmap in pixels	Must be greater than 0
Short	bmHeight	Height of bitmap in raster lines	Must be greater than 0
Short	bmWidthBytes	Number of bytes per raster line	Must be an even number
BYTE	bmPlanes	Points to number of color planes in bitmap	
BYTE	bmBitsPixel	Points to number of adjacent color bits on each plane	
LPSTR	bmBits	Points to bitmap	Long pointer to array of BYTE values comprising bitmap

**Notes:**

- C is case sensitive
- Numbers in parentheses show actual values

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 609 to 611

**See Also:** 1.17. Common String Formats

**6.40. COMSTAT STRUCTURE FORMAT**

<i>Field Type</i>	<i>Argument Type</i>	<i>Description</i>
BYTE	fCtsHold	Waiting for CTS?
BYTE	fDsrHold	Waiting for DSR?
BYTE	fRtsdHold	Waiting for received signal detect?
BYTE	fXoffHold	Waiting due to received XOFF?
BYTE	fXoffSent	Waiting due to sent XOFF?
BYTE	fEof	Has EOF been received?
BYTE	fTxim	Send char immediately?
WORD	cbInQue	Number of characters in receive queue
WORD	cbOutQue	Number of characters in transmit queue

**Notes:**

- C is case sensitive
- Numbers in parentheses show actual values

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 611 to 612

**6.41. CREATESTRUCT STRUCTURE FORMAT**

<i>Field Type</i>	<i>Argument Type</i>	<i>Description</i>	<i>Restrictions on Allowable Values</i>
LPSTR	lpCreateParams	Pointer to data for window creation parameters	
HANDLE	hInstance	Module instance handle of module owning new window	
HANDLE	hMenu	Handle of menu to be used by new window	
HWND	hwndParent	Window handle of window opening the new window	NULL=top-level window
int	cy	Height of new window	
int	cx	Width column of new window (child and popup only)	
int	y	y coordinate of upper-left corner of new window	Relative to parent (if new is child)
int	x	x coordinate of upper-left corner of new window	Relative to parent (if new is child)
long	style	New window's style	
LPSTR	lpzName	New window's name	Pointer to ASCII string
LPSTR	lpzClass	New window's class name	Pointer to ASCII string

**Notes:** C is case sensitive

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 612 to 613

**See Also:** 1.17. Common String Formats

## 6.42. DCB STRUCTURE FORMAT

Field Type	Argument Type	Description	Restrictions on Allowable Values
BYTE	Id	Communication device ID	Set by device driver; sig. bit set=parallel device
WORD	BaudRate	Baud rate	
BYTE	ByteSize	Number of bits in transmitted char	Must in range 4 to 8
BYTE	Parity	Parity scheme to use	Must be one of: NOPARITY (0) ODDPARITY (1) EVENPARITY (2) MARKPARITY (3) SPACEPARITY (4)
BYTE	StopBits	Number of stop bits in transmitted char	Must be one of: ONESTOPBIT (0) ONE5STOPBITS (1) TWO5STOPBITS (2)
WORD	RlsTimeout	Milliseconds to wait for CD to go high	
WORD	CtsTimeout	Milliseconds to wait for CTS to go high	
WORD	DsrTimeout	Milliseconds to wait for DSR to go high	
BYTE	Bit 7:fBinary Bit 6:fRtsDisable Bit 5:fParity Bit 4:fOutxCtsFlow Bit 3:fOutxDsrFlow Bits 1-2: fDummy Bit 0:fDtrDisable	Is binary mode? Is RTS disabled? Is Parity checking enabled? Monitor CTS for output flow control? Monitor DSR for output flow control? Place holder only Is DTR enabled?	0=ASCII mode; 1=binary mode 0=RTS enabled; 1=RTS disabled 0=parity not checked; 1=parity enabled 0=don't monitor CTS; 1=monitor CTS 0=don't monitor DSR; 1=monitor DSR 0=DTR enabled; 1=DTR not enabled
BYTE	Bit 7:fOutX Bit 6:flnX Bit 5:fPeChar Bit 4:fNull Bit 3:fChEvt Bit 2:fDtrFlow Bit 1:fRtsFlow Bit 0:fDummy2	Use XON/XOFF during transmission? Use XON/XOFF during reception? Replace parity chars with PeChar? Discard NULL characters? Flag EvtChar as an event? Monitor DTR for input flow control? Monitor RTS for input flow control? Place holder only	0=don't use; 1=use XON/XOFF 0=don't use; 1=use XON/XOFF 0=don't replace; 1=replace chars with parity error 0=don't discard; 1=discard NULL characters 0=don't flag; 1=EvtChar indicates event 0=don't monitor DTR; 1=monitor DTR 0=don't monitor RTS; 1=monitor RTS
Char	XonChar	XON character for transmit & receive	ASCII value
Char	XoffChar	XOFF character for transmit & receive	ASCII value
WORD	XonLim	Min. chars in receive queue before XON	
WORD	XoffLim	Max. chars in receive queue before XOFF	
Char	PeChar	Character that replaces parity errors	ASCII value
Char	EofChar	Character that signals an event	ASCII value
Char	EvtChar	Character that signals end-of-data	ASCII value
WORD	TxDelay	Min. milliseconds between transmissions	

**Notes:** •C is case sensitive  
•Numbers in parentheses show actual values

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 613 to 617

**See Also:** 1.17. Common String Formats

**6.43. DLGTEMPLATE STRUCTURE FORMAT**

**DLGTEMPLATE Header:**

Field Type	Argument Type	Description	Restrictions on Allowable Values
Long	dtStyle	Style of dialog box	
Byte	dtItemCount	Number of items in dialog box (controls)	
Int	dtX	x-coordinate of upper-left corner of box	
Int	dtY	y-coordinate of upper-left corner of box	
Int	dtCX	x-extent of the dialog box	
Int	dtCY	y-extent of the dialog box	
Char	dtResourceName[]	Name of application's resource file	ASCIIZ string
Char	dtClassName[]	Window's class name	ASCIIZ string
Char	dtCaptionText[]	Caption string for dialog box	ASCIIZ string

**Item List (of Controls) Follows Header with Each Item Containing:**

Field Type	Argument Type	Description	Restrictions on Allowable Values
Int	dtiIX	x-coordinate of upper-left corner of item	(Relative to origin of box)
Int	dtiY	y-coordinate of upper-left corner of item	(Relative to origin of box)
Int	dtiCX	x-extent of item	
Int	dtiCY	y-extent of item	
Int	dtiID	Dialog item ID number	
Long	dtiStyle	Style of the dialog item	
Char	dtiText	Text for the item (if any)	ASCIIZ string
BYTE	dtiInfo	Number of bytes to next item in structure	

**Version Info:** First defined in Windows 2.0

**Notes:** C is case sensitive

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 617 to 618

**6.44. EXTTEXTMETRIC STRUCTURE FORMAT**

Field Type	Argument Type	Description	Restrictions on Allowable Values
Short	etmSize	Size of EXTTEXTMETRIC structure	
Short	etmPointSize	Font's point size in twips	
Short	etmOrientation	Font orientation	1=portrait, 2=landscape, 0=either
Short	etmMasterHeight	Font height in device units	
Short	etmMinScale	Mmin range of device units for font	
Short	etmMaxScale	Mmax range of device units for font	
Short	etmMasterUnits	Number of units per em	
Short	etmCapHeight	Height of uppercase letters	In font units, typically height of 'H'
Short	etmXHeight	Height of lowercase letters	In font units, typically height of 'x'
Short	etmLowerCaseAscent	Distance ascenders above baseline	In font units, typically ascent of 'd'
Short	etmUpperCaseDescent	Distance descenders below baseline	In font units, typically descent of 'p'
Short	etmSlant	Angle counterclockwise from vert.	In degrees
Short	etmSuperScript	Distance above baseline	Specified as negative offset
Short	etmSubScript	Distance below baseline	Specified as positive offset
Short	etmSuperScriptSize	Recommended size of superscripts	
Short	etmSubScriptSize	Recommended size of subscripts	
Short	etmUnderlineOffset	Distance below baseline to top of line	
Short	etmUnderlineWidth	Thickness of underline	
Short	etmDoubleUpperUnderlineOffset	Distance below baseline to top of line	
Short	etmDoubleLowerUnderlineOffset	Distance below baseline to top of line	
Short	etmDoubleUpperUnderlineWidth	Thickness of underline	
Short	etmDoubleLowerUnderlineWidth	Thickness of underline	
Short	etmStrikeOutOffset	Distance above baseline to strikeout	
Short	etmStrikeOutWidth	Thickness of strikeout line	
Short	etmNKernPairs	Number of kerned pairs in font	
Short	etmNKernTracks	Number of kerning tracks defined for font	

**Notes:** C is case sensitive

**Source:** Microsoft Windows Reference Update 1.0, pages 46 to 48  
(Not documented in Microsoft Windows SDK Programmer's Reference 2.0)

6.45. HANDLETABLE STRUCTURE FORMAT

**DLGTEMPLATE Header:**

Field Type	Argument Type	Description	Restrictions on Allowable Values
HANDLE	objectHandle[1]	Array of handles	(Each handle contains address and description of GDI object)

**Version Info:** First defined in Windows 2.0

**Notes:** C is case sensitive

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 619

6.46. KERNPAIR STRUCTURE FORMAT

Field Type	Argument Type	Description	Restrictions on Allowable Values
BYTE*	letter1	First letter of kerning pair	ASCII character code
BYTE*	letter2	Second letter of kerning pair	ASCII character code
short	kernAmount	Amount that pair will be kerned	Generally a negative value

**Notes:**

- C is case sensitive
- Numbers in parentheses show actual values
- \*Note that the first two bytes of KERNPAIR are defined as a union, which may contain either two individual bytes, as shown here, or a single WORD, in which case letters are reversed in byte order

**Source:** Microsoft Windows Reference Manual Update 1.0, page 49  
(Not documented in Microsoft Windows Programmer's Reference 2.0)

**See Also:** 1.21. ASCII Character Set

6.47. KERNTTRACK STRUCTURE FORMAT

Field Type	Argument Type	Description	Restrictions on Allowable Values
Short	degree	Controls amount of track kerning	Increasing negative increases track kerning
Short	minSize	Minimum font size to apply track kerning	
Short	minAmount	Amount of track kerning to apply to fonts smaller than min size	
Short	maxSize	Maximum font size to apply track kerning	
Short	maxAmount	Amount of track kerning to apply to fonts larger than max size	

**Notes:** C is case sensitive

**Source:** Microsoft Windows Reference Update 1.0, pages 50 to 51  
(Not documented in Microsoft Windows SDK Programmer's Reference 2.0)

**See Also:** 1.17. Common String Formats

6.48. LOGBRUSH STRUCTURE FORMAT

Field Type	Argument Type	Description	Restrictions on Allowable Values
WORD	lbStyle	Brush style	Must be one of following: BS_SOLID (0) BS_HOLLOW (1) BS_HATCHED (2) BS_PATTERN (3) BS_INDEXED (4)
DWORD	lbColor	Brush color	Must be RGB color value*
Short int	lbHatch	Brush hatch style	If lbStyle=BS_PATTERN, must be handle to pattern bitmap If lbStyle=BS_SOLID or BS_HOLLOW, lbHatch is ignored Otherwise must be: HS_HORIZONTAL (0) ----- HS_VERTICAL (1)       HS_FDIAGONAL (2) ///// HS_BDIAGONAL (3) \\\\\ HS_CROSS (4) ++++ HS_DIAGCROSS (5) xxxxx

**Notes:** C is case sensitive

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 619 to 620

**See Also:** 1.17. Common String Formats

6.49. LOGFONT STRUCTURE FORMAT

Field Type	Argument Type	Description	Restrictions on Allowable Values
Short	lfHeight	Font height in user units	0=use reasonable size; <0 transform to device units
Short	lfWidth	Font width in user units	0=match aspect ratio against digitization aspect ratio
Short	lfEscapement	Angle between line origins and x-axis	In tenths of degree; measured counterclockwise from x-axis
Short	lfOrientation	Angle between char baseline and x-axis	In tenths of degree; measured counterclockwise from x-axis
Short	lfWeight	Font weight in inked pixels per .1000	400=normal, 700=bold, 0=use default weight
BYTE	lfItalic	Is font italic?	0=not italic; non-zero = italic
BYTE	lfUnderline	Is font underlined?	0=not underlined; non-zero = underlined
BYTE	lfStrikeOut	Is font stricken out?	0=not stricken; non-zero = stricken out
BYTE	lfCharSet	Character set to use for font	Must be either ANSI-CHARSET (0) or OEM_CHARSET (255)
BYTE	lfOutPrecision	Font's output precision	Must be OUT_DEFAULT_PRECIS
BYTE	lfClipPrecision	Font's clipping precision	Must be OUT_DEFAULT_PRECIS
BYTE	lfQuality	Font's output quality	Must be one of: PROOF_QUALITY (2) DRAFT_QUALITY (1) DEFAULT_QUALITY (0)
BYTE	lfPitchAndFamily	Font's pitch and family type	Pitch is indicated by low-order two bits Pitch must be one of: DEFAULT_PITCH (0) FIXED_PITCH (1) VARIABLE_PITCH (2) Font family is indicated by high-order four bits Family must be one of: FF_DONTCARE (0) FF_ROMAN (1) FF_SWISS (2) FF_MODERN (3) FF_SCRIPT (4) FF_DECORATIVE (5)
BYTE	lfFaceName[LF_FACESIZE]	Font's typeface name	Points to ASCII string; if NULL uses default typeface

**Notes:**            •C is case sensitive  
                      •Numbers in parentheses show actual values

**Source:**           Microsoft Windows SDK Programmer's Reference 2.0, pages 620 to 624

**See Also:**        1.17. Common String Formats

6.50. LOGPEN STRUCTURE FORMAT

Field Type	Argument Type	Description	Restrictions on Allowable Values
WORD	lopnStyle	Pen type	Must be one of following: 0 (solid line) 1 (dashed line) 2 (dotted line) 3 (dash-dot line) 4 (dash-dot-dot line) 5 (null line; invisible)
POINT	lopnWidth	Pen width	In logical units; 0=one pixel on raster devices
DWORD	lopnColor	Pen color	Must be RGB color value

**Notes:**            C is case sensitive

**Source:**           Microsoft Windows SDK Programmer's Reference 2.0, page 624

6.51. MENUITEMTEMPLATE STRUCTURE FORMAT

**DLGTEMPLATE Header:**

Field Type	Argument Type	Description	Restrictions on Allowable Values
BYTE	mtOption	Predefined menu option	One of the following options: GRAYED INACTIVE HELP CHECKED POPUP MENUBREAKBAR MENUBREAK END
WORD	mtID	ID code for menu item	(Must be non-popup menu item)
LPSTR	mtString	Name of menu item	ASCII string

**Version Info:**    First defined in Windows 2.0

**Notes:**            C is case sensitive

**Source:**           Microsoft Windows SDK Programmer's Reference 2.0, pages 625 to 626

**6.52. METAFILEPICT STRUCTURE FORMAT**

<i>Field Type</i>	<i>Argument Type</i>	<i>Description</i>
Int	mm	Mapping mode picture was drawn in
Int	xExt	x width of rectangle for picture*
Int	yExt	y height of rectangle for picture*
HANDLE	hMF	Memory metafile handle

**Notes:**

- C is case sensitive
- Except MM\_ISOTROPIC and MM\_ANISOTROPIC mapping modes.
- xExt and yExt are 0 or suggested size for MM\_ANISOTROPIC.
- xExt and yExt are negative values representing aspect ratio for MM\_ISOTROPIC (only ratio, not actual values, are used).

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 626 to 627

**See Also:** 6.16. MetaFile Format

**6.53. MSG STRUCTURE FORMAT**

<i>Field Type</i>	<i>Argument Type</i>	<i>Description</i>	<i>Restrictions on Allowable Values</i>
HWND	hwnd	Handle to window receiving message	
WORD	message	Message number	
WORD	wParam	Additional info about the message	Exact value depends on message value
LONG	lParam	Additional info about the message	Exact value depends on message value
DWORD	time	Time message posted	
POINT	pt	Position of mouse when message posted	In screen coordinates

**Notes:** C is case sensitive

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 627

**6.54. OFSTRUCT STRUCTURE FORMAT**

<i>Field Type</i>	<i>Argument Type</i>	<i>Description</i>	<i>Restrictions on Allowable Values</i>
BYTE	cBytes	Length of OFSTRUCT	In bytes
BYTE	fFixedDisk	Is file on fixed disk?	0=not fixed; non-zero=on fixed disk
WORD	nErrCode	DOS error code if open failed	-1
4 BYTES	RESERVED	RESERVED	
128 BYTES	szPathName	File pathname	ASCIIZ string

**Notes:** C is case sensitive

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 628

**See Also:** 1.17. Common String Formats

**6.55. PAINTSTRUCT STRUCTURE FORMAT**

<i>Field Type</i>	<i>Argument Type</i>	<i>Description</i>	<i>Restrictions on Allowable Values</i>
HDC	hdc	Display context for painting	
BOOL	fErase	Must background be redrawn	0=no; non-zero=yes
RECT	rcPaint	Upper-left, lower-right corners of rectangle to paint	
BOOL	fRestore	USED INTERNALLY BY WINDOWS	
BOOL	fIncUpdate	USED INTERNALLY BY WINDOWS	
BYTE	rgbReserved[16]	Block of memory reserved for use by Windows	

**Notes:** C is case sensitive

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 628 to 629

**6.56. POINT STRUCTURE FORMAT**

<i>Field Type</i>	<i>Argument Type</i>	<i>Description</i>
Int	x	x coordinate value of a point
Int	y	y coordinate value of a point

**Notes:** C is case sensitive

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 629

**6.57. RECT STRUCTURE FORMAT**

<i>Field Type</i>	<i>Argument Type</i>	<i>Description</i>
Int	Left	x coordinate of upper-left corner of rectangle
Int	Top	y coordinate of upper-left corner of rectangle
Int	Right	x coordinate of lower-right corner of rectangle
Int	Bottom	y coordinate of lower-right corner of rectangle

**Notes:** •C is case sensitive  
•The width of a rectangle (right-left) must not exceed 32 KB units

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 630

**6.58. RGB STRUCTURE FORMAT\***

<i>Byte Number</i>				<i>Description</i>	<i>Allowable Values</i>
3	2	1	0		
X				NOT USED	Must be 00H
	X			Red intensity of color	0=no red; 0FFH=maximum red
		X		Green intensity of color	0=no green; 0FFH=maximum green
			X	Blue intensity of color	0=no blue; 0FFH=maximum blue

**Notes:** •Black is defined as 0000 0000H; white is defined as 00FF FFFFH  
medium gray is defined as 007F 7F7FH  
\*An RGB structure consists of a single long integer, which is formatted as shown above

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 630

## 6.59. TEXTMETRIC STRUCTURE FORMAT

Field Type	Argument Type	Description	Restrictions on Allowable Values
Short	tmHeight	Height of characters (ascent-descent)	
Short	tmAscent	Ascent of characters above baseline	
Short	tmDescent	Descent of characters below baseline	
Short	tmInternalLeading	Amount of leading within tmHeight	
Short	tmExternalLeading	Amount of leading outside char box	
Short	tmAveCharWidth	Average width of characters	Usually width of X character
Short	tmMaxCharWidth	Maximum width of characters	Must be actual maximum width
Short	tmWeight	Font weight	0=default weight; 400=normal; 700=bold
BYTE	tmItalic	Is font italic?	0=not italic; non-zero=italic
BYTE	tmUnderlined	Is font underlined?	0=not underlined; non-zero=underlined
BYTE	tmStruckOut	Is font stricken out?	0=not stricken; non-zero=stricken out
BYTE	tmFirstChar	Value of first character defined in font	
BYTE	tmLastChar	Value of last character defined in font	
BYTE	tmDefaultChar	Value of character substituted for missing chars	
BYTE	tmBreakChar	Value of character used for word breaks	Usually 20H
BYTE	tmPitchAndFamily	Font's pitch and family type	Pitch is indicated by low-order two bits Pitch must be one of: DEFAULT_PITCH (0) DRAFT_QUALITY (1) DEFAULT_QUALITY (2)  Font family is indicated by high-order four bits Family must be one of: FF_DONTCARE (0) FF_ROMAN (1) FF_SWISS (2) FF_MODERN (3) FF_SCRIPT (4) FF_DECORATIVE (5)
BYTE	tmCharSet	Character set to use for font	Must be either ANSI_CHARSET (0) or OEM_CHARSET (255)
Short	tmOverhang	Extra width per string to add	Assumed to be top of char skew for italic fonts
Short	tmDigitizedAspectX	x aspect ratio of device font was designed for	
Short	tmDigitizedAspectY	y aspect ratio of device font was designed for	

Notes: •C is case sensitive  
•Numbers in parentheses show actual values

Source: Microsoft Windows SDK Programmer's Reference 2.0, pages 631 to 633

## 6.60. WNDCLASS STRUCTURE FORMAT

Field Type	Argument Type	Description	Restrictions on Allowable Values
WORD	style	Class style	Must be one of: CS_VREDRAW (1) CS_HREDRAW (2) CS_DBLCLKS (8) CS_OEMCHARS (10H) CS_OWNDC (20H) CS_CLASSDC (40H) CS_BYTEALIGNCLIENT (1000H)* CS_BYTEALIGNWINDOW (2000H)* CS_PARENTDC (80H)* CS_SAVEBITS (800H)* CS_NOCLOSE (200H)*
Long	lpfnWndProc	Window function	
Int	cbClsExtra	# Bytes to allocate after window class structure	
Int	cbWndExtra	# Bytes to allocate after window instance	
HANDLE	hInstance	Class module	Must not be NULL
HICON	hIcon	Class icon	If NULL, application must draw icon on close
HCURSOR	hCursor	Class cursor	If NULL, application must set cursor shape

(Continued)

Table 6.60. Continued

Field Type	Argument Type	Description	Restrictions on Allowable Values
HBRUSH	hbrBackground	Class background brush	Handle of physical brush; NULL; or one of: COLOR_SCROLLBAR+1 (1) COLOR_BACKGROUND+1 (2) COLOR_ACTIVECAPTION+1 (3) COLOR_INACTIVECAPTION+1 (4) COLOR_MENU+1 (5) COLOR_WINDOW+1 (6) COLOR_WINDOWFRAME+1 (7) COLOR_MENUTEXT+1 (8) COLOR_WINDOWTEXT+1 (9) COLOR_CAPTIONTEXT+1 (0AH) COLOR_ACTIVEBORDER+1* COLOR_APPWORKSPACE+1* COLOR_INACTIVEBORDER+1*
LPSTR	lpzMenuName	Resource name of class menu	Points to ASCIIZ string; if NULL, no default menu
LPSTR	lpzClassName	Name of window class	Points to ASCIIZ string

**Version Info:** \*Applies only to version 2.0 and later

**Notes:** •C is case sensitive  
 •Numbers in parentheses show actual values

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 634 to 636

**6.61. FORMAT OF A WINDOWS MESSAGE**

Offset	Size	Function
0	Word	Message identifier (message number)
2	Word	Word parameter (set to 0 if not used)
4	Dbl word	Long parameter (set to 0 if not used)

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 517

**See Also:** 6.62. Windows General Message Numbering

**6.62. WINDOWS GENERAL MESSAGE NUMBERING**

Number	Function
0 to (WM_USER-1)	RESERVED for use by Windows
WM_USER to 7FFFH	'Integer' messages for use within an application
8000 to BFFFH	RESERVED for future use by Windows
C000 to FFFFH	'String' messages for use by applications

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 517

**See Also:** 6.61. Format of a Windows Message

6.63. WINDOW MANAGEMENT MESSAGES

Message Name	Purpose	wParam	lParam
WM_ACTIVATE	Occurs when window becomes active or inactive	State of window 0=inactive 1=active (not mouse click) 2=active via mouse click	HO=non-zero if window iconic; LO=handle to new active window HO=non-zero if window iconic; LO=handle of inactive window
WM_ACTIVATEAPP	Sent when window activation is another app	0=window going inactive Non-zero=window becoming active	LO=handle of task of application being activated LO=handle of task of previously active application
WM_CHILDACTIVE	Occurs when child window has moved	Not used	Not used
WM_CLOSE	Occurs when a window is closed	Not used	Not used
WM_CREATE	Occurs when CreateWindow called	Not used	Not used
WM_CTLCOLOR	Sent to parent of control just before drawing it	Handle of display context for child window	Long pointer to CREATESTRUCT data structure LO=handle to child window HO is one of: CTLCOLOR_EDIT CTLCOLOR_LISTBOX CTLCOLOR_BTN CTLCOLOR_DLG CTLCOLOR_SCROLLBAR CTLCOLOR_STATIC
WM_DESTROY	Sent on call to DestroyWindow, after removal	Not used	Not used
WM_ENABLE	Occurs after window enabled or disabled	0=window disabled, non-zero=enabled	Not used
WM_ENDSESSION	Occurs when application responds non-zero to WM_QUERYENDSESSION	0=not end of session, non-zero=session being ended	Not used
WM_ERASEBKGND	Occurs when background needs erasing	Handle of display context	Not used
WM_GETDLGCODE	Sent by Windows dialog manager to control	Not used	Not used
WM_GETMINMAXINFO	Sent to determine size of window	Not used	Not used
WM_GETTEXT	Used to copy text corresponding to a window	Number of bytes to be copied (including ending null)	Long pointer to an array of 5 points Long pointer to buffer to receive text
WM_GETTEXTLENGTH	Used to find length of text associated w/ window	Not used	Not used
WM_KILLFOCUS	Sent before window loses input focus	Handle of window receiving input focus	Not used
WM_MOVE	Sent when a window is moved	Not used	Not used
WM_PAINT	Occurs when request to repaint window occurs	Not used	New location of upper-left corner of client area of window Long pointer to PAINTSTRUCT data structure
WM_QUERYENDSESSION	Occurs when user invokes End Session command	Not used	Not used
WM_QUEYROPEN	Sent to icon when user requests it be opened	Not used	Not used
WM_QUIT	Indicates a request to terminate an application	Exit code in PostQuitMessage call	Not used
WM_SETFOCUS	Sent after a window gets the input focus	Handle of window losing input focus	Not used
WM_SETREDRAW	Sets or clears the redraw flag	If non-zero, redraw flag is set; otherwise cleared	Not used
WM_SETTEXT	Used to set the text of a window	Not used	Long pointer to ASCIIZ string containing window text
WM_SETVISIBLE	Sent before a window is made visible or hidden	Non-zero if window being visible; otherwise invisible	Not used
WM_SHOWWINDOW	Sent when a window is hidden or shown	Non-zero if window being shown; otherwise hidden	0 if message sent due to ShowWindow call Otherwise one of: SW_OTHERZOOM SW_PARENTCLOSING SW_PARENTOPENING
WM_SIZE	Occurs after size of window has been changed	One of: SIZEFONIC SIZEFULLSCREEN SIZENORMAL SIZEZOOMSHOW SIZEZOOMHIDE	New width and height of client area (width=LO, height=HO)

Version Info: \*Message available beginning with Windows 2.0

Source: Microsoft Windows SDK Programmer's Reference 2.0, pages 501 to 502 and 549 to 594

See Also:

- 6.61. Format of a Windows Message
- 6.62. Windows General Message Numbering
- 6.64. Initialization Messages
- 6.65. Input Messages
- 6.66. System Information Messages
- 6.67. Clipboard Messages
- 6.68. Control Messages
- 6.69. Notification Codes
- 5.70. Non-Client Area Messages

**6.64. INITIALIZATION MESSAGES**

<i>Message Name</i>	<i>Purpose</i>	<i>wParam</i>	<i>lParam</i>
WM_INITDIALOG	Sent before dialog box displayed	Handle to first control item that can take input focus	Not used
WM_INITMENU	Request to initialize a menu	Handle of the menu to be initialized	Not used
WM_INITMENUPOPUP	Sent before popup menu is displayed	Handle of the popup menu	HO=non-zero if popup is system menu LO=index of popup menu in the main menu

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 503 and 565 to 567

**See Also:**

- 6.61. Format of a Windows Message
- 6.62. Windows General Message Numbering
- 6.63. Window Management Messages
- 6.65. Input Messages
- 6.66. System Information Messages
- 6.67. Clipboard Messages
- 6.68. Control Messages
- 6.69. Notification Codes
- 6.70. Non-Client Area Messages

6.65. INPUT MESSAGES

Message Name	Purpose	wParam	lParam
WM_CHAR	Result of translated WM_KEYUP or WM_KEYDOWN	ASCII value of the key	Formatted as follows: Bits 1-16 = repeat count Bits 17-25 = scan code (OEM dependent value) Bit 29 = context code (1=ALT key down) Bit 30 = previous key state (1=key held down before message) Bit 31 = transition state (1=key is being released, 0=pressed)
WM_COMMAND	Menu item selected, control passed message to Parent, or accelerator key translated	Either menu item, control ID, or accelerator ID	0=message (menu or HO=1 if accelerator otherwise HO=window handle of control, LO=control ID)
WM_DEADCHAR	Result of translated WM_KEYUP or WM_KEYDOWN	Character value of dead ke /	Formatted as follows: Bits 1-16 = repeat count Bits 17-25 = scan code (OEM dependent value) Bit 29 = context code (1=ALT key down) Bit 30 = previous key state (1=key held down before message) Bit 31 = transition state (1=key is being released, 0=pressed)
WM_HSCROLL	Occurs when user clicks mouse in scrollbar	One of following scrollbar codes: SB_LINEUP (scroll one line left) SB_LINEDOWN (scroll one line right) SB_PAGEUP (scroll one page left) SB_PAGEDOWN (scroll one page right) SB_THUMBPOSITION (scroll to absolute position) SB_THUMBTRACK (thumb dragged to specified pos) SB_TOP (scroll to far left) SB_BOTTOM (scroll to far right) SB_ENDSCROLL (end of scroll)	LO= current position of thumb Not used Not used Not used
WM_KEYDOWN	Sent when nonsystem key pressed	Virtual key code of the key pressed	Formatted as follows: Bits 1-16 = repeat count Bits 17-25 = scan code (OEM dependent value) Bit 29 = context code (1=ALT key down) Bit 30 = previous key state (1=key held down before message) Bit 31 = transition state (1=key is being released, 0=pressed)
WM_KEYUP	Sent when nonsystem key is released	Virtual key code of the key released	Formatted as follows: Bits 1-16 = repeat count Bits 17-25 = scan code (OEM dependent value) Bit 29 = context code (1=ALT key down) Bit 30 = previous key state (1=key held down before message) Bit 31 = transition state (1=key is being released, 0=pressed)
WM_LBUTTONDOWN	Sent when user double clicks left mouse button	One of the following: MK_RBUTTONDOWN (right button down) MK_MBUTTONDOWN (middle button down) MK_LBUTTONDOWN (left button down) MK_SHIFT (shift key down) MK_CONTROL (control key down)	LO=x coordinate of mouse cursor HO=y coordinate of mouse cursor (Coordinates relative to top left corner of window)
WM_LBUTTONDOWN	Sent when left mouse button pressed	One of the following: MK_RBUTTONDOWN (right button down) MK_MBUTTONDOWN (middle button down) MK_LBUTTONDOWN (left button down) MK_SHIFT (shift key down) MK_CONTROL (control key down)	LO=x coordinate of mouse cursor HO=y coordinate of mouse cursor (Coordinates relative to top left corner of window)
WM_LBUTTONUP	Sent when left mouse button released	One of the following: MK_RBUTTONDOWN (right button down) MK_MBUTTONDOWN (middle button down) MK_LBUTTONDOWN (left button down) MK_SHIFT (shift key down) MK_CONTROL (control key down)	LO=x coordinate of mouse cursor HO=y coordinate of mouse cursor (Coordinates relative to top left corner of window)

(Continued)

Message Name	Purpose	wParam	lParam
WM_MBUTTONDOWNBLCK	Sent when user double clicks middle mouse button	One of the following: MK_RBUTTONDOWN (right button down) MK_MBUTTONDOWN (middle button down) MK_LBUTTONDOWN (left button down) MK_SHIFT (shift key down) MK_CONTROL (control key down)	LO=x coordinate of mouse cursor HO=y coordinate of mouse cursor (Coordinates relative to top left corner of window)
WM_MBUTTONDOWN	Sent when middle mouse button pressed	One of the following: MK_RBUTTONDOWN (right button down) MK_MBUTTONDOWN (middle button down) MK_LBUTTONDOWN (left button down) MK_SHIFT (shift key down) MK_CONTROL (control key down)	LO=x coordinate of mouse cursor HO=y coordinate of mouse cursor (Coordinates relative to top left corner of window)
WM_MBUTTONDOWNUP	Sent when middle mouse button released	One of the following: MK_RBUTTONDOWN (right button down) MK_MBUTTONDOWN (middle button down) MK_LBUTTONDOWN (left button down) MK_SHIFT (shift key down) MK_CONTROL (control key down)	LO=x coordinate of mouse cursor HO=y coordinate of mouse cursor (Coordinates relative to top left corner of window)
WM_MOUSEMOVE	Sent when mouse is moved	One of the following: MK_RBUTTONDOWN (right button down) MK_MBUTTONDOWN (middle button down) MK_LBUTTONDOWN (left button down) MK_SHIFT (shift key down) MK_CONTROL (control key down)	LO=x coordinate of mouse cursor HO=y coordinate of mouse cursor (Coordinates relative to top left corner of window)
WM_RBUTTONDOWNBLCK	Sent when right mouse button is double clicked	One of the following: MK_RBUTTONDOWN (right button down) MK_MBUTTONDOWN (middle button down) MK_LBUTTONDOWN (left button down) MK_SHIFT (shift key down) MK_CONTROL (control key down)	LO=x coordinate of mouse cursor HO=y coordinate of mouse cursor (Coordinates relative to top left corner of window)
WM_RBUTTONDOWN	Sent when right mouse button is pressed	One of the following: MK_RBUTTONDOWN (right button down) MK_MBUTTONDOWN (middle button down) MK_LBUTTONDOWN (left button down) MK_SHIFT (shift key down) MK_CONTROL (control key down)	LO=x coordinate of mouse cursor HO=y coordinate of mouse cursor (Coordinates relative to top left corner of window)
WM_RBUTTONDOWNUP	Sent when right mouse button is released	One of the following: MK_RBUTTONDOWN (right button down) MK_MBUTTONDOWN (middle button down) MK_LBUTTONDOWN (left button down) MK_SHIFT (shift key down) MK_CONTROL (control key down)	LO=x coordinate of mouse cursor HO=y coordinate of mouse cursor (Coordinates relative to top left corner of window)
WM_TIMER	Sent when time limit for timer is elapsed	Timer ID	Long pointer to function passed to SetTimer
WM_VSCROLL	Sent when user clicks mouse in vert scroll bar	One of following scrollbar codes: SB_LINEUP (scroll up one line) SB_LINEDOWN (scroll down one line) SB_PAGEUP (scroll up one page) SB_PAGEDOWN (scroll down one page) SB_THUMBPOSITION (scroll to absolute position) SB_THUMBTRACK (thumb dragged to specified pos) SB_TOP (scroll to top) SB_BOTTOM (scroll to bottom) SB_ENDSCROLL (end of scroll)	Not used Not used Not used Not used LO= current position of thumb LO= current position of thumb Not used Not used

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 503 to 504 and 551 to 602

**See Also:** 6.61. Format of a Windows Message  
 6.62. Windows General Message Numbering  
 6.63. Window Management Messages  
 6.64. Initialization Messages  
 6.56. System Information Messages

6.67. Clipboard Messages  
 6.68. Control Messages  
 6.69. Notification Codes  
 6.70. Non-Client Area Messages

6.66. SYSTEM INFORMATION MESSAGES

Message Name	Purpose	wParam	lParam
WM_DEVMODECHANGE	Sent to top-level windows when device mode settings change	Not used	Long pointer to WIN.INI device name
WM_FONTCHANGE	Sent to top-level windows when pool of font resources changes	Not used	Not used
WM_SYSCOLORCHANGE	Sent to top-level windows when system color settings change	Not used	Not used
WM_SYSTEMERROR	Sent to top-level windows when out-of-memory error occurs	8-out of memory error code	Not used
WM_TIMECHANGE	Sent to top-level windows when application changes system time	Not used	Not used
WM_WININICHANGE	Sent to top-level windows when WIN.INI is changed	Not used	Long pointer to string specifying section that changed; 0 if more than one change

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 507 and 558 to 604

**See Also:**

- 6.61. Format of a Windows Message
- 6.62. Windows General Message Numbering
- 6.63. Window Management Messages
- 6.64. Initialization Messages
- 6.65. Input Messages
- 6.67. Clipboard Messages
- 6.68. Control Messages
- 6.69. Notification Codes
- 6.70. Non-Client Area Messages

6.67. CLIPBOARD MESSAGES

Message Name	Purpose	wParam	lParam
WM_ASKCBFORMATNAME	Sent when clipboard needs handle for CF_OWNERSHIP and clipboard app's client area needs repainting	Integer number of bytes to copy	Long pointer to buffer where copy of the format name is stored
WM_CHANGECHAIN	Sent to first window in viewer chain when window is removed from chain	Handle of window being removed from chain	LO-handle of window following one being removed (next wind)
WM_DESTROYCLIPBOARD	Sent to clipboard owner when clipboard is emptied by EmptyClipboard	Not used	Not used
WM_DRAWCLIPBOARD	Sent to first window in viewer chain when contents are changed	Not used	Not used
WM_HSCROLLCLIPBOARD	Sent when clipboard is CF_OWNERSHIP and horizontal scroll event occurs	Handle to clipboard application window	LO contains one of the following scrollbar codes: SB_LINEUP (scroll one line left) SB_LINEDOWN (scroll one line right) SB_PAGEUP (scroll one page left) SB_PAGEDOWN (scroll one page right) SB_THUMBPOSITION (scroll to absolute position) SB_TOP (scroll to far left) SB_BOTTOM (scroll to far right) SB_ENDSCROLL (end of scroll) HO contains thumb position if LO=SB_THUMBPOSITION
WM_PAINTCLIPBOARD	Sent when clipboard is CF_OWNERSHIP and clipboard app's client area needs repainting	Handle to clipboard application window	Long pointer to PAINTSTRUCT defining area to paint
WM_RENDERALLFORMATS	Sent to application that owns clipboard when application is being destroyed	Not used	Not used
WM_RENDERFORMAT	Sent to request clipboard owner format data in specified format	Data format to render	LO-pointer to RECT data structure defining area to paint LO contains one of the following scrollbar codes: SB_LINEUP (scroll one line left) SB_LINEDOWN (scroll one line right) SB_PAGEUP (scroll one page left) SB_PAGEDOWN (scroll one page right) SB_THUMBPOSITION (scroll to absolute position) SB_TOP (scroll to far left) SB_BOTTOM (scroll to far right) SB_ENDSCROLL (end of scroll) HO contains thumb position if LO=SB_THUMBPOSITION
WM_SIZECLIPBOARD	Sent when clipboard is CF_OWNERSHIP and clipboard app window has changed size	Handle to clipboard application window	LO contains one of the following scrollbar codes: SB_LINEUP (scroll one line left) SB_LINEDOWN (scroll one line right) SB_PAGEUP (scroll one page left) SB_PAGEDOWN (scroll one page right) SB_THUMBPOSITION (scroll to absolute position) SB_TOP (scroll to far left) SB_BOTTOM (scroll to far right) SB_ENDSCROLL (end of scroll) HO contains thumb position if LO=SB_THUMBPOSITION
WM_VSCROLLCLIPBOARD	Sent when clipboard is CF_OWNERSHIP and vertical scroll event occurs	Handle to clipboard application window	LO contains one of the following scrollbar codes: SB_LINEUP (scroll one line left) SB_LINEDOWN (scroll one line right) SB_PAGEUP (scroll one page left) SB_PAGEDOWN (scroll one page right) SB_THUMBPOSITION (scroll to absolute position) SB_TOP (scroll to far left) SB_BOTTOM (scroll to far right) SB_ENDSCROLL (end of scroll) HO contains thumb position if LO=SB_THUMBPOSITION

**Source:**

Microsoft Windows SDK Programmer's Reference 2.0, pages 506 to 507 and 550 to 603

**See Also:**

- 6.15. Clipboard Formats
- 6.61. Format of a Windows Message
- 6.62. Windows General Message Numbering
- 6.63. Window Management Messages
- 6.64. Initialization Messages
- 6.65. Input Messages
- 6.66. System Information Messages
- 6.68. Control Messages
- 6.69. Notification Codes
- 6.70. Non-Client Area Messages

6.68. CONTROL MESSAGES

Message Name	Purpose	wParam	lParam
BM_GETCHECK	Sent to determine status of check box or radio button	Not used	Not used
BM_GETSTATE	Sent to determine if cursor over button and moused clicked	Not used	Not used
BM_SETCHECK	Sent to check radio button or check box	0=remove check, non-zero=place check	Not used
BM_SETSTATE	Sent to highlight button or check box *	0=highlight removed, non-zero=highlighted	Not used
BM_SETSTYLE	Sent to alter button style	Style value	Not used
EM_CANUNDO	Sent to determine if edit control can undo last edit	Not used	Not used
EM_FMTLINES	Sent to add or remove EOL char from text lines	0=remove EOL, non-zero=add CR LF to lines	Not used
EM_GETHANDLE	Sent to determine handle of buffer holding control window contents	Not used	Not used
EM_GETLINE	Sent to copy a line from the edit control	Line number	Far pointer to buffer to store line (first word-max length allowed)
EM_GETLINECOUNT	Sent to determine number of lines of text in edit control	Not used	Not used
EM_GETRECT	Sent to determine bounding rectangle of control	Not used	Long pointer to RECT data structure
EM_GETSEL	Sent to determine start and end positions of selection	Not used	Not used
EM_LIMITTEXT	Sent to limit length of text the user may enter	Maximum number of bytes that can be entered	Not used
EM_LINEFROMCHAR*	Sent to determine which line contains a specific character	Index to character	Not used
EM_LINENEXT	Sent to determine number of char positions before first char on line	Line number or -1 for current line	Not used
EM_LINELENGTH	Sent to determine length of line in edit control's text buffer	Line number or -1 for current line	Not used
EM_LINESCROLL	Sent to scroll context of control by a number of lines	Not used	HO=number of lines, LO=number of horiz. char positions
EM_REPLACESEL	Sent to replace selection with new text	Not used	Far pointer to ASCIIZ string of replacement text
EM_SCROLL	Sent to direct edit control to scroll window vertically	One of the following values: SB_LINEUP (scroll one line up) SB_LINEDOWN (scroll one line down) SB_PAGEUP (scroll one page up) SB_PAGEDOWN (scroll one page down) SB_THUMBPOSITION (scroll to position) EM_GETTHUMB (retrieve thumb position)	Not used
EM_SETFONT	Sent to set edit control font being used*	Font ID (must be fixed pitch)	Not used
EM_SETHANDLE	Sent to establish text buffer used to hold control window contents	Handle to buffer in application's data segment	Not used
EM_SETRECTNP	Sent to set bounding rect of control w/ no repainting	Not used	Long pointer to RECT data structure specifying new rectangle
EM_SETSEL	Sent to select chars between start and end position	Not used	LO=start pos, HO=ending position
EM_SETSRECT	Sent to set formatting rectangle of control	Not used	Long pointer to RECT data structure specifying new rectangle
EM_SETWORDBREAK*	Sent to set word break for multiline edit controls	Not used	Long pointer to application-supplied word break function
EM_UNDO	Sent to undo last edit to edit control	Not used	Not used
LB_ADDSTRING	Sent to add string to list box	Not used	Long pointer to ASCIIZ string to add
LB_DELETESTRING	Sent to delete string from list box	Index to string to delete	Not used
LB_DIR	Sent to add list of files in current directory to list box	DOS attribute value	Long pointer to file specification string (may include * and ?)
LB_GETCOUNT	Sent to get count of number of items in list box	Not used	Not used
LB_GETCOURSEL	Sent to return index of current selection, if any	Not used	Not used
LB_GETSEL	Sent to return selection state of an item	Index to the item	Not used
LB_GETTEXT	Sent to copy string from list into buffer	Index to string to copy into buffer	Long pointer to buffer to receive copy of string
LB_GETTEXTLEN	Sent to determine length of string in list box	Index to string to determine length of	Not used
LB_INSERTSTRING	Sent to insert string into list box	Index to position for string, or -1 for end of list	Long pointer to ASCIIZ string to insert
LB_SELECTSTRING	Sent to change selection to first string matching prefix	Index to string to select	Long pointer to ASCIIZ prefix string
LB_SETCURSEL	Sent to select string and scroll it into view, if necessary	Index to string to select	-1 list box set to have no selection
LB_SETSEL	Sent to set selection state of a string	0=highlight removed, non-zero=set highlight	LO=order to string or -1 for all strings in list
WM_CLEAR	Sent to delete current selection	Not used	Not used
WM_COPY	Sent to copy current selection to clipboard in CF_TEXT format	Not used	Not used
WM_CUT	Sent to perform WM_COPY and WM_CLEAR in that order	Not used	Not used
WM_PASTE	Sent to copy clipboard data to current window at current cursor pos.	Not used	Not used

**Version Info:** \*Applies to Windows beginning with version 2.0 only

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 508 to 510 and 519 to 586

**See Also:** 6.61. Format of a Windows Message  
 6.62. Windows General Message Numbering  
 6.63. Window Management Messages  
 6.64. Initialization Messages  
 6.65. Input Messages  
 6.66. System Information Messages  
 6.67. Clipboard Messages  
 6.68. Notification Codes  
 6.70. Non-Client Area Messages

6.69. NOTIFICATION CODES

Code Name	Meaning
BN_CLICKED	The button has been clicked
BN_DISABLE	The button should be drawn as disabled
BN_DOUBLECLICKED	The user has double clicked a mouse button
BN_HILITE	The button requires highlighting
BN_PAINT	The button requires repainting
BN_UNHILITE	The button requires unhighlighting
EN_CHANGE	The user has taken an action that may have changed the content of the text
EN_ERSPACE	The edit control is out of space
EN_HSCROLL	The user has clicked on the edit control's horiz scroll bar
EN_KILLFOCUS	The edit control has lost the input focus
EN_SETFOCUS	The edit control has obtained the input focus
EN_UPDATE	The edit control will display altered text
EN_VSCROLL	The user has clicked on the edit control's vert scroll bar
LBN_DBLCLK	The user double clicked the mouse button over a string
LBN_ERSPACE	Out of memory
LBN_SELCHANGE	The selection has been changed

Version Info: \*Applies to versions of Windows beginning with 2.0 only

Source: Microsoft Windows SDK Programmer's Reference 2.0, pages 511 to 512 and 522 to 548

See Also: 6.61. Format of a Windows Message  
 6.62. Windows General Message Numbering  
 6.63. Window Management Messages  
 6.64. Initialization Messages  
 6.65. Input Messages  
 6.66. System Information Messages  
 6.67. Clipboard Messages  
 6.68. Control Messages

6.70. NON-CLIENT AREA MESSAGES

Message Name	Purpose	wParam	lParam
WM_NCACTIVATE	Sent to window when its caption bar or icon needs to be changed	0=make active; non-zero=make inactive	Not used
WM_NCCALCSIZE	Sent when size of client area needs to be calculated	Not used	Long pointer to RECT data structure
WM_NCCREATE	Sent before WM_CREATE message when window created	handle to window being created	Long pointer to CREATESTRUCT data structure for window
WM_NCDESTROY	Sent after WM_DESTROY message	Not used	Not used
WM_NCHITTEST	Sent each time mouse moved	Not used	LO=x coord of mouse, HO=y coord of mouse
WM_NCLBUTTONDBLCLK	Sent when left mouse button double clicked in non-client area	Code returned by WM_NCHITTEST	LO=x coord of mouse, HO=y coord of mouse
WM_NCLBUTTONDOWN	Sent when left mouse button is pressed in non-client area	Code returned by WM_NCHITTEST	LO=x coord of mouse, HO=y coord of mouse
WM_NCLBUTTONUP	Sent when left mouse button released in non-client area	Code returned by WM_NCHITTEST	LO=x coord of mouse, HO=y coord of mouse
WM_NCMBUTTONDBLCLK	Sent when middle mouse button double clicked in non-client area	Code returned by WM_NCHITTEST	LO=x coord of mouse, HO=y coord of mouse
WM_NCMBUTTONDOWN	Sent when middle mouse button is pressed in non-client area	Code returned by WM_NCHITTEST	LO=x coord of mouse, HO=y coord of mouse
WM_NCMBUTTONUP	Sent when middle mouse button released in non-client area	Code returned by WM_NCHITTEST	LO=x coord of mouse, HO=y coord of mouse
WM_NCMOUSEMOVE	Sent when mouse is moved in non-client area of window	Code returned by WM_NCHITTEST	LO=x coord of mouse, HO=y coord of mouse
WM_NCPAINT	Sent to window when frame needs repainting	Not used	Not used
WM_NCRBUTTONDBLCLK	Sent when right mouse button double clicked in non-client area	Code returned by WM_NCHITTEST	LO=x coord of mouse, HO=y coord of mouse
WM_NCRBUTTONDOWN	Sent when right mouse button is pressed in non-client area	Code returned by WM_NCHITTEST	LO=x coord of mouse, HO=y coord of mouse
WM_NCRBUTTONUP	Sent when right mouse button released in non-client area	Code returned by WM_NCHITTEST	LO=x coord of mouse, HO=y coord of mouse

Source: Microsoft Windows SDK Programmer's Reference 2.0, pages 513 to 514 and 576 to 584

See Also:

6.61. Format of a Windows Message  
 6.62. Windows General Message Numbering  
 6.63. Window Management Messages  
 6.64. Initialization Messages  
 6.65. Input Messages  
 6.66. System Information Messages  
 6.67. Clipboard Messages  
 6.68. Control Messages

6.71. WINDOWS FUNCTION SUMMARY BY VERSION

Function Name	1	2
AccessResource	X	X
AddAtom	X	X
AddFontResource	X	X
AdjustWindowRect	X	X
AllocResource	X	X
AnsiLower	X	X
AnsiNext	X	X
AnsiPrev	X	X
AnsiToOEM	X	X
AnsiUpper	X	X
AnyPopup	X	X
Arc	X	X
BeginPaint	X	X
BitBit	X	X
BringWindowToTop	X	X
BuildCommDCB	X	X
CallMsgFilter	X	X
CallWindowProc	X	X
Catch	X	X
ChangeClipboardChain	X	X
ChangeMenu	X	X
CheckDlgButton	X	X
CheckMenuItem	X	X
CheckRadioButton	X	X
ChildWindowFromPoint	X	X
Chord		X
ClearCommBreak	X	X
ClientToScreen	X	X
ClipCursor	X	X
CloseClipboard	X	X
CloseComm	X	X
CloseMetaFile	X	X
CloseSound	X	X
CloseWindow	X	X
CombineRgn	X	X
CopyMetaFile	X	X
CopyRect	X	X
CountClipboardFormats	X	X
CountVoiceNotes	X	X
CreateBitmap	X	X
CreateBitmapIndirect	X	X
CreateBrushIndirect	X	X
CreateCaret	X	X
CreateCompatibleBitmap	X	X
CreateCompatibleDC	X	X
CreateDC	X	X
CreateDialog	X	X
CreateDialogIndirect		X
CreateDiscardableBitmap	X	X
CreateEllipticRgn	X	X
CreateEllipticRgnIndirect		X
CreateEllipticRgnIndirect	X	X
CreateFont (see below)	X	X
CreateFontIndirect	X	X
CreateHatchBrush	X	X
CreateIC	X	X
CreateMenu	X	X
CreateMetaFile	X	X
CreatePatternBrush	X	X
CreatePen	X	X
CreatePenIndirect	X	X
CreatePolygonRgn	X	X
CreateRectRgn	X	X
CreateRectRgnIndirect	X	X
CreateSolidBrush	X	X
CreateWindow	X	X
DefHookProc		X
DefWindowProc	X	X
DeleteAtom	X	X

Function Name	1	2
GetViewportOrg	X	X
GetWindow		X
GetWindowDC	X	X
GetWindowExt	X	X
GetWindowLong	X	X
GetWindowOrg	X	X
GetWindowRect	X	X
GetWindowTask		X
GetWindowText	X	X
GetWindowTextLength	X	X
GetWindowWord	X	X
GlobalAddAtom		X
GlobalAlloc	X	X
GlobalCompact	X	X
GlobalDeleteAtom		X
GlobalDiscard	X	X
GlobalFindAtom		X
GlobalFlags	X	X
GlobalFree	X	X
GlobalGetAtomName		X
GlobalHandle	X	X
GlobalLock	X	X
GlobalReAlloc	X	X
GlobalSize	X	X
GlobalUnlock	X	X
GlobalUnwire		X
GlobalWire		X
GrayString	X	X
HIBYTE	X	X
HideCaret	X	X
HiliteMenuItem	X	X
HIWORD	X	X
InflateRect	X	X
InitAtomTable	X	X
InSendMessage	X	X
IntersectClipRect	X	X
IntersectRect	X	X
InvalidateRect	X	X
InvalidateRgn	X	X
InvertRect	X	X
InvertRgn	X	X
IsChild	X	X
IsClipboardFormatAvailable	X	X
IsDialogMessage	X	X
IsDlgButtonChecked	X	X
IsIconic	X	X
IsRectEmpty	X	X
IsWindow	X	X
IsWindowEnabled	X	X
IsWindowVisible	X	X
IsZoomed		X
KillTimer	X	X
LineDDA	X	X
LineTo	X	X
LoadAccelerators	X	X
LoadBitmap	X	X
LoadCursor	X	X
LoadIcon	X	X
LoadLibrary	X	X
LoadMenu	X	X
LoadMenuIndirect		X
LoadResource	X	X
LoadString	X	X
LOBYTE	X	X
LocalAlloc	X	X
LocalCompact	X	X
LocalData	X	X
LocalDiscard	X	X
LocalFlags	X	X

(Continued)

Table 6.71. Continued

Function Name	1	2	Function Name	1	2
DeleteDC	X	X	LocalFree	X	X
DeleteMetaFile	X	X	LocalFreeze	X	X
DeleteObject	X	X	LocalHandle	X	X
DestroyCaret	X	X	LocalHandleDelta	X	X
DestroyMenu	X	X	LocalInit	X	X
DestroyWindow	X	X	LocalLock	X	X
DeviceMode	X		LocalMelt	X	X
DialogBox	X	X	LocalNotify	X	X
DialogBoxIndirect		X	LocalReAlloc	X	X
DispatchMessage	X	X	LocalShrink		X
DlgDirList	X	X	LocalSize	X	X
DlgDirSelect	X	X	LocalUnlock	X	X
DPtoLP	X	X	LockResource	X	X
DrawIcon	X	X	LockSegment	X	X
DrawMenuBar	X	X	LOWORD	X	X
DrawText	X	X	LPtoDP	X	X
Ellipse	X	X	MAKEINTATOM	X	X
EmptyClipboard	X	X	MAKEINTRESOURCE	X	X
EnableHardwareInput		X	MAKELONG	X	X
EnableMenuItem	X	X	MAKEPOINT	X	X
EnableWindow	X	X	MakeProcInstance	X	X
EndDialog	X	X	MapDialogRect	X	X
EndPaint	X	X	max	X	X
EnumChildWindows	X	X	MessageBeep	X	X
EnumClipboardFormats	X	X	MessageBox	X	X
EnumFonts	X	X	min	X	X
EnumMetaFile		X	MoveConvertWindow		X
EnumObjects	X	X	MoveTo	X	X
EnumProps	X	X	MoveWindow	X	X
EnumTaskWindows		X	OemToAnsi	X	X
EnumWindows	X	X	OffsetClipRgn	X	X
EqualRect		X	OffsetRect	X	X
EqualRgn	X	X	OffsetRgn	X	X
Escape (ABORTDOC)	X	X	OffsetViewpctOrg		X
Escape (BANDINFO)		X	OffsetWindowOrg		X
Escape (DEVICEDATA)	X	X	OpenClipboard	X	X
Escape (DRAFTMODE)	X	X	OpenComm	X	X
Escape (DRAWPATTERNRECT)		X	OpenFile	X	X
Escape (ENABLEDUPLEX)		X	OpenIcon	X	X
Escape (ENABLEMANUALFEED)	X	X	OpenSound	X	X
Escape (ENABLEPAIRKERNING)	X	X	PaintRgn	X	X
Escape (ENABLERELATIVEWIDTHS)	X	X	PatBit	X	X
Escape (EXTTEXTOUT)	X	X	PeekMessage	X	X
Escape (ENDDOC)	X	X	Pie	X	X
Escape (FLUSHOUTPUT)	X	X	PlayMetaFile	X	X
Escape (GETCOLORTABLE)	X	X	PlayMetaFileRecord		X
Escape (GETEXTENDEDTEXTMETRICS)	X	X	Polygon	X	X
Escape (GETTEXTENTTABLE)	X	X	Polyline	X	X
Escape (GETPAIRKERNTABLE)	X	X	PostAppMessage	X	X
Escape (GETPHYSPAGESIZE)	X	X	PostMessage	X	X
Escape (GETPRINTINGOFFSET)	X	X	PostQuitMessage	X	X
Escape (GETSCALINGFACTOR)	X	X	PtInRect	X	X
Escape (GETTRACKERNTABLE)	X	X	PtInRegion	X	X
Escape (MFCOMMENT)		X	PtVisible	X	X
Escape (NEWFRAME)	X	X	ReadComm	X	X
Escape (NEXTBAND)	X	X	Rectangle	X	X
Escape (QUERYESCSUPPORT)	X	X	RectVisible	X	X
Escape (SELECTPAPERSOURCE)	X	X	RegisterClass	X	X
Escape (SETABORTPROC)	X	X	RegisterClipboardFormat	X	X
Escape (SETALLJUSTVALUES)		X	RegisterWindowDestroy		X
Escape (SETCHARSET)	X	X	RegisterWindowMessage	X	X
Escape (SETCOLORTABLE)	X	X	ReleaseCapture	X	X
Escape (SETCOPYCOUNT)	X	X	ReleaseDC	X	X
Escape (SETKERNTRACK)	X	X	RemoveFontResource	X	X
Escape (SETLINECAP)		X	RemoveProp	X	X
Escape (SETLINEJOIN)		X	ReplyMessage	X	X
Escape (SETMITERLIMIT)		X	RestoreDC	X	X
Escape (STARTDOC)	X	X	RGB	X	X
Escape (STRETCHBLT)	X	X	RoundRect	X	X
EscapeCommFunction	X	X	SaveDC	X	X
ExcludeClipRect	X	X	ScaleViewportExt		X
ExcludeUpdateRgn		X	ScaleWindowExt		X

(Continued)

Table 6.71. Continued

Function Name	1	2
ExtTextOut		X
FatalExit	X	X
FillRect	X	X
FillRgn	X	X
FindAtom	X	X
FindResource	X	X
FindWindow	X	X
FlashWindow	X	X
FloodFill	X	X
FlushComm	X	X
FrameRect	X	X
FrameRgn	X	X
FreeLibrary	X	X
FreeProclnstance	X	X
FreeResource	X	X
GetActiveWindow	X	X
GetAspectRatioFilter		X
GetAsyncKeyState		X
GetAtomHandle	X	X
GetAtomName	X	X
GetBitmapBits	X	X
GetBitmapDimension	X	X
GetBkColor	X	X
GetBkMode	X	X
GetBrushOrg	X	X
GetBValue	X	X
GetCapture		X
GetCaretBlinkTime	X	X
GetCaretPos		X
GetCharWidth		X
GetClassLong	X	X
GetClassName	X	X
GetClassWord	X	X
GetClientRect	X	X
GetClipboardData	X	X
GetClipboardFormatName	X	X
GetClipboardOwner	X	X
GetClipboardViewer	X	X
GetClipBox	X	X
GetCodeHandle	X	X
GetCommError	X	X
GetCommEventMask	X	X
GetCommState	X	X
GetCurrentPosition	X	X
GetCurrentTask	X	X
GetCurrentTime	X	X
GetCursorPos	X	X
GetDC	X	X
GetDCOrg		X
GetDeviceCaps	X	X
GetDlgItem	X	X
GetDlgItemInt	X	X
GetDlgItemText	X	X
GetDoubleClickTime	X	X
GetEnvironment	X	X
GetFocus	X	X
GetGValue	X	X
GetInputState		X
GetInstanceData	X	X
GetKeyboardState		X
GetKeyState	X	X
GetMapMode	X	X
GetMenu	X	X
GetMenuItemCount		X
GetMenuItemID		X
GetMenuState		X
GetMenuString	X	X
GetMessage	X	X
GetMessagePos	X	X
GetMessageTime	X	X
GetMetaFile	X	X
GetMetaFileBits	X	X

Function Name	1	2
ScreenToClient	X	X
ScrollDC		X
ScrollWindow	X	X
SelectClipRgn	X	X
SelectObject	X	X
SendDlgItemMessage	X	X
SendMessage	X	X
SetActiveWindow	X	X
SetBitmapBits	X	X
SetBitmapDimension	X	X
SetBkColor	X	X
SetBkMode	X	X
SetBrushOrg	X	X
SetCapture	X	X
SetCaretBlinkTime	X	X
SetCaretPos	X	X
SetClassLong	X	X
SetClassWord	X	X
SetClipboardData	X	X
SetClipboardViewer	X	X
SetCommBreak	X	X
SetCommEventMask	X	X
SetCommState	X	X
SetConvertHook		X
SetConvertParms		X
SetConvertWindowHeight		X
SetCursor	X	X
SetCursorPos	X	X
SetDlgItemInt	X	X
SetDlgItemText	X	X
SetDoubleClickTime		X
SetEnvironment	X	X
SetFocus	X	X
SetKeyboardState		X
SetMapMode	X	X
SetMapperFlags		X
SetMenu	X	X
SetMessageQueue		X
SetMetaFileBits	X	X
SetParent		X
SetPixel	X	X
SetPolyFillMode	X	X
SetPriority	X	X
SetProp	X	X
SetRect	X	X
SetRectEmpty	X	X
SetRectRgn	X	X
SetRelAbs	X	X
SetResourceHandler	X	X
SetROP2	X	X
SetScrollPos	X	X
SetScrollRange	X	X
SetSoundNoise	X	X
SetStretchBltMode	X	X
SetSwapAreaSize		X
SetSysColors	X	X
SetSysModalWindow	X	X
SetTextAlign		X
SetTextCharacterExtra	X	X
SetTextColor	X	X
SetTextJustification	X	X
SetTimer	X	X
SetViewportExt	X	X
SetViewportOrg	X	X
SetVoiceAccent	X	X
SetVoiceEnvelope	X	X
SetVoiceNote	X	X
SetVoiceQueueSize	X	X
SetVoiceSound	X	X
SetVoiceThreshold	X	X
SetWindowExt	X	X
SetWindowLong	X	X

(Continued)

Table 6.71. Continued

Function Name	1	2	Function Name	1	2
GetModuleFileName	X	X	SetWindowOrg	X	X
GetModuleHandle	X	X	SetWindowPos		X
GetModuleUsage	X	X	SetWindowsHook	X	X
GetNearestColor	X	X	SetWindowText	X	X
GetNextDlgGroupItem		X	SetWindowWord	X	X
GetNextDlgTabItem		X	ShowCaret	X	X
GetNextWindow		X	ShowCursor	X	X
GetNumTasks		X	ShowOwnedPopups		X
GetObject	X	X	ShowScrollBar		X
GetParent	X	X	ShowWindow	X	X
GetPixel	X	X	SizeofResource	X	X
GetPolyFillMode	X	X	StartSound	X	X
GetProcAddress	X	X	StopSound	X	X
GetProfileInt	X	X	StretchBlt	X	X
GetProfileString	X	X	SwapMouseButton	X	X
GetProp	X	X	SyncAllVoices	X	X
GetRelAbs	X	X	TextOut	X	X
GetROP2	X	X	Throw	X	X
GetRValue	X	X	TranslateAccelerator	X	X
GetScrollPos	X	X	TranslateCommChar	X	X
GetScrollRange	X	X	TranslateMessage	X	X
GetStockObject	X	X	UngetCommChar	X	X
GetStretchBltMode	X	X	UnhookWindowsHook		X
GetSubMenu	X	X	UnionRect	X	X
GetSysColor	X	X	UnlockData	X	X
GetSysModalWindow	X	X	UnlockResource		X
GetSystemMenu	X	X	UnlockSegment	X	X
GetSystemMetrics	X	X	UnrealizeObject	X	X
GetTempDrive	X	X	UpdateWindow	X	X
GetTempFileName	X	X	ValidateFreeSpaces		X
GetTextAlign		X	ValidateRect	X	X
GetTextCharacterExtra	X	X	ValidateRgn	X	X
GetTextColor	X	X	WaitMessage	X	X
GetTextExtent	X	X	WaitSoundState	X	X
GetTextFace	X	X	WindowFromPoint	X	X
GetTextMetrics	X	X	WinMain	X	X
GetThresholdEvent	X	X	WndProc	X	X
GetThresholdStatus	X	X	WriteComm	X	X
GetTickCount		X	WriteProfileString	X	X
GetTopWindow		X	Yield	X	X
GetUpdateRect	X	X			
GetUpdateRgn		X			
GetVersion	X	X			
GetViewportExt	X	X			

**Source:**

Microsoft Windows SDK Programmer's References 1.0 and 2.0

**See Also:**6.72. Windows Functions Summary by Name of Function  
6.73. Windows Functions Summary by Type of Function

6.72. WINDOWS FUNCTION SUMMARY BY NAME OF FUNCTION

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
AccessResource	Sets file pointer for read access to hFileInfo	Resource manager	AccessResource(hInstance, hResInfo)	nFile	148
AddAtom	Creates atom for character string lpString	Atom manager	AddAtom(lpString)	wAtom	148
AddFontResource	Adds resource in lpFilename to system font table	Resource manager	AddFontResource(lpFilename)	nFont	149
AdjustWindowRect	Converts client rectangle to a window rectangle	Window display	AdjustWindowRect(lpRect, lpszMenu)	None	150
AllocResource	Allocates dwSize bytes of memory for hResInfo	Resource manager	AllocResource(hInstance, hResInfo, dwSize)	hMem	150
AnsiLower	Converts string lpStr to lowercase	String translation	AnsiLower(lpStr)	cChar	151
AnsiNext	Points to next character in string lpCurrentChar	String translation	AnsiNext(lpCurrentChar)	lpNextChar	151
AnsiPrev	Points to prev character in string lpStr	String translation	AnsiPrev(lpStr)	lpPrevChar	152
AnsiToOEM	Converts ANSI string to OEM char string	String translation	AnsiToOem(lpAnsiStr, lpOemStr)	lpTranslated	152
AnsiUpper	Converts string lpStr to uppercase	String translation	AnsiUpper(lpStr)	cChar	153
AnyPopup	Indicates whether any popup window is visible	Window display	AnyPopup()	boolean	153
Ac	Draws arc from X3, Y3 to X4, Y4	GDI output	Ac(hDC, X1, Y1, X2, Y2, X3, Y3, X4, Y4)	boolean	154
BeginPaint	Prepares window for painting	Window painting	BeginPaint(hwnd, lpPaint)	hDC	154
BitBlt	Moves bitmap from src device to dest device	GDI output	BitBlt(hDestDC, X1, Y1, width, height, hSrcDC, XSrc, YSrc, dwRop)	boolean	156
BringWindowToTop	Makes popup or child window the top window	Window display	BringWindowToTop(hwnd)	boolean	159
BuildCommDCB	Fills device control block with control codes	Communications	BuildCommDCB(lpDevID, lpDCB)	hResult	160
CallMsgFilter	Passes message and code to message filter function	Window hook	CallMsgFilter(lpMsg, nCode)	boolean	161
CallWindowProc	Passes message info to lpPrevWindowProc function	Window class	CallWindowProc(lpPrevWindowProc, hwnd, wMsg, wParam, lParam)	boolean	161
Catch	Copies current exec environ to buffer lpCatchBuf	Module manager	Catch(lpCatchBuf)	boolean	162
ChangeClipboardChain	Removes hwnd from clipboard viewer chain	Window clipboard	ChangeClipboardChain(hwnd, hWndNext)	boolean	163
ChangeMenu	Changes menu item in hMenu	Window menu	ChangeMenu(hMenu, wID, dwFlags, wText)	boolean	163
CheckDlgButton	Changes checkmark status of menu item	Window menu	CheckDlgButton(hDlg, nIDButton, wCheck)	boolean	166
CheckMenuItem	Changes checkmark to wIDCheckButton in group	Window menu	CheckMenuItem(hMenu, wIDCheckItem, wCheck)	boolean	167
CheckRadioButton	Determines which child window contains Point	Window dialog box	CheckRadioButton(hDlg, nIDFirstButton, nIDLastButton, nIDCheckButton)	boolean	168
ChildWindowFromPoint	Draws a chord (ellipse intersection with line segment)	Window dialog box	ChildWindowFromPoint(hwndParent, Point)	boolean	168
Chord	Draws a chord (ellipse intersection with line segment)	GDI output	Chord(hDC, X1, Y1, X2, Y2, X3, Y3, X4, Y4)	boolean	169
ClearCommBreak	Clears comm break state for nCid device	Communications	ClearCommBreak(nCid)	boolean	169
ClientToScreen	Converts client coords to equiv. screen coords	Window coordinate	ClientToScreen(hwnd, lpPoint)	boolean	170
ClipCursor	Restricts mouse cursor to given rectangle on screen	Window cursor	ClipCursor(lpRect)	boolean	170
CloseClipboard	Closes the clipboard	Window clipboard	CloseClipboard()	boolean	171
CloseComm	Closes comm device (first flushes voice queues)	Communications	CloseComm(nCid)	boolean	171
CloseMetaFile	Closes metafile and creates handle	GDI metafile	CloseMetaFile(hDC)	hMF	171
CloseSound	Closes play device (first flushes voice queues)	Sound	CloseSound()	boolean	172
CloseWindow	Closes specified window	Window display	CloseWindow(hwnd)	boolean	172
CombineRgn	Combines two existing regions into new region	GDI region	CombineRgn(hDestRgn, hSrcRgn1, hSrcRgn2, nCombineMode)	boolean	173
CopyMetaFile	Copies metafile to lpFilename and returns new hMF	GDI metafile	CopyMetaFile(hSrcMetaFile, lpFilename)	boolean	174
CopyRect	Copies an existing rectangle	Window rectangle	CopyRect(lpDestRect, lpSourceRect)	boolean	174
CountClipboardFormats	Returns number of formats clipboard can render	Window clipboard	CountClipboardFormats()	nCount	174
CountVoiceNotes	Counts number of notes in voice queue	Sound	CountVoiceNotes(nVoice)	nNotes	175
CreateBitmap	Creates bitmap of specified height, width, pattern	GDI drawing	CreateBitmap(nWidth, nHeight, nPlanes, nBitCount, lpBits)	hBitmap	175
CreateBitmapIndirect	Creates bitmap from existing bitmap	GDI drawing	CreateBitmapIndirect(lpBitmap)	hBitmap	176
CreateBrushIndirect	Creates logical brush from existing brush	GDI drawing	CreateBrushIndirect(lpLogBrush)	hBrush	176
CreateCaret	Creates caret for hwnd using hBitmap	Window caret	CreateCaret(hwnd, hBitmap, nWidth, nHeight)	boolean	177
CreateCompatibleBitmap	Creates bitmap compatible with device hDC	GDI drawing	CreateCompatibleBitmap(hDC, nWidth, nHeight)	hBitmap	178
CreateDC	Creates memory display context compat. with hDC	GDI display context	CreateDC(lpDriverName, lpDeviceName, lpOutput, lpInitData)	hDC	178
CreateDCCom	Creates display context for specified device	GDI display context	CreateDCCom(hDevice, hDriverName, hPrinter, lpDialogFunc)	hDC	180
CreateDialog	Creates modeless dialog box	Window dialog box	CreateDialog(hInstance, lpTemplateName, hwndParent, lpDialogFunc)	boolean	182
CreateDialogIndirect*	Creates modeless dialog box like one in lpDialog1 template	Window dialog box	CreateDialogIndirect(hInstance, lpTemplateName, hwndParent, lpDialogFunc, lpDialog1Template, nWidth, nHeight)	boolean	184
CreateDiscardableBitmap	Creates discardable bitmap	GDI drawing	CreateDiscardableBitmap(hDC, nWidth, nHeight)	hBitmap	184
CreateEllipticRgn	Creates elliptical region bounded by rect X1, Y1, X2, Y2	GDI region	CreateEllipticRgn(X1, Y1, X2, Y2)	hRgn	185
CreateEllipticRgnIndirect*	Creates elliptical region bounded by lpRect	GDI region	CreateEllipticRgnIndirect(lpRect)	hRgn	185
CreatorFont	Creates logical font	GDI drawing	CreatorFont(nHeight, nWidth, nEscapement, nOrientation, nWeight, cItalic, cUnderline, cStrikeOut, nCharSet, cOutputPrecision, cClipPrecision, cQuality, cPitchAndFamily, lpFaceName)	hFont	188
CreatorFontIndirect	Creates logical font like lpLogFont	GDI drawing	CreatorFontIndirect(lpLogFont)	hFont	188
CreatorHatchBrush	Creates logical brush with hatched pattern	GDI drawing	CreatorHatchBrush(nIndex, rgbColor)	hBrush	189
CreatorInfo	Creates information context for device	GDI display context	CreatorInfo(hDeviceName, lpDeviceName, lpOutput, lpInitData)	hIC	189
CreateMenu	Creates menu	Window menu	CreateMenu()	hMenu	190
CreateMetaFile	Creates metafile display context	GDI metafile	CreateMetaFile(lpFilename)	hDC	191

(Continued)

Table 6.72. Continued

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
CreatePatternBrush	Creates logical brush with h3tmap pattern	GDI drawing	CreatePatternBrush(hBitmap)	hBrush	191
CreatePen	Creates logical pen	GDI drawing	CreatePen(nPenStyle, nWidth, rgbColor)	hPen	192
CreatePenIndirect	Creates logical pen like lpLogPen	GDI drawing	CreatePenIndirect(lpLogPen)	hPen	193
CreatePolygonRgn	Creates polygonal region	GDI region	CreatePolygonRgn(lpPoints, nCount, nPolyFillMode)	hRgn	193
CreateRectRgn	Creates rectangular region	GDI region	CreateRectRgn(X1, Y1, X2, Y2)	hRgn	194
CreateRectRgnIndirect	Creates rectangular region sized like lpRect	GDI region	CreateRectRgnIndirect(lpRect)	hRgn	194
CreateSolidBrush	Creates logical brush of a solid color	GDI drawing	CreateSolidBrush(rgbColor)	hBrush	195
CreateWindow	Creates tiled, popup, or child window	Window creation	CreateWindow(lpClassName, lpWindowName, dwStyle, X, Y, nWidth, nHeight, hWndParent, hMenu, hInstance, lpParam)	hWnd	195
DefHookProc*	Provides default hook processing of WM messages	Window message	DefHookProc(code, wParam, lParam, lpInNextHook)	code	206
DefWindowProc	Do default processing of messages that are ignored	Window default	DefWindowProc(hWnd, wParam, lParam, lpInNextHook)	hReply	206
DeleteAtom	Deletes atom if its reference count is zero	Atom manager	DeleteAtom(nAtom)	nOkAtom	207
DeleteDC	Deletes specified display context	GDI display context	DeleteDC(hDC)	hDeleted	208
DeleteMetaFile	Deletes object to metafile; frees system resources	GDI metafile	DeleteMetaFile(hMF)	hDeleted	208
DestroyObject	Deletes object by freeing system storage	GDI selection	DestroyObject(hObject)	None	208
DestroyCaret	Destroys current caret and memory it occupies	Window caret	DestroyCaret()	None	208
DestroyMenu	Destroys hMenu and frees memory it occupies	Window menu	DestroyMenu(hMenu)	None	208
DestroyWindow	Sends WM_DESTROY message; frees memory	Window creation	DestroyWindow(hWnd)	hDestroyed	210
DeviceMode	Displays dialog box for setting printer modes	Utility	DeviceMode(hWnd, hItem, lpString, lpString)	hDestroyed	210
DialogBox	Creates modal dialog box like hDI template	Window dialog box	DialogBox(hInstance, lpTemplateName, hWndParent, lpDialogFunc)	hResult	211
DialogBoxIndirect*	Creates modal dialog box like hDI template	Window dialog box	DialogBoxIndirect(hInstance, hDI Template, hWndParent, lpDialogFunc)	hResult	211
DispatchMessage	Passes message to window function in MSG structure	Window message	DispatchMessage(lpMsg)	hResult	212
DlgDirList	Fills hDIListBox with files matching lpDirNameSpec	Window dialog box	DlgDirList(hDlg, lpDirNameSpec, nIDListBox, nIDStaticPath, wFileTypes)	nListed	215
DlgDirSelect	Copies selection from hDIListBox to lpString	Window dialog box	DlgDirSelect(hDlg, lpString, nIDListBox)	hDirectory	217
DPItoP	Converts device points into logical points	GDI conversion	DPItoP(hDC, lpPoints, nCount)	bConverted	217
DrawIcon	Draws icon with upper-left corner at X, Y	GDI output	DrawIcon(hDC, X, Y, hIcon)	hDrawn	218
DrawMenuBar	Redraws menu bar	Window menu	DrawMenuBar(hWnd)	None	219
DrawText	Draws nCount chars of lpString clipped in lpRect	GDI output	DrawText(hDC, lpString, nCount, lpRect, wFormat)	Height of text	219
Ellipse	Draws ellipse with center in X1, Y1, X2, Y2 rect	GDI output	Ellipse(hDC, X1, Y1, X2, Y2)	hDrawn	222
EmptyClipboard	Empties clipboard; frees data handles	Window clipboard	EmptyClipboard()	bEmptied	222
EnableHardwareInput*	Enables/disables mouse and keyboard	Window input	EnableHardwareInput(fEnableInput)	bEnabled	223
EnableMenuItem	Enables, disables, or grays menu item	Window menu	EnableMenuItem(hMenu, wIDEnableItem, wEnable)	bEnabled	223
EnableWindow	Enables or disables mouse; keyboard input to hWnd	Window menu	EnableWindow(hWnd, bEnable)	bDone	224
EndDialog	Frees resources and destroys windows of dialog box	Window input	EndDialog()	None	225
EndPaint	Marks end of window repainting	Window dialog box	EndPaint(hDlg, nResult)	None	225
EnumChildWindows	Enumerates child windows of hWndParent	Window painting	EnumChildWindows(hWndParent, lpEnumFunc, lpParam)	bDone	226
EnumClipboardFormats	Enumerates available clipboard formats	Window display	EnumClipboardFormats(wFormat)	wNextFormat	228
EnumFonts	Enumerates fonts available on device	Window clipboard	EnumFonts(hDC, lpScanName, lpFontFunc, lpData)	nResult	228
EnumMetaFile*	Enumerates GDI calls in a metafile	GDI information	EnumMetaFile(hDC, hMF, lpCallbackFunc, lpClientData)	bEnumerated	230
EnumObjects	Enumerates objects available on device	GDI information	EnumObjects(hDC, nObjectType, lpObjectFunc, lpData)	nResult	231
EnumProps	Enumerates each property of hWnd to lpEnumFunc	Window property	EnumProps(hWnd, lpEnumFunc)	nResult	233
EnumTaskWindows*	Enumerates all windows associated with a task	Window information	EnumTaskWindows(hTask, lpEnumFunc, lpParam)	bEnumerate	235
EnumWindows	Enumerates all windows on screen	Window display	EnumWindows(lpEnumFunc, lpParam)	bDone	236
EqualRect	Determines whether two rectangles are equal	Window display	EqualRect(lpRect1, lpRect2)	bEqual	237
EqualRgn	Determines if two regions are identical	GDI information	EqualRgn(hSrcRgn1, hSrcRgn2)	bEqual	237
Escape	Accesses device facilities not available through GDI	GDI region	Escape(hDC, nEscape, nCount, lpInData, lpOutData)	nResult	238
Escape (ABORTDOC)	Aborts current job	GDI control	Escape(hDC, ABORTDOC, Null, lpInData, lpOutData)	nResult	681
Escape (BANDINQEO)*	Sends data directly to printer	GDI control	Escape(hDC, BANDINQEO, nCount, lpInData, lpOutData)	nResult	681
Escape (BANDINQEO)	Aborts current job	GDI control	Escape(hDC, BANDINQEO, nCount, lpInData, lpOutData)	nResult	681
Escape (BANDINQEO)	Sends data directly to printer	GDI control	Escape(hDC, BANDINQEO, nCount, lpInData, lpOutData)	nResult	681
Escape (DRAFTMODE)	Turns draft mode ON or OFF	GDI control	Escape(hDC, DRAFTMODE, 2, lpDraftMode, lpInData)	nResult	684
Escape (DRAFTMODE)	Creates pattern using rules for PCL printers	GDI control	Escape(hDC, DRAFTMODE, nCount, lpInData, lpOutData)	nResult	684
Escape (ENABLEDUPLICATE)*	Enables duplex printing capabilities	GDI control	Escape(hDC, ENABLEDUPLICATE, nCount, lpInData, lpOutData)	nResult	684
Escape (ENABLEDUPLICATE)	Enables or disables terming ability of device	GDI control	Escape(hDC, ENABLEDUPLICATE, nCount, lpInData, lpOutData)	nResult	686
Escape (ENABLEPAIRKERNING)*	Enables or disables relative character widths on device	GDI control	Escape(hDC, ENABLEPAIRKERNING, nCount, lpInData, lpOutData)	nResult	687
Escape (ENABLEPAIRKERNING)	Enables or disables relative character widths on device	GDI control	Escape(hDC, ENABLEPAIRKERNING, nCount, lpInData, lpOutData)	nResult	687
Escape (ENABLERELATIVEWIDTHS)	Enables or disables relative character widths on device	GDI control	Escape(hDC, ENABLERELATIVEWIDTHS, nCount, lpInData, lpOutData)	nResult	687
Escape (EXTTEXTOUT)	More efficient TEXTOUT for justification and kerning	GDI control	Escape(hDC, EXTTEXTOUT, nCount, lpInData, lpOutData)	nResult	689
Escape (EXTTEXTOUT)	Enables output in device buffer	GDI control	Escape(hDC, EXTTEXTOUT, nCount, lpInData, lpOutData)	nResult	691
Escape (FLUSHOUTPUT)	Flushes output in device buffer	GDI control	Escape(hDC, FLUSHOUTPUT, Null, lpInData, lpOutData)	nResult	691
Escape (GETCOLORTABLE)	Copies RGB color table to lpOutData	GDI control	Escape(hDC, GETCOLORTABLE, Null, lpInData, lpOutData)	nCount	691
Escape (GETEXTENDEDTEXTMETRICS)	Fills buffer with extended text metrics for font	GDI control	Escape(hDC, GETEXTENDEDTEXTMETRICS, nCount, lpInData, lpOutData)	nCount	691

(Continued)

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
Escape (GETTEXTTABLE)	Returns width of individual group of consec chars	GDI control	Escape(nDC, GETTEXTTABLE, nCount, lpInData, lpOutData)	nCount	692
Escape (GETPAIRKERNTABLE)	Fills buffer at lpOutData with kerning pair table for font	GDI control	Escape(nDC, GETPAIRKERNTABLE, nCount, lpstrNull, lpOutData)	nCount	693
Escape (GETPHYSPAGESET)	Copies physical page size to lpOutData POINT structure	GDI control	Escape(nDC, GETPHYSPAGESET, nCount, lpstrNull, lpDimensions)	nResult	694
Escape (GETPRINTINGOFFSET)	Copies printing offset to lpOutData POINT structure	GDI control	Escape(nDC, GETPRINTINGOFFSET, nCount, lpstrNull, lpOffset)	nResult	694
Escape (GETSCALINGFACTOR)	Returns scaling factors for x and y axes of printer	GDI control	Escape(nDC, GETSCALINGFACTOR, nCount, lpstrNull, lpFactors)	nCount	695
Escape (GETTRACKKERNTABLE)	Fills buffer at lpOutData with track kerning table for font	GDI control	Escape(nDC, GETTRACKKERNTABLE, nCount, lpInData, lpOutData)	nCount	695
Escape (MFCOMMENT)	Adds comment to metafile	GDI control	Escape(nDC, MFCOMMENT, nCount, lpComment, lpstrNull)	nResult	696
Escape (NEWFRAME)	Ends writing to a page	GDI control	Escape(nDC, NEWFRAME, nCount, lpstrNull, lpstrNull)	nResult	696
Escape (NEXTBAND)	Ends writing to a band	GDI control	Escape(nDC, NEXTBAND, nCount, lpstrNull, lpBandRect)	nResult	697
Escape (QUERYESCUPPORT)	Tests whether device supports Escap <sup>3</sup>	GDI control	Escape(nDC, QUERYESCUPPORT, 2, lpEscNum, lpstrNull)	nResult	698
Escape (SELECTPAPERSOURCE)	Determines and selects available paper sources	GDI control	Escape(nDC, SELECTPAPERSOURCE, 2, lpInData, lpOutData)	nResult	698
Escape (SELETPROCC)	Sets abort function for print task	GDI control	Escape(nDC, SELETPROCC, nCount, lpAbortFunc, lpstrNull)	nResult	698
Escape (SETALLJUSTVALUES)	Sets text justification values	GDI control	Escape(nDC, SETALLJUSTVALUES, nCount, lpInData, lpOutData)	nResult	699
Escape (SETCOLORTABLE)	Sets RGB color table entry	GDI control	Escape(nDC, SETCOLORTABLE, nCount, lpColorEntry, lpColor)	nResult	701
Escape (SETCOPYSOURCE)	Specifies number of copies per page to print (uncolored)	GDI control	Escape(nDC, SETCOPYSOURCE, 2, lpInData, lpOutData)	nResult	702
Escape (SETLINECAP)	Specifies which kerning track to use	GDI control	Escape(nDC, SETLINECAP, nCount, lpInData, lpOutData)	nResult	702
Escape (SETLINEJOIN)	Sets line end cap	GDI control	Escape(nDC, SETLINEJOIN, nCount, lpInData, lpOutData)	nResult	703
Escape (SETMITERLIMIT)	Sets miter limit for a device	GDI control	Escape(nDC, SETMITERLIMIT, nCount, lpInData, lpOutData)	nResult	703
Escape (STARTDOC)	Starts print task	GDI control	Escape(nDC, STARTDOC, nDocLength, lpDocName, lpstrNull)	nResult	705
Escape (STRETCHBLT)	Implements StretchBlt on driver level	GDI control	Escape(nDC, STRETCHBLT, nCount, lpInData, lpOutData)	nResult	706
EscapeCommFunction	Executes escape function nFunc for device nCid	GDI control	EscapeCommFunction(nCid, nFunc)	nResult	707
ExcludeClipRect	Creates new clipping region for rectangle	Communications	ExcludeClipRect(hdc, X1, Y1, X2, Y2)	nResult	238
ExcludeUpdateRgn*	Excludes a region in window from clipping region for window	GDI clipping rgn	ExcludeUpdateRgn(hdc, hWnd)	nResult	239
ExtTextOut*	Writes character string within rect region on display	GDI output	ExtTextOut(hdc, X, Y, wOptions, lpRect, lpString, nCount, lpDx)	nResult	240
FillRect	Fills Windows and prompts through AUX	Outputting	FillRect(hdc, lpRect, hBrush)	None	241
FillRect	Fills rectangle using specified brush	GDI output	FillRect(hdc, lpRect, hBrush)	None	243
FillRect	Fills region with specified brush	GDI output	FillRect(hdc, lpRect, hBrush)	None	243
FindAtom	Retrieves atom associated with lpString	Atom manager	FindAtom(lpString)	wAtom	244
FindResource	Locates resource lpName of type lpType	Resource manager	FindResource(hInstance, lpName, lpType)	hResource	245
FindWindow	Returns handle of window	Window property	FindWindow(lpClassName, lpWindowName)	hWnd	246
FlashWindow	Flashes window once	Window error	FlashWindow(hWnd, bInvert)	blnverted	247
FlushComm	Fills area with current brush starting at X, Y	GDI output *	FlushComm(nCid, nQueue)	blnverted	247
FrameRect	Flashes characters from queue of device nCid	Communications	FrameRect(hdc, lpRect, hBrush)	None	248
FrameRgn	Draws border for rectangle	GDI output	FrameRgn(hdc, lpRect, hBrush, nWidth, nHeight)	blnverted	249
FreeLibrary	Removes library module if reference count is zero	Module manager	FreeLibrary(hLibModule)	None	250
FreeProcInstance	Removes function instance at address lpProc	Module manager	FreeProcInstance(lpProc)	None	250
FreeResource	Removes resource from memory if ref count is zero	Resource manager	FreeResource(hResource)	None	251
GetActiveWindow	Returns handle to active window	Window display	GetActiveWindow()	hWnd	252
GetAspectRatioFilter	Gets setting of current aspect-ratio filter	Window input	GetAspectRatioFilter(hdc)	nState	252
GetAsyncKeyState*	Determines whether key is up or down	Window input	GetAsyncKeyState(vKey)	hMem	252
GetAtomHandle	Returns handle of atom string	Atom manager	GetAtomHandle(wAtom)	nLength	253
GetAtomName	Copies nSize chars of string of atom to lpBuffer	Atom manager	GetAtomName(nAtom, lpBuffer, nSize)	lpCopied	254
GetBitmapBits	Copies lCount bits of bitmap to lpBits buffer	GDI drawing	GetBitmapBits(hBimap, dwCount, lpBits)	piDimensions	254
GetBitmapDimension	Returns width and height of bitmap	GDI display context	GetBitmapDimension(hBimap)	rgbColor	255
GetBKColor	Returns current background color of device	GDI display context	GetBKColor(hdc)	nBMAMode	255
GetBKMode	Returns background mode of device	GDI display context	GetBKMode(hdc)	dwOrigin	255
GetBrushOrg	Returns current brush origin	Utility	GetBrushOrg(hdc)	hWnd	256
GetBValue	Returns blue component of rgbColor	Window input	GetBValue(rgbColor)	wkSeconds	257
GetCapture*	Determines which window is receiving mouse input	Window caret	GetCapture()	None	257
GetCaretBlinkTime	Returns current caret flash rate	Window caret	GetCaretBlinkTime()	None	257
GetCaretPos*	Returns current caret position	GDI output	GetCaretPos(lpPoint)	None	257
GetCharWidth*	Retrieves width of a character	Window class	GetCharWidth(hdc, wChar, wLastChar, lpBuffer)	None	258
GetClassLong	Returns info at index in WNDCLASS structure	Window class	GetClassLong(hWnd, nIndex)	None	259
GetClassName	Copies nMaxCount chars of hWnd's class name	Window class	GetClassName(hWnd, lpClassName, nMaxCount)	None	259
GetClassWord	Returns info at index in WNDCLASS structure	Window class	GetClassWord(hWnd, nIndex)	None	259
GetClientRect	Copies window client area coords to lpRect	Window attributes	GetClientRect(hWnd, lpRect)	None	260
GetClipboardData	Returns data from clipboard in specified format	Window clipboard	GetClipboardData(wFormat)	hClipboard	261
GetClipboardFormatName	Copies nMaxCount chars of format to lpFormatName	Window clipboard	GetClipboardFormatName(wFormat, lpFormatName, nMaxCount)	hClipboard	261
GetClipboardOwner	Returns window handle of clipboard owner	Window clipboard	GetClipboardOwner()	hWnd	262

(Continued)

Table 6.72. Continued

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
GetClipboardViewer	Returns window handle of 1st window in viewer chain	Window clipboard	GetClipboardViewer()	hWnd	263
GetClipboard	Copies clipping rect boundary to ipRect	GDI clipping obj	GetClipboardInfo(&ipRect)	nRect	263
GetCodePage	Returns handle of code segment containing function	Module manager	GetCodePage()	hInstance	264
GetCommError	Fills lpStar buffer with status of nCid device	Communications	GetCommError(nCid,lpStar)	wError	264
GetCommEventMask	Returns, then clears, the event mask for nCid	Communications	GetCommEventMask(nCid,nEvtMask)	wResult	266
GetCommState	Fills lpDCB buffer with DCB of nCid device	Communications	GetCommState(nCid,lpDCB)	nResult	266
GetCurrentPosition	Returns logical coords of current position	GDI output	GetCurrentPosition(hDC)	lpPos	267
GetCurrentTask	Returns handle of current task	Task	GetCurrentTask()	hTask	267
GetCurrentTime	Returns elapsed time since boot	Window message	GetCurrentTime()	lTime	267
GetCursorPos	Stores cursor position in POINT structure	Window cursor	GetCursorPos(lpPoint)	None	268
GetDC	Returns display context of client area for window	Window painting	GetDC(hWnd)	hDC	268
GetDCOrg	Returns origin for display context	Window painting	GetDCOrg(hDC)	lpPoint	268
GetDeviceCaps	Returns device-specific info	GDI information	GetDeviceCaps(hDC,nIndex)	nValue	269
GetDlgItem	Returns dialog control handle	Window dialog box	GetDlgItem(hDlg,nIDDlgItem)	hCtrl	274
GetDlgItemInt	Translates text of nIDDlgItem to integer value	Window dialog box	GetDlgItemInt(hDlg,nIDDlgItem,lpTranslated,lpSigned)	wValue	274
GetDlgItemText	Copies nMaxCount chars of control text to lpString	Window dialog box	GetDlgItemText(hDlg,nIDDlgItem,lpString,nMaxCount)	nCoped	275
GetDoubleClickTime	Returns doubleclick time for mouse	Window input	GetDoubleClickTime()	wClickTime	276
GetEnvironment	Copies device environment to lpEnviron	GDI information	GetEnvironment(lpPortName,lpEnviron,nMaxCount)	nCoped	276
GetFocus	Returns handle of window with input focus	Window input	GetFocus()	hWnd	277
GetGVValue	Returns green component of rgbColor	Utility	GetGVValue(rgbColor)	cGreen	277
GetInputState	Determines whether there are input events in queue	Window input	GetInputState()	bEvent	277
GetInstanceData	Copies nCount bytes from hInstance to pData	Module manager	GetInstanceData(hInstance,pData,nCount)	nBytes	278
GetKeyboardState	Copies status of virtual keys to a buffer	Window input	GetKeyboardState(lpKeyState)	none	278
GetKeyState	Returns state of virtual key	Window input	GetKeyState(nVirtKey)	nState	279
GetMapMode	Returns current mapping mode	GDI clipping obj	GetMapMode(hDC)	hMapMode	282
GetMenu	Returns handle to window's menu	Window menu	GetMenu(hWnd)	hMenu	282
GetMenuItemCount	Determines how many items are in hMenu	Window menu	GetMenuItemCount(hMenu)	nItems	282
GetMenuItemID	Obtains identifier for a menu item	Window menu	GetMenuItemID(hMenu,nID)	nID	283
GetMenuState	Identifies top-level menu	Window menu	GetMenuState(hMenu,wID,wFlags)	wItem	283
GetMenuString	Copies nMaxCount chars of menu label to lpString	Window menu	GetMenuString(hMenu,wID,lpString,nMaxCount,wFlag)	nCoped	284
GetMessage	Retrieves message	Window message	GetMessage(lpMsg,lpWnd,wMsg,lpWnd,lpMsgFilterMax)	bContinue	285
GetMessagePos	Returns mouse position screen coords at last message	Window message	GetMessagePos()	dwPos	286
GetMessageTime	Returns time of last message	Window message	GetMessageTime()	lTime	287
GetMetaFile	Creates handle for metafile named by lpFileName	GDI metafile	GetMetaFile(lpFileName)	hMetaFile	287
GetModuleFileBits	Stores metafile bits in global memory block	GDI metafile	GetModuleFileBits(hMetaFile)	hMetaFile	288
GetModuleFileName	Copies module filename to lpFileName	Module manager	GetModuleFileName(hModule,lpFileName,nSize)	nLength	288
GetModuleHandle	Returns module handle	Module manager	GetModuleHandle(lpModuleName)	hModule	289
GetModuleUsage	Returns reference count of module hModule	Module manager	GetModuleUsage(hModule)	nCount	289
GetNearestColor	Returns device color closest to rgbColor	GDI conversion	GetNearestColor(hDC,rgbColor)	rgbSolidColor	289
GetNextDlgTabItem*	Searches for next control in group of dialog controls	Window dialog box	GetNextDlgTabItem(hDlg,hCtrl,lpPrevious)	hCtrl	290
GetNextWindow*	Obtains handle for first control preceding another	Window dialog box	GetNextWindow(hWnd,wFlag)	hWnd	291
GetNumTasks*	Searches for next window handle	Task	GetNumTasks()	nTasks	291
GetObject	Returns number of tasks in system	GDI selection	GetObject(hObject,nCount,lpObject)	nCoped	292
GetParent	Copies nCount bytes of hObject data to lpObject	Window attribute	GetParent(hWnd)	hWndParent	292
GetPixel	Retrieves RGB color of pixel at X,Y	GDI output	GetPixel(hDC,x,y)	rgbColor	293
GetPolyFillMode	Retrieves current polygon filling mode	GDI display context	GetPolyFillMode(hDC)	nPolyFillMode	294
GetProcAddress	Returns address of lpProcName function	Module manager	GetProcAddress(hModule,lpProcName)	lpAddress	295
GetProfileInt	Returns integer info from WIN.INI file	Windows ini file	GetProfileInt(lpAppName,lpKeyName,nDefault)	nKeyValue	295
GetProfileString	Returns string info from WIN.INI file	Windows ini file	GetProfileString(lpAppName,lpKeyName,lpDefault,lpReturnedString,nSize)	nLength	296
GetProp	Returns handle associated with lpString	Window property	GetProp(hWnd,lpString)	hData	297
GetRetAbs	Returns the relabs flag	GDI display context	GetRetAbs(hDC)	nRetAbsMode	298
GetROP2	Returns current drawing mode	GDI display context	GetROP2(hDC)	nDrawMode	299
GetRValue	Returns the red component of rgbColor	Utility	GetRValue(rgbColor)	cRed	299
GetScrollPos	Returns current position of scrollbar	Window scrolling	GetScrollPos(hWnd,nBar)	nPos	300
GetScrollRange	Copies min/max scrollbar positions	Window scrolling	GetScrollRange(hWnd,nBar,lpMinPos,lpMaxPos)	None	300
GetStockObject	Returns handle to predefined object	GDI drawing obj	GetStockObject(nIndex)	hObject	301
GetStretchBltMode	Returns current stretching mode	GDI display context	GetStretchBltMode(hDC)	nStretchMode	303

(Continued)

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
GetSubMenu	Returns menu handle of popup menu	Window menu	GetSubMenu(hMenu,nPos)	HMENU	303
GetSysColor	Returns system color identified by nIndex	Window sys info	GetSysColor(nIndex)	DWORD	303
GetSystemMode	Returns handle of system mode window, if present	Window attribute	GetSystemMode()	HWND	304
GetSystemMenu	Allows access to system menu	Window menu	GetSystemMenu(hWnd,bRevert)	HMENU	304
GetSystemMetrics	Returns information about system metrics	Window sys info	GetSystemMetrics(nIndex)	int	305
GetTempDir	Returns optimal drive letter for temp file	File IO	GetTempDir()	LPCTSTR	307
GetTempFileName	Creates temporary file name	File IO	GetTempFileName(ChDriveLetter,lpPrefix,String,wUniqueNumber)	LPCTSTR	308
GetTextAlign	Returns status of text alignment flag	GDI text justify	GetTextAlign(hDC)	int	310
GetTextCharacterExtra	Returns current intercharacter spacing	GDI display context	GetTextCharacterExtra(hDC)	int	310
GetTextColor	Returns current text color	GDI text justify	GetTextColor(hDC)	DWORD	310
GetTextExtent	Computes width and height of text line in lpString	GDI text justify	GetTextExtent(hDC,lpString,nCount)	TEXTMETRIC	310
GetTextFace	Copies current font face name to lpFaceName	GDI text justify	GetTextFace(hDC,nCount,lpFaceName)	LPCTSTR	311
GetTextMetrics	Fills buffer with metrics for current font	GDI information	GetTextMetrics(hDC,lpMetrics)	TEXTMETRIC	311
GetThresholdEvent	Returns pointer to threshold flag	Sound	GetThresholdEvent()	HANDLE	312
GetTickCount	Returns time since system started	Utility	GetTickCount()	DWORD	313
GetTopWindow	Returns handle to top-level child window	Window display	GetTopWindow(hWnd)	HWND	313
GetUpdateRect	Copies dim of rect that needs updating to lpRect	Window painting	GetUpdateRect(hWnd,lpRect,bErase)	BOOL	313
GetUpdateRgn	Copies window's update region to specified region	Window painting	GetUpdateRgn(hWnd,hRgn,bErase)	BOOL	314
GetVersion	Returns Windows version number	Module manager	GetVersion()	DWORD	314
GetViewportExt	Returns x,y extent of display context's viewport	GDI display context	GetViewportExt(hDC)	POINT	315
GetViewportOrg	Returns x,y coords of display context viewport org	GDI display context	GetViewportOrg(hDC)	POINT	316
GetWindow	Searches for window in window manager's list	Window manager	GetWindow(hWnd,wCmd)	HWND	316
GetWindowDC	Returns display context for entire window	Window painting	GetWindowDC(hWnd)	HDC	317
GetWindowExt	Returns x,y extents of display context's window	GDI display context	GetWindowExt(hDC)	POINT	318
GetWindowLong	Returns information about window	Window creation	GetWindowLong(hWnd,nIndex)	LONG	318
GetWindowOrg	Returns x,y coords of display context window origin	GDI display context	GetWindowOrg(hDC)	POINT	319
GetWindowRect	Copies dimensions of entire window to lpRect	Window attribute	GetWindowRect(hWnd,lpRect)	RECT	319
GetWindowTask	Returns task handle	Task	GetWindowTask(hWnd)	HANDLE	319
GetWindowText	Copies window's caption into lpString	Window attribute	GetWindowText(hWnd,lpString,nMaxCount)	int	320
GetWindowTextLength	Returns length of window's caption or text	Window attribute	GetWindowTextLength(hWnd)	int	321
GetWindowWord	Returns information about window	Window creation	GetWindowWord(hWnd,nIndex)	WORD	321
GlobalAlloc	Adds global atom to the atom table	Atom manager	GlobalAlloc(lpString)	HATOM	322
GlobalCompact	Compacts global memory to free dwMinFree bytes	Memory manager	GlobalCompact(dwMinFree)	int	324
GlobalDeleteAtom	Deletes global atom from the atom table	Atom manager	GlobalDeleteAtom(nAtom)	int	325
GlobalDiscard	Discards global memory block if ref count is zero	Memory manager	GlobalDiscard(hMem)	int	326
GlobalFindAtom	Finds character string within atom table	Atom manager	GlobalFindAtom(lpString)	HATOM	326
GlobalFree	Returns memory type of global memory block	Memory manager	GlobalFree(hMem)	int	327
GlobalGetAtomName	Removes global memory block, if ref count is zero	Memory manager	GlobalGetAtomName(nAtom,lpBuffer,nSize)	int	327
GlobalHandle	Returns copy of string associated with an atom	Atom manager	GlobalHandle(hMem)	LPCTSTR	328
GlobalLock	Returns handle of global memory object	Memory manager	GlobalLock(hMem)	HGLOBAL	328
GlobalReAlloc	Reallocates global memory block, if nMem, ups ref count	Memory manager	GlobalReAlloc(hMem,dwBytes,wFlags)	HGLOBAL	329
GlobalSize	Reallocates global memory block to dwBytes	Memory manager	GlobalSize(hMem)	HGLOBAL	331
GlobalUnlock	Returns the size of global memory block, in bytes	Memory manager	GlobalUnlock(hMem)	int	331
GlobalUnwire	Unlocks block, decreases reference count	Memory manager	GlobalUnwire(hMem)	int	332
GlobalWire	Locks memory segment	Memory manager	GlobalWire(hMem)	int	332
GrayString	Moves segment to low memory and locks it	GDI output	GrayString(hDC,hBrush,lpOutputFunc,lpData,nCount,X,Y,nWidth,nHeight)	int	332
HIBYTE	Writes nCount chars of String using brush to gray	Utility	HIBYTE(nInteger)	int	335
HideCaret	Returns in-order byte of minileg	Window caret	HideCaret(hWnd)	int	335
HiliteMenuItem	Removes system caret from window	Window menu	HiliteMenuItem(hWnd,hMenu,wID,HiliteItem,wHilite)	int	337
HIMORPH	Fills or unhilites top-level menu item	Window menu	HIMORPH(hWnd)	int	337
InitiateRect	Returns n-order word of integer	Window menu	InitiateRect(hWnd,X,Y)	int	338
InitAtomTable	Resizes lpRect by X units horiz and Y units vertically	Window rectangle	InitAtomTable(nSize)	int	338
InSendMessage	Initializes atom hash table	Atom manager	InSendMessage()	int	338
InSendMessage	Returns True if function is processing SendMessage	Window message	InSendMessage()	int	339
IntersectClipRect	Forms new clipping region from intersection	GDI clipping	IntersectClipRect(hDC,X1,Y1,X2,Y2)	int	339
IntersectRect	Finds intersection of two rects, copies to lpDestRect	Window rectangle	IntersectRect(lpDestRect,lpSrc1Rect,lpSrc2Rect)	int	340
InvalidateRect	Finds intersection of two rects, copies to lpDestRect	Window painting	InvalidateRect(hWnd,lpRect,bErase)	int	340

(Continued)

Table 6.72. Continued

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
InvalidateRgn	Marks hRgn for repainting	Window painting	InvalidateRgn(hWnd, hRgn, bErase)	None	342
InvertRect	Inverts display bits of lpRect	GDI output	InvertRect(hdc, lpRect)	HRESULT	343
InvertRgn	Inverts colors in hRgn	GDI output	InvertRgn(hdc, hRgn)	Inverted	343
IsChild	Returns TRUE if window is child of hParentWnd	Window display	IsChild(hWnd, hParent, hWnd)	BChild	344
IsClipboardFormatAvailable	Returns TRUE if data is available in wParam	Window clipboard	IsClipboardFormatAvailable(wFormat)	BAvailable	344
IsDialogMessage	Determines whether wParam is intended for modeless dialog	Window dialog box	IsDialogMessage(hDlg, lParam)	BUsed	345
IsDlgButtonChecked	Returns state of nIDButton	Window dialog box	IsDlgButtonChecked(nDlg, nIDButton)	wCheck	345
IsIconic	Returns status of window (iconic or open)	Window display	IsIconic(hWnd)	BIconic	346
IsRectEmpty	Determines whether lpRect is empty	Window rectangle	IsRectEmpty(lpRect)	BEmpty	346
IsWindow	Determines whether hWnd is a valid, existing window	Window creation	IsWindow(hWnd)	BExists	347
IsWindowEnabled	Returns state of hWnd input from mouse and keyboard	Window input	IsWindowEnabled(hWnd)	BEnabled	347
IsWindowVisible	Determines whether hWnd is visible	Window display	IsWindowVisible(hWnd)	BVisible	347
IsZoomed*	Determines whether window is at maximum size	Window display	IsZoomed(hWnd)	BZoomed	348
KillTimer	Deletes timer event iden, filed by hWnd and nIDEvent	Window input	KillTimer(hWnd, nIDEvent)	BKilled	348
LineTo	Completes successive points in line X1, Y1, X2, Y2	GDI output	LineTo(hdc, X1, Y1, X2, Y2)	None	350
LoadAccelerators	Draws line from current pos up to X, Y (but not X, Y)	Resource manager	LoadAccelerators(hInstance, lpTableName)	hRes	351
LoadBitmap	Loads accelerator table named by lpTableName	Resource manager	LoadBitmap(hInstance, lpBitmapName)	hBitmap	352
LoadCursor	Loads cursor named by lpCursorName	Resource manager	LoadCursor(hInstance, lpCursorName)	hCursor	353
LoadIcon	Loads icon named by lpIconName	Resource manager	LoadIcon(hInstance, lpIconName)	hIcon	354
LoadLibrary	Loads library module named by lpLibFileName	Resource manager	LoadLibrary(lpLibFileName)	hModule	355
LoadMenu	Loads menu named by lpMenuName	Resource manager	LoadMenu(hInstance, lpMenuName)	hMenu	355
LoadMenuIndirect*	Loads menu from lpMenu template	Resource manager	LoadMenuIndirect(lpMenuTemplate)	BLoaded	356
LoadResource	Loads the resource named by hResInfo	Resource manager	LoadResource(hInstance, hResInfo)	hResData	356
LoadString	Loads string, wID into buffer lpBuffer	Resource manager	LoadString(hInstance, wID, lpBuffer, nBufferMax)	HRESULT	357
LOBYTE	Returns low-order byte of nInteger	Utility	LOBYTE(nInteger)	DWORD	357
LocalAlloc	Allocates wBytes of memory from local heap	Memory manager	LocalAlloc(wFlags, wBytes)	hMem	358
LocalCompact	Compacts local memory to generate wMinFree free bytes	Memory manager	LocalCompact(wMinFree)	wLargest	358
LocalDiscard	Discards local memory block hMem if ref count is zero	Memory manager	LocalDiscard(hMem)	hOldMem	359
LocalFlags	Returns memory type of block hMem	Memory manager	LocalFlags(hMem)	wFlags	360
LocalFree	Deletes local memory block hMem if ref count is zero	Memory manager	LocalFree(hMem)	hOldMem	360
LocalFreeze	Prevents compaction of local heap	Memory manager	LocalFreeze(hMem)	None	361
LocalHandle	Returns handle of local heap	Memory manager	LocalHandle(hMem)	hMem	361
LocalHandleDelta	Returns handle of local memory object at wMem	Memory manager	LocalHandleDelta(hNewDelta)	hCurrentDelta	361
LocalInit	Sets entry count for each new handle table in local heap	Memory manager	LocalInit(wSegment, wStart, wEnd)	HRESULT	362
LocalLock	Permits compaction of local heap	Memory manager	LocalLock(hMem)	pAddress	362
LocalMem	Returns address of block, locks block, ups ref count by 1	Memory manager	LocalMem(hMem)	None	363
LocalNotify	Sets callback function for handling notification messages	Memory manager	LocalNotify(lpNotifyFunc)	lpPrevFunc	363
LocalReAlloc	Reallocates local memory block hMem to wBytes	Memory manager	LocalReAlloc(hMem, wBytes, wFlags)	hNewMem	364
LocalShrink*	Shrinks specified memory heap	Memory manager	LocalShrink(hSeg, wSize)	wSize	365
LocalSize	Returns the size of local block hMem, in bytes	Memory manager	LocalSize(hMem)	wBytes	366
LocalUnlock	Unlocks local memory block, decreases ref count by 1	Memory manager	LocalUnlock(hMem)	BResult	367
LockData	Locks data segment in memory	Memory manager	LockData(hMem)	hMem	367
LockResource	Returns address of hResInfo, locks it, ups ref count by 1	Resource manager	LockResource(hResData)	lpResData	368
LockSegment	Locks segment at address wSegment	Resource manager	LockSegment(wSegment)	hSegment	368
LOWORD	Returns low-order word of nInteger	Utility	LOWORD(nInteger)	wLowWord	369
LPtoDP	Converts logical points to device points	GDI conversion	LPtoDP(hdc, lpPoints, nCount)	BConverted	369
MAKEINTATOM	Casts integer as argument for AddAtom	Atom manager	MAKEINTATOM(nInteger)	nAtom	370
MAKEINTRESOURCE	Casts integer as argument for AddAtom	Atom manager	MAKEINTRESOURCE(nInteger)	lpIntegerID	370
MAKELONG	Creates unsigned long integer	Utility	MAKELONG(nLowWord, nHighWord)	dwInteger	370
MAKEPOINT	Converts long value into a POINT structure	Utility	MAKEPOINT(nInteger)	lpPoint	371
MakeProcInstance	Returns address for lpProc	Module manager	MakeProcInstance(lpProc, hInstance)	lpAddress	371
MapDialogRect	Converts dialog box coords to client coords	Window dialog box	MapDialogRect(hDlg, lpRect)	None	372
max	Returns maximum value of A and B	Utility	max(value 1, value 2)	nMaximum	373
MessageBeep	Generates a beep when message box displayed	Window error	MessageBeep(wType)	BBeep	373
MessageBox	Creates message box window	Window error	MessageBox(hWnd, lpText, lpCaption, wType)	nMessageBox	373
min	Returns minimum value of A and B	Utility	min(value 1, value 2)	nMinimum	374
MoveTo	Moves current position to point X, Y	GDI output	MoveTo(hdc, X, Y)	lpPrevPos	376

(Continued)

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
MoveWindow	Causes WM_SIZE message to be sent to hWnd	Window display	MoveWindow(hWnd, X, Y, nWidth, nHeight, bRepaint)	None	377
OEM toANSI	Converts OEM char string to ANSI string	String translation	OemToAnsi(lpOemStr, lpAnsiStr)	bTranslated	378
OnSetClipboard	Moves clipping region X units horiz and Y units vertically	GDI clipping rgn	OnSetClipboard(hDC, X, Y)	nRgnType	378
OnSetRect	Moves rectangle X units horiz and Y units vertically	Window rectangle	OnSetRect(hRect, X, Y)	nResult	379
OnSetFont	Moves region X unit horiz and Y units vertically	GDI region	OnSetFont(hRgn, X, Y)	nRgnType	380
OnSetFontOrig	Modifies viewport origin relative to current values	GDI region	OnSetFontOrig(hDC, X, Y)	piPrevPos	380
OnSetFontOrg	Modifies window origin relative to current values	Window display	OnSetFontOrg(hDC, X, Y)	piPrevPos	381
OpenClipboard	Opens clipboard (prevents other apps from modifying)	Window clipboard	OpenClipboard()	bOpened	381
OpenComm	Opens device named by lpCommName for comm use	Communications	OpenComm(lpCommName, nInQueue, nOutQueue)	nCID	382
OpenFile	Creates, opens, reopens, or deletes file named by lpFileName	File I/O	OpenFile(lpFileName, lpOpenBuf, wStyle)	nFile	383
OpenIcon	Opens specified window	Window display	OpenIcon(hWnd)	bOpened	384
OpenSound	Opens play device for exclusive use	Sound	OpenSound()	nVoices	385
PaintRgn	Fills hRgn with current brush	GDI output	PaintRgn(hDC, hRgn)	bFilled	386
PatBit	Combines bit pattern with one already on device	GDI output	PatBit(hDC, X, Y, nWidth, nHeight, dwROP)	bDrawn	386
PeekMessage	Places message (if any) at lpMsg	Window message	PeekMessage(lpMsg, hWnd, wMsgFilterMin, wMsgFilterMax, bRemoveMsg)	bPresent	387
Pie	Draws arc and connects two endpoints to center	GDI output	Pie(hDC, X1, Y1, X2, Y2, X3, Y3, X4, Y4)	bDrawn	389
PlayMetaFile	Plays contents of metafile on device context hDC	GDI metafile	PlayMetaFile(hDC, hMF)	bPlayed	390
PlayMetaFileRecord*	Plays metafile record by executing GDI calls	GDI metafile	PlayMetaFileRecord(hDC, lpHandleable, lpMetaRecord, nHnd)	None	391
Polygon	Draws polygon	GDI output	Polygon(hDC, lpPoints, nCount)	bDrawn	391
Polyline	Draws set of line segments	GDI output	Polyline(hDC, lpPoints, nCount)	bDrawn	392
PostAppMessage	Posts message to application	Window message	PostAppMessage(lTask, wParam, lParam)	bPosted	393
PostMessage	Posts message in application queue	Window message	PostMessage(hWnd, wMsg, wParam, lParam)	bPosted	393
PostQuitMessage	Posts WM_QUIT message to application	Window message	PostQuitMessage(nExitCode)	None	394
PrintRect	Determines whether point lies within lpRect	Window message	PrintRect(lpRect, Point)	bInRect	395
PrintRegion	Determines whether X, Y is within hRgn	GDI region	PrintRegion(hRgn, X, Y)	bSuccess	395
Private	Determines whether X, Y is in clipping region of hDC	GDI region	Private(hDC, X, Y)	bVisible	396
ReadComm	Reads up to nSize bytes from nCID into lpBuf	Communications	ReadComm(nCID, lpBuf, nSize)	nBytes	397
Rectangle	Draws rectangle	GDI output	Rectangle(hDC, X1, Y1, X2, Y2)	bDrawn	397
RectVisible	Determines if any part of lpRect lies within clipping rgn	GDI clipping rgn	RectVisible(hDC, lpRect)	bVisible	398
RegisterClass	Registers a window class	Window class	RegisterClass(lpWndClass)	bRegistered	398
RegisterClipboardFormat	Registers new clipboard format	Window clipboard	RegisterClipboardFormat(lpFormatName)	wFormat	400
RegisterWindowDestroy*	Locks windows from destruction by other tasks	Window manager	RegisterWindowDestroy(hWnd, Register)	bProtected	400
RegisterWindowMessage	Defines new, unique window message	Window message	RegisterWindowMessage(lpString)	wMsg	400
ReleaseCapture	Releases mouse input, restores normal processing	Window input	ReleaseCapture()	None	401
ReleaseDC	Releases display context	Window painting	ReleaseDC(hWnd, HDC)	bReleased	401
RemoveFontResource	Removes font from font table	Resource manager	RemoveFontResource(lpFileName)	bSuccess	402
RemoveProp	Removes lpString from property list	Window property	RemoveProp(hWnd, lpString)	nData	403
ReplyMessage	Replies to message without returning control	Window message	ReplyMessage(wParam)	None	403
RestoreDC	Restores display context to previous state	GDI display context	RestoreDC(hDC, nSavedDC)	bSucceeded	403
RGB	Creates RGB color from individual color values	GDI output	RGB(rgb, g, b, c, green, blue)	DWORD	403
RoundRect	Draws rounded rectangle	GDI output	RoundRect(hDC, X1, Y1, X2, Y2, X3, Y3)	bDrawn	403
SaveDC	Saves current state of display context	GDI display context	SaveDC(hDC)	bDrawn	403
ScaleViewportEx*	Modifies viewport extents relative to current values	GDI region	ScaleViewportEx(hDC, Xnum, Ydenom, Xnum, Ydenom)	hWndPrev	407
ScaleWindowEx*	Modifies window extents from current values	Window display	ScaleWindowEx(hDC, Xnum, Ydenom, Xnum, Ydenom)	hWndPrev	407
ScreenToClient	Converts screen coords at lpPoint to client coords	Window coordinate	ScreenToClient(hWnd, lpPoint)	nPrevExits	408
ScrollDC	Scrolls rectangle of bits in display context	GDI display context	ScrollDC(hDC, dx, dy, pscrcolor, pscrcolor)	None	408
ScrollWindow	Scrolls contents of client area by XAmount, YAmount	Window scrolling	ScrollWindow(hWnd, XAmount, YAmount, lpRect, lpClipRect)	hWndScroll	409
SelectClipRgn	Selects hRgn as current clipping region for disp context	GDI selection	SelectClipRgn(hDC, hRgn)	None	410
SelectObject	Selects hObject as current object	GDI selection	SelectObject(hDC, hObject)	hOldObject	412
SendDlgItemMessage	Sends message to nIDDitem within dialog box hDlg	Window dialog box	SendDlgItemMessage(hDlg, nIDDitem, wMsg, wParam, lParam)	Result	414
SendMessage	Sends message to window or windows	Window message	SendMessage(hWnd, wMsg, wParam, lParam)	Result	414
SetActiveWindow	Makes tiled or popup window the active window	Window display	SetActiveWindow(hWnd)	hWndPrev	415
SetBitmapBits	Sets bitmap bits to values given at lpBits	GDI drawing obj	SetBitmapBits(hBitmap, dwCount, lpBits)	bCopied	416
SetBitmapDimension	Associates width and height with a bitmap (in .1 mm)	GDI drawing obj	SetBitmapDimension(hBitmap, X, Y)	pfOldDimensions	416
SetBKColor	Sets background color to closest to rgbColor	GDI display context	SetBKColor(hDC, rgbColor)	hOldColor	417
SetBKMode	Sets background mode	GDI display context	SetBKMode(hDC, nBKMode)	nOldBKMode	417
SetBrushOrg	Sets origin of all brushes into hDC display context	GDI display context	SetBrushOrg(hDC, X, Y)	dwOldOrigin	418
SetCapture	Causes mouse input to be sent to hWnd	Window input	SetCapture(hWnd)	hWndPrev	418
SetCarefblink Time	Establishes caret flash rate	Window caret	SetCarefblinkTime(wMSeconds)	None	419
SetCaretPos	Moves caret to X, Y position	Window caret	SetCaretPos(X, Y)	None	419
SetClassLong	Replaces long value at nIndex in WNDCLASS struct	Window class	SetClassLong(hWnd, nIndex, NewLong)	OldLong	420

(Continued)

Table 6-72. Continued

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
SetClassesWord	Replaces word at nIndex in WNDCLASS struct	Window class	SetClassesWord(hWnd, nIndex, wNewWord)	LOidWord	421
SetClipboardData	Copies hMem into clipboard	Window clipboard	SetClipboardData(wFormat, hMem)	hClipData	422
SetClipboardViewer	Adds hWnd to clipboard viewer chain	Window clipboard	SetClipboardViewer(hWnd)	hWndNext	424
SetCommBreak	Sets break state of device nCid and suspends transmission	Communications	SetCommBreak(nCid)	nResult	424
SetCommEventMask	Sets event mask of device nCid	Communications	SetCommEventMask(nCid, nEventMask)	lpEvent	425
SetCommState	Sets device to state specified in lpDCB	Communications	SetCommState(lpDCB)	nResult	426
SetConvertHook					
SetConvertParams					
SetConvertWindowHeight					
SetCursor	Sets cursor shape to hCursor, removes if hCursor=NULL	Window cursor	SetCursor(hCursor)	hOldCursor	426
SetCursorPos	Sets mouse cursor to screen coords X,Y	Window cursor	SetCursorPos(X,Y)	None	426
SetDlgItemInt	Sets text of nIDDlgItem to string representing wValue	Window dialog box	SetDlgItemInt(nID, nIDDlgItem, wValue, bSigned)	None	427
SetDlgItemText	Sets caption or text of nIDDlgItem to string	Window dialog box	SetDlgItemText(nID, nIDDlgItem, lpString)	None	428
SetDoubleClickTime	Sets mouse double-click time	Window input	SetDoubleClickTime(wCount)	None	429
SetEnvironment	Copies data at hEnvironment to device at lpPortName	GDI information	SetEnvironment(lpPortName, hEnvironment, nCount)	nCopied	429
SetFocus	Assigns input focus to hWnd	Window input	SetFocus(hWnd)	hWndPrev	430
SetKeyboardState	Copies buffer to keyboard state table	Window input	SetKeyboardState(lpKeyState)	None	431
SetMapMode	Sets mapping mode of HDC	GDI display context	SetMapMode(hDC, nMapMode)	nOldMapMode	431
SetMapFlags	Alters algorithm used by font mapper	GDI font	SetMapFlags(hDC, nMapFlag)	dwPrevFlag	433
SetMessageQueue	Sets window message queue	Window message	SetMessageQueue(hInst, nMsg)	hNewQ	434
SetMetafileBits	Creates new message queue	GDI metafile	SetMetafileBits(hInst)	hMetafile	435
SetParent	Changes parent window or child window	Window manager	SetParent(hWndChild, hWndNewParent)	hOldParent	435
SetPixel	Sets pixel at X,Y to device color closest to rgbColor	GDI output	SetPixel(hDC, X, Y, rgbColor)	rgbActualColor	436
SetPriority	Sets task priority	Task	SetPriority(task, nChangeAmount)	nNew	437
SetProp	Copies string and data handle to property list of hWnd	Window property	SetProp(hWnd, lpString, hData)	bSet	437
SetRect	Fills RECT struct at lpRect with given coords	Window rectangle	SetRect(lpRect, X1, Y1, X2, Y2)	nResult	438
SetRectEmpty	Sets lpRect to empty rectangle (all coords zero)	Window rectangle	SetRectEmpty(lpRect)	nResult	439
SetRectRgn	Creates rectangular region	Window rectangle	SetRectRgn(hRgn, X1, Y1, X2, Y2)	None	439
SetRelAbs	Sets the relabs flag	GDI display context	SetRelAbs(hDC, nRelAbsMode)	None	440
SetResourceHandler	Sets function address of resource handler	Resource manager	SetResourceHandler(hInstance, lpType, lpLoadFunc)	lpLoadFunc	440
SetROP2	Sets drawing mode	GDI display context	SetROP2(hDC, nDrawMode)	nOldDrawMode	442
SetScrollPos	Sets scrollbar elevator to nPos; redraws if nonzero	Window scrolling	SetScrollPos(hWnd, nBar, nPos, bRedraw)	nOldPos	444
SetScrollRange	Sets min/max scrollbar positions for scrollbar	Window scrolling	SetScrollRange(hWnd, nBar, nMinPos, nMaxPos, bRedraw)	None	445
SetSoundNoise	Sets source and duration of noise from play device	Sound	SetSoundNoise(nSource, nDuration)	nResult	446
SetStretchBltMode	Sets stretching mode for StretchBlt function	GDI display context	SetStretchBltMode(hDC, nStretchMode)	nOldStretchMode	447
SetSwapAreaSize	Changes amount of memory used by code segment	Memory manager	SetSwapAreaSize(nSize)	nParagraphs	448
SetSysColors	Changes one or more system colors	Window sys info	SetSysColors(nChanges, lpSysColor, lpColorValues)	None	448
SetSysModalWindow	Makes window a system modal window	Window attribute	SetSysModalWindow(hWnd)	hPrevWnd	450
SetTextAlign	Sets text alignment flag	GDI display context	SetTextAlign(hDC, wFlag)	wYAlign	450
SetTextCharacterExtra	Sets amount of intercharacter spacing	GDI text justify	SetTextCharacterExtra(hDC, nCharExtra)	nOldCharExtra	452
SetTextColor	Sets text color to device color closest to rgbColor	GDI display context	SetTextColor(hDC, rgbColor)	rgbOldColor	452
SetTextJustification	Prepares GDI to justify text line	GDI text justify	SetTextJustification(hDC, nBreakExtra, nBreakCount)	nSet	453
SetTimer	Creates system timer event	Window input	SetTimer(hWnd, nIDEvent, wElapsed, lpTimerFunc)	nIDNewEvent	454
SetViewportExt	Sets x,y extents of viewport for HDC	GDI display context	SetViewportExt(hDC, X,Y)	nOldExtents	455
SetViewportOrg	Sets viewport origin for HDC	GDI display context	SetViewportOrg(hDC, X,Y)	nOldOrigin	457
SetVoiceAccent	Places an accent in voice queue	Sound	SetVoiceAccent(nVoice, nEmpo, nVolume, nMode, nPitch)	nResult	457
SetVoiceEnvelope	Places envelope in voice queue	Sound	SetVoiceEnvelope(nVoice, nShape, nRepeat)	nResult	459
SetVoiceNote	Places note in voice queue	Sound	SetVoiceNote(nVoice, nValue, nLength, nCdots)	nResult	459
SetVoiceQueueSize	Allocates nBytes of memory for voice queue	Sound	SetVoiceQueueSize(nVoice, nBytes)	nResult	460
SetVoiceSound	Places frequency and duration in voice queue	Sound	SetVoiceSound(nVoice, nFrequency, nDuration)	nResult	461
SetVoiceThreshold	Sets threshold level for voice queue	Sound	SetVoiceThreshold(nVoice, nNotes)	nResult	461
SetWindowExt	Sets x,y extents of window of HDC	GDI display context	SetWindowExt(hDC, X,Y)	nOldExtents	462
SetWindowOrg	Changes window attribute identified by nIndex	Window attribute	SetWindowOrg(hDC, X,Y)	LOidOrg	463
SetWindowProc	Sets window origin of HDC	GDI display context	SetWindowProc(hWnd, nWndProc, nStyle, cx, cy, wFlag)	LOidOrg	464
SetWindowPos	Changes size, position, ordering of window	Window manager	SetWindowPos(hWnd, hWndInsertAfter, x,y, cx, cy, wFlag)	None	465
SetWindowHook	Installs system or application hook	Window hook	SetWindowHook(nFilterType, lpFilterFunc)	lpPrevFilterFunc	466

(Continued)

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
SetWindowText	Sets window caption or text to lpString	Window attribute	SetWindowText(hWnd, lpString)	None	474
SetWindowWord	Changes window attribute specified by nIndex	Window attribute	SetWindowWord(hWnd, nIndex, wNewWord)	wOldWord	475
ShowCaret	Displays new caret or redisplay hidden caret	Window caret	ShowCaret(hWnd)	None	475
ShowCursor	Adds 1 to cursor display count if nonzero, otherwise -1	Window cursor	ShowCursor(hWnd)	nCount	476
ShowOwnedPopups*	Displays or hides all popup windows	Window display	ShowOwnedPopups(hWnd, (Show))	None	477
ShowScrollBar*	Displays or hides scroll bar	Window display	ShowScrollBar(hWnd, wBar, (Show))	None	477
ShowWindow	Displays or removes window as specified by nCmdShow	Window display	ShowWindow(hWnd, nCmdShow)	bShown	478
ShowWindowResource	Returns size of resource hResInfo, in bytes.	Resource manager	ShowWindowResource(hInstance, hResInfo)	wBytes	480
StartSound	Starts play in each voice queue	Sound	StartSound()	None	480
StopSound	Stops playing all voices	Sound	StopSound()	None	480
StretchBlt	Moves bitmap from source rect to destination rect	GDI output	StretchBlt(hDestDC, X, Y, nWidth, nHeight, hSrcDC, XSrc, YSrc, nSrcWidth, nSrcHeight, dwROP)	bDrawn	481
SwapMouseButton	Swaps meaning of left/right mouse buttons if bSwap= True	Window input	SwapMouseButton(bSwap)	bSwapped	483
SyncAllVoices	Places sync mark in each voice queue	Sound	SyncAllVoices()	nResult	484
TextOut	Writes character string at X, Y	GDI output	TextOut(hdc, X, Y, lpString, nCount)	bDrawn	485
Throw	Restores execution environment to values in lpCatchBuf	Module manager	Throw(lpCatchBuf, nThrowBack)	None	485
TranslateAccelerator	Processes keyboard accelerators for menu commands	Window message	TranslateAccelerator(hWnd, hAcc, Table, lpMsg)	nTranslated	486
TranslateMessage	Translates virtual keystrokes into char messages	Window message	TranslateMessage(lpMsg)	bTranslated	487
TransmitCommChar	Places character cChar at head of transmit queue	Communications	TransmitCommChar(hCom, cChar)	nResult	488
UngetCommChar	Makes character cChar next character to be read from queue	Communications	UngetCommChar(hCom, cChar)	nResult	489
UnhookWindowsHook*	Removes filter function from hook chain	Window hook	UnhookWindowsHook(hHook, lpHook)	bUnhooked	489
UnhookRect	Stops union of two rectangles	Window rectangle	UnhookRect(lpDestRect, lpSrcRect, lpSrcZRect)	nUnion	489
UnlockData	Unlocks data segment	Memory manager	UnlockData(hInstance)	None	490
UnlockResource*	Unlocks resource, decrements reference count	Resource manager	UnlockResource(hResData)	nSeg	491
UnlockSegment	Unlocks segment	Memory manager	UnlockSegment(hSegment)	hMem	491
UnrealizeObject	Directs GDI to reset origin of brush when it is selected	GDI display context	UnrealizeObject(hBrush)	bUnrealized	492
UpdateWindow	Notifies application when window needs redrawing	Window painting	UpdateWindow(hWnd)	None	492
ValidateFreeSpaces*	Determines whether free segments contain valid comments	Memory manager	ValidateFreeSpaces()	lpstrInvalid	493
ValidateRect	Releases rectangle lpRect from repainting	Window painting	ValidateRect(hWnd, lpRect)	None	493
ValidateRgn	Releases hRgn from repainting	Window painting	ValidateRgn(hWnd, hRgn)	None	494
WaitMessage	Yields control to other application	Window message	WaitMessage()	None	495
WaitSoundState	Waits until play driver enters nState	Sound	WaitSoundState(nState)	nResult	495
WindowFromPoint	Identifies window containing Point (in screen coords)	Window coordinate	WindowFromPoint(Point)	hWnd	496
WinMain	Entry point for Windows application execution	Window main	WinMain(hInstance, hPrevInstance, lpCmdLine, nCmdShow)	nExitCode	496
WndProc	Processes messages sent to it	Window	WndProc(hWnd, wParam, lParam)	lReply	496
WriteComm	Writes up to nSize bytes from buffer to device hCid	Communications	WriteComm(hCid, lpBuf, nSize)	nBytes	496
WriteProfileString	Copies lpString to WIN.INI file	Windows ini file	WriteProfileString(lpApplicationName, lpKeyName, lpString)	bResult	497
Yield	Halts current task and starts any waiting task	Task	Yield()	bResult	498

\*Applicable to versions of Windows beginning with 2.0

C is case sensitive. Low-case prefix to argument and result names are data type indicators.

Source: Microsoft Windows SDK Programmer's Reference 2.0

See Also: 6.71. Windows Function Summary by Version  
6.73. Windows Function Summary by Type of Function

6.73. WINDOWS FUNCTION SUMMARY BY TYPE OF FUNCTION

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
MoveConventWindow*					376
SetConventHook*					
SetConventParams*					
SetConventWindowHeight*					
AddAtom	Creates atom for character string lpString	Atom manager	AddAtom(lpString)	wAtom	148
DeleteAtom	Deletes nAtom if its reference count is zero	Atom manager	DeleteAtom(nAtom)	nAtom	207
FindAtom	Retrieves atom associated with lpString	Atom manager	FindAtom(lpString)	wAtom	244
GetAtomHandle	Returns handle of atom string	Atom manager	GetAtomHandle(wAtom)	hMem	253
GetAtomName	Copies nSize chars of string of atom to lpBuffer	Atom manager	GetAtomName(nAtom, lpBuffer, nSize)	hMem	253
GlobalAddAtom*	Adds global atom to the atom table	Atom manager	GlobalAddAtom(lpString)	nAtom	325
GlobalDeleteAtom*	Deletes global atom from the atom table	Atom manager	GlobalDeleteAtom(nAtom)	nDeleted	325
GlobalFindAtom*	Finds character string within atom table	Atom manager	GlobalFindAtom(lpString)	nAtom	326
GlobalGetAtomName	Returns copy of string associated with an atom	Atom manager	GlobalGetAtomName(nAtom, lpBuffer, nSize)	nAtom	327
InitAtomTable	Initializes atom hash table	Atom manager	InitAtomTable(nSize)	hResult	338
MAKEINTATOM	Casts integer as argument for AddAtom	Atom manager	MAKEINTATOM(integer)	nAtom	370
MAKEINTRESOURCE	Casts integer as argument for AddAtom	Atom manager	MAKEINTRESOURCE(integer)	lpIntegerID	370
BuildCommDCB	Fills device control block with control codes	Communications	BuildCommDCB(lpDcb)	hResult	160
CloseComm	Closes comm break state for nCid device	Communications	CloseComm(nCid)	hResult	171
EscapeCommFunction	Executes escape function nFunc for device nCid	Communications	EscapeCommFunction(nCid, nFunc)	hResult	233
FlushComm	Flushes characters from queue of device nCid	Communications	FlushComm(nCid)	hResult	243
GetCommError	Fills lpStat buffer with status of nCid device	Communications	GetCommError(nCid, lpStat)	hResult	266
GetCommEventMask	Retrieves, then clears, the event mask for nCid	Communications	GetCommEventMask(nCid, nEventMask)	hResult	266
GetCommState	Fills lpDCB buffer with DCB or nCid device	Communications	GetCommState(nCid, lpDCB)	hResult	266
OpenComm	Opens device named by lpCommName for comm use	Communications	OpenComm(lpCommName, nInQueue, nOutQueue)	nCid	382
ReadComm	Reads up to nSize bytes from nCid into lpBuf	Communications	ReadComm(nCid, lpBuf, nSize)	nBytes	397
SetCommBreak	Seis break state of device nCid and suspends transmission	Communications	SetCommBreak(nCid)	hResult	424
SetCommEventMask	Seis device to state specified in lpDCB	Communications	SetCommEventMask(nCid, nEventMask)	hResult	425
SetCommState	Places character cChar at head of transmit queue	Communications	SetCommState(lpDCB)	hResult	426
TransmitCommChar	Makes character cChar next character to be read from queue	Communications	TransmitCommChar(nCid, cChar)	hResult	488
UngetCommChar	Writes up to nSize bytes from buffer to device nCid	Communications	UngetCommChar(nCid, cChar)	hResult	489
WriteComm	Halls Windows and prompts through AUX	Communications	WriteComm(nCid, lpBuf, nSize)	nBytes	496
FatalExit	Returns optimal drive letter for temp file	Debugging	FatalExit(Code)	Result	243
GetTempDrive	Creates temporary file name	File I/O	GetTempDrive()	cOptDriveLetter	307
OpenFile	Creates, opens, reopens or deletes file named by lpFileName	File I/O	OpenFile(lpFileName, lpFileOpenBuf, wStyle)	hFile	383
ExcludeUpdateRgn*	Excludes a region in window from clipping region for window	GDI clipping	ExcludeUpdateRgn(hWnd)	nRgn_Type	240
ExcludeClipRect	Creates new clipping region for rectangle	GDI clipping_rgn	ExcludeClipRect(hdc, X1, Y1, X2, Y2)	nRgn_Type	239
GetClipBox	Copies clipping rect boundary to lpRect	GDI clipping_rgn	GetClipBox(hdc, lpRect)	nMapMode	263
GetMapMode	Returns current mapping mode	GDI clipping_rgn	GetMapMode(hdc)	nMapMode	282
IntersectClipRect	Forms new clipping region from intersection	GDI clipping_rgn	IntersectClipRect(hdc, X1, Y1, X2, Y2)	nRgn_Type	339
OffsetClipRgn	Moves clipping region X units horiz and Y units vertically	GDI clipping_rgn	OffsetClipRgn(hdc, X, Y)	nRgn_Type	378
RectVisible	Determines if any part of lpRect lies within clipping_rgn	GDI clipping_rgn	RectVisible(hdc, lpRect)	bVisible	398
Escape	Accesses device facilities not available through GDI	GDI control	Escape(hdc, nEscape, nCount, lpInData, lpOutData)	nResult	238
Escape (ABORTDC)	Aborts current job	GDI control	Escape(hdc, ABORTDC, nCount, lpInData, lpOutData)	nResult	681
Escape (BANDINFO*)	Copies banding capability info to lpInData structure	GDI control	Escape(hdc, BANDINFO, nCount, lpInData, lpOutData)	nResult	681
Escape (DEVICE DATA)	Sends data directly to printer	GDI control	Escape(hdc, DEVICE DATA, nCount, lpInData, lpOutData)	nCount	683
Escape (DRAW PATTERNRECT*)	Turns draft mode ON or OFF	GDI control	Escape(hdc, DRAW PATTERNRECT, 2, lpDrawMode, lpInData, lpOutData)	nResult	684
Escape (ENABLE DUPLICATE*)	Creates pattern using rules for PCL printers	GDI control	Escape(hdc, ENABLE DUPLICATE, nCount, lpInData, lpOutData)	nResult	684
Escape (ENABLE PAIRKERNING)	Enables duplex printing capabilities	GDI control	Escape(hdc, ENABLE PAIRKERNING, nCount, lpInData, lpOutData)	nResult	686
Escape (ENABLE RELATIVE WIDTHS)	Enables or disables relative character widths on device	GDI control	Escape(hdc, ENABLE RELATIVE WIDTHS, nCount, lpInData, lpOutData)	nResult	687
Escape (ENDDOC)	Enables or disables relative character widths on device	GDI control	Escape(hdc, ENDDOC, nCount, lpInData, lpOutData)	nResult	688
Escape (EXTTEXTOUT)	Ends print job started by Escape STARTDOC	GDI control	Escape(hdc, EXTTEXTOUT, nCount, lpInData, lpOutData)	nResult	688
Escape (FLUSHOUTPUT)	More efficient TEXTOUT for justification and kerning	GDI control	Escape(hdc, FLUSHOUTPUT, nCount, lpInData, lpOutData)	nResult	689
Escape (GET COLOR TABLE)	Fetches output in device buffer	GDI control	Escape(hdc, GET COLOR TABLE, nCount, lpInData, lpOutData)	nResult	691
Escape (GET EXTENDED TEXT METRICS)	Copies RGB color table to lpOutData	GDI control	Escape(hdc, GET EXTENDED TEXT METRICS, nCount, lpInData, lpOutData)	nCount	691
Escape (GET TEXT TABLE)	Fills buffer with extended text metrics for font	GDI control	Escape(hdc, GET TEXT TABLE, nCount, lpInData, lpOutData)	nCount	692
Escape (GET PAIRKERN TABLE)	Returns width of individual group of consicr chars	GDI control	Escape(hdc, GET PAIRKERN TABLE, nCount, lpInData, lpOutData)	nCount	693
Escape (GET PAIRKERN TABLE)	Fills buffer at lpOutData with kerning pair table for font	GDI control	Escape(hdc, GET PAIRKERN TABLE, nCount, lpInData, lpOutData)	nCount	693

(Continued)

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
Escape (GETPHYSPAGE(SIZE))	Copies physical page size to lpOutData POINT structure	GDI control	Escape(hdc, GETPHYSPAGE(SIZE), Null, lpstrNull, lpDimensions)	nResult	694
Escape (GETPRINTING(OFFSET))	Copies printing offset to lpOutData POINT structure	GDI control	Escape(hdc, GETPRINTING(OFFSET), Null, lpstrNull, lpOffset)	nResult	694
Escape (GETSCALING(FACTOR))	Returns scaling factors for x and y axes of printer.	GDI control	Escape(hdc, GETSCALING(FACTOR), null, lpstrNull, lpFactors)	nResult	695
Escape (GETTRACK(KERN(TABLE)))	Fills buffer, a lpOutData with track kerning table for font	GDI control	Escape(hdc, GETTRACK(KERN(TABLE)), nCount, lpInData, lpOutData)	nCount	695
Escape (MF(COMMENT*))	Adds comment to metafile	GDI control	Escape(hdc, MF(COMMENT*), nCount, lpComment, lpstrNull)	nResult	696
Escape (NEWFRAME)	Ends writing to a page	GDI control	Escape(hdc, NEWFRAME, Null, lpstrNull, lpBandRect)	nResult	696
Escape (NEXTBAND)	Ends writing to a band	GDI control	Escape(hdc, NEXTBAND, Null, lpstrNull, lpBandRect)	nResult	697
Escape (QUERY(ESCSUPPORT))	Tests whether device supports Escape	GDI control	Escape(hdc, QUERY(ESCSUPPORT), 2, lpEscNum, lpstrNull)	nResult	698
Escape (SELECT(PAPER(SOURCE))	Determines and selects available paper sources	GDI control	Escape(hdc, SELECT(PAPER(SOURCE)), lpInData, lpOutData)	nResult	698
Escape (SET(ABORT(PROC)))	Sets abort function for print task	GDI control	Escape(hdc, SET(ABORT(PROC)), Null, lpAbortFunc, lpstrNull)	nResult	699
Escape (SET(COLOR(VALUE)))	Sets text justification values	GDI control	Escape(hdc, SET(COLOR(VALUE)), nCount, lpInData, lpOutData)	nResult	701
Escape (SET(COPY(COUNT)))	Sets RGB color table entry	GDI control	Escape(hdc, SET(COPY(COUNT)), 2, lpInData, lpOutData)	nResult	702
Escape (SET(KERN(TRACK))	Specifies number of copies per page to print (uncoerated)	GDI control	Escape(hdc, SET(KERN(TRACK)), lpInData, lpOutData)	nResult	702
Escape (SET(LINE(CAP)))	Specifies which kerning track to use	GDI control	Escape(hdc, SET(LINE(CAP)), nCount, lpInData, lpOutData)	nResult	703
Escape (SET(LINE(JOIN))	Sets line end cap	GDI control	Escape(hdc, SET(LINE(JOIN)), nCount, lpInData, lpOutData)	nResult	704
Escape (SET(LINE(LIMIT))	Sets how line segments joined	GDI control	Escape(hdc, SET(LINE(LIMIT)), nCount, lpInData, lpOutData)	nResult	705
Escape (SET(START(DOC)))	Sets miller limit for a device	GDI control	Escape(hdc, SET(START(DOC)), nDocLength, lpDocName, lpstrNull)	nResult	706
Escape (SET(STR(CTRL)))	Starts print task	GDI control	Escape(hdc, SET(STR(CTRL)), nCount, lpInData, lpOutData)	nResult	707
DPItoLP	Implements StretchBlt on driver level	GDI conversion	DPItoLP(hdc, lpPoints, nCount)	bConverted	217
GetNearestColor	Converts device points into logical points	GDI conversion	GetNearestColor(hdc, rgbColor)	rgbColor	208
LPHDDP	Returns device color closest to rgbColor	GDI conversion	LPHDDP(hdc, lpPoints, nCount)	rgbColor	255
CreateCompatibleDC	Creates memory display context compat. with hdc	GDI conversion	CreateCompatibleDC(hdc)	hMemDC	269
CreateDC	Creates display context for specified device	GDI display context	CreateDC(lpDriverName, lpDeviceName, lpOutput, lpInitData)	hDC	179
CreateIC	Creates information context for device	GDI display context	CreateIC(lpDriverName, lpDeviceName, lpOutput, lpInitData)	hIC	189
DeleteDC	Deletes specified display context	GDI display context	DeleteDC(hdc)	bDeleted	208
GetBkColor	Returns current background color of device	GDI display context	GetBkColor(hdc)	rgbColor	295
GetBkMode	Returns background mode of device	GDI display context	GetBkMode(hdc)	nBkMode	295
GetBrushOrg	Returns current brush origin	GDI display context	GetBrushOrg(hdc)	dwOrgin	295
GetPolyFillMode	Retrieves current polygon filling mode	GDI display context	GetPolyFillMode(hdc)	nPolyFillMode	294
GetRelAbs	Returns the relabs flag	GDI display context	GetRelAbs(hdc)	nRelAbsMode	298
GetROP2	Returns current drawing mode	GDI display context	GetROP2(hdc)	nDrawMode	299
GetStretchBltMode	Returns current stretching mode	GDI display context	GetStretchBltMode(hdc)	rStretchMode	303
GetTextColor	Returns current text color	GDI display context	GetTextColor(hdc)	rgbColor	310
GetViewportExt	Returns x/y extent of display context's viewport	GDI display context	GetViewportExt(hdc)	piExtents	315
GetViewportOrg	Returns x/y coords of display context viewport org.	GDI display context	GetViewportOrg(hdc)	piOrigin	316
GetWindowExt	Returns x/y extents of display context's window	GDI display context	GetWindowExt(hdc)	piExtents	318
GetWindowOrg	Returns x/y coords of display context window origin	GDI display context	GetWindowOrg(hdc)	piOrigin	319
RestoreDC	Restores display context to previous state	GDI display context	RestoreDC(hdc, nSavedDC)	bRestored	404
SaveDC	Saves current state of display context	GDI display context	SaveDC(hdc)	nSavedDC	407
ScrollDC*	Scrolls rectangle of bits in display context	GDI display context	ScrollDC(hdc, dx, dy, lprcScroll, lprcClip, hrgnUpdate, lprcUpdate)	bDidScroll	409
SetBkColor	Sets background color to closest to rgbColor	GDI display context	SetBkColor(hdc, rgbColor)	rgbColor	416
SetBkMode	Sets background mode	GDI display context	SetBkMode(hdc, nBkMode)	nBkMode	417
SetBrushOrg	Sets origin of all brushes into hdc display context	GDI display context	SetBrushOrg(hdc, X, Y)	dwOldOrigin	418
SetMapMode	Sets mapping mode of hdc	GDI display context	SetMapMode(hdc, nMapMode)	nOldMapMode	431
SetPolyFillMode	Sets polygon filling mode for hdc	GDI display context	SetPolyFillMode(hdc, nPolyFillMode)	nOldPolyFillMode	436
SetRelAbs	Sets the relabs flag	GDI display context	SetRelAbs(hdc, nRelAbsMode)	nOldRelAbsMode	440
SetROP2	Sets drawing mode	GDI display context	SetROP2(hdc, nDrawMode)	nOldDrawMode	442
SetStretchBltMode	Sets stretching mode for StretchBlt function	GDI display context	SetStretchBltMode(hdc, nStretchMode)	nOldStretchMode	447
SetTextColor*	Sets text alignment flag	GDI display context	SetTextColor(hdc, wFlags)	wYAlign	450
SetViewportExt	Sets text color to device color closest to rgbColor	GDI display context	SetViewportExt(hdc, rgbColor)	rgbOldColor	452
SetViewportOrg	Sets viewport origin for hdc	GDI display context	SetViewportOrg(hdc, X, Y)	piOldOrigin	455
SetWindowExt	Sets x/y extents of viewport for hdc	GDI display context	SetWindowExt(hdc, X, Y)	piOldExtents	457
SetWindowOrg	Sets x/y extents of window of hdc	GDI display context	SetWindowOrg(hdc, X, Y)	piOldOrigin	464
SetWindowExt	Sets window origin of hdc	GDI display context	SetWindowExt(hdc, X, Y)	piOldExtents	464
UnrealizeObject	Directs GDI to reset origin of brush when it is selected	GDI display context	UnrealizeObject(hBrush)	hUnrealized	492
CreateFont	Creates logical font	GDI drawing	CreateFont(nHeight, nWidth, nEscapement, nOrientation, nWeight, cItalic, cUnderline, cStrikeOut, nCharSet, cOutputPrecision, cColPitch, cQuality, cPitchAndFamily, lpFaceName)	HFont	185

(Continued)

Table 6.7.3 Continued

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
CreateBitmap	Creates bitmap of specified height, width, pattern	GDI drawing	CreateBitmap(nWidth, nHeight, nPlanes, nBitCount, lpBits)	hBitmap	175
CreateBitmapIndirect	Creates bitmap from existing bitmap	GDI drawing	CreateBitmapIndirect(lpBitmap)	hBitmap	175
CreateBrushIndirect	Creates logical brush from existing brush	GDI drawing	CreateBrushIndirect(lpLogBrush)	hBrush	175
CreateCompatibleBitmap	Creates bitmap compatible with device HDC	GDI drawing	CreateCompatibleBitmap(hDC, nWidth, nHeight)	hBitmap	175
CreateDiscardableBitmap	Creates discardable bitmap	GDI drawing	CreateDiscardableBitmap(hDC, nWidth, nHeight)	hBitmap	184
CreatorFontIndirect	Creates logical font like lpLogFont	GDI drawing	CreatorFontIndirect(lpLogFont)	hFont	184
CreateHatchBrush	Creates logical brush with hatch pattern	GDI drawing	CreateHatchBrush(nIndex, rgbColor)	hBrush	189
CreateHatchBrushIndirect	Creates logical brush with hBitmap pattern	GDI drawing	CreateHatchBrushIndirect(lpLogBrush)	hBrush	191
CreatePen	Creates logical pen	GDI drawing	CreatePen(nPenStyle, nWidth, rgbColor)	hPen	192
CreatePenIndirect	Creates logical pen like lpLogPen	GDI drawing	CreatePenIndirect(lpLogPen)	hPen	193
CreateSolidBrush	Creates logical brush of a solid color	GDI drawing	CreateSolidBrush(rgbColor)	hBrush	195
GetBitmapBits	Copies Count bits of bitmap to lpBits buffer	GDI drawing	GetBitmapBits(nCount, lpBits)	(Copied Dimensions)	254
GetBitmapDimension	Returns width and height of bitmap	GDI drawing	GetBitmapDimension(lpBitmap)	Dimensions	301
GetStockObject	Returns handle to predefined object	GDI drawing obj	GetStockObject(nIndex)	hObject	416
SetBitmapBits	Sets bitmap bits to values given at lpBits	GDI drawing obj	SetBitmapBits(nCount, lpBits)	hObject	416
SetBitmapDimension	Associates width and height with a bitmap (in 1 mm)	GDI drawing obj	SetBitmapDimension(nWidth, nHeight)	hObject	416
SetFontMapperFlags	Alters algorithm used by font mapper	GDI font	SetFontMapperFlags(hDC, wFlags)	dwPrevFlag	433
EnumFonts	Enumerates fonts available on device	GDI information	EnumFonts(hDC, lpAcname, lpFont, lpData)	nResult	228
EnumMetaFile*	Enumerates GDI calls in a metafile	GDI information	EnumMetaFile(hDC, hMF, lpCallbackFunc, lpClientData)	hResult	230
EnumObjects	Enumerates objects available on device	GDI information	EnumObjects(hDC, hObject, lpType, lpObjectFunc, lpData)	nResult	231
EqualRect*	Determines whether two rectangles are equal	GDI information	EqualRect(lpRect1, lpRect2)	boolean	237
GetDeviceCaps	Returns device-specific info	GDI information	GetDeviceCaps(hDC, nIndex)	nValue	269
GetEnvironment	Copies device environment to lpEnviron	GDI information	GetEnvironment(lpPortName, lpEnviron, nMaxCount)	nCopied	311
GetTextFace	Copies current font face name to lpPortName	GDI information	GetTextFace(hDC, lpPortName)	hResult	316
GetTextMetrics	Fills buffer with metrics for current font	GDI information	GetTextMetrics(hDC, lpMetrics)	hResult	311
SetEnvironment	Copies data at lpEnviron to device at lpPortName	GDI information	SetEnvironment(lpPortName, lpEnviron, nCount)	nCopied	429
CopyMetaFile	Closes metafile and creates handle	GDI metafile	CopyMetaFile(hSrcMetaFile, lpFilename)	hMF	174
CreateMetaFile	Creates metafile display context	GDI metafile	CreateMetaFile(lpFilename)	hMF	174
DeleteMetaFile	Deletes access to metafile; frees system resources	GDI metafile	DeleteMetaFile(hMF)	boolean	208
GetMetaFile	Creates handle for metafile named by lpFilename	GDI metafile	GetMetaFile(lpFilename)	hMF	287
GetMetaFileBits	Stores metafile bits in global memory block	GDI metafile	GetMetaFileBits(hMF)	hMem	288
PlayMetaFile	Plays contents of metafile on device context hDC	GDI metafile	PlayMetaFile(hDC, hMF)	boolean	390
PlayMetaFileRecord*	Plays metafile record by executing GDI calls	GDI metafile	PlayMetaFileRecord(hDC, lpHandleTable, lpMetaRecord, nHnd)	boolean	391
SetMetaFileBits	Creates memory metafile from data in memory block	GDI metafile	SetMetaFileBits(hMem)	boolean	434
StretchBlt	Moves bitmap from source rect to destination rect	GDI output	StretchBlt(hSrcDC, X1, Y1, nWidth, nHeight, hDestDC, X2, Y2, nSrcWidth, nSrcHeight, dwRop)	boolean	481
Arc	Draws arc from X3, Y3 to X4, Y4	GDI output	Arc(hDC, X1, Y1, X2, Y2, X3, Y3, X4, Y4)	boolean	154
BitBlt	Moves bitmap from src device to dest device	GDI output	BitBlt(hDestDC, X1, Y1, nWidth, nHeight, hSrcDC, X2, Y2, nCount, dwRop)	boolean	156
Chord*	Draws a chord (ellipse intersection with line segment)	GDI output	Chord(hDC, X1, Y1, X2, Y2, X3, Y3, X4, Y4)	boolean	163
DrawIcon	Draws icon with upper-left corner at X, Y	GDI output	DrawIcon(hDC, X, Y, hIcon)	boolean	218
DrawText	Draws nCount chars of lpString clipped in lpRect	GDI output	DrawText(hDC, lpString, nCount, lpRect, wFormat)	Height of text	219
Ellipse	Draws ellipse with center in X1, Y1; X2, Y2 rect	GDI output	Ellipse(hDC, X1, Y1, X2, Y2)	boolean	222
EXITextOut*	Writes character string within rect region on display	GDI output	EXITextOut(hDC, X, Y, wOptions, lpRect, lpString, nCount, lpDx)	boolean	241
FillRect	Fills rectangle using specified brush	GDI output	FillRect(hDC, lpRect, hBrush)	boolean	243
FillRgn	Fills region with specified brush	GDI output	FillRgn(hDC, hRgn, hBrush)	boolean	244
FloodFill	Fills area with current brush starting at X, Y	GDI output	FloodFill(hDC, X, Y, rgbColor)	boolean	247
FrameRect	Draws border for rectangle	GDI output	FrameRect(hDC, lpRect, hBrush)	boolean	249
FrameRgn	Draws border for region	GDI output	FrameRgn(hDC, hRgn, hBrush, nWidth, nHeight)	boolean	249
GetCharWidth*	Returns width of a character	GDI output	GetCharWidth(hDC, wFirstChar, wLastChar, lpBuffer)	boolean	257
GetCurrentPosition	Returns logical coords of current position	GDI output	GetCurrentPosition(hDC)	lpPos	267
GetPixel	Returns RGB color of pixel at X, Y	GDI output	GetPixel(hDC, X, Y)	rgbColor	293
GrayString	Writes nCount chars of String using hBrush to gray	GDI output	GrayString(hDC, nBrush, lpOutputFunc, lpData, nCount, X, Y, nWidth, nHeight)	boolean	332
InvertRect	Inverts display bits of lpRect	GDI output	InvertRect(hDC, lpRect)	boolean	343
InvertRgn	Inverts colors in hRgn	GDI output	InvertRgn(hDC, hRgn)	boolean	343
LineDDA	Computes successive points in line X1, Y1; X2, Y2	GDI output	LineDDA(X1, Y1, X2, Y2, lpLineFunc, lpData)	boolean	350
LineTo	Draws line from current pos up to X, Y (but not X, Y)	GDI output	LineTo(hDC, X, Y)	boolean	351
MoveTo	Moves current position to point X, Y	GDI output	MoveTo(hDC, X, Y)	boolean	376
PaintRgn	Fills hRgn with current brush	GDI output	PaintRgn(hDC, hRgn)	boolean	386

(Continued)

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
PatBlt	Combines bit pattern with one already on device	GDI output	PatBlt(hDC, X1, Y1, X2, Y2, hPattern, dwROP)	hDrawn	386
Pie	Draws arc and connects two endpoints to center	GDI output	Pie(hDC, X1, Y1, X2, Y2, X3, Y3, X4, Y4)	hDrawn	389
Polygon	Draws polygon	GDI output	Polygon(hDC, lpPoints, nCount)	hDrawn	391
Polylines	Draws set of line segments	GDI output	Polylines(hDC, lpPoints, nCount)	hDrawn	392
Rectangle	Draws rectangle	GDI output	Rectangle(hDC, X1, Y1, X2, Y2)	hDrawn	397
RGB	Creates RGB color from individual color values	GDI output	RGB(rgRed, rgGreen, rgBlue)	DWORD	405
RoundRect	Draws rounded rectangle	GDI output	RoundRect(hDC, X1, Y1, X2, Y2, X3, Y3)	hDrawn	405
SelfPixel	Sets pixel at X, Y to device color closest to rgbColor	GDI output	SelfPixel(hDC, X, Y, rgbColor)	hDrawn	435
TextOut	Writes character string at X, Y	GDI output	TextOut(hDC, X, Y, lpString, nCount)	hDrawn	485
CombineRgn	Combines two existing regions into new region	GDI region	CombineRgn(hDestRgn, hSrcRgn1, hSrcRgn2, nCombineMode)	hRgnType	173
CreateEllipticRgn	Creates elliptical region bounded by rect, X1, Y1, X2, Y2	GDI region	CreateEllipticRgn(X1, Y1, X2, Y2)	hRgn	184
CreateEllipticRgnIndirect	Creates elliptical region bounded by lpRect	GDI region	CreateEllipticRgnIndirect(lpRect)	hRgn	185
CreatePolygonRgn	Creates polygonal region	GDI region	CreatePolygonRgn(lpPoints, nCount, nPolyFillMode)	hRgn	193
CreateRectRgn	Creates rectangular region	GDI region	CreateRectRgn(X1, Y1, X2, Y2)	hRgn	194
CreateRectRgnIndirect	Creates rectangular region sized like lpRect	GDI region	CreateRectRgnIndirect(lpRect)	hRgn	194
EqualRgn	Determines if two regions are identical	GDI region	EqualRgn(hSrcRgn1, hSrcRgn2)	hEqual	237
OffsetRgn	Moves region X units horiz and Y units vertically	GDI region	OffsetRgn(hRgn, X, Y)	hRgnType	360
OffsetRect	Moves viewport origin relative to current values	GDI region	OffsetRect(hRgn, X, Y)	hRgnType	360
OffsetViewportOrg	Determines whether X, Y is within hRgn	GDI region	OffsetViewportOrg(hRgn, X, Y)	hRgnType	363
Visible	Determines whether X, Y is within hRgn	GDI region	Visible(hRgn, X, Y)	hRgnType	396
ScaleViewportExt	Determines viewport extents relative to current values	GDI region	ScaleViewportExt(hDC, Xnum, Xdenom, Ynum, Ydenom)	hRgnType	407
GetObject	Deletes object by freeing system storage	GDI selection	GetObject(hObject, nCount, lpObject)	hObject	208
SelectClipRgn	Deletes object by freeing system storage	GDI selection	SelectClipRgn(hDC, hRgn)	hObject	292
SelectObject	Selects hObj as current clipping region for disp context	GDI selection	SelectObject(hDC, hObject)	hObject	411
GetTextAlign	Returns status of text alignment flag	GDI text justify	GetTextAlign(hDC)	hObject	412
GetTextCharacterExtra	Returns current intercharacter spacing	GDI text justify	GetTextCharacterExtra(hDC)	hObject	309
GetTextExtent	Computes width and height of text line in lpString	GDI text justify	GetTextExtent(hDC, lpString, nCount)	hObject	310
SetTextCharacterExtra	Sets amount of intercharacter spacing	GDI text justify	SetTextCharacterExtra(hDC, nCharExtra)	hObject	452
SetTextJustification	Prepares GDI to justify text line	GDI text justify	SetTextJustification(hDC, nBreakExtra, nBreakCount)	hObject	453
GlobalCompact	Compacts global memory to free dwMinFree bytes	Memory manager	GlobalCompact(dwMinFree)	hObject	324
GlobalAlloc	Allocates dwBytes of memory from global heap	Memory manager	GlobalAlloc(dwFlags, dwBytes)	hObject	322
GlobalDiscard	Discards global memory block if ref count is zero	Memory manager	GlobalDiscard(hMem)	hObject	325
GlobalFree	Returns memory type of global memory block	Memory manager	GlobalFree(hMem)	hObject	326
GlobalFlags	Returns global memory block if ref count is zero	Memory manager	GlobalFlags(hMem)	hObject	327
GlobalHandle	Returns handle of global memory object	Memory manager	GlobalHandle(wMem)	hObject	328
GlobalLock	Returns address of block, locks it in mem, ups ref count	Memory manager	GlobalLock(hMem)	hObject	328
GlobalReAlloc	Reallocates global memory block to dwBytes	Memory manager	GlobalReAlloc(hMem, dwBytes, wFlags)	hObject	329
GlobalSize	Returns the size of global memory block, in bytes	Memory manager	GlobalSize(hMem)	hObject	331
GlobalUnlock	Unlocks block, decreases reference count	Memory manager	GlobalUnlock(hMem)	hObject	331
GlobalUnwire*	Unlocks memory segment	Memory manager	GlobalUnwire(hMem)	hObject	332
GlobalWire*	Moves segment to low memory, and locks it	Memory manager	GlobalWire(hMem)	hObject	332
LocalAlloc	Allocates wBytes of memory from local heap	Memory manager	LocalAlloc(wFlags, wBytes)	hObject	358
LocalCompact	Compacts local memory to generate wMinFree free bytes	Memory manager	LocalCompact(wMinFree)	hObject	358
LocalDiscard	Discards local memory block hMem if ref count is zero	Memory manager	LocalDiscard(hMem)	hObject	359
LocalFree	Returns local memory type of block hMem	Memory manager	LocalFree(hMem)	hObject	360
LocalFlags	Releases local memory block hMem if ref count is zero	Memory manager	LocalFlags(hMem)	hObject	361
LocalHandle	Returns address of local memory object at wMem	Memory manager	LocalHandle(wMem)	hObject	361
LocalInit	Sets entry count for each new handle table in local heap	Memory manager	LocalInit(wSegment, wStart, wEnd)	hObject	362
LocalLock	Initializes the local heap	Memory manager	LocalLock(hMem)	hObject	362
LocalMem	Returns address of block, locks block, ups ref count by 1	Memory manager	LocalMem(hMem)	hObject	362
LocalNotify	Permits compaction of local heap	Memory manager	LocalNotify(hMem)	hObject	363
LocalReAlloc	Sets callback function for handling notification messages	Memory manager	LocalReAlloc(hMem, wBytes, wFlags)	hObject	363
LocalShrink*	Reallocates local memory block hMem to wBytes	Memory manager	LocalShrink(hMem, wBytes)	hObject	364
LocalShrink*	Shrinks specified term of heap	Memory manager	LocalShrink(hSeg, wSize)	hObject	366
LocalSize	Returns the size of local memory block, in bytes	Memory manager	LocalSize(hMem)	hObject	366
LocalUnlock	Unlocks local memory block, decreases ref count by 1	Memory manager	LocalUnlock(hMem)	hObject	367
LocalData	Locks data segment in memory	Memory manager	LocalData(hMem)	hObject	367
SetSwapAreaSize*	Changes amount of memory used by code segment	Memory manager	SetSwapAreaSize(nSize)	hObject	448
UnlockData	Unlocks data segment	Memory manager	UnlockData(hMem)	hObject	490

(Continued)

Table 6.73. Continued

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
UnlockSegment	Unlocks wSegment	Memory manager	UnlockSegment(wSegment)	nMem	491
ValidateFreeSpaces*	Determines whether free segments contain valid contents	Memory manager	ValidateFreeSpaces()	ipRetVal	493
Catch	Copies content exec environment to buffer. ipCatchBuf	Module manager	Catch(ipCatchBuf)	nThrowBack	162
FreeLibrary	Removes library module if reference count is zero	Module manager	FreeLibrary(hLibModule)	None	260
FreeProcInstance	Removes function instance at address ipProc	Module manager	FreeProcInstance(ipProc)	None	260
GetCodeHandle	Returns handle of code segment containing function	Module manager	GetCodeHandle(ipProc)	Instance	264
GetInstanceData	Copies nCount bytes from instance to current instance	Module manager	GetInstanceData(hInstance, pData, nCount)	nBytes	278
GetModuleFileName	Copies module filename to ipFileName	Module manager	GetModuleFileName(hModule, ipFileName, nSize)	nLength	286
GetModuleHandle	Returns module handle	Module manager	GetModuleHandle(ipModuleName)	nModule	289
GetModuleUsage	Returns reference count of module hModule	Module manager	GetModuleUsage(hModule)	nCount	289
GetProcAddress	Returns address of ipProcName function	Module manager	GetProcAddress(hModule, ipProcName)	ipAddress	295
GetVersion	Returns Windows version number	Module manager	GetVersion()	nVersion	315
MakeProcInstance	Returns address for ipProc	Module manager	MakeProcInstance(ipProc, hInstance)	ipAddress	371
Throw	Restores execution environment to values in ipCatchBuf	Module manager	Throw(ipCatchBuf, nThrowBack)	None	485
AccessResource	Seis file pointer for read access to hResInfo	Resource manager	AccessResource(hInstance, hResInfo)	nFile	148
AddFontResource	Adds resource in ipFileName to system font table	Resource manager	AddFontResource(ipFileName)	nFont	149
AllocResource	Allocates dwSize bytes of memory for hResInfo	Resource manager	AllocResource(hInstance, dwSize)	nMem	150
FindResource	Locates resource ipName of type lpType	Resource manager	FindResource(hInstance, ipName, lpType)	hResInfo	245
FreeResource	Removes resource from memory. If ref count is zero	Resource manager	FreeResource(hResData)	hResInfo	245
LoadAccelerators	Loads accelerator table named by lpTableName	Resource manager	LoadAccelerators(hInstance, lpTableName)	hRes	351
LoadBitmap	Loads bitmap named by lpBitmapName	Resource manager	LoadBitmap(hInstance, lpBitmapName)	hBitmap	352
LoadCursor	Loads cursor named by lpCursorName	Resource manager	LoadCursor(hInstance, lpCursorName)	hCursor	353
LoadIcon	Loads icon named by lpIconName	Resource manager	LoadIcon(hInstance, lpIconName)	hIcon	354
LoadLibrary	Loads library module named by lpLibFileName	Resource manager	LoadLibrary(lpLibFileName)	hLibModule	355
LoadMenu	Loads menu named by lpMenuName	Resource manager	LoadMenu(hInstance, lpMenuName)	hMenu	355
LoadMenuIndirect*	Loads menu from ipMenuTemplate	Resource manager	LoadMenuIndirect(ipMenuTemplate)	hMenu	356
LoadResource	Loads the resource named by hResInfo	Resource manager	LoadResource(hInstance, hResInfo)	hResData	356
LoadString	Loads string wID into buffer. ipBuffer	Resource manager	LoadString(hInstance, wID, ipBuffer, nBufferMax)	nSize	357
LockResource	Returns address of hResInfo. locks it. ups ref count by 1	Resource manager	LockResource(hResData)	ipResData	368
LockSegment	Locks segment at address wSegment	Resource manager	LockSegment(wSegment)	hSegment	368
RemoveFontResource	Removes font from font table	Resource manager	RemoveFontResource(ipFileName)	bSuccess	402
SetResourceHandler	Seis function address of resource handler	Resource manager	SetResourceHandler(hInstance, lpType, lpLoadFunc)	ipLoadFunc	440
SizeOfResource	Returns size of resource. hResInfo, in bytes	Resource manager	SizeOfResource(hInstance, hResInfo)	wBytes	480
UnlockResource*	Unlocks resource, decrements reference count	Resource manager	UnlockResource(hResData)	hSeg	491
CloseSound	Closes play device (first flushes voice queue)	Sound	CloseSound()	None	172
CountVoiceNotes	Returns number of notes in voice queue	Sound	CountVoiceNotes(nVoice)	nNotes	175
GetThresholdEvent	Returns pointer to threshold flag	Sound	GetThresholdEvent()	ipInt	312
GetThresholdStatus	Returns bit mask containing threshold event status	Sound	GetThresholdStatus()	Status	312
OpenSound	Opens play device for exclusive use	Sound	OpenSound()	Voices	383
SetSoundNoise	Seis source and duration of noise from play device	Sound	SetSoundNoise(nSource, nDuration)	nResult	446
SetVoiceAccent	Places an accent in voice queue	Sound	SetVoiceAccent(nVoice, nTempo, nVolume, nMode, nPitch)	nResult	457
SetVoiceEnvelope	Places note in voice queue	Sound	SetVoiceEnvelope(nVoice, nShape, nRepeat)	nResult	459
SetVoiceNote	Places note in voice queue	Sound	SetVoiceNote(nVoice, nValue, nLength, nCutoff)	nResult	459
SetVoiceQueueSize	Allocates nBytes of memory for voice queue	Sound	SetVoiceQueueSize(nVoice, nBytes)	nResult	460
SetVoiceSound	Places frequency and duration in voice queue	Sound	SetVoiceSound(nVoice, nFrequency, nDuration)	nResult	461
SetVoiceThreshold	Seis threshold level for voice queue	Sound	SetVoiceThreshold(nVoice, nNotes)	nResult	461
StartSound	Starts play in each voice queue	Sound	StartSound()	None	480
StopSound	Stops playing all voices	Sound	StopSound()	None	480
SyncAllVoices	Places sync mark in each voice queue	Sound	SyncAllVoices()	nResult	484
WaitSoundState	Waits until play driver enters nState	Sound	WaitSoundState(nState)	nResult	495
AnsLower	Converts string ipStr to lowercase	String	AnsLower(ipStr)	cChar	151
AnsNext	Points to next character in string. ipCurrentChar	String translation	AnsNext(ipCurrentChar)	ipNextChar	151
AnsPrev	Points to prev character in string. ipStart	String translation	AnsPrev(ipStart, ipCurrentChar)	ipPrevChar	152
ANSIToOEM	Converts ANSI string to OEM char string	String translation	ANSIToOEM(ipAnsiStr, ipOemStr)	cChar	153
AnsUpper	Converts string ipStr to uppercase	String translation	AnsUpper(ipStr)	cChar	153
OEMToANSI	Converts OEM char string to ANSI string	String translation	OEMToANSI(ipOemStr, ipAnsiStr)	btTranslated	378
GetCurrentTask	Returns handle of current task	Task	GetCurrentTask()	htask	267
GetNumTasks*	Returns number of tasks in system	Task	GetNumTasks()	htask	292
GetWindowTask*	Returns task handle	Task	GetWindowTask(hWnd)	htask	319

(Continued)

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
Yield	Halts current task, and starts any waiting task	Task	Yield()	None	498
SetPriority	Sets task priority	Task	SetPriority(hTask, nChangeAmount)	lpNew	437
GetRVValue	Returns the red component of rgbColor	Utility	GetRVValue(rgbColor)	Byte	299
DeviceMode	Displays dialog box for setting printer modes	Utility	DeviceMode(hWnd, hItem, lpString, lpString)	lpString	311
GetBVValue	Returns blue component of rgbColor	Utility	GetBVValue(rgbColor)	Byte	256
GetGVValue	Returns green component of rgbColor	Utility	GetGVValue(rgbColor)	Byte	272
GetTickCount*	Returns time since system started	Utility	GetTickCount()	DWORD	313
HIBYTE	Returns hi-order byte of nInteger	Utility	HIBYTE(nInteger)	Byte	335
HIWORD	Returns hi-order word of nInteger	Utility	HIWORD(nInteger)	WORD	337
LOBYTE	Returns lo-order byte of nInteger	Utility	LOBYTE(nInteger)	Byte	357
LOWORD	Returns lo-order word of nInteger	Utility	LOWORD(nInteger)	WORD	369
MAKELONG	Creates unsigned long integer	Utility	MAKELONG(nLowWord, nHighWord)	DWORD	370
MAKEPOINT	Converts long value into a POINT structure	Utility	MAKEPOINT(nInteger)	POINT	371
max	Returns maximum value of A and B	Utility	max value 1, value 2	nMaximum	373
min	Returns minimum value of A and B	Utility	min value 1, value 2	nMinimum	376
WndProc	Processes messages sent to it	Window	WndProc(hWnd, wParam, lParam, lParam)	LPARAM	260
GetClientRect	Copies window client area coords to lpRect	Window attribute	GetClientRect(hWnd, lpRect)	None	293
GetParent	Retrieves window handle of window's parent (if any)	Window attribute	GetParent(hWnd)	hWndParent	293
GetSysModalWindow	Returns handle of system modal window to lpRect	Window attribute	GetSysModalWindow()	hWnd	304
GetWindowRect	Copies dimensions of entire window to lpRect	Window attribute	GetWindowRect(hWnd, lpRect)	None	319
GetWindowText	Copies window's caption into lpString	Window attribute	GetWindowText(hWnd, lpString, nMaxCount)	nCopied	320
GetWindowTextLength	Returns length of window's caption or text	Window attribute	GetWindowTextLength(hWnd)	nLength	321
SetSysModalWindow	Makes window a system modal window	Window attribute	SetSysModalWindow(hWnd)	FALSE	450
SetWindowLong	Changes window attribute identified by nIndex	Window attribute	SetWindowLong(hWnd, nIndex, nNewLong)	DWORD	463
SetWindowText	Sets window caption or text to lpString	Window attribute	SetWindowText(hWnd, lpString)	None	474
SetWindowWord	Changes window attribute specified by nIndex	Window attribute	SetWindowWord(hWnd, nIndex, wNewWord)	wOldWord	475
CreateCaret	Creates caret for hWnd using hBitmap	Window caret	CreateCaret(hWnd, hBitmap, nWidth, nHeight)	None	177
DestroyCaret	Destroys current caret and memory, it occupies	Window caret	DestroyCaret()	None	209
GetCaretBlinkTime	Returns current caret flash rate	Window caret	GetCaretBlinkTime()	DWORD	257
GetCaretPos*	Returns current caret position	Window caret	GetCaretPos(lpPoint)	None	257
HideCaret	Removes system caret from window	Window caret	HideCaret(hWnd)	None	335
SetCaretBlinkTime	Establishes caret flash rate	Window caret	SetCaretBlinkTime(wMSecSeconds)	None	419
SetCaretPos	Moves caret to X, Y position	Window caret	SetCaretPos(X, Y)	None	419
ShowCaret	Displays new caret or redisplay hidden caret	Window caret	ShowCaret(hWnd)	None	475
CallWindowProc	Passes message into lpPrevWndFunc function	Window class	CallWindowProc(lpPrevWndFunc, hWnd, wParam, lParam)	LPARAM	161
GetClassLong	Returns info at nIndex in WNDCLASS structure	Window class	GetClassLong(hWnd, nIndex)	LONG	258
GetClassName	Copies nMaxCount chars of hWnd's class name	Window class	GetClassName(hWnd, lpClassName, nMaxCount)	nCopied	259
GetClassWord	Returns info at nIndex in WNDCLASS structure	Window class	GetClassWord(hWnd, nIndex)	DWORD	269
RegisterClass	Registers a window class	Window class	RegisterClass(hWndClass)	FALSE	308
SetClassLong	Replaces long value at nIndex in WNDCLASS struct	Window class	SetClassLong(hWnd, nIndex, nNewLong)	DWORD	421
SetClassWord	Replaces word at nIndex in WNDCLASS struct	Window class	SetClassWord(hWnd, nIndex, wNewWord)	DWORD	421
ChangeClipboardChain	Removes hWnd from clipboard viewer chain	Window clipboard	ChangeClipboardChain(hWnd, hWndNext)	hRemoved	163
CloseClipboard	Closes the clipboard	Window clipboard	CloseClipboard()	FALSE	171
CountClipboardFormats	Counts number of formats clipboard can render	Window clipboard	CountClipboardFormats()	nCount	174
EnumClipboardFormats	Enumerates available clipboard formats	Window clipboard	EnumClipboardFormats(wFormat)	DWORD	222
GetClipboardData	Returns data from clipboard in specified format	Window clipboard	GetClipboardData(wFormat)	HANDLE	228
GetClipboardOwner	Copies nMaxCount chars of format to lpFormatName	Window clipboard	GetClipboardOwner(hFormat, lpFormatName, nMaxCount)	None	261
GetClipboardViewer	Returns window handle of clipboard owner	Window clipboard	GetClipboardViewer()	hWnd	262
IsClipboardFormatAvailable	Returns True if data is available in wFormat	Window clipboard	IsClipboardFormatAvailable(wFormat)	TRUE	344
OpenClipboard	Open clipboard (prevents other apps from modifying)	Window clipboard	OpenClipboard(hWnd)	FALSE	381
RegisterClipboardFormat	Registers new clipboard format	Window clipboard	RegisterClipboardFormat(lpFormatName)	DWORD	400
SetClipboardData	Copies hMem into clipboard	Window clipboard	SetClipboardData(wFormat, hMem)	HANDLE	422
ChildWindowFromPoint	Acids hWnd to clipboard viewer chain	Window clipboard	ChildWindowFromPoint(hWnd, Point)	hWndNext	424
ClientToScreen	Determines which child window contains Point	Window coordinate	ClientToScreen(hWnd, Point)	None	168
ScreenToClient	Converts client coords to equiv. screen coords	Window coordinate	ScreenToClient(hWnd, Point)	None	170
WindowFromPoint	Converts screen coords at lpPoint to client coords	Window coordinate	WindowFromPoint(lpPoint)	hWnd	408
Identifies window containing Point (in screen coords)	Identifies window containing Point (in screen coords)	Window coordinate	WindowFromPoint(lpPoint)	hWnd	496
Creates tiled, popup, or chud window	Creates tiled, popup, or chud window	Window creation	CreateWindow(lpClassName, lpWindowName, dwStyle, X, Y, nWidth, nHeight, hWndParent, hMenu, hInstance, lpParam)	hWnd	195

(Continued)

Table 6 73. Continued

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
DestroyWindow	Sends WM_DESTROY message, frees memory	Window creation	DestroyWindow(hWnd)	bDestroyed	310
GetWindowLong	Returns information about window	Window creation	GetWindowLong(hWnd, nIndex)	long	318
GetWindowWord	Returns information about window	Window creation	GetWindowWord(hWnd, nIndex)	word	321
IsWindow	Determines whether hWnd is a valid, existing window	Window creation	IsWindow(hWnd)	bExists	347
ClipCursor	Restricts mouse cursor to given rectangle on screen	Window cursor	ClipCursor(lpRect)	None	170
GetCursorPos	Stores cursor position in POINT structure	Window cursor	GetCursorPos(lpPoint)	None	268
SetCursor	Sets cursor shape to hCursor; removes if hCursor=NULL	Window cursor	SetCursor(hCursor)	hOldCursor	428
SetCursorPos	Sets mouse cursor to screen coords XY	Window cursor	SetCursorPos(X, Y)	None	428
ShowCursor	Adds 1 to cursor display count; nonzero, otherwise -1	Window cursor	ShowCursor(bShow)	None	476
GetWindowProc	Do default processing of messages that are ignored	Window default	GetWindowProc(hWnd, wParam, lParam)	lReply	208
CreateDialogIndirect*	Creates modal dialog box like one in lpDialogTemplate	Window dialog	CreateDialogIndirect(hInstance, hDialogTemplate, hWndParent, lpDialogFunc)	hResult	182
DialogBoxIndirect*	Creates modal dialog box, like hDlgTemplate	Window dialog	DialogBoxIndirect(hInstance, hDlgTemplate, hWndParent, lpDialogFunc)	wResult	212
CheckDlgButton	Changes state of button	Window dialog box	CheckDlgButton(hDlg, nIDButton, wCheck)	None	166
CheckRadioButton	Changes, checkmark to nIDCheckButton in group	Window dialog box	CheckRadioButton(hDlg, nIDFirstButton, nIDLastButton, nIDCheckButton)	None	188
CreateDialog	Creates modal dialog box	Window dialog box	CreateDialog(hInstance, lpTemplateName, hWndParent, lpDialogFunc)	hDlg	180
DialogBox	Creates modal dialog box	Window dialog box	DialogBox(hInstance, lpTemplateName, hWndParent, lpDialogFunc)	wResult	211
DialogBoxEx*	Fills nIDListBox with lines matching lpStrSpec	Window dialog box	DialogBoxEx(hDlg, lpStrSpec, nIDListBox, nIDStatePart, wFlags)	nListed	215
DlgDirSelect	Copies selection from nIDListBox to lpString	Window dialog box	DlgDirSelect(hDlg, lpString, nIDListBox)	bDirectory	217
EndDialog	Frees resources and destroys windows of dialog box	Window dialog box	EndDialog(hDlg, nResult)	None	225
GetDlgItem	Returns dialog control handle	Window dialog box	GetDlgItem(hDlg, nIDDlgItem)	hCtrl	274
GetDlgItemInt	Translates text of nIDDlgItem to integer value	Window dialog box	GetDlgItemInt(hDlg, nIDDlgItem, lpTranslated, bSigned)	wValue	274
GetDlgItemText	Copies nMaxCount chars of control text to lpString	Window dialog box	GetDlgItemText(hDlg, nIDDlgItem, lpString, nMaxCount)	nCopied	275
GetNextDlgGroupItem*	Searches for next control in group of dialog controls	Window dialog box	GetNextDlgGroupItem(hDlg, hCtrl, fPrevious)	hWnd	290
GetNextDlgTabItem*	Obtains handle for first control preceding another	Window dialog box	GetNextDlgTabItem(hDlg, hCtrl, fPrevious)	hCtrl	290
IsDialogMessage	Determines whether lpMsg is intended for modeless dialog	Window dialog box	IsDialogMessage(hDlg, lpMsg)	bUsed	345
IsDlgButtonChecked	Returns state of nIDButton	Window dialog box	IsDlgButtonChecked(hDlg, nIDButton)	wCheck	345
MapDialogRect	Converts dialog box coords to client coords	Window dialog box	MapDialogRect(hDlg, lpRect)	None	372
SendMessage	Sends message to nIDDlgItem, within dialog box hDlg	Window dialog box	SendMessage(hWnd, wMsg, wParam, lParam)	lResult	414
SendDlgItemMessage	Sets text of nIDDlgItem to string representing wValue	Window dialog box	SendDlgItemMessage(hDlg, nIDDlgItem, wValue, bSigned)	None	427
GetDlgItemText	Sets caption or text of nIDDlgItem to string	Window dialog box	GetDlgItemText(hDlg, nIDDlgItem, lpString)	None	428
AdjustWindowRect	Converts client rectangle to a window rectangle	Window display	AdjustWindowRect(lpRect, lStyle, bMenu)	None	150
AnyPopup	Indicates whether any popup window is visible	Window display	AnyPopup()	bVisible	153
BringWindowToTop	Makes popup or child window the top window	Window display	BringWindowToTop(hWnd)	None	159
CloseWindow	Closes specified window	Window display	CloseWindow(hWnd)	None	172
EnumChildWindows	Enumerates child windows of hWndParent	Window display	EnumChildWindows(hWndParent, lpEnumFunc, lParam)	bDone	226
EnumWindows	Enumerates windows on screen	Window display	EnumWindows(lpEnumFunc, lParam)	bDone	236
GetActiveWindow	Returns handle to active window	Window display	GetActiveWindow()	hWnd	252
GetNextWindow*	Searches for next window handle	Window display	GetNextWindow(hWnd, wFlag)	hWnd	291
GetTopWindow*	Returns handle to top-level child window	Window display	GetTopWindow(hWnd)	hWnd	313
IsChild	Returns True if window is child of hParentWnd	Window display	IsChild(hWnd, hParent)	bChild	344
IsIconic	Returns status of window (iconic or open)	Window display	IsIconic(hWnd)	bIconic	346
IsWindowVisible	Determines whether hWnd is visible	Window display	IsWindowVisible(hWnd)	bVisible	347
IsZoomed*	Determines whether window is at maximum size	Window display	IsZoomed(hWnd)	bZoomed	348
MoveWindow	Causes WM_SIZE message to be sent to hWnd	Window display	MoveWindow(hWnd, X, Y, nWidth, nHeight, bRepaint)	None	377
OffsetWindowOrg*	Modifies window origin relative to current values	Window display	OffsetWindowOrg(nDC, X, Y)	lpPrevPos	381
OpenIcon	Opens specified window	Window display	OpenIcon(hWnd)	bOpenIcon	384
ScaleWindowEx*	Modifies window extents from current values	Window display	ScaleWindowEx(hDC, Xnum, Ydenom, Ynum, Ydenom)	hPrevExits	409
SetActiveWindow	Makes hWnd or popup window the active window	Window display	SetActiveWindow(hWnd)	hWndPrev	415
ShowOwnedPopups*	Displays or hides all popup windows	Window display	ShowOwnedPopups(hWnd, fShow)	None	477
ShowScrollBar	Displays or hides scrollbar	Window display	ShowScrollBar(hWnd, nCmdShow)	None	477
ShowWindow	Displays or removes window as specified by: CmdShow	Window display	ShowWindow(hWnd, nCmdShow)	bShown	478
FlashWindow	Flashes window once	Window error	FlashWindow(hWnd, bInvert)	hWnd	247
MessageBeep	Generates a beep when message box displayed	Window error	MessageBeep(wType)	bBeep	373
MessageBox	Creates message box window	Window error	MessageBox(hWndParent, lpText, lpCaption, wType)	nMenuItems	373
CallMsgFilter	Passes message and code to message filter func.	Window hook	CallMsgFilter(hMsg, nCode)	bResult	161
SetWindowHook	Installs system or application hook	Window hook	SetWindowHook(nFilterType, lpFilterFunc)	lpPrevFilterFunc	466
UnhookWindowHook*	Removes filter function from hook chain	Window hook	UnhookWindowHook(hHook, lpfnHook)	bUnhooked	489
EnumTaskWindows*	Enumerates all windows associated with a task	Window information	EnumTaskWindows(hTask, lpEnumFunc, lParam)	bEnumerate	235
EnableHardwareInput*	Enables/disables mouse and keyboard	Window input	EnableHardwareInput(fEnableInput)	bEnabled	223

(Continued)

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
EnableWindow	Enables or disables mouse, keyboard input to hWnd	Window input	EnableWindow(hWnd, bEnable)	bDone	224
GetAsyncKeyState	Determines whether key is up or down	Window input	GetAsyncKeyState(vKey)	nState	232
GetCapture	Determines which window is receiving mouse input	Window input	GetCapture()	hWnd	236
GetDoubleClickTime	Returns doubleclick time for mouse	Window input	GetDoubleClickTime()	wClickTime	276
GetFocus	Returns handle of window with input focus	Window input	GetFocus()	hWnd	277
GetInputState	Determines whether there are input events in queue	Window input	GetInputState()	bEvent	277
GetKeyboardState	Copies status of virtual keys to a buffer	Window input	GetKeyboardState(lpKeyState)	none	278
GetKeyState	Returns state of virtual key	Window input	GetKeyState(virtKey)	nState	279
IsWindowEnabled	Returns state of hWnd input from mouse and keyboard	Window input	IsWindowEnabled(hWnd)	bEnabled	347
KillTimer	Kills timer event identified by hWnd and nIDEvent	Window input	KillTimer(hWnd, nIDEvent)	bKilled	349
ReleaseCapture	Release mouse input, restores normal processing	Window input	ReleaseCapture()	None	401
SetCapture	Causes mouse input to be sent to hWnd	Window input	SetCapture(hWnd)	hWndPrev	418
SetDoubleClickTime	Sets mouse doubleclick time	Window input	SetDoubleClickTime(wCount)	None	429
SetFocus	Assigns input focus to hWnd	Window input	SetFocus(hWnd)	hWndPrev	430
SetKeyboardState	Copies buffer to keyboard state table	Window input	SetKeyboardState(lpKeyState)	None	431
SetTimer	Creates system timer event	Window input	SetTimer(hWnd, nIDEvent, wElapsed, lpTimerFunc)	nIDNewEvent	454
SwapMouseButton	Swaps meaning of left/right mouse buttons if bSwap-True	Window input	SwapMouseButton(bSwap)	bSwapped	483
WinMain	Entry point for Windows application execution	Window main	WinMain(hInstance, hPReserved, lpCmdLine, nCmdShow)	nExitCode	316
GetWindow*	Searches for windows in window manager's list	Window manager	GetWindow(hWnd, wCmd)	hWnd	316
RegisterWindowDestroy*	Locks windows from destruction by other tasks	Window manager	RegisterWindowDestroy(hWnd, (Register)	hPrevParent	400
SetParent*	Changes parent window of child window	Window manager	SetParent(hWndChild, hWndNewParent)	hPrevParent	435
SetWindowPos*	Changes size, position, ordering of window	Window manager	SetWindowPos(hWnd, hWndInsertAfter, x, y, cx, cy, wFlag)	None	465
ChangeMenu	Changes menu item in hMenu	Window menu	ChangeMenuItem(hWnd, wIDChangeItem, lpNewItem, wIDNewItem, wChange)	bChanged	163
CheckMenuItem	Changes checkmark status of menu item	Window menu	CheckMenuItem(hWnd, wIDCheckItem, wCheck)	bOldCheck	167
CreateMenu	Creates empty menu	Window menu	CreateMenu()	hMenu	190
DestroyMenu	Destroys hMenu and frees memory, if occupied	Window menu	DestroyMenu(hWnd)	bDestroyed	210
DrawMenuBar	Redraws menu bar	Window menu	DrawMenuBar(hWnd)	None	219
EnableMenuItem	Enables, disables, or gray's menu item	Window menu	EnableMenuItem(hWnd, wIDEnableItem, wEnable)	bEnabled	223
GetMenuItem	Returns handle to window's menu	Window menu	GetMenuItem(hWnd)	hMenu	282
GetMenuItemCount*	Determines how many items are in hMenu	Window menu	GetMenuItemCount(hWnd)	menuItem	283
GetMenuItemID*	Obtains identifier for a menu item	Window menu	GetMenuItemID(hWnd, wID)	nID	283
GetMenuState*	Identifies top-level menu	Window menu	GetMenuState(hWnd, wID, wFlags)	wItem	283
GetMenuString*	Copies nMaxCount chars of menu label to pString	Window menu	GetMenuString(hWnd, wIDItem, pString, nMaxCount, wFlag)	nCount	284
GetSubMenu	Returns menu handle of popup menu	Window menu	GetSubMenu(hWnd, wID)	hSubMenu	302
GetSystemMenu	Allows access to system menu	Window menu	GetSystemMenu(hWnd, bInvert)	bSysMenu	302
HitTestMenu	HitTest or unHitTest top-level menu item	Window menu	HitTestMenu(hWnd, hWndMenu, wIDHitItem, wHitIt)	bHitIt	303
SetMenu	Sets window menu to hMenu, removes if hMenu-Null	Window menu	SetMenu(hWnd, hMenu)	bSet	303
DefHookProc*	Provides default hook processing of WM messages	Window message	DefHookProc(code, wParam, lParam, lpfnNextHook)	code	206
DispatchMessage	Passes message to window function in MSG structure	Window message	DispatchMessage(lpMsg)	lResult	214
GetCurrentTime	Returns elapsed time since boot	Window message	GetCurrentTime()	Time	267
GetMessage	Retrieves message	Window message	GetMessage(lpMsg, hWnd, wMsgFilterMin, wMsgFilterMax)	bContinue	285
GetMessagePos	Returns: mouse position screen coords at last message	Window message	GetMessagePos()	qWPos	286
GetMessageTime	Returns time of last message	Window message	GetMessageTime()	Time	287
InSendMessage	Returns True if function is processing SendMessage	Window message	InSendMessage()	bInSend	339
PeekMessage	Places message (if any) at lpMsg	Window message	PeekMessage(lpMsg, hWnd, wMsgFilterMin, wMsgFilterMax, bRemoveMsg)	bPrest	387
PostAppMessage	Posts message to application	Window message	PostAppMessage(hWnd, wMsg, wParam, lParam)	bPosted	393
PostAppMessageQueue	Posts message in application queue	Window message	PostAppMessageQueue(hWnd, wMsg, wParam, lParam)	bPosted	393
PostQuitMessage	Posts WM_QUIT message to application	Window message	PostQuitMessage(nExitCode)	None	394
PostRet	Determines whether point lies within lpRect	Window message	PostRet(lpRect, Point)	bInRect	395
RegisterWindowMessage	Defines new, unique window message	Window message	RegisterWindowMessage(pString)	wMsg	400
ReplyMessage	Replies to message without returning control	Window message	ReplyMessage(Reply)	None	403
SendMessage	Sends message to window or windows	Window message	SendMessage(hWnd, wMsg, wParam, lParam)	Reply	414
SendMessageQueue	Creates new message queue	Window message	SendMessageQueue(wMsg)	bNewQ	434
TranslateAccelerator	Processes keyboard accelerators for menu commands	Window message	TranslateAccelerator(hWnd, hAccTable, lpMsg)	nTranslated	486
TranslateMessage	Translates virtual keystrokes into char messages	Window message	TranslateMessage(lpMsg)	bTranslated	487
WaitMessage	Yields control to other application	Window message	WaitMessage()	None	495
BeginPaint	Prepares window for painting	Window painting	BeginPaint(hWnd, lpPaint)	hDC	156
EndPaint	Marks end of window repainting	Window painting	EndPaint(hWnd, lpPaint)	None	226
GetDC	Returns display context of client area for window	Window painting	GetDC(hWnd)	hDC	268
GetDCOrg*	Returns origin for display context	Window painting	GetDCOrg(hDC)	iPoint	269
GetUpdateRect	Copies dim of rect that needs updating to lpRect	Window painting	GetUpdateRect(hWnd, lpRect, bErase)	bUpdate	313

(Continued)

Table 6.73 Continued

Function Name	Description	Type	Syntax (arguments)	Returns	Ref Page #
GetUpdateRgn*	Copies window's update region to specified region	Window painting	GetUpdateRgn(hWnd, hRgn, lErase)	sRgnType	314
GetWindowDC	Returns display context for entire window	Window painting	GetWindowDC(nWind)	hDC	317
InvalidateRect	Marks hRgn for repainting	Window painting	InvalidateRect(hWnd, lpRect, bErase)	None	341
InvalidateRgn	Marks hRgn for repainting	Window painting	InvalidateRgn(hWnd, hRgn, bErase)	None	342
ReleaseDC	Releases display context	Window painting	ReleaseDC(hWnd, hDC)	nReleased	401
UpdateWindow	Notifies application when window needs redrawing	Window painting	UpdateWindow(hWnd)	None	492
ValidateRect	Releases rectangle lpRect from repainting	Window painting	ValidateRect(hWnd, lpRect)	None	493
ValidateRgn	Releases hRgn from repainting	Window painting	ValidateRgn(hWnd, hRgn)	None	494
EnumProps	Passes each property of hWnd to pEnumFunc	Window property	EnumProps(hWnd, lpEnumFunc)	nResult	233
EnumWindow	Returns handle of window	Window property	EnumWindows(className, lpWindowName)	hWnd	245
GetProp	Returns handle associated with lpString	Window property	GetProp(hWnd, lpString)	pData	29
RemoveProp	Removes lpString from property list	Window property	RemoveProp(hWnd, lpString)	None	403
SetProp	Copies string and data handle to property list of hWnd	Window property	SetProp(hWnd, lpString, pData)	bSet	437
CopyRect	Copies an existing rectangle	Window rectangle	CopyRect(lpDestRect, lpSourceRect)	None	174
InitiateRect	Freezes hRgn by X units horiz and Y units vertically	Window rectangle	InitiateRect(lpRect, X, Y)	nResult	338
IntersectRect	Finds intersection of two rects, copies to lpDestRect	Window rectangle	IntersectRect(lpDestRect, lpSrc1Rect, lpSrc2Rect)	nIntersect	340
IsRectEmpty	Determines whether lpRect is empty	Window rectangle	IsRectEmpty(lpRect)	bEmpty	346
OffsetRect	Moves rectangle X units horiz and Y units vertically	Window rectangle	OffsetRect(lpRect, X, Y)	nResult	379
SetRect	Fills RECT struct at lpRect with given coords	Window rectangle	SetRect(lpRect, X1, Y1, X2, Y2)	nResult	438
SetRectEmpty	Sets lpRect to empty rectangle (all coords zero)	Window rectangle	SetRectEmpty(lpRect)	nResult	438
SetRectRgn*	Creates rectangular region	Window rectangle	SetRectRgn(hRgn, X1, Y1, X2, Y2)	None	439
UnionRect	Stores union of two rectangles	Window rectangle	UnionRect(lpDestRect, lpSrc1Rect, lpSrc2Rect)	nUnion	490
GetScrollPos	Returns current position of scrollbar	Window scrolling	GetScrollPos(hWnd, nBar)	nPos	300
ScrollWindow	Copies min/max scrollbar positions	Window scrolling	ScrollWindow(hWnd, nBar, lpMinPos, lpMaxPos)	None	300
SetScrollPos	Moves scrollbar to nPos, redraws if nonzero	Window scrolling	SetScrollPos(hWnd, nBar, nPos, bRedraw)	nOldPos	410
ScrollWindowEx	Moves contents of client area by Xamount, Yamount	Window scrolling	ScrollWindowEx(hWnd, XAmount, YAmount, lpRect, lpClipRect)	None	444
SetScrollRange	Sets scrollbar elevator to nPos, redraws if nonzero	Window scrolling	SetScrollRange(hWnd, nBar, nMinPos, nMaxPos, bRedraw)	None	445
GetSysColor	Returns system color identified by nIndex	Window sys info	GetSysColor(nIndex)	rgbColor	303
GetSystemMetrics	Returns information about system metrics	Window sys info	GetSystemMetrics(nIndex)	nValue	305
SetSysColors	Changes one or more system colors	Window sys info	SetSysColors(nChanges, lpSysColor, lpColorValues)	None	448
GetProfileString	Returns string info from WIN.INI file	Windows int file	GetProfileString(lpAppName, lpKeyName, lpDefault, lpReturnedString, nSize)	nLength	296
GetProfileInt	Returns integer info from WIN.INI file	Windows int file	GetProfileInt(lpAppName, lpKeyName, nDefault)	nKeyValue	295
WriteProfileString	Copies lpString to WIN.INI file	Windows int file	WriteProfileString(lpAppName, lpKeyName, lpString)	bResult	497
GetAspectRatioFilter	Get setting of current aspect-ratio filter	Windows int file	GetAspectRatioFilter(hDC)	bResult	252

\*Applicable to versions of Windows beginning with 2.0

**Version Info:**

**Notes:**  
C is case sensitive. Lowercase prefix to argument and result names are data type indicators.

**Source:**  
Microsoft Windows SDK Programmer's Reference 2.0


**See Also:**  
6.71. Windows Function Summary by Version  
6.72. Windows Function Summary by Name of Function

**6.74. DIAGNOSTIC AND ERROR CODES**

Value	Message	Value	Message
1 (1)	Insufficient memory for allocation	301 (769)	Invalid task ID
2 (2)	Error reallocating memory	302 (770)	Invalid exit system call
3 (3)	Memory cannot be freed	303 (771)	Invalid BP register chain
4 (4)	Memory cannot be locked	400 (1024)	Dynamic loader/linker errors
5 (5)	Memory cannot be unlocked	401 (1025)	Error during boot process
7 (7)	Window handle not valid	402 (1026)	Error loading a module
8 (8)	Cached display contexts are busy	403 (1027)	Invalid ordinal reference
10 (16)	Clipboard already open	404 (1028)	Invalid entry name reference
13 (19)	Mouse module not valid	405 (1029)	Invalid start procedure
14 (20)	Display module not valid	406 (1030)	Invalid module handle
15 (21)	Unlocked data segment should be locked	407 (1031)	Invalid relocation record
16 (22)	Invalid lock on system queue	408 (1032)	Error saving forward reference
100 (256)	Local memory errors	409 (1033)	Error reading segment contents
103 (259)	LocalReAlloc -- invalid local heap	410 (1034)	Error reading segment contents
140 (320)	Local heap is busy	411 (1035)	Insert disk for specified file
143 (323)	Invalid local heap	412 (1036)	Error reading non-resident table
14B (331)	Invalid local heap	4FF (1279)	INT 3F handler unable to load segment
15B (347)	Invalid local heap	500 (1280)	Resource manager/user profile errors
180 (384)	Invalid local handle	501 (1281)	Missing resource table
1C0 (448)	LocalLock count overflow	502 (1282)	Bad resource type
1F0 (496)	LocalUnlock count underflow	503 (1283)	Bad resource name
200 (512)	Global memory errors	504 (1284)	Bad resource file
240 (576)	Critical section problems	505 (1285)	Error reading resource
280 (640)	Invalid global handle	600 (1536)	Atom manager errors
2C0 (704)	GlobalLock count overflow	700 (1792)	Input/Output package errors
2F0 (752)	GlobalUnlock count underflow	FFEE (65518)	Divide by zero
300 (768)	Task schedule errors		

**Source:** Microsoft Windows SDK Programming Tools 2.0, pages 247 to 248  
 Microsoft Windows Reference Manual 1.0, page 225.  
 (Not documented in Microsoft Windows Reference Manual 2.0)

**6.75. WINDOWS LOGICAL COORDINATE MAPPING**



**Coordinate System Transformation Equations**

Variable	Meaning
xWO	The x coordinate of the window origin
yWO	The y coordinate of the window origin
xWE	The x component of the window extent
yWE	The y component of the window extent
xVO	The x coordinate of the viewport origin
yVO	The y coordinate of the viewport origin
xVE	The x component of the viewport extent
yVE	The y component of the viewport extent
Lx	The x coordinate in the logical coordinate system
Ly	The y coordinate in the logical coordinate system
Dx	The x coordinate in the physical coordinate system
Dy	The y coordinate in the physical coordinate system

Thus:

$$Dx = (Lx - xWO) * xVE/xWE + xVO$$

$$Dy = (Ly - yWO) * yVE/yWE + yVO$$

$$Lx = (Dx - xVO) * (xWE/xVE) + xWO$$

$$Ly = (Dy - yVO) * (yWE/yVE) + yWO$$

**Notes:**

- The viewport generally, but not always, is the same as the physical device.
- Width and height of the viewport must be >-1 and <32768

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 88 to 90

6.76. WINDOW STYLES

Style Name	Description	Restrictions
WS_BORDER	Window that has a border	
WS_CAPTION	Window that has a caption bar	Implies WS_BORDER
WS_CHILD	Child window	Cannot be used with WS_POPUP
WS_CHILDWINDOW	Child window	
WS_CLIPCHILDREN	Exclude area occupied by child windows when drawing within parent	Used when creating parent window
WS_CLIPSIBLINGS	Clip child windows relative to one another	Used with WS_CHILD only
WS_DISABLED	Window that is initially disabled	
WS_DLGFRAME	Window with double border, no caption	
WS_GROUP**	Defines a group of controls	Group applies until next WS_GROUP
WS_HSCROLL	Window that has horizontal scrollbar	
WS_ICONIC	Window is initially iconic	
WS_MAXIMIZE**	Window is maximum size possible	For use with WS_TILED only
WS_MAXIMIZEBOX**	Window contains maximize box	
WS_MINIMIZE**	Window is minimum size possible	
WS_MINIMIZEBOX**	Window contains minimize box	
WS_OVERLAPPED**	Overlapping window	
WS_OVERLAPPEDWINDOW**	Window w/ WS_OVERLAPPED, WS_CAPTION, WS_SYSMENU, WS_THICKFRAME	
WS_POPUP	Popup window	Cannot be used with WS_CHILD
WS_POPUPWINDOW	Window having styles WS_POPUP, WS_BORDER, WS_SYSMENU	
WS_SIZEBOX*	Window that has a size box	
WS_SYSMENU	Window that has system menu box in caption bar	Use with windows w/caption or scrollbars only
WS_TABSTOP**	Defines controls that can be moved to by tabbing	Use with windows w/ caption bars only
WS_THICKFRAME**	Window has a thick frame, which can be used to size window	Tabbing applies until next WS_TABSTOP
WS_TILED*	Tiled window	
WS_TILEDWINDOW*	Window w/ WS_TILED, WS_CAPTION, WS_SYSMENU, WS_SIZEBOX	
WS_VISIBLE	Window that is initially visible	
WS_VSCROLL	Window that has vertical scrollbar	

Version Info:

- \*\*Applies to Windows 1.0 only
- \*\*\*Applies to Windows 2.0 and later only

Source:

Microsoft Windows SDK Programmer's Reference 2.0, pages 199 to 200  
 Microsoft Windows SDK Programmer's Reference 1.0, pages 28 to 29

See Also:

- 6.37. Include File Constants Definitions by Name
- 6.38. Include File Constants Definitions by Use
- 6.72. Windows Function Summary by Name of Function
- 6.73. Windows Function Summary by Type of Function

**6.77. WINDOWS FILE TYPES**

<i>Bit is wFiletype</i>	<i>Meaning</i>	<i>Use</i>
0 (0)	Normal File	Find all 'normal' files
1 (1)	Read-only File	Find all read-only files
2 (2)	Hidden File	Find all hidden files
4 (4)	System File	Find all System files
10 (16)	Directory File	Find all Directories
20 (32)	Archive File	Find all files with 'archive' bit set
2000 (8192)	LB_DIR flag	If set Windows puts message in apps queue
4000 (16384)	Drive bit	
8000 (32768)	Exclusive Bit	Find only files of the type listed (don't include normal files)

**Notes:** wFiletype is determined by ANDing together the bits for the file types you want to match.

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 216

**See Also:** 6.72. Windows Function Summary by Name of Function  
6.73. Windows Function Summary by Type of Function

**6.78. DISPLAY CONTEXT DEFAULT SETTINGS**

<i>Attribute</i>	<i>Default Setting</i>
Background Color	White
Background Mode	OPAQUE
Bitmap	No default
Brush	WHITE_BRUSH
Brush Origin	(0,0)
Clipping Region	The whole display surface
Current Pen Position	(0,0)
Drawing Mode	R2_COPYPEN
Font	SYSTEM_FONT
Intercharacter spacing	0
Mapping Mode	MM_TEXT
Pen	BLACK_PEN
Polygon Filling Mode	ALTERNATE
Relabs Flag	ABSOLUTE
Stretching Mode	BLACKONWHITE
Text Color	Black
Viewport Extents	(1,1)
Viewport Origin	(0,0)
Window Extents	(1,1)
Window Origin	(0,0)

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 92 to 93

**See Also:** 6.37. Include File Constants Definitions by Name  
6.38. Include File Constants Definitions by Use

**6.79. BINARY RASTER OPERATION CODES (ROP2)**

<i>Value</i>	<i>Function</i>
R2_BLACK	Pixel is always black
R2_NOTMERGEPEN	Pixel is inverse of R2_MERGEPEN color
R2_MASKNOTOPEN	Pixel is combination of colors common to the display and inverse of pen
R2_NOTCOPYPEN	Pixel is inverse of pen color
R2_MASKPENNOT	Pixel is combination of colors common to the pen and inverse of display
R2_NOT	Pixel is inverse of the display color
R2_XORPEN	Pixel is combination of colors in pen and display, but not in both
R2_NOTMASKPEN	Pixel is inverse of R2_MASKPEN
R2_MASKPEN	Pixel is combination of colors common to the pen and the display
R2_NOTXORPEN	Pixel is inverse of R2_XORPEN color
R2_NOP	Pixel remains unchanged
R2_MERGENOTPEN	Pixel is a combination of display and inverse of the pen color
R2_COPYPEN	Pixel is the pen color
R2_MERGEENNOT	Pixel is a combination of the pen and the inverse of the display color
R2_MERGEPEN	Pixel is a combination of pen and the display color
R2_WHITE	Pixel is always white

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, page 443

**See Also:** 6.37. Include File Constants Definitions by Name  
6.38. Include File Constants Definitions by Use

**6.80. TERTIARY RASTER OPERATION CODES**

<i>Name</i>	<i>Value</i>	<i>Meaning</i>
BLACKNESS	42H (66)	Dest=BLACK
DSTINVERT	550009H (5570569)	Dest=(not dest)
MERGCOPY	C000CAH (12583114)	Dest=(source AND pattern)
MERGEPAINT	BB0226H (12255782)	Dest=(source AND pattern) OR dest
NOTSRCOPY	330008H (3342344)	Dest=(not source)
NOTSRCERASE	1100A6H (1114278)	Dest=(not source) AND (not dest)
PATCOPY	F00021 (15728673)	Dest=pattern
PATINVERT	5A0049H (5898313)	Dest=pattern XOR dest
PATPAINT	FB0A09H (16452105)	DP Snoo
SRCAND	8800C6H (8913094)	Dest=source AND dest
SRCERASE	440328H (4457256)	Dest=source AND (not dest)
SRCINVERT	660046H (6684742)	Dest=source XOR dest
SRCCOPY	CC00020 (13369376)	
SRCPAINT	EE0086H (15597702)	Dest=source OR dest
WHITENESS	FF0062H (16711778)	Dest=WHITE

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 670 to 677

**See Also:** 6.37. Include File Constants Definitions by Name  
6.38. Include File Constants Definitions by Use

6.81. GDI INFORMATION INDEX DATA

<i>Index Name</i>	<i>Description</i>	<i>Allowable Values</i>
DRIVERVERSION	The GDI version number	100H (256)
TECHNOLOGY	The device technology used	0=vector plotter 1=raster display 2=raster printer 3=raster camera 4=character stream, PLP 5=metafile, VDM 6=display file
HORZSIZE	Width of physical display	In millimeters
VERTSIZE	Height of physical display	In millimeters
HORZRES	Width of display	In pixels
VERTRES	Height of display	In raster lines
LOGPIXELSX*	Number pixels along display width	In pixels per logical inch
LOGPIXELSY*	Number pixels along display height	In pixels per logical inch
BITSPIXEL	Number of adjacent color bits per pixel	
PLANES	Number of color planes	
NUMBRUSHES	Number of device-specific brushes	
NUMPENS	Number of device-specific pens	
NUMFONTS	Number of device-specific fonts	
NUMCOLORS	Number of entries in device's color table	
ASPECTX	Relative width of device pixel used for lines	
ASPECTY	Relative height of device pixel used for lines	
ASPECTXY	Diagonal width of device pixel used for lines	
PDEVICESIZE	Size of internal data structure PDEVICE	In bytes
CLIPCAPS	Clipping capabilities of device	0=cannot clip, 1=can clip rectangle
RASTERCAPS	Raster capabilities of device	RC_BITBLT (can transfer bitmap) RC_BANDING (requires banding support) RC_GDI20_OUTPUT (supports 2.0 features) RC_BITMAP64 (supports bitmaps >64K) RC_SCALING (capable of scaling)
CURVECAPS	Curve creation capabilities of device	Bit 0=can do circles Bit 1=can do pie wedges Bit 2=can do chord arcs Bit 3=can do ellipses Bit 4=can do wide borders Bit 5=can do styled borders Bit 6=can do wide and styled borders Bit 7=can do interiors Bits 8-15=NOT USED
LINECAPS	Line creation capabilities of device	Bit 0=RESERVED Bit 1=can do polyline Bits 2-3=RESERVED Bit 4=can do wide lines Bit 5=can do styled lines Bit 6=can do wide and styled lines Bit 7=can do interiors Bits 8-15=NOT USED
POLYGONALCAPS	Polygonal creation capabilities of device	Bit 0=can do alternate fill polygon Bit 1=can do rectangle Bit 2=can do winding number fill polygon Bit 3=can do scanline Bit 4=can do wide borders Bit 5=can do styled borders Bit 6=can do both wide and styled borders Bit 7=can do interiors Bits 8-15=NOT USED
TEXTCAPS	Text creation capabilities of device	Bit 0=can do character output precision Bit 1=can do stroke output precision Bit 2=can do stroke clip precision Bit 3=can do 90-degree character rotations Bit 4=can do any character rotation Bit 5=can do scaling independent of X and Y Bit 6=can do doubled character for scaling Bit 7=can do integer multiples for scaling Bit 8=can do any multiples for exact scaling Bit 9=can do double weight characters Bit 10=can do italics Bit 11=can do underlining Bit 12=can do strikeouts Bit 13=can do raster fonts Bit 14=can do vector fonts Bit 15=RESERVED, must be 0

**Version Info:** \*First defined in Windows 2.0; not listed in Windows 1.0 documentation

**Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 270 to 273

6.82. BITMAP DATA STRUCTURES

*Monochrome Bitmaps:*

<i>Scan Order</i>
Scan 0
Scan 1
...
Scan n-2
Scan n-1

**Pixel Order**

<i>Word #</i>	<i>Bit #</i>	<i>Pixel #</i>
0	15	0
	14	1
	13	2
	12	3
	11	4
	10	5
	9	6
	8	7
	7	8
	6	9
	5	10
	4	11
	3	12
	2	13
	1	14
	0	15
1	15	16
	14	17
	13	18
	12	19
	11	20
	10	21
	9	22
	8	23
	7	24
	6	25
	5	26
	4	27
	3	28
	2	29
	1	30
	0	31

0=black  
1=white

Etcetera

Table 6.82. Continued

**Color Bitmaps:**

		<i>Pixel Order</i>			
<i>Scan Order</i>		<i>Word #</i>	<i>Bit #</i>	<i>Pixel #</i>	
Red Scan 0		0	15	0	0=color disabled 1=color enabled
Red Scan 1			14	1	
...			13	2	
Red Scan n-2			12	3	
Red Scan n-1			11	4	
Green Scan 0			10	5	
Green Scan 1			9	6	
...			8	7	
Green Scan n-2			7	8	
Green Scan n-1			6	9	
Blue Scan 0			5	10	
Blue Scan 1			4	11	
...			3	12	
Blue Scan n-2			2	13	
Blue Scan n-1			1	14	
		0	15		
		1	15	16	
			14	17	
			13	18	
			12	19	
			11	20	
			10	21	
			9	22	
			8	23	
			7	24	
			6	25	
			5	26	
			4	27	
			3	28	
			2	29	
			1	30	
			0	31	

Etcetera

- Notes:** Color bitmaps require three arrays: red, green, and blue
- Source:** Microsoft Windows SDK Programmer's Reference 2.0, pages 609 to 611
- See Also:** 6.39. BITMAP Structure Format

**6.83. SYMBOLIC DEBUGGER (SYMDEB) COMMAND SUMMARY**

**Command Line Options:**

<i>Option</i>	<i>Function</i>	<i>Allowable Values</i>
/m	Redirects output to secondary mono monitor	
/x	Disables the 'more' feature	
/w#	Sets memory allocation reporting level to #	0=no reporting 1=allocation messages only (default) 2=movement messages only 3=both allocation and movement messages
/@filename	Loads macro definitions from named file	
/n	Permits use of nonmaskable interrupts	
/i	Use features available on IBM compatibles	
/!filename	Prevents named symbol file being used with executable file	
/"cmdlist"	Causes commands in list to be executed	Each command separated by semicolon

- Notes:**
- Options may be preceded by a hyphen instead of a forward slash
  - Options may be identified with upper- or lowercase letters

Table 6.83. Continued

Command	Function
a[address]	Assemble
ba[mode][size]address[value][cmdstring]	Set 80386 address breakpoint(s)
bc[idlist]	Clear breakpoint(s)
bd[idlist]	Disable breakpoint(s)
be[idlist]	Enable breakpoint(s)
bl	List breakpoint(s)
bp[id]address [value][cmdstring]	Set breakpoint
c range address	Compare
d [range]	Dump memory using previous type
da [range]	Dump memory in ASCII format
db [range]	Dump memory in bytes
dd [range]	Dump memory in double words
dq	Display global memory heap
dh	Display local memory heap for current DS
dl [range]	Dump memory as long floating point
dq	Display task queue
ds [range]	Dump memory as short floating point
dt [range]	Dump memory in 10-byte real numbers
dw [range]	Dump memory in words
e address [list]	Enter values using previous type
ea address [list]	Enter ASCII values
eb address [list]	Enter bytes
ed address [list]	Enter double words
el address [list]	Enter long floating-point values
es address [list]	Enter short floating-point values
et address [list]	Enter 10-byte real values
ew address [list]	Enter words
f range list	Fill
g [=address[address]...]	Go
h value value	Add hexadecimal values
i value	Input from port
k [value]	Backtrace stack
kt pdb [value]	Backtrace task
l [address[drive record count]]	Load
m range address	Mmove
m [d]=cmdstring]	Define or execute macro
n filename[filename...]	Set name of file
o value byte	Output byte to port
p [=address][value]	Trace program instruction
q	Quit
r [register][[=]value]	Set register
s range list	Search for match
s-	Set machine debugging only
s&	Set machine and source debugging
s+	Set source debugging only
t [=address][value]	Trace program instruction
u [range]	Display unassembled instructions
v [range]	View source code lines
w [address[drive record count]]	Write to disk
x [?] symbol	Examine symbols
xo symbol	Open map or segment
z symbol value	Set symbol to value
? expression	Compute and display expression
	Display current source code line
<filename	Redirect SYMDEB input to file
>filename	Redirect SYMDEB output to file
=filename	Redirect SYMDEB input and output
{filename	Redirect program input to file
]filename	Redirect program output to file
~filename	Redirect program input and output
!doscommand]	Execute DOS shell or command and return
* string	Comment

**Source:**

Microsoft Windows SDK Programming Tools 2.0,  
pages 100 to 102 and 110 to 138

— PART —

**III**

GENERAL PC  
HARDWARE

---



— SECTION —

# 7

Keyboards,  
Video Adapters,  
and Peripherals

---

7.01. MACHINE SUMMARY AND HISTORY

System	PC Class Machines			AT Class Machines			PS/2 Machines				
	PC	PC/XT	PCjr	PC Portable	Convertible	PC/AT	PC/XT, 286	Model 30	Model 50	Model 60	Model 80
Processor	5 mhz 8088	5 mhz 8088	5 mhz 8088	5 mhz 8088	5 mhz 8088	6.8 mhz*** 80286	6 mhz 80286	8 mhz 8036	10 mhz 80286	10 mhz 80286	16 mhz 80386
RAM coprocessor	Optional	Optional	No	Optional	No	Optional	Optional	Optional	Optional	Optional	Optional
RAM on motherboard	64K***	128K	256K	256K	256K	512K	640K	640K	1M	1M	1M
Maximum RAM allowed	512K***	640K	640K	640K	640K	640K, 16M	640K, 16M	7M	15M	15M	15M
ROM on motherboard	40K	40K	40K	40K	40K	64K	64K	64K	128K	128K	128K
Power supply	63.5-watt	130-watt	33-watt	130-watt	130-watt	450VA	130-watt	70-watt	not specified	not specified	not specified
8-bit PC slots	5	8	0	0	0	2	2	3	0	0	0
16-bit AT slots	0	0	0	0	0	6	0	0	0	0	0
32-bit PS/2 slots	0	0	0	0	0	0	0	0	0	0	0
Drives slots	4	4	1	2	2	3	3	2	3	4	4
Supplied floppy drive(s)	1, 160K v	1, 360K 5.25"	None	2, 360K 5.25"	2, 720K 3.5"	1, 1.2M 5.25"	1, 360K 5.25"	2, 720K 3.5"	1, 1.4M 3.5"	1, 1.4M 3.5"	4, 1.4M 3.5"
Supplied hard drive	None	10 Meg	None	None	None	20 Meg	20 Meg	20 Meg	20 Meg	44 Meg	44 Meg
Optional hard drive	Supported	Optional	Supported	Optional	Optional	Optional	Optional	None	None	70 Meg	70 - 115 Meg
Cassette	Optional	No	Optional	Optional	Optional	Optional	Optional	No	No	No	No
Parallel ports	Optional	Optional	Optional	Optional	Optional	Optional	Optional	Yes, 1	Yes, 1	Yes, 1	Yes, 1
Serial ports	Optional	Optional	Optional	Optional	Optional	Optional	Optional	Yes, 1	Yes, 1	Yes, 1	Yes, 1
Mouse ports	Optional	Optional	Optional	Optional	Optional	Optional	Optional	Yes, 1	Yes, 1	Yes, 1	Yes, 1
Supplied video adapter	None	None	Built-in PCjr	Special	CGA emulation	Optional	Optional	MCGA	VGA	VGA	VGA
Optional video adapter	MDA, CGA	MDA, CGA, EGA	None	None	None	MDA, CGA, EGA	MDA, CGA, EGA	VGA	VGA	VGA	VGA
Keyboard	83-key	83-key	"chiclet"	83-key	78-key	84-key, 101/102-key	84-key, 101/102-key	101/102-key	101/102-key	101/102-key	101/102-key
Height	5.5"	5.5"	3.8"	8"	2.7"	5.6	5.5	4	5.5	23.5	23.5
Width	19.6"	19.6"	13.9"	20"	12.8"	21.2	19.6	16	14.1	6.5	6.5
Depth	16.1"	16.1"	11.4"	17"	14.7"	16.9	16.1	15.6	16.5	19	19
Weight	29 lbs	32 lbs	8 lbs 4 oz	33 lbs	12.7 lbs	43 lbs	32 lbs	15.7 lbs	21 lbs	44 lbs	44 lbs
Cassette BIOS support	Yes	Yes	Yes	Yes	No	No	No	No	No	No	No
EGA BIOS support	No \$	Yes	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
Serial BIOS support	Yes-2 ports	Yes-2 ports	Yes	Yes-2 ports	Yes-2 ports	Yes-2 ports	Yes-2 ports	Yes-4 ports	Yes-4 ports	Yes-4 ports	Yes-4 ports
Parallel BIOS support	Yes-2 ports	Yes-2 ports	Yes	Yes-2 ports	Yes-2 ports	Yes-2 ports	Yes-2 ports	Yes-3 ports	Yes-3 ports	Yes-3 ports	Yes-3 ports
Hard disk BIOS support	No	Yes	No	Yes-2 ports	Yes-2 ports	Yes	Yes	Yes	Yes	Yes	Yes
Recommended DOS version**	1.0	2.0	2.0	2.0	2.1	2.1	3.2	3.2	3.3	3.3	3.3
Introduced	Aug-81	Mar-83	Oct-83	Mar-84	Apr-86	Aug-86	Apr-87	Apr-87	Apr-87	Apr-87	Apr-87
Updated	Jul-85	Jul-85	Jul-87	Jul-87	Jun-87	Apr-86	Apr-87	Apr-87	Apr-87	Apr-87	Jul-87
Dropped	Jul-87	Jul-87	Jul-87	Jul-87	Jul-87	Jul-87	Jul-87	Jul-87	Jul-87	Jul-87	Jul-87

**Notes:**  
 \*Case housing motherboard  
 \*\*At time of introduction  
 \*\*\*Originally 6, upgraded to 8  
 \*\*\*\*Eventually upgraded to 640K  
 †For half height drives  
 ‡Other drives and sizes available  
 §Eventually upgraded to Yes

**Source:**  
 B/18, June 1987  
 B/19, August 1987  
 PC Magazine, May 26, 1987  
 PC Magazine, July 21, 1987  
 PCjr Technical Reference, pages 2-19, 2-135, D-1

**7.02. PC, AT, AND PS/2 MEMORY USAGE SUMMARY**

<i>Address</i>	<i>Used By</i>	<i>Comments</i>
00000 - 9FFFF	640K on system board	May be 64KB to 640KB depending upon model
A0000 - BFFFF	Display adapter reserved	EGA and VGA use all of this, CGA and MDA use portion
C0000 - DFFFF	Reserved for ROM expansion	Used for I/O channel BIOS (as in XT disk controller) C0000-C3FFF EGA BIOS C6000-C63FF PGA communications area C8000-CBFFF hard disk BIOS D0000-D7FFF cluster adapter BIOS D0000-DFFFF PCjr expansion cartridges
E0000 - EFFFF	Expansion of system ROM	As in AT, PS/2 (standard cartridges in PCjr)
F0000 - FFFFF	System ROM	May be duplicate of ROM in higher memory
100000 - 15FFFF	384K on system board	Model 50, 60, and 80 only
160000 - FDFFFF	Memory expansion	AT and PS/2 only
FE0000 - FEFFFF	RESERVED	AT and PS/2 only
FF0000 - FFFFFF	64K ROM BIOS	AT and PS/2 only

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, page 4-181  
 IBM PS/2 Model 30 Technical Reference, page 1-5  
 IBM AT Technical Reference, page 1-8  
 IBM PC/XT Technical Reference, pages 1-8, 1-9

**See Also:** 4.002. BIOS Memory Usage Summary

7.03. I/O PORT USAGE SUMMARY

Hex Range	XT Use	AT Use	PS/2 Use	Comments
0-F	DMA controller (8237A-5) UNDOCUMENTED	DMA controller (8237A-5) RESERVED FOR SYSTEM BOARD	DMA controller DMA controller	
20-2F	Interrupt controller (8259A)	Interrupt controller 1 (8259A)	Interrupt controller 1 (8259A)	Only ports 20, 21 actually used
30-3F	UNDOCUMENTED	Interrupt controller 1 (8259A)	UNDOCUMENTED	
40-4F	Timer (8253-5)	Timer (8254-2)	System timers	XT uses 40-43 only, PS/2 uses 40,42,44, 47 only
50-5F	Timer (8253-5)	Timer (8254-2)	UNDOCUMENTED	
60-6F	Parallel port (8255A-5)	Keyboard (8042)	Keyboard	XT uses 60-63 only, PS/2 uses 60-61, 64 only
70-7F	UNDOCUMENTED	RTC, NMI mask	RTC, NMI mask	PS/2 uses 70-71 only, reserves 74-76
80-8F	DMA page registers	DMA Page Registers (74LS612)	DMA page registers	XT uses 80-83 only, AT and PS/2 use 81-83, 87, 89-8B, 8F only
90-9F	DMA page registers	DMA page registers	I/O channel	PS/2 uses 90-94, 96-97 only
A0-AF	NMI mask register	Interrupt controller 2 (8259A)	Interrupt controller 2 (8259A)	PS/2 uses A0-A1 only
B0-BF	UNDOCUMENTED	Interrupt controller 2 (8259A)	UNDOCUMENTED	
C0-CF	RESERVED	DMA controller 2 (8237A-5)	DMA controller	
D0-DF	UNDOCUMENTED	DMA controller 2 (8237A-5)	DMA controller	
E0-EF	RESERVED	RESERVED FOR SYSTEM BOARD	UNDOCUMENTED	
F0-FF	UNDOCUMENTED	Math coprocessor (80x87)	Math coprocessor (80x87)	AT uses F0-F1, F8-FF only
100-10F	UNDOCUMENTED	AVAILABLE FOR I/O CHANNEL	Programmable option select	PS/2 uses 100-107 only
110-11F	UNDOCUMENTED	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
1F0-1FF	UNDOCUMENTED	Fixed disk	UNDOCUMENTED	
200-20F	Game I/O adapter	Game I/O adapter	UNDOCUMENTED	Game I/O uses 200-207 only
210-21F	Expansion unit	21F RESERVED	UNDOCUMENTED	XT uses 210-217 only
220-24F	RESERVED	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
250-25F	UNDOCUMENTED	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
260-26F	UNDOCUMENTED	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
270-27F	Parallel printer 2	Parallel printer port 2	Parallel port 3	All use 278-27F only except PS/2 uses 278-27B
280-28F	UNDOCUMENTED	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
290-29F	UNDOCUMENTED	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
2A0-2AF	UNDOCUMENTED	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
2B0-2BF	Alternate EGA	Alternate EGA	UNDOCUMENTED	
2C0-2CF	Alternate EGA	Alternate EGA	UNDOCUMENTED	
2D0-2DF	Alternate EGA (3270 also uses)	Alternate EGA	UNDOCUMENTED	
2E0-2EF	UNDOCUMENTED	GPB 0, data acquisition 0	UNDOCUMENTED	AT uses 2E1, 2E2-2E3 only
2F0-2FF	Secondary asynchronous adapter	Serial port 2	Serial port 2 (RS-232-C)	All use 2F8-2FF only
300-30F	Prototype card	Prototype card	UNDOCUMENTED	
310-31F	Prototype card	Prototype card	UNDOCUMENTED	
320-32F	Fixed disk adapter	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
330-33F	UNDOCUMENTED (XT/370 uses)	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
340-34F	UNDOCUMENTED	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
350-35F	UNDOCUMENTED	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
360-36F	UNDOCUMENTED	PC network (low address)	UNDOCUMENTED	
370-37F	Parallel printer	Parallel printer 1	Parallel port 2	All use 378-37F only except PS/2 uses 378-37B
380-38F	SDLC or second bisync controller	SDLC or second bisync controller	UNDOCUMENTED	
390-39F	UNDOCUMENTED	Cluster adapter	UNDOCUMENTED	
3A0-3AF	First bisync controller	First bisync controller	UNDOCUMENTED	
3B0-3BF	Monochrome display adapter	Monochrome display adapter	Video subsystem, parallel 1	All use 3BC-3BF for parallel port
3C0-3CF	Enhanced graphics adapter	Enhanced graphics adapter	Video subsystem	
3D0-3DF	Color graphics adapter	Color graphics adapter	Video subsystem	
3E0-3EF	3E0-3E7 RESERVED	AVAILABLE FOR I/O CHANNEL	UNDOCUMENTED	
3F0-3FF	Floppy disk adapter, 1st async	Floppy disk adapter, 1st async	Diskette drive controller, Serial 1	All use 3F0-3F7 for disk, 3F8-3FF for async communications

**Legend:** UNDOCUMENTED means not specifically mentioned in IBM technical reference

**Notes:** The AT also uses additional ports in the range 6E2-E2E1 for GPIB, Cluster, and Data Acquisition adapters

**Source:** IBM PC/XT Technical Reference, pages 1-24 and 1-25  
 IBM PC/AT Technical Reference, pages 1-37 and 1-38  
 IBM PS/2 Model 50 and 60 Technical Reference, page 1-9

7.04. PC INTERRUPT USAGE SUMMARY

Interrupt Number	Vector Address	Interrupt Name	Type	BIOS Entry Label	Comments
0H	00-03	Divide by zero exception	System	D11	
1H	04-07	Single step	System	D11	
2H	08-0B	Nonmaskable	System	NMI INT	
3H	0C-0F	Breakpoint	System	D11	
4H	10-13	Overflow	System	D11	
5H	14-17	Print screen	BIOS	PRINT_SCREEN	See 4.001. BIOS Services Summary
6H	18-1B	RESERVED		D11	
7H	1C-1F	RESERVED		D11	
8H	20-23	Time of day service	Hardware	TIMER_INT	IRQ0 timer 0
9H	24-27	Keyboard service	Hardware	KB_INT	IRQ1 keyboard
AH	28-2B	RESERVED		D11	IRQ2 AT slave 8259
BH	2C-2F	Communications service COM2:	Hardware	D11	IRQ3 COM2:
CH	30-33	Communications service COM1:	Hardware	D11	IRQ3 COM1:
DH	34-37	Disk service/alt. printer service	Hardware	D11	IRQ5 PC: fixed disk adapter AT: LPT2
EH	38-3B	Diskette service	Hardware	DISK_INT	IRQ6 floppy disk adapter
FH	3C-3F	Printer service	Hardware	D11	IRQ7 LPT1:
10H	40-43	Video I/O	BIOS	VIDEO_IO	See 4.001. BIOS Services Summary
11H	44-47	Equipment check	BIOS	EQUIPMENT	See 4.001. BIOS Services Summary
12H	48-4B	Memory size	BIOS	MEMORY_SIZE_DETERMINE	See 4.001. BIOS Services Summary
13H	4C-4F	Disk I/O	BIOS	DISKETTE_IO	See 4.001. BIOS Services Summary
14H	50-53	Communications	BIOS	RS232_IO	See 4.001. BIOS Services Summary
15H	54-57	PC: cassette AT: extended services	BIOS	CASSETTE_IO	See 4.001. BIOS Services Summary
16H	58-5B	Keyboard I/O	BIOS	KEYBOARD_IO	See 4.001. BIOS Services Summary
17H	5C-5F	Printer	BIOS	PRINTER_IO	See 4.001. BIOS Services Summary
18H	60-63	Resident BASIC	BIOS	F600.0000	See 4.001. BIOS Services Summary
19H	64-67	Bootstrap	BIOS	BOOT_STRAP	See 4.001. BIOS Services Summary
1AH	68-6B	Time of day	BIOS	TIME_OF_DAY	See 4.001. BIOS Services Summary
1BH	6C-6F	Keyboard break	BIOS	DUMMY_RETURN	Ctrl-Break exit
1CH	70-73	Timer tick	BIOS	DUMMY_RETURN	18.2 ticks/second
1DH	74-77	Video parameters	BIOS	VIDEO_PARAMS	Table address of video parameters
1EH	78-7B	Disk parameters	BIOS	DISK_BASE	Table address of disk parameters
1FH	7C-7F	Video graphics	BIOS		Table address of graphics characters
20H	80-83	Program termination	BIOS		Obsolete
21H	84-87	General function services	DOS		All DOS services available through this interrupt
22H	88-8B	Terminate address	DOS		
23H	8C-8F	Ctrl-Break exit address	DOS		
24H	90-93	Critical error handler address	DOS		
25H	94-97	Absolute disk read	DOS		Read logical sector(s)
26H	98-9B	Absolute disk write	DOS		Write logical sector(s)
27H	9C-9F	Terminate/stay resident	DOS		Obsolete
28H	A0-A3	RESERVED	DOS		Idle signal
29H	A4-A7	RESERVED	DOS		TTY output
2AH	A8-AB	RESERVED	DOS		Critical section
2BH	AC-AF	RESERVED	DOS		
2CH	B0-B3	RESERVED	DOS		
2DH	B4-B7	RESERVED	DOS		
2EH	B8-BB	RESERVED	DOS		
2FH	BC-BF	RESERVED	DOS		
30H	C0-C3	RESERVED	DOS		
31H	C4-C7	RESERVED	DOS		
32H	C8-CB	RESERVED	DOS		
33H	CC-CF	RESERVED	DOS		
34H	D0-D3	RESERVED	DOS		
35H	D4-D7	RESERVED	DOS		
36H	D8-DB	RESERVED	DOS		
37H	DC-DF	RESERVED	DOS		
38H	E0-E3	RESERVED	DOS		

(Continued)

Table 7.04, Continued

Interrupt Number	Vector Address	Interrupt Name	Type	BIOS Entry Label	Comments
39H	E4-E7	RESERVED	DOS		
3AH	E8-EB	RESERVED	DOS		
3BH	EC-EF	RESERVED	DOS		
3CH	F0-F3	RESERVED	DOS		
3DH	F4-F7	RESERVED	DOS		
3EH	F8-FB	RESERVED	DOS		
3FH	FC-FF	RESERVED	DOS		
40H	100-103	RESERVED	BIOS		Revectored disk I/O (Int 13)
41H	104-107	RESERVED	BIOS		Fixed disk 0 parameter table address
42H	108-10B	RESERVED	BIOS		EGA revectored video (Int 10)
43H	10C-10F	RESERVED	BIOS		EGA video parameters table address
44H	110-113	RESERVED	BIOS		EGA/PCjr 1st 128 characters table address
45H	114-117	RESERVED	BIOS		
46H	118-11B	RESERVED	BIOS		Fixed disk 1 parameter table address
47H	11C-11F	RESERVED	BIOS		
48H	120-123	RESERVED	BIOS		PCjr translate from 62-key keyboard
49H	124-127	RESERVED	BIOS		PCjr scan code translate table address
4AH	128-12B	RESERVED	BIOS		AT alarm interrupt user exit address
4BH	12C-12F	RESERVED	BIOS		
4CH	130-133	RESERVED	BIOS		
4DH	134-137	RESERVED	BIOS		
4EH	138-13B	RESERVED	BIOS		
4FH	13C-13F	RESERVED	BIOS		
50H	140-143	AT alarm interrupt	BIOS		
51H	144-147	Mouse functions	BIOS		See 5.08, INT 33H: Mouse Functions Summary
52H	148-14B	RESERVED	BIOS		
53H	14C-14F	RESERVED	BIOS		
54H	150-153	RESERVED	BIOS		
55H	154-157	RESERVED	BIOS		
56H	158-15B	RESERVED	BIOS		
57H	15C-15F	RESERVED	BIOS		
58H	160-163	RESERVED	BIOS		
59H	164-167	RESERVED	BIOS		
5AH	168-16B	Functions	PC CLUSTER		
5BH	16C-16F	Revectored in 19H	PC CLUSTER		
5CH	170-173	Network use	PC CLUSTER		NETBIOS entry point
5DH	174-177	RESERVED	BIOS		
5EH	178-17B	RESERVED	BIOS		
5FH	17C-17F	RESERVED	BIOS		
60H	180-183	RESERVED	USER PROGRAMS		
61H	184-187	RESERVED	USER PROGRAMS		
62H	188-18B	RESERVED	USER PROGRAMS		
63H	18C-18F	RESERVED	USER PROGRAMS		
64H	190-193	RESERVED	USER PROGRAMS		
65H	194-197	RESERVED	USER PROGRAMS		
66H	198-19B	RESERVED	USER PROGRAMS		
67H	19C-19F	Functions	LIM EMS		See 5.29, Expanded Memory Manager Functions Summary
68H	1A0-1A3	UNUSED	UNASSIGNED		
69H	1A4-1A7	UNUSED	UNASSIGNED		
6AH	1A8-1AB	UNUSED	UNASSIGNED		
6BH	1AC-1AF	UNUSED	UNASSIGNED		
6CH	1B0-1B3	UNUSED	UNASSIGNED		
6DH	1B4-1B7	UNUSED	UNASSIGNED		
6EH	1B8-1BB	UNUSED	UNASSIGNED		Also resume system vector
6FH	1BC-1BF	UNUSED	UNASSIGNED		
70H	1C0-1C3	PC-RESERVED AT/PS2; IRQ8 real time clock	AT BIOS	RTC INT	IRQ8

(Continued)

Table 7.04 Continued

Interrupt Number	Vector Address	Interrupt Name	Type	BIOS Entry Label	Comments
71H	1C4-1C7	PC-RESERVED AT/PS2:IRQ9 redirected to IRQ2	AT BIOS	RE DIRECT	IRQ9
72H	1C8-1CB	PC-RESERVED AT/PS2:IRQ10	AT BIOS	D11	IRQ10
73H	1CC-1CF	PC-RESERVED AT/PS2:IRQ11	AT BIOS	D11	IRQ11
74H	1D0-1D3	PC-RESERVED AT/PS2:IRQ12	AT BIOS	D11	IRQ12
75H	1D4-1D7	PC-RESERVED AT/PS2:IRQ13, 80287	AT BIOS	INT_287	IRQ13
76H	1D8-1DB	PC-RESERVED AT/PS2: fixed disk controller	AT BIOS	D11	IRQ14
77H	1DC-1DF	PC-RESERVED AT/PS2:IRQ15	AT BIOS	D11	IRQ15
78H-7FH	1E0-1FF	NOT USED			
80H-85H	200-217	RESERVED FOR BASIC			
86H-F0H	218-3C3	Used by BASIC			
F1H-FFH	3C4-3FF	NOT USED			

**Compiled From:** IBM PC/XT Technical Reference, Section 2 (see BIOS listings or page 2-4 of old XT manual for summary)  
 IBM PC/AT Technical Reference, Section 5 (see pages 5-5 and 5-6 for summary)  
 IBM DOS 3.3 Technical Reference, Section 6 (see pages 6-13 to 6-33)  
 IBM PS/2 and PC BIOS Technical Reference, Section 2 (see page 2-3 for summary)

**See Also:**

- 4.001: BIOS Services Summary
- 5.01: DOS Interrupt Usage by Version
- 5.08: INT 33H: Mouse Functions Summary
- 5.29: INT 67H: Expanded Memory Manager Functions Summary

## 7.05. PC KEYBOARD KEY NUMBERS AND SCAN CODES

Key Number	Hex Scan Code	Base Case	Uppercase	With Ctrl	With Alt
1	01	Esc	Esc	Esc	Suppressed
2	02	1	!	Suppressed	Extended
3	03	2	@	Nul	Extended
4	04	3	#	Suppressed	Extended
5	05	4	\$	Suppressed	Extended
6	06	5	%	Suppressed	Extended
7	07	6	^	RS (30)	Extended
8	08	7	&	Suppressed	Extended
9	09	8	*	Suppressed	Extended
10	0A	9	(	Suppressed	Extended
11	0B	0	)	Suppressed	Extended
12	0C	-	_	US (31)	Extended
13	0D	=	+	Suppressed	Extended
14	0E	Backspace	Backspace	Del (127)	Suppressed
15	0F	Tab	Extended	Suppressed	Suppressed
16	10	q	Q	DC1 (17)	Extended
17	11	w	W	ETB (23)	Extended
18	12	e	E	ENQ (5)	Extended
19	13	r	R	DC2 (18)	Extended
20	14	t	T	DC4 (20)	Extended
21	15	y	Y	EM (25)	Extended
22	16	u	U	NAK (21)	Extended
23	17	i	I	HT (9)	Extended
24	18	o	O	SI (15)	Extended
25	19	p	P	DLE (16)	Extended
26	1A	[	{	Esc (27)	Suppressed
27	1B	]	}	GS (29)	Suppressed
28	1C	Enter	Enter	LF (10)	Suppressed
29	1D	Ctrl	Suppressed	Suppressed	Suppressed
30	1E	a	A	SOH (1)	Extended
31	1F	s	S	DC3 (19)	Extended
32	20	d	D	EOT (4)	Extended
33	21	f	F	ACK (6)	Extended
34	22	g	G	BEL (7)	Extended
35	23	h	H	BS (8)	Extended
36	24	j	J	LF (10)	Extended
37	25	k	K	VT (11)	Extended
38	26	l	L	FF (12)	Extended
39	27	;	:	Suppressed	Suppressed
40	28	'	"	Suppressed	Suppressed
41	29	~	~	Suppressed	Suppressed
42	2A	Left Shift	Suppressed	Suppressed	Suppressed
43	2B	\		FS (28)	Suppressed
44	2C	z	Z	SUB (26)	Extended
45	2D	x	X	CAN (24)	Extended
46	2E	c	C	ETX (3)	Extended
47	2F	v	V	SYN (22)	Extended
48	30	b	B	STX (2)	Extended
49	31	n	N	SO (14)	Extended
50	32	m	M	CR (13)	Extended
51	33	.	<	Suppressed	Suppressed
52	34	,	>	Suppressed	Suppressed
53	35	/	?	Suppressed	Suppressed
54	36	Right Shift	Suppressed	Suppressed	Suppressed
55	37	*	Print Screen	Extended	Suppressed
56	38	Alt	Suppressed	Suppressed	Suppressed
57	39	Spacebar	Spacebar	Spacebar	Spacebar
58	3A	Caps Lock	Suppressed	Suppressed	Suppressed
59	3B	F1	Extended	Extended	Extended
60	3C	F2	Extended	Extended	Extended
61	3D	F3	Extended	Extended	Extended
62	3E	F4	Extended	Extended	Extended
63	3F	F5	Extended	Extended	Extended
64	40	F6	Extended	Extended	Extended
65	41	F7	Extended	Extended	Extended
66	42	F8	Extended	Extended	Extended
67	43	F9	Extended	Extended	Extended
68	44	F10	Extended	Extended	Extended
69	45	Num Lock	Suppressed	Pause	Suppressed

(Continued)

Table 7.05. Continued

Key Number	Hex Scan Code	Base Case	Uppercase	With Ctrl	With Alt
70	46	Scroll Lock	Suppressed	Break	Suppressed
71	47	Home	NA	Clear Screen	Suppressed
72	48	Up Arrow	NA	Suppressed	Suppressed
73	49	PgUp	NA	Top of Text	Suppressed
74	4A	Numpad -	NA	Suppressed	Suppressed
75	4B	Left Arrow	NA	Extended	Suppressed
76	4C	Numpad 5	NA	Suppressed	Suppressed
77	4D	Right Arrow	NA	Extended	Suppressed
78	4E	Numpad +	NA	Suppressed	Suppressed
79	4F	End	NA	Extended	Suppressed
80	50	Down Arrow	NA	Suppressed	Suppressed
81	51	PgDn	NA	Extended	Suppressed
82	52	Ins	NA	Suppressed	Suppressed
83	53	Del	NA	Reset the system	

**Notes:**

- Extended means first scan code returned is 00, followed by an extended ASCII code
- Suppressed indicates the key combination is not passed by the keyboard routine in BIOS

**Source:** IBM PC/XT Technical Reference, Section: 4

**See Also:** 1.21. ASCII Character Set  
1.23. IBM Extended Character Codes

7.06. AT 84-KEY KEY NUMBERS AND SCAN CODES

Key Number	Hex Scan Code	Base Case	Uppercase
1	29	`	~
2	02	1	!
3	03	2	@
4	04	3	#
5	05	4	\$
6	06	5	%
7	07	6	^
8	08	7	&
9	09	8	*
10	0A	9	(
11	0B	0	)
12	0C	-	
13	0D	=	+
14	2B	\	
15	0E	Backspace	Backspace
16	0F	Tab	Back Tab
17	10	q	Q
18	11	w	W
19	12	e	E
20	13	r	R
21	14	t	T
22	15	y	Y
23	16	u	U
24	17	i	I
25	18	o	O
26	19	p	P
27	1A	[	{
28	1B	]	}
30	1D	Ctrl (suppressed)	(suppressed)
31	1E	a	A
32	1F	s	S
33	20	d	D
34	21	f	F
35	22	g	G
36	23	h	H
37	24	j	J
38	25	k	K
39	26	l	L
40	27	;	:
41	28	'	"
43	1C	Enter	Enter
44	2A	(suppressed)	(suppressed)

(Continued)

Table 7.06. Continued

Key Number	Hex Scan Code	Base Case	Uppercase
46	2C	z	Z
47	2D	x	X
48	2E	c	C
49	2F	v	V
50	30	b	B
51	31	n	N
52	32	m	M
53	33	,	<
54	34	.	>
55	35	/	?
57	36	Right Shift (suppressed)	(suppressed)
58	38	Alt (suppressed)	(suppressed)
61	39	Spacebar	
64	3A	Caps Lock (suppressed)	(suppressed)
65	3C	F2	
66	3E	F4	
67	40	F6	
68	42	F8	
69	44	F10	
70	3B	F1	
71	3D	F3	
72	3F	F5	
73	41	F7	
74	43	F9	
75	E0, 52	Insert	
90	01	Esc	Esc
91	47	Keypad 7	Home
92	4B	Keypad 4	←
93	4F	Keypad 1	End
95	45	Num Lock (suppressed)	(suppressed)
96	48	Keypad 8	↑
97	4C	Keypad 5	(suppressed)
98	50	Keypad 2	↓
99	52	Keypad 0	Ins
100	46	Scroll Lock (suppressed)	(suppressed)
101	49	Keypad 9	Page Up
102	4D	Keypad 6	→
103	51	Keypad 3	Page Down
104	53	Keypad .	Delete
105	54	Sys Req	
106	Not documented	Keypad *	Prt Sc
107	4A	Keypad -	
108	4E	Keypad +	

**Notes:**

- Some key numbers and scan code numbers are missing and reserved by IBM
- Suppressed indicates key combination is not passed by the keyboard routine in BIOS

**Source:** IBM PC/AT Technical Reference, pages 1-44 to 1-46.4, 4-18 to 4-20, 4-33

**See Also:**

- 1.21. ASCII Character Set
- 1.23. IBM Extended Character Codes
- 7.05. PC Keyboard Key Numbers and Scan Codes
- 7.07. AT 101/102-key Key Numbers and Scan Codes

## 7.07. AT 101/102-KEY KEY NUMBERS AND SCAN CODES

Key Number	Hex Scan Code	Base Case	Uppercase
1	29		~
2	02	1	!
3	03	2	@
4	04	3	#
5	05	4	\$
6	06	5	%
7	07	6	^
8	08	7	&
9	09	8	*
10	0A	9	(
11	0B	0	)
12	0C	-	_
13	0D	=	+
15	0E	Backspace	Backspace
16	0F	Tab	Back Tab
17	10	q	Q
18	11	w	W
19	12	e	E
20	13	r	R
21	14	t	T
22	15	y	Y
23	16	u	U
24	17	i	I
25	18	o	O
26	19	p	P
27	1A	[	{
28	1B	]	}
29	2B	\	
30	3A	Caps Lock (suppressed)	(suppressed)
31	1E	a	A
32	1F	s	S
33	20	d	D
34	21	f	F
35	22	g	G
36	23	h	H
37	24	j	J
38	25	k	K
39	26	l	L
40	27	;	:
41	28	'	"
42*	2B	#	~
43	1C	Enter	Enter
44	2A	Left Shift (suppressed)	(suppressed)
45*	D5	\	
46	2C	z	Z
47	2D	x	X
48	2E	c	C
49	2F	v	V
50	30	b	B
51	31	n	N
52	32	m	M
53	33	,	<
54	34	.	>
55	35	/	?
57	36	Right Shift (suppressed)	(suppressed)
58	1D	Left Ctrl (suppressed)	(suppressed)
60	38	Left Alt (suppressed)	(suppressed)
61	39	Spacebar	
62	E0,38	Right Alt (suppressed)	(suppressed)
64	E0,1D	Right Ctrl (suppressed)	(suppressed)
75	E0,52	Insert	
76	E0,53	Delete	

\*(Continued)

Table 7.07. Continued

Key Number	Hex Scan Code	Base Case	Uppercase
79	E0,4B	Left Arrow	
80	E0,47	Home	
81	E0,4F	End	
83	E0,48	Up Arrow	
84	E0,50	Down Arrow	
85	E0,49	PgUp	
86	E0,51	PgDn	
89	E0,4D	Right Arrow	
90	45,C5	NumLock (suppressed)	(suppressed)
91	47	Keypad 7	Home
92	4B	Keypad 4	Left Arrow
93	4F	Keypad 1	End
95	E0,35	Keypad /	Keypad/
96	48	Keypad 8	Up Arrow
97	4C	Keypad 5	
98	50	Keypad 2	Down Arrow
99	52	Keypad 0	Ins
100	E0,37	Keypad *	Keypad *
101	49	Keypad 9	Page Up
102	4D	Keypad 6	Right Arrow
103	51	Keypad 3	Page Down
104	53	Keypad .	Delete
105	4A	Keypad -	Keypad -
106	4E	Keypad +	Keypad +
108	E0,1C	Keypad Enter	Keypad Enter
110	01	Esc	Esc
112	3B	F1	
113	3C	F2	
114	3D	F3	
115	3E	F4	
116	3F	F5	
117	40	F6	
118	41	F7	
119	42	F8	
120	43	F9	
121	44	F10	
122	D9	F11	
123	DA	F12	
124	2A,37	Print Screen	
125	46	Scroll Lock	
126	1D,E0,45,E0,C5,9D	Pause Break	

**Notes:**

- Some key numbers and scan code numbers are missing and reserved by IBM
- Suppressed indicates key combination is not passed by the keyboard routine in BIOS
- \*Only applicable to non-U.S. keyboards

**Source:** IBM PC/AT Technical Reference, pages 1-45 to 1-46.4, 4-65 to 4-68

**See Also:**

- 1.21. ASCII Character Set
- 1.22. IBM ASCII Character Set
- 7.05. PC Keyboard Key Numbers and Scan Codes
- 7.06. AT 84-key Key Numbers and Scan Codes
- 7.08. PS/2 Key Numbers and Scan Codes

7.08. PS/2 KEY NUMBERS AND SCAN CODES

Key Number	Set 1 Make/Break	Set 2 Make/Break	Set 3 Make/Break	Base Case	Uppercase
1	29 / A9	0E / F0 0E	0E / F0 0E	`	~
2	02 / 82	16 / F0 16	16 / F0 16	1	!
3	03 / 83	1E / F0 1E	1E / F0 1E	2	@
4	04 / 84	26 / F0 26	26 / F0 26	3	#
5	05 / 85	25 / F0 25	25 / F0 25	4	\$
6	06 / 86	2E / F0 2E	2E / F0 2E	5	%
7	07 / 87	36 / F0 36	36 / F0 36	6	^
8	08 / 88	3D / F0 3D	3D / F0 3D	7	&
9	09 / 89	3E / F0 3E	3E / F0 3E	8	*
10	0A / 8A	46 / F0 46	46 / F0 46	9	(
11	0B / 8B	45 / F0 45	45 / F0 45	0	)
12	0C / 8C	4E / F0 4E	4E / F0 4E	-	_
13	0D / 8D	55 / F0 55	55 / F0 55	=	+
15	0E / 8E	66 / F0 66	66 / F0 66	Backspace	
16	0F / 8F	0D / F0 0D	0D / F0 0D	Tab	
17	10 / 90	15 / F0 15	15 / F0 15	q	Q
18	11 / 91	1D / F0 1D	1D / F0 1D	w	W
19	12 / 92	24 / F0 24	24 / F0 24	e	E
20	13 / 93	2D / F0 2D	2D / F0 2D	r	R
21	14 / 94	2C / F0 2C	2C / F0 2C	t	T
22	15 / 95	35 / F0 35	35 / F0 35	y	Y
23	16 / 96	3C / F0 3C	3C / F0 3C	u	U
24	17 / 97	43 / F0 43	43 / F0 43	i	I
25	18 / 98	44 / F0 44	44 / F0 44	o	O
26	19 / 99	4D / F0 4D	4D / F0 4D	p	P
27	1A / 9A	54 / F0 54	54 / F0 54	[	{
28	1B / 9B	5B / F0 5B	5B / F0 5B	]	}
30	3A / BA	58 / F0 58	14 / F0 14	Caps Lock	
31	1E / 9E	1C / F0 1C	1C / F0 1C	a	A
32	1F / 9F	1B / F0 1B	1B / F0 1B	s	S
33	20 / A0	23 / F0 23	23 / F0 23	d	D
34	21 / A1	2B / F0 2B	2B / F0 2B	f	F
35	22 / A2	34 / F0 34	34 / F0 34	g	G
36	23 / A3	33 / F0 33	33 / F0 33	h	H
37	24 / A4	3B / F0 3B	3B / F0 3B	j	J
38	25 / A5	42 / F0 42	42 / F0 42	k	K
39	26 / A6	4B / F0 4B	4B / F0 4B	l	L
40	27 / A7	4C / F0 4C	4C / F0 4C	;	:
41	28 / A8	52 / F0 52	52 / F0 52	'	"
43	1C / 9C	5A / F0 5A	5A / F0 5A	Enter	Enter
44	2A / AA	12 / F0 12	12 / F0 12	Left Shift	
46	2C / AC	1A / F0 1A	1A / F0 1A	z	Z
47	2D / AD	22 / F0 22	22 / F0 22	x	X
48	2E / AE	21 / F0 21	21 / F0 21	c	C
49	2F / AF	2A / F0 2A	2A / F0 2A	v	V
50	30 / B0	32 / F0 32	32 / F0 32	b	B
51	31 / B1	31 / F0 31	31 / F0 31	n	N
52	32 / B2	3A / F0 3A	3A / F0 3A	m	M
53	33 / B3	41 / F0 41	41 / F0 41	.	<
54	34 / B4	49 / F0 49	49 / F0 49	.	>
55	35 / B5	4A / F0 4A	4A / F0 4A	/	?
57	36 / B6	59 / F0 59	59 / F0 59	Right Shift	
58	1D / 9D	14 / F0 14	11 / F0 11	Left Ctrl	
60	38 / B8	11 / F0 11	19 / F0 19	Left Alt	
61	39 / B9	29 / F0 29	29 / F0 29	Spacebar	
62	E0 38 / E0 B8	E0 11 / E0 F0 11	39 / F0 39	Right Alt	
64	E0 1D / E0 9D	E0 14 / E0 F0 14	58 / F0 58	Right Ctrl	
75	E0 52 / E0 D2 (base)	E0 70 / E0 F0 70 (base)	67 / F0 67	Insert	
76	E0 53 / E0 D3 (base)	E0 71 / E0 F0 71 (base)	64 / F0 64	Delete	
79	E0 4B / E0 CB (base)	E0 6B / E0 F0 6B (base)	61 / F0 61	Left Arrow	
80	E0 47 / E0 C7 (base)	E0 6C / E0 F0 6C (base)	6E / F0 6E	Home	
81	E0 4F / E0 CF (base)	E0 69 / E0 F0 69 (base)	65 / F0 65	End	
83	E0 48 / E0 C8 (base)	E0 75 / E0 F0 75 (base)	63 / F0 63	Up Arrow	
84	E0 50 / E0 D0 (base)	E0 72 / E0 F0 72 (base)	60 / F0 60	Down Arrow	
85	E0 49 / E0 C9 (base)	E0 7D / E0 F0 7D (base)	6F / F0 6F	PgUp	
86	E0 51 / E0 D1 (base)	E0 7A / E0 F0 7A (base)	6D / F0 6D	PgDn	
89	E0 4D / E0 CD (base)	E0 74 / E0 F0 74 (base)	6A / F0 6A	Right Arrow	
90	45 / C5	77 / F0 77	76 / F0 76	NumLock	
91	47 / C7	6C / F0 6C	6C / F0 6C	Keypad 7	

(Continued)

Table 7.08. Continued

Key Number	Set 1 Make/Break	Set 2 Make/Break	Set 3 Make/Break	Base Case	Uppercase
92	4B / CB	6B / F0 6B	6B / F0 6B	Keypad 4	
93	4F / CF	69 / F0 69	69 / F0 69	Keypad 1	
95	E0 35 / E0 B5 (base)	E0 4A / E0 F0 4A (base)	77 / F0 77	Keypad /	
96	48 / C8	75 / F0 75	75 / F0 75	Keypad 8	
97	4C / CC	73 / F0 73	73 / F0 73	Keypad 5	
98	50 / D0	72 / F0 72	72 / F0 72	Keypad 2	
99	52 / D2	70 / F0 70	70 / F0 70	Keypad 0	
100	37 / B7	7C / F0 7C	7E / F0 7E	Keypad *	
101	49 / C9	7D / F0 7D	7D / F0 7D	Keypad 9	
102	4D / CD	74 / F0 74	74 / F0 74	Keypad 6	
103	51 / D1	7A / F0 7A	7A / F0 7A	Keypad 3	
104	53 / D3	71 / F0 71	71 / F0 71	Keypad .	
105	4A / CA	7B / F0 7B	84 / F0 84	Keypad -	
106	4E / CE	79 / F0 79	7C / F0 7C	Keypad +	
108	E0 1C / E0 9C	E0 5A / E0 F0 5A	79 / F0 79	Keypad Enter	
110	01 / B1	76 / F0 76	08 / F0 08	Esc	
112	3B / BB	05 / F0 05	07 / F0 07	F1	
113	3C / BC	06 / F0 06	0F / F0 0F	F2	
114	3D / BD	04 / F0 04	17 / F0 17	F3	
115	3E / BE	0C / F0 0C	1F / F0 1F	F4	
116	3F / BF	03 / F0 03	27 / F0 27	F5	
117	40 / C0	0B / F0 0B	2F / F0 2F	F6	
118	41 / C1	83 / F0 83	37 / F0 37	F7	
119	42 / C2	0A / F0 0A	3F / F0 3F	F8	
120	43 / C3	01 / F0 01	47 / F0 47	F9	
121	44 / C4	09 / F0 09	4F / F0 4F	F10	
122	57 / D7	78 / F0 78	56 / F0 56	F11	
123	58 / D8	07 / F0 07	5E / F0 5E	F12	
124	E0 2A E0 37 / E0 B7 E0 AA	E0 12 E0 7C / E0 F0 7C E0 F0 12	57 / F0 57	Print Screen	
125	46 / C6	7E / F0 7E	5F / F0 5F	Scroll Lock	
126	E1 1D 45 / E1 9D C5	E1 14 77 E1 / F0 14 F0 77	62 / F0 62	Pause Break	
29 or 42*	2B / AB	5D / F0 5D	5C / F0 5C or 53 / F0 53	\	

**Notes:**

- \*42 is only applicable to non-U.S. keyboards
- Some key numbers and scan code numbers are missing and reserved by IBM
- In set 1, shift case adds an E0 AA preceding the make code, and an E0 2A following the break code (for applicable keys only)
- In set 1, num lock case adds an E0 2A preceding the make code, and an E0 AA following the break code (for applicable keys only)
- In set 2, shift case adds an E0 F0 12 preceding the make code, and an E0 12 following the break code (for applicable keys only)
- In set 2, num lock case adds an E0 12 preceding the make code, and an E0 F0 12 following the break code (for applicable keys only)
- Set 2 is the default set

**Source:**

IBM PS/2 Model 50 and 60 Technical Reference, pages 6-30 to 6-39

**See Also:**

- 1.21. ASCII Character Set
- 1.23. IBM Extended Character Codes
- 7.05. PC Keyboard Key Numbers and Scan Codes
- 7.06. AT 84-key Key Numbers and Scan Codes
- 7.07. AT 101/102-key Key Numbers and Scan Codes

**7.09. PC & XT TYPEAHEAD BUFFER LAYOUT**

Offset	Length	Name	Description
0 (0)	word	Buffer_Head	Points to next character in buffer
2 (2)	word	Buffer_Tail	Points to next blank space in buffer
4 (4)	32 bytes	Buffer_Area	Area used to store keystroke data

**Notes:**

- If Buffer\_Head = Buffer\_Tail, the buffer is empty
- Two bytes are necessary to store each keystroke, since the IBM extended keys (F1-F10, for example) consist of two byte codes. If the first byte for a keystroke is non-zero, then it represents the ASCII key and the second byte will be zero. If the first byte is zero, then it represents an extended key, and the second byte indicates the actual key pressed.
- Two low-memory words store the location of the buffer start (at 0040:0080) and one byte past its end (at 0040:0082)
- On a standard PC, the keyboard buffer is usually located at 0040:001A

**Source:** IBM PC/XT Technical Reference, BIOS Listing, page A-3 (original manuals only)  
 IBM PS/2 and PC BIOS Interface Technical Reference, Page 3-5

**See Also:** 4.002. BIOS Memory Usage Summary

**7.10. AT KEYBOARD STATUS REGISTER**

*Bit Numbers*

7	6	5	4	3	2	1	0	Name	Allowable Values
X								Parity error	0=odd parity (no error), 1=even parity
	X							Receive time out	0=no error, 1=keyboard did not finish
		X						Transmit time out	0=no error, 1=keyboard did not finish
			X					Inhibit switch	0=keyboard inhibited, 1=not inhibited
				X				Command/data	0=addressed as port 60H, 1=port 64H
					X			System flag	0=reset by power ON, 1=self test OK
						X		Input buffer full	0=empty, 1=full
							X	Output buffer full	0=empty, 1=full

**Notes:** The status register is at I/O address 64H

**Source:** IBM PC/AT Technical Reference, pages 1-49 to 1-50

**See Also:** 7.11. AT Keyboard I/O Command Summary  
 7.12. AT Keyboard Input Port Bit Definitions  
 7.13. AT Keyboard Output Port Bit Definitions

7.11. AT KEYBOARD I/O COMMAND SUMMARY

Command Value	Command Name	Comments	Bit Numbers										
			7	6	5	4	3	2	1	0			
20H	Read keyboard controller												
60H	Write keyboard controller	Writes command byte -- see bitmap at right RESERVED--always 0 IBM PC compatibility mode IBM PC mode Disable keyboard Inhibit override System flag RESERVED--always 0 Enable output-buffer-full interrupt	0	X									
AAH	Self test	55H placed in output buffer if successful											
ABH	Interface test	Returns code in output buffer as follows: No error detected Keyboard clock line is stuck low Keyboard clock line is stuck high Keyboard data line is stuck low Keyboard data line is stuck high	0	0	0	0	0	0	0	0	0	0	0
ACH	Diagnostic dump	Sends 16 bytes of controller's RAM											
ADH	Disable keyboard feature	Sets bit 4 of controller's command byte											
AEH	Enable keyboard interface	Clears bit 4 of controller's command byte											
COH	Read input port	Reads input port, data put in output buffer											
DOH	Read output port	Reads output port, data put in output buffer											
D1H	Write output port	Next byte placed in controller's output port											
E0H	Read test inputs	T0 and T1 inputs placed in output buffer											
F0-FFH	Pulse output port	Bits 0-3 of command determine bits to pulse											

Source: IBM PC/AT Technical Reference, pages 1-51 to 1-54

7.12. AT KEYBOARD INPUT PORT BIT DEFINITIONS

Bit Numbers								Function	Allowable Values
7	6	5	4	3	2	1	0		
X								Keyboard inhibit switch	0=inhibited, 1=not inhibited
	X							Display switch	0=CGA, 1=MDA
		X						Manufacturing jumper status	0=jumper installed, 1=not installed
			X					System RAM	0=512K, 1=256K
				X	X	X	X	RESERVED	

Source: IBM PC/AT Technical Reference, page 1-55

See Also: 7.11. AT Keyboard I/O Command Summary

7.13. AT KEYBOARD OUTPUT PORT BIT DEFINITIONS

Bit Numbers								Function	Allowable Values
7	6	5	4	3	2	1	0		
X								Keyboard data output	
	X							Keyboard clock output	
		X						Input buffer empty	0=buffer full, 1=buffer empty
			X					Output buffer full	0=buffer empty, 1=buffer full
				X	X			RESERVED	
						X		Gate A20	
							X	System reset	

Source: IBM PC/AT Technical Reference, page 1-55

See Also: 7.11. AT Keyboard I/O Command Summary

7.14. AT KEYBOARD TYPEMATIC RATE DEFINITIONS

Bit Numbers

7	6	5	4	3	2	1	0	Typematic Rate ( $\pm 20\%$ )
0	*	*	0	0	0	0	0	30.0
0	*	*	0	0	0	0	1	26.7
0	*	*	0	0	0	1	0	24.0
0	*	*	0	0	0	1	1	21.8
0	*	*	0	0	1	0	0	20.0
0	*	*	0	0	1	0	1	18.5
0	*	*	0	0	1	1	0	17.1
0	*	*	0	0	1	1	1	16.0
0	*	*	0	1	0	0	0	15.0
0	*	*	0	1	0	0	1	13.3
0	*	*	0	1	0	1	0	12.0
0	*	*	0	1	0	1	1	10.9
0	*	*	0	1	1	0	0	10.0
0	*	*	0	1	1	0	1	9.2
0	*	*	0	1	1	1	0	8.0
0	*	*	0	1	1	1	1	8.0
0	*	*	1	0	0	0	0	7.5
0	*	*	1	0	0	0	1	6.7
0	*	*	1	0	0	1	0	6.0
0	*	*	1	0	0	1	1	5.5
0	*	*	1	0	1	0	0	5.0
0	*	*	1	0	1	0	1	4.6
0	*	*	1	0	1	1	0	4.3
0	*	*	1	0	1	1	1	4.0
0	*	*	1	1	0	0	0	3.7
0	*	*	1	1	0	0	1	3.3
0	*	*	1	1	0	1	0	3.0
0	*	*	1	1	0	1	1	2.7
0	*	*	1	1	1	0	0	2.5
0	*	*	1	1	1	0	1	2.3
0	*	*	1	1	1	1	0	2.1
0	*	*	1	1	1	1	1	2.0

**Notes:** \*Used to set delay (1 plus binary value \* 250 milliseconds)

**Source:** IBM PC/AT Technical Reference, pages 4-10, 4-45

**See Also:** 7.11. AT Keyboard I/O Command Summary

**7.15. VIDEO ADAPTER MEMORY USAGE AND OUTPUT SPECIFICATIONS**

		MDA	CGA	EGA	VGA
<i>Memory Use</i>	<i>Buffer Address</i>	B0000	B8000	*	*
	<i>Buffer Size</i>	4 K	16 K	64 K - 256 K	256 K
	<i>Pages in Buffer</i>	1	4 to 8	Max of 8	Max of 8
	<i>I/O Ports Used</i>	3B0-3BF	3D0-3DF	3B0-3DF	3B0-3DF
<i>Output</i>	<i>Bandwidth</i>	16.257 MHz**	14.30 MHz	14.3 to 16.3 MHz	28 MHz
	<i>Horiz. Sweep Rate</i>	18.432 KHz**	15.75 KHz	15.7 to 21.8 KHz	31.5 KHz
	<i>Vert. Sweep Rate</i>	50 Hz**	60 Hz	60 Hz	50 to 70 Hz
	<i>Max. Horiz. Pixels</i>	720	640	*	720
	<i>Max. Vert. Pixels</i>	350	200	350	480
	<i>Character Box Size</i>	9x14	8x8	9x14 or 8x8	9x16
	<i>Actual Character Size</i>	7x9	7x7 or 5x7	7x9 or 7x7	7x9
	<i>System</i>	<i>Accesses CPU</i>	When not refreshing	Anytime	Anytime
	<i>Data Transfer Rate</i>	1.8 M/sec	1.5 M/sec	?	?
<i>Features</i>	<i>Light Pen</i>	NO	YES	YES	NO
	<i>Composite Out</i>	NO	YES	NO	NO
	<i>Digital RGB Out</i>	NO	YES	YES	NO
	<i>Analog RGB Out</i>	NO	NO	NO	YES
	<i>Direct Video Out</i>	YES	YES	YES	NO
	<i>Color Palette</i>	NONE	16 colors	64 colors	256 K colors
	<i>Feature Connector</i>	NO	NO	YES	NO
	<i>Modulator Connector</i>	NO	YES	NO	NO

**Notes:** \*B0000 for 32 K, or B8000 for 32 K, or A0000 for 64 K, or A0000 for 128 K. Also for the EGA, a 16 K BIOS EGA extension module is mapped to processor address C0000.  
 \*\*When used with IBM Monochrome Display

**Source:** IBM Technical Reference Options and Adapters  
 IBM PS/2 Model 50 and 60 Technical Reference

**See Also:** 7.19. MDA Memory Map  
 7.22. MDA I/O Port Usage  
 7.23. CGA Memory Map  
 7.26. CGA I/O Port Usage  
 7.27. EGA Memory Map  
 7.30. EGA I/O Port Usage  
 7.31. VGA Memory Map  
 7.34. VGA I/O Port Usage

**7.16. VIDEO MODES SUMMARY**

<i>BIOS Mode Details</i>						<i>Adapter Support</i>				
Mode #	Type	Rows	Cols	Resolution	Colors	MDA	CGA	EGA	MCGA	VGA
0	Char	25	40	320x200	16		X	X	X	X
1	Char	25	40	320x200	16		X	X	X	X
2	Char	25	80	640x200	16		X	X	X	X
3	Char	25	80	640x200	16		X	X	X	X
4	Graph	25	40	320x200	4		X	X	X	X
5	Graph	25	40	320x300	4		X	X	X	X
6	Graph	25	80	640x200	2		X	X	X	X
7	Char	25	80	720x350*	Mono	X		X		X
13	Graph	25	40	320x200	16			X		X
14	Graph	25	80	640x200	16			X		X
15	Graph	25	80	640x350	Mono			X		X
16	Graph	25	80	640x350	16			X		X
17	Graph	30	80	640x480	2				X	X
18	Graph	30	80	640x480	16					X
19	Graph	25	40	320x200	256				X	X

**Notes:** •EGA figures assume it has a full 256K of RAM  
 •Modes 8-12 are used by PCjr only  
 \*\*720x400 on VGA

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 2-11, 2-12, 4-27

**7.17. VIDEO CHARACTER FONT SIZES**

BIOS Mode				Char Box Size				
Mode #	Rows	Cols	Colors	MDA	CGA	EGA	MCGA	VGA
0	25	40	16		8x8	8x14	8x16	9x16
1	25	40	16		8x8	8x14	8x16	9x16
2	25	80	16		8x8	8x14	3x16	9x16
3	25	80	16		8x8	8x14	8x16	9x16
7	25	80	Mono	9x14		9x14		9x16

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 2-11, 2-12, 4-27


**See Also:** 7.20. MDA Character Box  
7.24. CGA Character Box  
7.28. EGA Character Box  
7.32. VGA Character Box

**7.18. VIDEO MONITOR USE SUMMARY**

	MDA	CGA	EGA	MCGA	VGA
Can Use B/W TV	NO	MARGINAL	NO	NO	NO
Can Use B/W Composite Monitor	NO	YES	NO	NO	NO
Can Use IBM Monochrome Monitor	OPTIMUM	NO	YES	NO	NO
Can Use Color TV	NO	MARGINAL	NO	NO	NO
Can Use Composite Color Monitor	NO	MARGINAL	NO	NO	NO
Can Use Digital RGB Monitor	NO	OPTIMUM	OPTIMUM	NO	NO
Can Use Analog RGB Monitor	NO	NO	NO	OPTIMUM	OPTIMUM

**Notes:** Optimum indicates monitor for which display adapter was designed

**7.19. MDA MEMORY MAP**



**Notes:** •MDA may only be used in video mode 7 (See 7.16. Video Modes Summary)  
•Additional "pages" follow sequentially in memory

**Source:** IBM Technical Reference Options and Adapters Volume 2, page Monochrome Adapter 6

**See Also:** 7.15. Video Adapter Memory Usage and Output Specifications  
7.21. MDA Character Attributes



**7.22. MDA I/O PORT USAGE**


Port	Function	Comment
3B0H	NOT USED	
3B1H	NOT USED	
3B2H	NOT USED	
3B3H	NOT USED	
3B4H	6845 Index register	
3B5H	6845 Data register	
3B6H	NOT USED	
3B7H	NOT USED	
3B8H	CRT Control Port 1	Bit 0 = +high resolution mode Bit 1 = NOT USED Bit 2 = NOT USED Bit 3 = +video enable Bit 4=NOT USED Bit 5 = +enable blink Bit 6 = NOT USED Bit 7 = NOT USED
3B9H	RESERVED	
3BAH	CRT Status Port	Bit 0 = +horizontal drive Bit 1 = RESERVED Bit 2 = RESERVED Bit 3 = +black/white video
3BBH	RESERVED	
3BCH	Parallel data port	See 7.46. Printer Adapter I/O Port Usage
3BDH	Parallel status port	See 7.46. Printer Adapter I/O Port Usage
3BEH	Parallel control port	See 7.46. Printer Adapter I/O Port Usage
3BFH	NOT USED	

**Source:** IBM Technical Reference Options and Adapters  
Volume 2, pages Monochrome 7 and 8

**See Also:** 7.26. CGA I/O Port Usage  
7.30. EGA I/O Port Usage  
7.46. Printer Adapter I/O Port Usage

**7.23. CGA MEMORY MAP**


**For Alphanumeric Text Display (modes 0-3):**



(Continued)

Table 7.23. Continued


**For Medium Resolution Graphics Display (320x200 all points addressable, modes 4 and 5):**



(Continued)

Table 7.23. Continued

**For High Resolution Graphics Display (640x200 all points addressable, mode 6):**



**Notes:** •\*Up to eight consecutive pages in modes 0 and 1, four consecutive pages in modes 2 and 3

•\*\*In other words, the highest numbered pixel goes into the lowest bit (or bits), the lowest numbered pixel goes into the highest bit (or bits). For example:

-The first byte in medium resolution

bit number	7	6	5	4	3	2	1	0
pixel number	1		2		3		4	

-The first byte in high resolution:

bit number	7	6	5	4	3	2	1	0
pixel number	1	2	3	4	5	6	7	8

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Color Monitor Adapter 9 to 13

**See Also:** 7.15. Video Adapter Memory Usage and Output Specifications  
7.25. CGA Character Attributes

**7.24. CGA CHARACTER BOX**

		X	X	X			
	X	X		X	X		
X	X				X	X	
X	X	X	X	X	X	X	X
X	X				X	X	
X	X				X	X	
*	*	*	*	*	*	*	*

Character is a 7x7 pel area in an 8x8 pel box

X = pels set for a typical character "A"  
 \* = pels set for default cursor

**Notes:** •Pel is short for pixel element  
 •Optionally, if jumper P3 inserted, character is 5x7 bit area in 8x8 box

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Color Graphics Adapter 5 to 8

**See Also:** 7.17. Video Character Font Sizes

**7.25. CGA CHARACTER ATTRIBUTES**

*Bit Number*

7	6	5	4	3	2	1	0	Function	Allowable Values
X								Blink	0=no blink, 1=blink
	X	X	X					Background	000=black 001=blue 010=green 011=cyan 100=red 101=magenta 110=brown 111=white
			X					Intensity	0=normal, 1=high intensity
					X	X	X	Foreground	000=black      gray with intensity on 001=blue      light blue with intensity on 010=green      light green with intensity on 011=cyan      light cyan with intensity on 100=red      light red with intensity on 101=magenta      light magenta with intensity on 110=brown      yellow with intensity on 111=white      bright white with intensity on

**Notes:** •Invisible characters are created by placing character on same colored background (e.g., white on white)

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Color/Graphics 6 to 8

**See Also:** 7.21. MDA Character Attributes  
 7.29. EGA Character Attributes  
 7.33. VGA Character Attributes

7.26. CGA I/O PORT USAGE


Port	Function	Bit Numbers										Allowable Values	
		7	6	5	4	3	2	1	0				
3D0	RESERVED												
3D1	RESERVED												
3D2	RESERVED												
3D3	RESERVED												
3D4	6845 index register												See 8.12. 6845 Registers
3D5	6845 data register												See 8.12. 6845 Registers
3D6	RESERVED												
3D7	RESERVED												
3D8	Mode control register (D0)	X	X										NOT USED 0=blink disabled, 1=blink enabled 1=640x200 graphics mode 0=video signal disabled, 1=video signal enabled 0=video signal enabled, 1=monochrome (black and white) signal 0=text mode, 1=320x200 graphics mode 0=40x25 text mode, 1=80x25 text mode
3D9	Color select register (D0)	X	X										NOT USED Active color set: 0=red/green/brown, 1=cyan/magenta/white Intense colors in graphics, background colors in text mode Intense border in 40x25 text, intense background in 320x200 graphics, intense foreground in 640x200 graphics Red border in 40x25 text, red background in 320x200 graphics, red foreground in 640x200 graphics Green border in 40x25 text, green background in 320x200 graphics, green foreground in 640x200 graphics Blue border in 40x25 text, blue background in 320x200 graphics, blue foreground in 640x200 graphics
3DA	Status register (D1)	X	X	X	X								NOT USED 0=not in retrace, 1=in vertical retrace mode 0=light pen switch is ON, 1=light pen switch is OFF 0=no trigger, 1=positive-going edge from light pen has set trigger 0=do not use memory, 1=memory may be accessed without interfering with display
3DB	Clear light pen latch												
3DC	Preset light pen latch												
3DD	RESERVED												
3DE	RESERVED												
3DF	RESERVED												

Source: IBM Technical Reference Options and Adapters Volume 2, pages Color/Graphics 15 to 21


See Also: 7.22. MDA I/O Port Usage  
7.30. EGA I/O Port Usage

**7.27. EGA MEMORY MAP**

**For Alphanumeric Text Display (modes 0-3):**




**For Medium Resolution Graphics Display (320x200 all points addressable, modes 4 and 5):**




(Continued)

Table 7.27. Continued

**For High Resolution Graphics Display (640x200 all points addressable, mode 6):**




**For Medium Resolution Graphics Display (340x200 all points addressable, mode 13):**




(Continued)

Table 7.27. Continued

**For High Resolution Graphics Display (640x200 all points addressable, mode 14):**




**For High Resolution Graphics Display (640x350 all points addressable, mode 16):**



(Continued)

Table 7.27. Continued

**For High Resolution Graphics Display (640x350 all points addressable, mode 15):**



- Notes:**
- When in purely EGA modes, memory organization is four planes of either 16K or 64K, and the use and definition of "pages" is up to the programmer
  - Up to eight consecutive pages in modes 0 and 1, four consecutive pages in modes 2 and 3
  - \*\*In other words, the highest numbered pixel goes into the lowest bit (or bits), the lowest numbered pixel goes into the highest bit (or bits). For example:

-The first byte in medium resolution:

bit number	7	6	5	4	3	2	1	0
pixel number	1		2		3		4	

-The first byte in high resolution:

bit number	7	6	5	4	3	2	1	0
pixel number	1	2	3	4	5	6	7	8

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Enhanced Adapter

**See Also:** 7.15. Video Adapter Memory Usage and Output Specifications  
7.29. EGA Character Attributes

**7.28. EGA CHARACTER BOX**

**For modes 7 and 15:**

					X				
			X	X	X				
		X	X		X	X			
	X	X				X	X		
	X	X				X	X		
	X	X	X	X	X	X	X		
	X	X				X	X		
	X	X				X	X		
	.	.	.	.	.	.	.	.	.
	.	.	.	.	.	.	.	.	.

Character is a 7x9 pel area in a 9x14 pel box

X = pels set for a typical character "A"  
 • = pels set for default cursor

**For modes 0-3:**

			X	X	X		
		X	X		X	X	
	X	X				X	X
	X	X				X	X
	X	X	X	X	X	X	X
	X	X				X	X
	X	X				X	X
	.	.	.	.	.	.	.

Character is a 7x7 pel area in an 8x8 pel box

X = pel set for a typical character "A"  
 • = pels set for default cursor

**Notes:** Pel is short for pixel element

**Source:** IBM Technical Reference Options and Adapters Volume 2, page Enhanced Graphics Adapter 1

**See Also:** 7.17. Video Character Font Sizes

**7.29. EGA CHARACTER ATTRIBUTES**

**For Text (modes 0-3):**

7	6	5	4	3	2	1	0	Function	Allowable Values
X								Blink	0=no blink, 1=blink
	X	X	X					Background	000=black 001=blue 010=green 011=cyan 100=red 101=magenta 110=brown 111=white
				X				Intensity	0=normal, 1=high intensity
					X	X	X	Foreground	000=black gray with intensity on 001=blue light blue with intensity on 010=green light green with intensity on 011=cyan light cyan with intensity on 100=red light red with intensity on 101=magenta light magenta with intensity on 110=brown yellow with intensity on 111=white bright white with intensity on

**For Text (mode 7):**

7	6	5	4	3	2	1	0	Function	Allowable Values
X								Blink	0=no blink, 1=blink
	X	X	X					Background	000=black 111=white
				X				Intensity	0=normal, 1=high intensity
					X	X	X	Foreground	000=black gray with intensity on 001=underline 111=white bright white with intensity on

(Continued)

Table 7.29. Continued

**For mode 15:**

Pixel Plane:				Function
3	2	1	0	
0	0	0	0	Black character
0	0	1	1	White character
1	1	0	0	Blinking white character
1	1	1	1	Intense white character

**For modes 13,14, and 16:**

Pixel Plane:				Function
3	2	1	0	
X				Blue pixel component
	X			Green pixel component
		X		Red pixel component
			X	Intensity pixel component

**Notes:** Invisible characters in modes 0-3 and 7 are created by placing character on same colored background (e.g., white on white)

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 4-30 to 4-33

**See Also:** 7.21. MDA Character Attributes  
7.25. CGA Character Attributes  
7.33. VGA Character Attributes


**7.30. EGA I/O PORT USAGE**

Port	Function	Comment
3C0H	ATC index/data register	Write only
3C2H	Input status 0 register	Read only
3C4H	TS index register	Write only
3C5H	TS data register	Write only
3CAH	Graphics 2 position register	Write only
3CCH	Graphics 1 position register	Write only
3CEH	GDC index register	Write only
3CFH	GDC data register	Write only
3B4H	CRTC index register	Write only
3B5H	CRTC data register	Write only
3BAH	Input status 1 register	Read only (feature control register when written to)
3D4H	CRTC index register	Write only
3D5H	CRTC data register	Write only
3DAH	Input stats 1 register	Read only (feature control register when written to)


**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Enhanced Graphics  
IBM PS/2 Model 50 and 60 Technical Reference, pages 4-28 to 4-59

**7.31. VGA MEMORY MAP**

**For Alphanumeric Text Display (modes 0-3):**




**For Medium Resolution Graphics Display (320x200 all points addressable, modes 4 and 5):**




(Continued)

Table 7.31. Continued

**For High Resolution Graphics Display (640x200 all points addressable, mode 6):**




**For Medium Resolution Graphics Display (340x200 all points addressable, mode 13):**




(Continued)

Table 7.31. Continued

**For High Resolution Graphics Display (640x200 all points addressable, mode 14):**




**For High Resolution Graphics Display (640x350 all points addressable, mode 16):**




(Continued)

Table 7.31. Continued


**For High Resolution Graphics Display (640x350 all points addressable, mode 15):**



**For High Resolution Graphics Display (640x480 all points addressable, mode 17):**




**For High Resolution Graphics Display (640x480 all points addressable, mode 18):**



(Continued)

Table 7.31. Continued

**For Medium Resolution Graphics Display (320x200 all points addressable, mode 19):**



**Notes:**

- When in purely EGA modes, memory organization is four planes of either 16K or 64K, and the use and definition of "pages" is up to the programmer
- \*\*Up to eight consecutive pages in modes 0 and 1, four consecutive pages in modes 2 and 3
- \*\*In other words, the highest numbered pixel goes into the lowest bit (or bits), and the lowest numbered pixel goes into the highest bit (or bits). For example:

-The first byte in medium resolution:

bit number	7	6	5	4	3	2	1	0
pixel number	1	2		3		4		

-The first byte in high resolution:


bit number	7	6	5	4	3	2	1	0
pixel number	1	2	3	4	5	6	7	8

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 4-34 to 4-55

**See Also:** 7.15. Video Adapter Memory Usage and Output Specifications  
7.33. VGA Character Attributes

**7.32. VGA CHARACTER BOX**


**For modes 7 and 15:**



Character is a 7x9 pel area in a 9x14 or 9x16 pel box

X = pels set for a typical character "A"  
• = pels set for default cursor

**For modes 0-3:**



Character is a 7x7 pel area in an 8x8 or 8x14 or 9x16 pel box

X = pels set for a typical character "A"  
• = pels set for default cursor

**Notes:** Pel is short for pixel element

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, page 4-27

**See Also:** 7.17. Video Character Font Sizes

**7.33. VGA CHARACTER ATTRIBUTES**

**For Text (modes 0-3):**

7	6	5	4	3	2	1	0	Function	Allowable Values
X								Blink	0=no blink, 1=blink
	X	X	X					Background	000=black 001=blue 010=green 011=cyan 100=red 101=magenta 110=brown 111=white
				X				Intensity	0=normal, 1=high intensity
					X	X	X	Foreground	000=black gray with intensity on 001=blue light blue with intensity on 010=green light green with intensity on 011=cyan light cyan with intensity on 100=red light red with intensity on 101=magenta light magenta with intensity on 110=brown yellow with intensity on 111=white bright white with intensity on

**For Text (mode 7):**

7	6	5	4	3	2	1	0	Function	Allowable Values
X								Blink	0=no blink, 1=blink
	X	X	X					Background	000=black 111=white
				X				Intensity	0=normal, 1=high intensity
					X	X	X	Foreground	000=black gray with intensity on 001=underline 111=white bright white with intensity on

**For modes 15 and 18:**

*Pixel Plane:*

3	2	1	0	Function
0	0	0	0	Black character
0	0	1	1	White character
1	0	0	0	Blinking white character
1	0	1	1	Intense white character

**For modes 13, 14, and 16:**

*Pixel Plane:*

Function
C0 Blue pixel component
C1 Green pixel component
C2 Red pixel component
C3 Intensity pixel component

**Notes:** •Invisible characters in modes 0-3 and 7 are created by placing character on same colored background (e.g., white on white)

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 4-30 to 4-39

**See Also:** 7.21. MDA Character Attributes  
7.25. CGA Character Attributes  
7.29. EGA Character Attributes

## 7.34. VGA I/O PORT USAGE

*I/O Port Used*

<i>Register Name</i>	<i>Register Type</i>	<i>Color</i>	<i>Mono</i>	<i>Ether</i>	<i>R/W</i>
Miscellaneous output	General			3C2H	W
Miscellaneous output	General			3CCH	R
Input status register 0	General			3C2H	R
Input status register 1	General	3BAH	3DAH		R
Feature control register	General	3BAH	3DAH		W
Feature control register	General			3CAH	R
Video subsystem enable	General			3C3H	RW
Address register	Attribute			3C0H	RW
Other attribute register	Attribute			3C0H	W
Other attribute register	Attribute			3C1H	R
Index register	CRT Controller	3B4H	3D4H		RW
Other CRT controller registers	CRT Controller	3B5H	3D5H		RW
Address register	Sequencer			3C4H	RW
Other sequencer register	Sequencer			3C5H	RW
Address register	Graphics			3CEH	RW
Other graphics register	Graphics			3CFH	RW
PEL address write mode	Video DAC			3C8H	RW
PEL address read mode	Video DAC			3C7H	RW
DAC state register	Video DAC			3C7H	R
PEL data register	Video DAC			3C9H	RW
PEL mask register	Video DAC			3C6H	RW

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 4-58 to 4-59

**See Also:** 7.22. MDA I/O Port Usage  
7.26. CGA I/O Port Usage  
7.30. EGA I/O Port Usage

## 7.35. ASYNCHRONOUS ADAPTER I/O PORT USAGE

*I/O Port*

<i>Primary*</i>	<i>Secondary**</i>	<i>Used for</i>	<i>Comments</i>
3F8H	2F8H	TX buffer	If bit 7 of line control register is 0
3F8H	2F8H	RX buffer	If bit 7 of line control register is 0
3F8H	2F8H	Divisor latch LO byte	If bit 7 of line control register is 1
3F9H	2F9H	Divisor latch HO byte	If bit 7 of line control register is 1
3F9H	2F9H	Interrupt enable register	
3FAH	2FAH	Interrupt identification registers	
3FBH	2FBH	Line control register	
3FCH	2FCH	Modem control register	
3FDH	2FDH	Line status register	
3FEH	2FEH	Modem status register	

**Notes:** \*Primary asynchronous adapter is mapped to COM1 by MS-DOS  
\*\*Secondary asynchronous adapter is mapped to COM2 by MS-DOS

**Source:** IBM Technical Reference Options and Adapters Volume 2, page Async 3

**See Also:** 7.36. Line Control Register  
7.37. Divisor Latch Register  
7.38. Line Status Register  
7.39. Interrupt Identification Register  
7.40. Interrupt Enable Register  
7.41. Modem Control Register  
7.42. Modem Status Register

**7.36. LINE CONTROL REGISTER**

Bit Number								Function	State on Reset	Allowable Values
7	6	5	4	3	2	1	0			
X								Divisor latch access bit	0	1=access baud rate divisor latch
	X							Set break control	0	0=disabled, 1=enabled
		X						Stick parity	0	
			X					Even parity select	0	0=odd parity, 1=even parity
				X				Parity enable	0	0=disabled, 1=enabled
					X			Stop bits	0	0=1 stop bit, 1=1.5 (if bits 0/1=00) or 2
						X	X	Word length	00	00=5 bits 01=6 bits 10=7 bits 11=8 bits

**Notes:** Bits 4 and 5 affect parity only if bit 3 is enabled

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Async 5 to 7

**See Also:** 7.35. Asynchronous Adapter I/O Port Usage

**7.37. DIVISOR LATCH REGISTER**

Bit Number HO byte (3F9H)								Bit Number LO byte (3F8H)								Hex Value	Baud Rate Selected	Comments
7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0			
				X			X									900	50	
					X	X										600	75	
					X					X		X	X	X		417	110	.026 percent error
						X	X		X	X	X			X		359	134.5	.058 percent error
						X	X									300	150	
							X	X								180	300	
								X	X							C0	600	
									X	X						60	1200	
										X						40	1800	
										X	X	X		X		3A	2000	.69 percent error
										X	X					30	2400	
											X					20	3600	
											X	X				18	4800	
												X				10	7200	
												X	X			C	9600	

**Notes:** Assume a baud-rate generator with a frequency of 1.8432 MHz

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Async 7 to 9

**See Also:** 7.35. Asynchronous Adapter I/O Port Usage

**7.38. LINE STATUS REGISTER**

Bit Number								Function	State on Reset	Allowable Values
7	6	5	4	3	2	1	0			
X								Always zero	0	No function
	X							Trans-shift-register empty	1	0=data transfer; 1=transmitter idle
		X						Trans-hold-register empty	1	0=ready; 1=transferring character
			X					Break interrupt indicator	0	0=normal receive; 1=break received
				X				Framing error indicator	0	0=normal receive; 1=framing error
					X			Parity error indicator	0	0=normal receive; 1=parity error
						X		Overrun error indicator	0	0=normal receive; 1=overrun error
							X	Receiver data ready	0	0=no data received; 1=data received

**Notes:** Bit 6 is read only

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Async 10 to 11

**See Also:** 7.35. Asynchronous Adapter I/O Port Usage

**7.39. INTERRUPT IDENTIFICATION REGISTER**

Bit Number								Function	State on Reset	Allowable Values
7	6	5	4	3	2	1	0			
X	X	X	X	X				Always zero	00000	No function
						X	X	Interrupt ID	00	11=receiver line status interrupt 10=received data available interrupt 01=transmitter holding register empty interrupt 00=modem status interrupt
							X	Interrupt pending	1	0=interrupt pending; 1=no interrupt pending

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Async 12 to 13

**See Also:** 7.35. Asynchronous Adapter I/O Port Usage

**7.40. INTERRUPT ENABLE REGISTER**

Bit Number								Function	State on Reset	Allowable Values
7	6	5	4	3	2	1	0			
X	X	X	X					Always zero	0000	No function
					X			Enable modem status Int	0	1=enable modem status interrupt; 0=disabled
						X		Receiver line status Int	0	1=enable receiver-line status interrupt; 0=disabled
							X	Transmitter holding reg empty	0	1=enable trans. holding reg. empty int; 0=disabled
							X	Received data available Int	0	1=enable received data avail. interrupt; 0=disabled

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Async 14 to 15

**See Also:** 7.35. Asynchronous Adapter I/O Port Usage

**7.41. MODEM CONTROL REGISTER**

Bit Number								Function	State on Reset	Allowable Values
7	6	5	4	3	2	1	0			
X	X	X						Always zero	000	No function
			X					Loopback test mode	0	0=disabled; 1=enabled
				X				-OUT2 signal	0	0=-OUT2 forced high; 1=-OUT2 forced low
					X			-OUT1 signal	0	0=-OUT1 forced high; 1=-OUT1 forced low
						X		-RTS output	0	0=-RTS forced high; 1=-RTS forced low
							X	-DTR output	0	0=-DTR forced high; 1=-DTR forced low

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Async 15 to 16

**See Also:** 7.35. Asynchronous Adapter I/O Port Usage

**7.42. MODEM STATUS REGISTER**

Bit Number								Function	State on Reset	Allowable Values
7	6	5	4	3	2	1	0			
X								-RLSD complement	Input signal	
	X							-RI complement	Input signal	
		X						-DSR complement	Input signal	
			X					-CTS complement	Input signal	
				X				Delta RLSD	0	0=no change; 1=-RLSD has changed state
					X			Trailing edge ring detector	0	0=no TE RI; 1=-RI has changed to OFF
						X		Delta DSR indicator	0	0=no change; 1=-DSR has changed state
							X	Delta CTS indicator	0	0=no change; 1=-CTS has changed state

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Async 16 to 18

**See Also:** 7.35. Asynchronous Adapter I/O Port Usage

**7.43. GAME ADAPTER I/O PORT USAGE**

Port	Direction	Function
201H	Write	Fire joysticks four one-shots
	Read	Read joystick position and status

**Notes:** Resistive inputs are read by first outputting to port 201H, then noting the amount of time they remain high by inputting continuously from port 201H

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Game Adapter 3 to 6

**See Also:** 7.44. Game Adapter AB Joystick Data Byte  
7.45. Game Adapter ABCD Paddle Data Byte

**7.44. GAME ADAPTER AB JOYSTICK DATA BYTE**

Bit Numbers								Function
7	6	5	4	3	2	1	0	
X								Status of B joystick button 2
	X							Status of B joystick button 1
		X						Status of A joystick button 2
			X					Status of A joystick button 1
				X				B joystick Y coordinate*
					X			B joystick X coordinate*
						X		A joystick Y coordinate*
							X	A joystick X coordinate*

**Notes:** \*Coordinates are determined by the length of time the bit is held high

**Source:** IBM Technical Reference Options and Adapters Volume 2, page Game Adapter 6

**See Also:** 7.43. Game Adapter I/O Port Usage  
7.45. Game Adapter ABCD Paddle Data Byte

**7.45. GAME ADAPTER ABCD PADDLE DATA BYTE**

Bit Numbers								Function
7	6	5	4	3	2	1	0	
X								Status of D paddle button
	X							Status of C paddle button
		X						Status of B paddle button
			X					Status of A paddle button
				X				D paddle coordinate*
					X			C paddle coordinate*
						X		B paddle coordinate*
							X	A paddle coordinate*

**Notes:** \*Coordinates are determined by the length of time the bit is held high

**Source:** IBM Technical Reference Options and Adapters Volume 2, page Game Adapter 6

**See Also:** 7.43. Game Adapter I/O Port Usage  
7.44. Game Adapter AB Joystick Data Byte

7.46. PRINTER ADAPTER I/O PORT USAGE

Port	Bit Numbers								Adapter	Direction	Function
	7	6	5	4	3	2	1	0			
378	X								Printer	Output	Controls pin 9 (data bit 7)
		X							Printer	Output	Controls pin 8 (data bit 6)
			X						Printer	Output	Controls pin 7 (data bit 5)
				X					Printer	Output	Controls pin 6 (data bit 4)
					X				Printer	Output	Controls pin 5 (data bit 3)
						X			Printer	Output	Controls pin 4 (data bit 2)
							X		Printer	Output	Controls pin 3 (data bit 1)
								X	Printer	Output	Controls pin 2 (data bit 0)
379	X								Printer	Input	Status of pin 11 (busy)
		X							Printer	Input	Status of pin 10 (acknowledge)
			X						Printer	Input	Status of pin 12 (out of paper)
				X					Printer	Input	Status of pin 13 (select)
					X				Printer	Input	Status of pin 15 (error)
						X	X	X	Printer	Input	NOT USED
37A	X	X	X						Printer	Input	NOT USED
				X					Printer	Input	Status of IRQ Enable
					X				Printer	Input	Inverted status of pin 17 (select input)
						X			Printer	Input	Status of pin 16 (initialize printer)
							X		Printer	Input	Inverted status of pin 14 (auto feed)
								X	Printer	Input	Inverted status of pin 1 (strobe)
	X	X	X	X					Printer	Output	NOT USED
					X				Printer	Output	Inverted status of pin 17 (select input)
						X			Printer	Output	Status of pin 16 (initialize printer)
							X		Printer	Output	Inverted status of pin 14 (auto feed)
3BC	X								MDA	Output	Controls pin 9 (data bit 7)
		X							MDA	Output	Controls pin 8 (data bit 6)
			X						MDA	Output	Controls pin 7 (data bit 5)
				X					MDA	Output	Controls pin 6 (data bit 4)
					X				MDA	Output	Controls pin 5 (data bit 3)
						X			MDA	Output	Controls pin 4 (data bit 2)
							X		MDA	Output	Controls pin 3 (data bit 1)
								X	MDA	Output	Controls pin 2 (data bit 0)
3BD	X								MDA	Input	Status of pin 11 (busy)
		X							MDA	Input	Status of pin 10 (acknowledge)
			X						MDA	Input	Status of pin 12 (out of paper)
				X					MDA	Input	Status of pin 13 (select)
					X				MDA	Input	Status of pin 15 (error)
						X	X	X	MDA	Input	NOT USED
3BE	X	X	X						MDA	Input	NOT USED
				X					MDA	Input	Status of IRQ Enable
					X				MDA	Input	Inverted status of pin 17 (select input)
						X			MDA	Input	Status of pin 16 (initialize printer)
							X		MDA	Input	Inverted status of pin 14 (auto feed)
								X	MDA	Input	Inverted status of pin 1 (strobe)
	X	X	X	X					MDA	Output	NOT USED
					X				MDA	Output	Inverted status of pin 17 (select input)
						X			MDA	Output	Status of pin 16 (initialize printer)
							X		MDA	Output	Inverted status of pin 14 (auto feed)
							X	MDA	Output	Inverted status of pin 1 (strobe)	

**Notes:** •While the printer adapter and monochrome display adapter printer ports work identically, they appear at different port addresses  
 •The source contains incomplete material

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Printer Adapter 3 to 7  
 IBM Technical Reference Options and Adapters Volume 2, pages Monochrome Adapter 13 to 17

7.47. IBM PRINTER CONTROL CODES SUMMARY

Function Type	Function	Code Sequence in ASCII Charts	Code Sequence in Hex Bytes	Printer Type*		
Character Style				Graphics	Color	Compact
Character Style	Select char set 1	<Escape>7	1B 37	Yes	Yes	Yes
	Select char set 2	<Escape>6	1B 36	Yes	Yes	Yes
	10 characters per inch spacing (Compressed OFF)	<DC2>	12	Yes	Yes	Yes
	17.1 characters per inch spacing (Compressed ON)	<SI>	0F	Yes	Yes	Yes
	Doublestrike ON	<Escape> or <SI>	1B 0F	Yes	Yes	Yes
	Doublestrike OFF	<Escape>G	1B 47	Yes	Yes	Yes
	Doublewidth ON (lines)	<Escape>H	1B 48	Yes	Yes	Yes
	Doublewidth OFF (lines)	<Escape>W<SOH>	1B 57 01	Yes	Yes	Yes
	Doublewidth by line ON	<Escape>W<Null>	1B 57 00	Yes	Yes	Yes
	Doublewidth by line OFF	<SO>	0E	Yes	Yes	Yes
	Emphasized printing ON	<Escape> or <SO>	1B 0E	Yes	Yes	Yes
	Emphasized printing OFF	<DC4>	14	Yes	Yes	Yes
	Subscript ON	<Escape>E	1B 45	Yes	Yes	Yes
	Subscript/superscript OFF	<Escape>F	1B 46	Yes	Yes	Yes
	Set draft quality print	<Escape>S<SOH>	1B 53 01	Yes	Yes	Yes
	Set text quality print	<Escape>S<Null>	1B 53 00	Yes	Yes	Yes
	Set letter quality print	<Escape>T	1B 54	Yes	Yes	Yes
	Proportional spacing ON	<Escape>I<SOH>	1B 49 01	Yes	Yes	Yes
	Proportional spacing OFF	<Escape>I<STX>	1B 49 02	Yes	Yes	Yes
	Print all characters in block	<Escape>I<ETX>	1B 49 03	Yes	Yes	Yes
	Print next character	<Escape>P<SOH>	1B 50 01	Yes	Yes	Yes
	Underline ON	<Escape>P<Null>	1B 50 00	Yes	Yes	Yes
	Underline OFF	<Escape>W## [data]	1B 3A	Yes	Yes	Yes
	Ignore paper end ON	<Escape>^	1B 5E	Yes	Yes	Yes
	Ignore paper end OFF	<Escape><SOH>	1B 2D 01	Yes	Yes	Yes
	Set length of page in lines	<Escape><Null>	1B 2D 00	Yes	Yes	Yes
	Set length of page in inches	<Escape>8	1B 38	Yes	Yes	Yes
	Automatic line justification ON	<Escape>9	1B 39	Yes	Yes	Yes
Automatic line justification OFF	<Escape>C#	1B 43 #	Yes	Yes	Yes	
Perforation skip ON	<Escape>C<SOH>#	1B 43 00 #	Yes	Yes	Yes	
Perforation skip OFF	<Escape>M<SOH>	1B 4D 01	Yes	Yes	Yes	
Set top of page	<Escape>M<Null>	1B 4D 00	Yes	Yes	Yes	
Set left and right margins	<Escape>N#	1B 4E #	Yes	Yes	Yes	
Set tabs to power-on defaults	<Escape>O	1B 4F	Yes	Yes	Yes	
Set horizontal tab stops	<Escape>4	1B 34	Yes	Yes	Yes	
Set vertical tab stops	<Escape>X##	1B 58 # #	Yes	Yes	Yes	
Carriage return	<Escape>R	1B 52	Yes	Yes	Yes	
Line feed	<Escape>D#...#<Null>	1B 44 #...# 00	Yes	Yes	Yes	
Set variable line feed to m/72 inch	<Escape>B#...#<Null>	1B 42 #...# 00	Yes	Yes	Yes	
Set variable line feed to m/216 inch	<CR>	0D	Yes	Yes	Yes	
Set 1/8 inch line feed	<LF>	0A	Yes	Yes	Yes	
	<Escape>A#	1B 41 #	Yes	Yes	Yes	
	<Escape>J#	1B 4A #	Yes	Yes	n/144*	
	<Escape>0	1B 30	Yes	Yes	Yes	

(Continued)

Table 7.47. Continued

Function Type	Function	Code Sequence in ASCII Chars	Code Sequence in Hex Bytes	Graphics	Color	Compact	
Line Settings	Set 7/72 inch line feed	<Escape>1	1B 31	Yes	6/72"	1/9"	
	Start variable line feed (used after EscA)	<Escape>2	1B 32	Yes	Yes	1/6"	
	Set n/216 inch line feed	<Escape>3#	1B 33 #	Yes	n/144"	Yes	
	Vertical tab	<VT>	0B		Yes	Yes	
	Reverse line feed	<Escape>J	1B 5D		Yes	Yes	
	Automatic line feed ON	<Escape>5<SOH>	1B 35 01		Yes	Yes	
	Automatic line feed OFF	<Escape>5<Null>	1B 35 00		Yes	Yes	
	Printer Control	Ring bell	<BELL>	7	Yes	Yes	Yes
		Clear printer buffer	<CAN>	18	Yes	Yes	Yes
		Select printer	<DC1>	11	Yes	Yes	Yes
		Deselect printer	<DC3>	13	Yes	Yes	Yes
		Automatic ribbon band shift	<Escape>a	1B 61		Yes	
		Select ribbon band 4 (black)	<Escape>b	1B 62		Yes	
		Select ribbon band 3	<Escape>c	1B 63		Yes	
		Space n/120 forward to next character	<Escape>d##	1B 64 # #		Yes	
Space n/120 backward to next character		<Escape>e##	1B 65 # #		Yes		
Select ribbon band 2		<Escape>m	1B 6D		Yes		
Set aspect ratio to 1:1		<Escape>n<SOH>	1B 6E 01		Yes		
Set aspect ratio to 5:6		<Escape>n<Null>	1B 6E 00		Yes		
Deselect color printer		<Escape>Q<STX>	1B 51 02		Yes		
Select ribbon band 1		<Escape>y	1B 79		Yes		
Initialize function ON		<Escape>?<SOH>	1B 3F 01		Yes		
Initialize function OFF		<Escape>?<Null>	1B 3F 00		Yes		
Unidirectional printing ON		<Escape>U<SOH>	1B 55 01		Yes		
Unidirectional printing OFF		<Escape>U<Null>	1B 55 00		Yes	Yes	
Home print head		<Escape><	1B 3C		Yes	Yes	
Form feed		<FF>	0C		Yes	Yes	
Horizontal tab	<HT>	9		Yes	Yes		
Select control-value data type	<Escape>@#	1B 40#		Yes	Yes		
Backspace	<BS>	8		Yes	Yes		
Graphics	Set to 480 bit image graphics mode	<Escape>K## [data]	1B 4B # #	Yes	1108	560	
	Set to 960 bit image graphics mode	<Escape>L## [data]	1B 4C # #	Yes	2216		
	Set to 960 bit image graphics mode normal speed	<Escape>Y## [data]	1B 59 # #	Yes	2216		
	Set to 1920 bit image graphics mode	<Escape>Z## [data]	1B 5A # #	Yes	4432		

**Notes:**

- Characters enclosed in brackets are ASCII code names, as in <Escape>#
- # should be replaced by the relevant numeric value in this chart
- [data] indicates a bitstream of appropriately formatted data
- Numbers in "bit image graphics modes" indicate number of data bytes that follow
- \*Refers to IBM Graphics Printer, IBM Color Printer, and IBM Compact Printer, respectively

**Source:**

IBM Technical Reference Options and Adapters Volume 1, pages Graphics Printer

**See Also:**

- 1.20. ASCII Control Codes
- 7.48. HP LaserJet Printer Control Codes Summary

**7.48. HP LASERJET PRINTER CONTROL CODES SUMMARY**

Function Type	Function	Code Sequence in ASCII Chars	Code Sequence in Hex Bytes
<i>Orientation</i>	Portrait Mode	<Escape>&l0O	1B 26 6C 30 4F
	Landscape Mode	<Escape>&l1O	1B 26 6C 31 4F
<i>Font Symbol Set</i>	Roman-8	<Escape>(8U	1B 28 38 55
	USASCII	<Escape>(0U	1B 28 30 55
	Roman Ext.	<Escape>(0E	1B 28 30 45
	Danish/Norwegian	<Escape>(0D	1B 28 30 44
	British (U.K.)	<Escape>(1E	1B 28 31 45
	French	<Escape>(0F	1B 28 30 46
	German	<Escape>(0G	1B 28 30 47
	Italian	<Escape>(0I	1B 28 30 49
	Swedish/Finnish	<Escape>(0S	1B 28 30 53
	Spanish	<Escape>(1S	1B 28 31 53
	Legal	<Escape>(1U	1B 28 31 55
	Linedraw	<Escape>(0B	1B 28 30 42
	Math8	<Escape>(8M	1B 28 38 4D
	Math8a	<Escape>(0Q	1B 28 30 51
	Math8b	<Escape>(1Q	1B 28 31 51
	Math7	<Escape>(0A	1B 28 30 41
PiFont	<Escape>(15U	1B 28 31 35 55	
PiFonta	<Escape>(2Q	1B 28 32 51	
<i>Character Spacing</i>	Proportional	<Escape>(s1P	1B 28 73 31 50
	Fixed	<Escape>(s0P	1B 28 73 30 50
<i>Character Pitch</i>	10 chars per inch	<Escape>(s10H	1B 28 73 31 30 48
	12 chars per inch	<Escape>(s12H	1B 28 73 31 32 48
	16.6 chars per inch	<Escape>(s16.6H	1B 28 73 31 36 2E 36 48
	Standard Pitch (10 cpi)	<Escape>&k0S	1B 26 6B 30 53
	Compressed Pitch (16.6 cpi)	<Escape>&k2S	1B 26 6B 32 53
<i>Character Point Size</i>	7 point	<Escape>(s7V	1B 28 73 37 56
	8 point	<Escape>(s8V	1B 28 73 38 56
	8.5 point	<Escape>(s8.5V	1B 28 73 38 2E 35 56
	10 point	<Escape>(s10V	1B 28 73 31 30 56
	12 point	<Escape>(s12V	1B 28 73 31 32 56
	14.4 point	<Escape>(s14.4V	1B 28 73 31 34 2E 34 56
<i>Character Style</i>	Upright	<Escape>(s0S	1B 28 73 30 53
	Italic	<Escape>(s1S	1B 28 73 31 53
<i>Character Weight</i>	Light stroke	<Escape>(s-3B	1B 28 73 2D 42
	Medium stroke	<Escape>(s0B	1B 28 73 30 42
	Bold (heavy) stroke	<Escape>(s3B	1B 28 73 33 42
<i>Character Typeface</i>	Courier	<Escape>(s3T	1B 28 73 33 54
	Line Printer	<Escape>(s0T	1B 28 73 30 54
	Helv	<Escape>(s4T	1B 28 73 34 54
	TMS RMN	<Escape>(s5T	1B 28 73 35 54
	Prestige Elite	<Escape>(s8T	1B 28 73 38 54
	Gothic	<Escape>(s6T	1B 28 73 36 54
<i>Page Settings</i>	Page Length	<Escape>&l*P	1B 26 6C # 50
	Top Margin	<Escape>&l*E	1B 26 6C # 45
	Text Length	<Escape>&l*F	1B 26 6C # 46
	Clear Left/Right Margin	<Escape>9	1B 39
	Set Left Margin	<Escape>&a*L	1B 26 61 # 4C
	Set Right Margin	<Escape>&a*M	1B 26 61 # 4D
	Perforation Skip Enable	<Escape>&l0L	1B 26 6C 31 4C
	Perforation Skip Disable	<Escape>&l1L	1B 26 6C 30 4C
<i>Line Spacing</i>	Vertical Motion Index	<Escape>&l1#C	1B 26 6C # 43
	1 line/inch	<Escape>&l1D	1B 26 6C 31 44
	2 lines/inch	<Escape>&l2D	1B 26 6C 32 44
	3 lines/inch	<Escape>&l3D	1B 26 6C 33 44
	4 lines/inch	<Escape>&l4D	1B 26 6C 34 44
	6 lines/inch	<Escape>&l6D	1B 26 6C 36 44
	8 lines/inch	<Escape>&l8D	1B 26 6C 38 44
	12 lines/inch	<Escape>&l12D	1B 26 6C 31 32 44
	16 lines/inch	<Escape>&l16D	1B 26 6C 31 36 44
	24 lines/inch	<Escape>&l24D	1B 26 6C 32 34 44
	Half line feed	<Escape>=	1B 3D
<i>Raster Graphics</i>	75 dpi resolution	<Escape>*r75R	1B 2A 74 37 35 52
	100 dpi resolution	<Escape>*r100R	1B 2A 74 31 30 30 52
	150 dpi resolution	<Escape>*r150R	1B 2A 74 31 35 30 52
	300 dpi resolution	<Escape>*r300R	1B 2A 74 33 30 30 52
	Start at leftmost pos.	<Escape>*r0A	1B 2A 72 30 41
	Start at current cursor	<Escape>*r1A	1B 2A 72 31 41

(Continued)

Table 7.48. Continued

Function Type	Function	Code Sequence in ASCII Chars	Code Sequence in Hex Bytes
Raster Graphics	Transfer graphic rows	<Escape>*b#W [data]	1B 2A 62 # 57
	End graphics	<Escape>*rB	1B 2A 72 42
Printer Control	Reset printer	<Escape>E	1B 45
	Selftest mode	<Escape>z	1B 7A
Cursor Positioning	Move to Row	<Escape>&a#R	1B 26 61 # 52
	Move to Column	<Escape>&a#C	1B 26 61 # 43
	Horizontal Movement	<Escape>&a#H	1B 26 61 # 48
	Vertical Movement	<Escape>&a#V	1B 26 61 # 56
Underlining	Underline ON	<Escape>&dD	1B 26 64 44
	Underline OFF	<Escape>&d@	1B 26 64 40
Miscellaneous Control	Display Functions ON	<Escape>Y	1B 59
	Display Functions OFF	<Escape>Z	1B 5A
	Transparent Print Data	<Escape>&p#X [data]	1B 26 70 # 58
	Horizontal Motion Index	<Escape>&k#H	1B 26 6B # 48
	Carriage Return=CR	<Escape>&k0G	1B 26 6B 30 47
	Carriage Return=CR+LF	<Escape>&k1G	1B 26 6B 31 47
	LF=CR+LF, FF=CR+FF	<Escape>&k2G	1B 26 6B 32 47
	Add CR to LF and FF, CR=CR+LF	<Escape>&k3G	1B 26 6B 33 47
	Enable End of Line Wrap	<Escape>&s0C	1B 26 73 30 43
	Disable End of Line Wrap	<Escape>&s1C	1B 26 73 31 43
	Number of Copies	<Escape>&1#X	1B 26 6C # 58
	Eject Page	<Escape>&l0H	1B 26 6C 30 48
	Feed From Tray	<Escape>&l1H	1B 26 6C 31 48
	Manual Feed	<Escape>&l2H	1B 26 6C 32 48
	Envelope Feed	<Escape>&l3H	1B 26 6C 33 48
Laserjet +/-500+ Extensions	Graphics Horz Cursor Position	<Escape>*p#X	1B 2A 70 # 58
	Graphics Vert Cursor Position	<Escape>*p#Y	1B 2A 70 # 59
	Font ID Number	<Escape>*c#D	1B 2A 63 # 44
	ASCII Char Code Number	<Escape>*c#E	1B 2A 63 # 45
	Create Font	<Escape>*s#W [data]	1B 29 73 # 57
	Download Character	<Escape>*s#W [data]	1B 28 73 # 57
	Primary Font ID Number	<Escape>#X	1B 28 # 58
	Secondary Font ID Number	<Escape>#X	1B 29 # 58
	Delete all Fonts	<Escape>*c0F	1B 2A 63 30 46
	Delete all Temp Fonts	<Escape>*c1F	1B 2A 63 31 46
	Delete Last Font ID specified	<Escape>*c2F	1B 2A 63 32 46
	Delete Last Font ID & Char Code	<Escape>*c3F	1B 2A 63 33 46
	Make Temporary Font	<Escape>*c4F	1B 2A 63 34 46
	Make Permanent Font	<Escape>*c5F	1B 2A 63 35 46
	Copy/Assign	<Escape>*c6F	1B 2A 63 36 46
	Primary Font Value 0	<Escape> 0@	1B 28 30 40
	Primary Font Value 1	<Escape> 1@	1B 28 31 40
	Primary Font Value 2	<Escape> 2@	1B 28 32 40
	Primary Font Value 3	<Escape> 3@	1B 28 33 40
	Secondary Font Value 0	<Escape> 0@	1B 29 30 40
	Secondary Font Value 1	<Escape> 1@	1B 29 31 40
	Secondary Font Value 2	<Escape> 2@	1B 29 32 40
	Secondary Font Value 3	<Escape> 3@	1B 29 33 40
	Macro ID	<Escape>&f#Y	1B 26 66 # 59
	Start Macro	<Escape>&f0X	1B 26 66 30 58
	Stop Macro	<Escape>&f1X	1B 26 66 31 58
	Execute Macro	<Escape>&f2X	1B 26 66 32 58
	Call Macro	<Escape>&f3X	1B 26 66 33 58
	Enable Overlay	<Escape>&f4X	1B 26 66 34 58
	Disable Overlay	<Escape>&f5X	1B 26 66 35 58
	Delete Macros	<Escape>&f6X	1B 26 66 36 58
	Delete all Temporary Macros	<Escape>&f7X	1B 26 66 37 58
	Delete Macro ID	<Escape>&f8X	1B 26 66 38 58
	Make Macro Temporary	<Escape>&f9X	1B 26 66 39 58
	Make Macro Permanent	<Escape>&f10X	1B 26 66 31 30 58
	Push Position	<Escape>&f0S	1B 26 66 30 53
	Pop Position	<Escape>&f1S	1B 26 66 31 53
	Horz # dots in pattern	<Escape>*c#A	1B 2A 63 # 41
	Horz # decipoints in pattern	<Escape>*c#H	1B 2A 63 # 48
	Vert # dots in pattern	<Escape>*c#B	1B 2A 63 # 42
	Vert # decipoints in pattern	<Escape>*c#V	1B 2A 63 # 56
	Print Rule	<Escape>*c0P	1B 2A 63 30 50
	Print Gray Scale	<Escape>*c2P	1B 2A 63 32 50
	Print HP Pattern	<Escape>*c3P	1B 2A 63 33 50

(Continued)

Table 7.48. Continued

Function Type	Function	Code Sequence in ASCII Chars	Code Sequence in Hex Bytes
Laserjet+/500+ Extensions	Print 2% Gray Scale	<Escape>*c2G	1B 2A 63 32 47
	Print 10% Gray Scale	<Escape>*c10G	1B 2A 63 31 30 47
	Print 15% Gray Scale	<Escape>*c15G	1B 2A 63 31 35 47
	Print 30% Gray Scale	<Escape>*c30G	1B 2A 63 33 30 47
	Print 45% Gray Scale	<Escape>*c45G	1B 2A 63 34 35 47
	Print 70% Gray Scale	<Escape>*c70G	1B 2A 63 37 30 47
	Print 90% Gray Scale	<Escape>*c90G	1B 2A 63 39 30 47
	Print 100% Gray Scale	<Escape>*c100G	1B 2A 63 31 30 30 47
	HP Pattern 1 Vert Lines	<Escape>*c1G	1B 2A 63 31 47
	HP Pattern 2 Horz lines	<Escape>*c2G	1B 2A 63 32 47
	HP Pattern 3 Diagonal Lines	<Escape>*c3G	1B 2A 63 33 47
	HP Pattern 4 Diagonal Lines	<Escape>*c4G	1B 2A 63 34 47
	HP Pattern 5 Grid	<Escape>*c5G	1B 2A 63 35 47
	HP Pattern 6 Diagonal Grid	<Escape>*c6G	1B 2A 63 36 47
	Laserjet 500+ Extensions	Default Stacking Position	<Escape>&l0T
Toggle Stacking Position		<Escape>&l1T	1B 26 6C 31 54
Eject Page		<Escape>&l0H	1B 26 6C 30 48
Feed from Upper Cassette		<Escape>&l1H	1B 26 6C 31 48
Manual Feed		<Escape>&l2H	1B 26 6C 32 48
Envelope Feed		<Escape>&l3H	1B 26 6C 33 48
Feed from Lower Cassette		<Escape>&l4H	1B 26 6C 34 48

**Notes:**                   • # should be replaced by the relevant numeric value in this chart  
                               • [data] indicates a bitstream of appropriately formatted data

**Source:**                   HP Laserjet Printer Family Technical Reference Manual, pages A1-A6

**See Also:**                7.47. IBM Printer Control Codes Summary

**7.49. AT REAL TIME CLOCK RAM CONFIGURATION USAGE**

Address	Function	Comments
0H	Seconds	
1H	Second alarm	
2H	Minutes	
3H	Minute alarm	
4H	Hours	
5H	Hour alarm	
6H	Day of week	
7H	Day in month	
8H	Month	
9H	Year	
0AH	Status register A	See 7.50. AT Real Time Clock Status Register A
0BH	Status register B	See 7.51. AT Real Time Clock Status Register B
0CH	Status register C	See 7.52. AT Real Time Clock Status Register C
0DH	Status register D	See 7.53. AT Real Time Clock Status Register D
0EH	Diagnostic status byte	See 7.54. AT Real Time Clock Diagnostic Status Byte
0FH	Shutdown status byte	Defined by power-on diagnostics
10H	Disk drive type byte	See 7.55. AT Real Time Clock Diskette Drive Type Byte
11H	RESERVED	
12H	Fixed drive type byte	See 7.56. AT Real Time Clock Fixed Drive Type Byte
13H	RESERVED	
14H	Equipment byte	See 7.57. AT Real Time Clock Equipment Byte
15H	Low-base memory byte	
16H	High-base memory byte	100H=256K, 200H=512K, 280H=640K
17H	Low expansion memory byte	
18H	High expansion memory byte	200H=512K, 400H=1024K, 600-3C00H=up to 15360K
19H	Drive C extended byte	See 8.30 AT Fixed Disk Drive Types
1AH	Drive D extended byte	See 8.30 AT Fixed Disk Drive Types

(Continued)

Table 7.49. Continued

Address	Function	Comments
1BH-2DH	RESERVED	
2EH-2FH	Checksum	Checksum based on 10-2DH addresses
30H	Low expansion memory byte	
31H	High expansion memory byte	200H=512K, 400H=1024K, 600-3C00H=up to 15360K
32H	Date century byte	BCD value for century
33H	Information flags	Bit 7 set = top 128K installed, bit 6 set = first user message
34H-3FH	RESERVED	

**Source:** IBM PC/AT Technical Reference, pages 1-56 to 1-68

**See Also:** 7.50. AT Real Time Clock Status Register A  
 7.51. AT Real Time Clock Status Register B  
 7.52. AT Real Time Clock Status Register C  
 7.53. AT Real Time Clock Status Register D  
 7.54. AT Real Time Clock Diagnostic Status Byte  
 7.55. AT Real Time Clock Diskette Drive Type Byte  
 7.56. AT Real Time Clock Fixed Drive Type Byte  
 7.57. AT Real Time Clock Equipment Byte  
 8.30 AT Fixed Disk Drive Types

**7.50. AT REAL TIME CLOCK STATUS REGISTER A**

Bit Numbers

7	6	5	4	3	2	1	0	Name	Function	Allowable Values
X								Update in progress	Indicates update cycle in progress	0=date/time available, 1=date/time being updated
	X	X	X					22-stage divider	Identifies time-base frequency used	default=010, 32.768KHz time base
				X	X	X	X	Rate selection	Identifies divider output frequency	default=0110, 1.024KHz frequency

**Source:** IBM PC/AT Technical Reference, pages 1-57 to 1-58

**See Also:** 7.51. AT Real Time Clock Status Register B  
 7.52. AT Real Time Clock Status Register C  
 7.53. AT Real Time Clock Status Register D

**7.51. AT REAL TIME CLOCK STATUS REGISTER B**

Bit Numbers

7	6	5	4	3	2	1	0	Name	Function	Allowable Values
X								Set	Advances count (1-per second)	0=update normally, 1=abort update cycle
	X							Periodic Int enable	Allows interrupts at status reg A settings	0=disable int (default) 1=enable int
		X						Alarm int enable	Sets alarm interrupt	0=disabled (default), 1=enabled
			X					Update-ended Int enable	Sets end-of-update interrupt	0=disabled (default), 1=enabled
				X				Square wave enable	Sets frequency as per status reg A 0:3 bits	0=disabled (default), 1=enabled
					X			Date mode	Sets binary or BCD updates	0=BCD (default), 1=binary
						X		24/12 mode	Sets hours format in time	0=12-hour clock, 1=24-hour clock (default)
							X	Daylight savings enable	Sets clock to recognize daylight savings	0=disabled (default), 1=enabled

**Source:** IBM PC/AT Technical Reference, pages 1-58 to 1-59

**See Also:** 7.50. AT Real Time Clock Status Register A  
 7.52. AT Real Time Clock Status Register C  
 7.53. AT Real Time Clock Status Register D

**7.52 AT REAL TIME CLOCK STATUS REGISTER C**

Bit Numbers

7	6	5	4	3	2	1	0	Name	Function	Allowable Values
X								IRQF flag		Read only
	X							PF flag		Read only
		X						AF flag		Read only
			X					UF flag		Read only
				X	X	X	X	RESERVED		Should always be 0

**Source:** IBM PC/AT Technical Reference, page 1-59

**See Also:** 7.50. AT Real Time Clock Status Register A  
 7.51. AT Real Time Clock Status Register B  
 7.53. AT Real Time Clock Status Register D

**7.53. AT REAL TIME CLOCK STATUS REGISTER D***Bit Numbers*

7	6	5	4	3	2	1	0	Name	Function	Allowable Values
X								Valid RAM bit	Status of power-sense pin (bat. level)	0=battery dead, RAM invalid, 1=battery good
	X	X	X	X	X	X	X	RESERVED		Should always be 0

**Source:** IBM PC/AT Technical Reference, page 1-59

**See Also:** 7.50. AT Real Time Clock Status Register A  
7.51. AT Real Time Clock Status Register B  
7.52. AT Real Time Clock Status Register C

**7.54. AT REAL TIME CLOCK DIAGNOSTIC STATUS BYTE***Bit Numbers*

7	6	5	4	3	2	1	0	Function	Allowable Values
X								Power status of RTC chip	0=chip hasn't lost power, 1=chip has lost power
	X							Configuration record (checksum status)	0=checksum is good, 1=checksum bad
		X						Incorrect configuration information	0=valid configuration, 1=invalid configuration
			X					Memory size comparison	0=power-on check showed same memory size, 1=diff. size
				X				Fixed disk status	0=proper function, 1=adapter or drive failed initialization
					X			Time status indicator	0=time is valid, 1=time invalid
						X	X	RESERVED	

**Source:** IBM PC/AT Technical Reference, pages 1-59 to 1-60

**See Also:** 7.49. AT Real Time Clock RAM Configuration Usage

**7.55. AT REAL TIME CLOCK DISKETTE DRIVE TYPE BYTE***Bit Numbers*

7	6	5	4	3	2	1	0	Function	Allowable Values
X	X	X	X					Type of first diskette drive	0000=no drive, 0001=48TPI, 0010=96TPI
				X	X	X	X	Type of second diskette drive	0000=no drive, 0001=48TPI, 0010=96TPI

**Source:** IBM PC/AT Technical Reference, page 1-61

**See Also:** 7.49. AT Real Time Clock RAM Configuration Usage

**7.56. AT REAL TIME CLOCK FIXED DRIVE TYPE BYTE***Bit Numbers*

7	6	5	4	3	2	1	0	Function	Allowable Values
X	X	X	X					Type of first fixed drive	0000=no drive, otherwise see 8.30. AT Fixed Disk Drive Types
				X	X	X	X	Type of second fixed drive	0000=no drive, otherwise see 8.30. AT Fixed Disk Drive Types

**Source:** IBM PC/AT Technical Reference, page 1-62

**See Also:** 7.49. AT Real Time Clock RAM Configuration Usage  
8.30. AT Fixed Disk Drive Types

**7.57. AT REAL TIME CLOCK EQUIPMENT BYTE***Bit Numbers*

7	6	5	4	3	2	1	0	Function	Allowable Values
X	X							Number of disk drives	00=1 drive, 01=2 drives, other values RESERVED
		X	X					Primary display type	00=display has own BIOS, 01=40 col CGA, 10=80 col CGA, 11=MDA
				X	X			NOT USED	
					X			Math coprocessor	0=not installed, 1=math coprocessor available
						X		Disk drives available	0=no disk drives available, 1=disk drives available

**Source:** IBM PC/AT Technical Reference, pages 1-63 to 1-64

**See Also:** 7.49. AT Real Time Clock RAM Configuration Usage



— SECTION —

# 8

Chips, Jumpers,  
Switches, and  
Registers

---

**8.01. 8086 FAMILY MEMORY ADDRESSING MODES**

<i>Mode</i>	<i>Example</i>	<i>Explanation</i>
Direct register addressing	ADD AX,CX	Uses contents of registers for operation
Indirect memory addressing	ADD AX,[CX]	Uses CX as a relative offset to point to memory
	ADD [CX],AX	
Immediate addressing	ADD AX,123	Uses immediate value (123)
Relative memory addressing	ADD AX,[123]	Immediate value (123) is relative offset to point to memory
Indexed indirect addressing	ADD AX,[BX+SI]	Uses BX+SI as relative offset to point to memory

**Source:** *Programmer's Guide to the IBM PC* (Microsoft Press), Peter Norton, pages 34 to 35

8.02. 8086 FAMILY INSTRUCTION SET SUMMARY

Instruction	Function	Clock Cycles**	Bytes***	Flags Affected	Undefined Flags	8088/86	80286	80386
AAA	ASCII adjust AL after add	3	1	Aux carry	Overflow, sign, zero, parity	X	X	X
AAD	ASCII adjust before divide	14	2	Sign, zero, parity	Overflow, aux, carry	X	X	X
AAM	ASCII adjust after multiply	16	2	Sign, zero, parity	Overflow, aux, carry	X	X	X
AAS	ASCII adjust after subtract	3	1	Aux, carry	Overflow, sign, zero, parity	X	X	X
ADC accum, imm****	Add with carry	3	2-3	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADC mem, imm	Add with carry	7*	3-6	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADC mem, reg	Add with carry	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADC reg, imm	Add with carry	3	3-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADC reg, mem	Add with carry	7*	3-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADC reg, reg	Add with carry	2	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADD accum, imm****	Add	3	2	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADD mem, imm	Add	7*	3-6	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADD mem, reg	Add	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADD reg, imm	Add	3	3-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADD reg, mem	Add	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ADD reg, reg	Add	2	2	Overflow, sign, zero, aux, parity, carry	None	X	X	X
AND accum, imm****	Logical AND	3	2-3	Overflow, sign, zero, aux, parity, carry	None	X	X	X
AND mem, imm	Logical AND	7*	3-6	Overflow, sign, zero, aux, parity, carry	None	X	X	X
AND mem, reg	Logical AND	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
AND reg, imm	Logical AND	3	3-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
AND reg, mem	Logical AND	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
AND reg, reg	Logical AND	2	2	Overflow, sign, zero, aux, parity, carry	None	X	X	X
ARPL	Adjust requested privilege level	10*, 11*	2-3	ZF	None	X	X	X
BOUND reg, source	Detect array index out of range	13*	2	None	None		X	X
BSF reg, mem or reg, reg	Bit scan forward	10-bytes	3-4	ZF	None		X	X
BSR reg, mem or reg, reg	Bit scan reverse	10-bytes	3-4	ZF	None		X	X
BT	Test bit	3-6	3-5	CF	None		X	X
BTC	Test bit and complement	6, 8	3-5	CF	None		X	X
BTR	Test bit and reset	6, 8	3-5	CF	None		X	X
BTS	Test bit and scan	6, 8	3-5	CF	None		X	X
CALL 16memptr	Call (control transfer)	11+bytes*	2-4	None except when task switching	None	X	X	X
CALL 16regptr	Call (control transfer)	7+bytes	2	None except when task switching	None	X	X	X
CALL 32memptr	Call (control transfer)	16+bytes	2-4	None except when task switching	None	X	X	X
CALL 32regptr	Call (control transfer)	13+bytes	5	None except when task switching	None	X	X	X
CALL nearproc	Call (control transfer)	7+bytes	3	None except when task switching	None	X	X	X
CBW/CWDE	Convert byte to word/word to double word	2	1	None	None	X	X	X
CLC	Clear carry	2	1	Carry=0	None	X	X	X
CLD	Clear direction	2	1	Direction=0	None	X	X	X
CLI	Clear interrupt	3	1	Interrupt=0	None	X	X	X
CLTS	Clear task switched flag	5	2	TS=0 in CR0 register	None	X	X	X
CMC	Complement carry	2	1	Carry	None	X	X	X
CMP accum, imm****	Compare	3	2-3	Overflow, sign, zero, aux, parity, carry	None	X	X	X
CMP mem, imm	Compare	6*	3-6	Overflow, sign, zero, aux, parity, carry	None	X	X	X
CMP mem, reg	Compare	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
CMP reg, imm	Compare	3	3-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
CMP reg, mem	Compare	6*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
CMP reg, reg	Compare	2	2	Overflow, sign, zero, aux, parity, carry	None	X	X	X
CMPS (rep) deststr, sourcestr	Compare byte, word or double word string	5+9(rep)	8	Overflow, sign, zero, aux, parity, carry	None	X	X	X
CMPS (rep) deststr, sourcestr	Compare byte, word or double word	8	1	Overflow, sign, zero, aux, parity, carry	None	X	X	X
CLTS	Clear task switched flag	2	2	Overflow, sign, zero, aux, parity, carry	None	X	X	X
CWD/CQD	Convert word to double word/dw to qw	2	2	None	None	X	X	X
DAA/DAS	Decimal adjust after add/subtract	3	1	Sign, zero, aux, parity, carry	None	X	X	X
DEC mem	Decrement	7*	2-4	Overflow, sign, zero, aux, parity	None	X	X	X
DEC reg	Decrement	2	1-2	Overflow, sign, zero, aux, parity	None	X	X	X
DIV 16mem	Divide	25*	2-4	None	Overflow, sign, zero, aux, parity, carry	X	X	X

(Continued)

Table 9.02 Continued

Instruction	Function	Clock Cycles**	Bytes***	Flags Affected	Undefined Flags	8088/86	80286	80386
DIV 16reg	Divide	22	2	None	Overflow, sign, zero, aux, parity, carry	X	X	X
DIV 8mem	Divide	17*	2-4	None	Overflow, sign, zero, aux, parity, carry	X	X	X
DIV 8reg	Divide	14	2	None	Overflow, sign, zero, aux, parity, carry	X	X	X
ENTER 16mm,0	Enter procedure	11	4	None	None			
ENTER 16mm,1	Enter procedure	15	4	None	None			
ENTER 16mm,level	Enter procedure	12+4(L)	4	None	None			
ESC imm,mem	Escape to external device	9-20*	2-4	None	None			
ESC imm,reg	Escape to external device	9-20*	2	None	None			
HALT	Halt	2	1	None	None	X	X	X
IDIV 16mem	Signed integer divide	28*	2-4	None	Overflow, sign, zero, aux, parity, carry	X	X	X
IDIV 16reg	Signed integer divide	25*	2	None	Overflow, sign, zero, aux, parity, carry	X	X	X
IDIV 8mem	Signed integer divide	20*	2-4	None	Overflow, sign, zero, aux, parity, carry	X	X	X
IDIV 8reg	Signed integer divide	17	2	None	Overflow, sign, zero, aux, parity, carry	X	X	X
IMUL 16mem	Signed integer multiply	24*	2-4	Overflow, carry	Sign, zero, aux, parity	X	X	X
IMUL 16reg	Signed integer multiply	21	2	Overflow, carry	Sign, zero, aux, parity	X	X	X
IMUL 8mem	Signed integer multiply	16*	2-4	Overflow, carry	Sign, zero, aux, parity	X	X	X
IMUL 8reg	Signed integer multiply	13	2	Overflow, carry	Sign, zero, aux, parity	X	X	X
IMUL destreg,16reg,imm	Signed integer multiply	21	3-4	Overflow, carry	Sign, zero, aux, parity	X	X	X
IMUL destreg,mem,imm	Signed integer multiply	24*	3-4	Overflow, carry	Sign, zero, aux, parity	X	X	X
IN accum,8mm	Input from port	5	2	None	None	X	X	X
IN accum,DX	Input from DX port	5	1	None	None	X	X	X
INC mem	Increment	7*	2-4	Overflow, sign, zero, aux, parity	None	X	X	X
INC reg	Increment	2	1-2	Overflow, sign, zero, aux, parity	None	X	X	X
INS (rep) deststr,DX	Input string	5+4(rep)	1	None	None	X	X	X
INS deststr,DX	Input string	5	1	None	None	X	X	X
INT 8mm	Interrupt	23+bytes or 3	1-2	Interrupt-0,trap-0	None	X	X	X
INTO	Interrupt on overflow	24+bytes or 3	1-2	Interrupt-0,trap-0	None	X	X	X
IRET	Interrupt return	17+bytes	1	All	None	X	X	X
JMP 16memptr	Unconditional jump	11+bytes*	2-4	None	None	X	X	X
JMP 16regptr	Unconditional jump	7+bytes	2	None	None	X	X	X
JMP 32memptr	Unconditional jump	15+bytes*	2-4	None	None	X	X	X
JMP far	Unconditional jump	11+bytes	5	None	None	X	X	X
JMP near	Unconditional jump	7+bytes	3	None	None	X	X	X
JMP short	Unconditional jump	7+bytes	2	None	None	X	X	X
Jxxx short	Unconditional jump	7+bytes or 3	2	None	None	X	X	X
LAHF	Load AH with flags (LO byte of flags)	2	1	None	None	X	X	X
LAR	Load access rights byte	14,16*	3-4	ZF	None	X	X	X
LDS 16reg,32mem	Load pointer to DS	7*	2-4	None	None	X	X	X
LEA 16reg,16mem	Load effective address to register	3*	2-4	None	None	X	X	X
LEAVE	Leave procedure	5	1	None	None	X	X	X
LES 16reg,32mem	Load pointer to ES	7*	2-4	None	None	X	X	X
LFS	Load pointer to FS	7	3-4	None	None	X	X	X
LGDT	Load global descriptor table	11*	3-4	None	None	X	X	X
LGS	Load local descriptor table	7	3-4	None	None	X	X	X
LIDT	Load interrupt descriptor table	12*	3-4	None	None	X	X	X
LLDT	Load local descriptor table	17,19*	3-4	None	None	X	X	X
LMSW	Load machine status word	3,6*	3-4	None	None	X	X	X
LOCK	Bus lock prefix	0	1	None	None	X	X	X
LODS (rep) sourcestr	Repeat load byte/word/dword	5+4(rep)	1	None	None	X	X	X
LODS sourcestr	Load byte/word/dword	5	1	None	None	X	X	X
LOOP short	Loop	8+bytes or 4	2	None	None	X	X	X
LOOPE/LOOPZ short	Loop equal/zero	8+bytes or 4	2	None	None	X	X	X
LOOPNE/LOOPNZ short	Loop while not equal/not zero	8+bytes or 4	2	None	None	X	X	X

(Continued)

Table 8.02. Continued

Instruction	Function	Clock Cycles**	Bytes***	Flags Affected	Undefined Flags	80386/86	80286	80386
LSL	Load segment limit	14, 16*	3-4	ZF	None		X	X
LSS	Load pointer to SS	7	3-4	None	None		X	X
LTR	Load task register	17, 19*	3-4	None	None		X	X
MOV 16reg,segreg	Move	2	2	None	None	X	X	X
MOV accum,mem***	Move	5	3	None	None	X	X	X
MOV mem,accum***	Move	3	3	None	None	X	X	X
MOV mem,imm	Move	3*	3-6	None	None	X	X	X
MOV mem,reg	Move	3*	2-4	None	None	X	X	X
MOV mem,segreg	Move	3*	2-4	None	None	X	X	X
MOV reg,imm	Move	2	2-3	None	None	X	X	X
MOV reg,mem	Move	5*	2-4	None	None	X	X	X
MOV reg,reg	Move	2	2	None	None	X	X	X
MOV segreg,16mem	Move	5*	2-4	None	None	X	X	X
MOV segreg,16reg	Move	2	2	None	None	X	X	X
MOVS (repeat) desistr,sourcestr	Move string	5+4(rep)	1	None	None	X	X	X
MOVS desistr,sourcestr	Move string	5	1	None	None	X	X	X
MOVSB	Move with sign extension	3, 6	3-4	None	None	X	X	X
MOVZX	Move with zero extension	3, 6	3-4	None	None	X	X	X
MUL 16mem	Multiply	24*	2-4	Overflow, carry	Sign, zero, aux, parity	X	X	X
MUL 16reg	Multiply	21	2-4	Overflow, carry	Sign, zero, aux, parity	X	X	X
MUL 8mem	Multiply	16*	2-4	Overflow, carry	Sign, zero, aux, parity	X	X	X
MUL 8reg	Multiply	13	2-4	Overflow, carry	Sign, zero, aux, parity	X	X	X
NEG mem	Change sign	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
NEG reg	Change sign	2	2	Overflow, sign, zero, aux, parity, carry	None	X	X	X
NOP	No operation	2	1	None	None	X	X	X
NOT mem	Invert	7*	2-4	None	None	X	X	X
NOT reg	Invert	2	2	None	None	X	X	X
OR accum,imm***	Logical OR	3	2-3	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
OR mem,imm	Logical OR	7*	3-6	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
OR mem,reg	Logical OR	7*	2-4	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
OR reg,imm	Logical OR	3	3-6	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
OR reg,mem	Logical OR	7*	2-4	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
OR reg,reg	Logical OR	2	2	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
OUT 8imm,accum	Output to port	3	2	None	None	X	X	X
OUT DX,accum	Output to DX port	3	1	None	None	X	X	X
OUTS (rep) DX,sourcestr	Output string	5+4(rep)	1	None	None	X	X	X
OUTS DX,sourcestr	Output string	5	1	None	None	X	X	X
POP mem	Restore from stack	5*	2-4	None	None	X	X	X
POP reg	Restore from stack	5	1	None	None	X	X	X
POPA	Restore all general registers from stack	19	1	None	None	X	X	X
POPB	Restore flags	5	1	All	None	X	X	X
PUSH imm	Save to stack	3	2-3	None	None	X	X	X
PUSH mem	Save to stack	5*	2-4	None	None	X	X	X
PUSH reg	Save to stack	3	1	None	None	X	X	X
PUSHA	Save all to stack	17	1	None	None	X	X	X
PSHFB	Save flags to stack	3	1	None	None	X	X	X
RCL/RCL/RCL/ROR mem,1	Rotate carry left/carry right/left/right	7*	2-4	Overflow, carry	None	X	X	X
RCL/RCL/RCL/ROR mem,CL	Rotate carry left/carry right/left/right	8*+1 per bit	2-4	Carry	Overflow	X	X	X
RCL/RCL/RCL/ROR mem,count	Rotate carry left/carry right/left/right	8*+1 per bit	3-5	Carry	Overflow	X	X	X
RCL/RCL/RCL/ROR reg,1	Rotate carry left/carry right/left/right	2	2	Overflow, carry	None	X	X	X
RCL/RCL/RCL/ROR reg,CL	Rotate carry left/carry right/left/right	5-1 per bit	2	Carry	Overflow	X	X	X
RCL/RCL/RCL/ROR reg,count	Rotate carry left/carry right/left/right	5-1 per bit	3	Carry	Overflow	X	X	X
REP	Repeat	0	1	None	None	X	X	X
REPE/REPZ	Repeat equal/zero	0	1	None	None	X	X	X
REPNE/REPNZ	Repeat not equal/not zero	0	1	None	None	X	X	X
RET (far, with pop)	Return	15-bytes	3	None	None	X	X	X
RET (far, no pop)	Return	15-bytes	1	None	None	X	X	X

(Continued)

Table 8.02. Continued

Instruction	Function	Clock Cycles**	Bytes***	Flags Affected	Undefined Flags	8088/86	80286	80386
RET (near with pop)	Return	11+bytes	3	None	None	X	X	X
RET (near, no pop)	Return	11+bytes	1	None	None	X	X	X
SAHF	Store AH into flags	2	1	Sign, zero, aux, parity, carry	None	X	X	X
SAL/SAR/SHR/SHR mem,1	Shift arithmetic left/right/arithmetic right/right	7*	2-4	Overflow=0, sign, zero, parity, carry	Zero (SAR/SHR aux only)	X	X	X
SAL/SAR/SHR mem,CL	Shift arithmetic left/left/arithmetic right/right	8*+1 per bit	2-4	Sign, zero, parity, carry (SHR sign=0)	Overflow, zero (SAR/SHR overflow, aux only)	X	X	X
SAL/SAR/SHR mem,count	Shift arithmetic left/left/arithmetic right/right	8*+1 per bit	3-5	Sign, zero, parity, carry (SHR sign=0)	Overflow, zero (SAR/SHR overflow, aux only)	X	X	X
SAL/SAR/SHR reg,1	Shift arithmetic left/left/arithmetic right/right	2	2	Overflow=0, sign, zero, parity, carry	Zero (SAR/SHR aux only)	X	X	X
SAL/SAR/SHR reg,CL	Shift arithmetic left/left/arithmetic right/right	5+1 per bit	2	Sign, zero, parity, carry (SHR sign=0)	Overflow, zero (SAR/SHR overflow, aux only)	X	X	X
SAL/SAR/SHR reg,count	Shift arithmetic left/left/arithmetic right/right	5+1 per bit	3	Sign, zero, parity, carry (SHR sign=0)	Overflow, zero (SAR/SHR overflow, aux only)	X	X	X
SBB accum,imm****	Subtract with borrow	3	2-3	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SBB mem,imm	S:ubtract with borrow	7*	3-6	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SBB mem,reg	Subtract with borrow	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SBB reg,imm	Subtract with borrow	3	3-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SBB reg,mem	Subtract with borrow	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SBB reg,reg	Subtract with borrow	2	2	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SCAS (repeat) destsr	Scan byte/word	5+8(rep)	1	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SCAS destsr	Scan byte/word	7	1	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SET xxx	Conditional byte set	4,5	3-5	None	None	X	X	X
SGDT	Store global descriptor table	11*	3-4	None	None	X	X	X
SIDT	Store interrupt descriptor table	11*	3-4	None	None	X	X	X
SLD	Store local descriptor table	12*	3-4	None	None	X	X	X
SLEA	Store local descriptor table	2,3*	3-4	None	None	X	X	X
SMSW	Store machine status word	2,3*	3-4	None	None	X	X	X
STC/STD/STI	Set carry/direction/interrupt	2	1	Carry=1/DF=1/IF=1	None	X	X	X
STOS (repeat) destsr	Store byte/word	4+3(rep)	1	None	None	X	X	X
STOS destsr	Store byte/word	3	1	None	None	X	X	X
STR	Store task register	2,3*	3-4	None	None	X	X	X
SUB accum,imm****	Subtract	3	2-3	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SUB mem,imm	Subtract	7*	3-6	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SUB mem,reg	Subtract	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SUB reg,imm	Subtract	3	3-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SUB reg,mem	Subtract	7*	2-4	Overflow, sign, zero, aux, parity, carry	None	X	X	X
SUB reg,reg	Subtract	2	2	Overflow, sign, zero, aux, parity, carry	None	X	X	X
TEST accum,imm****	AND function to flags	3	2-3	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
TEST mem,imm	AND function to flags	6*	3-6	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
TEST reg,imm	AND function to flags	3	3-4	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
TEST reg,mem	AND function to flags	6*	2-4	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
TEST reg,reg	AND function to flags	2	2	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
VERW	Verify read access	14,16*	3-4	ZF	None	X	X	X
WAIT	Verify write access	14,16*	3-4	ZF	None	X	X	X
XCHG accum,16reg****	Exchange	3	1	None	None	X	X	X
XCHG mem,reg	Exchange	5*	1	None	None	X	X	X
XCHG reg,reg	Exchange	3	2-4	None	None	X	X	X
XLAT source/label	Translate byte	5	2	None	None	X	X	X
XOR accum,imm****	Exclusive OR	3	1	None	None	X	X	X
XOR mem,imm	Exclusive OR	7*	2-3	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
XOR mem,reg	Exclusive OR	7*	3-6	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
XOR reg,imm	Exclusive OR	3	2-4	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
XOR reg,mem	Exclusive OR	7*	3-4	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X
XOR reg,reg	Exclusive OR	2	2-4	Overflow=0, sign, zero, parity, carry=0	Aux	X	X	X

Legend:

- Reg=register
- Mem=memory
- Accum=accumulator (AL, AX, EAX)
- Imm=immediate
- Destsr=destination string
- Sourcestr=source string
- Segreg=segment register
- Number preceding item indicates number of bits

Flags: EFLAGS is a 32 bit register in the 80386  
 FLAGS (LO word of EFLAGS) is a 16 bit register

(Continued)

Table 8.02. Continued


Bit	Abbr	Name
0	CF	Carry Flag
1		RESERVED
2	PF	Parity flag
3		RESERVED
4	AF	Auxiliary carry flag
5		RESERVED
6	ZF	Zero flag
7	SF	Sign flag
8	TF	Trap flag
9	IF	Interrupt enable
10	DF	Direction flag
11	OF	Overflow
12-13	IOPL	I/O privilege level
14	NT	Nested task flag
15		RESERVED
16	RF	Resume flag (80386 only)
17	VM	Virtual 8086 mode (80386 only)
18-31		RESERVED

- Notes:**
- \*"+Bytes" means plus additional cycle for each byte following instruction.
  - \*\*Uses additional cycle if using base indexed addressing.
  - \*\*Clock cycles vary, depending upon actual CPU used. Timings here are typical for 8088; see your CPU Technical Reference for complete timing considerations.
  - \*\*\*Number of bytes in instruction varies slightly depending on actual CPU used. Bytes shown here are for 8088/8086 except for instructions that are specific to 286 or 386.
  - \*\*\*\*Instructions that use AL, AX, or EAX are faster than equivalent instructions using any other register.

**Source:** *Assembly Language Programming for the IBM PC/AT* (Robert J. Brady Co.), Leo Scanlon, pages 421 to 430  
*Intel Microprocessor and Peripheral Handbook Volume 1*, pages 2-26 to 2-30, 2-55 to 2-59, 2-85 to 2-89, 2-117 to 2-121, 3-46 to 3-53, 4-106 to 4-119  
*Intel 80386 Programmer's Reference Manual*, pages 17-18 to 17-174

8.03. 8086 FAMILY REGISTER SUMMARY

For 8088/8086/80286:



Intel name for register

- Accumulator
- Base
- Count
- Data

SP
BP
SI
DI
IP
CS
DS
SS
ES

- Stack Pointer
- Base Pointer
- Source Index
- Destination Index
- Instruction Pointer
- Status Flags ---->
- Code Segment
- Data Segment
- Stack Segment
- Extra Segment

Bit Numbers


15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
-	NT	IO	PL	OF	DF	IF	TF	SF	ZF	-	AF	-	PF	-	CF

NT=nested task      IF=interrupt flag      AF=auxiliary carry  
 IOPL=I/O privilege level      TF=trap flag      PF=parity flag  
 OF=overflow flag      SF=sign flag      CF=carry flag  
 DF=direction flag      ZF=zero flag

(Continued)

Table 8.03. Continued


For 80386:




Intel name for register

Extended Accumulator  
Extended Base  
Extended Count  
Extended Data

Stack Pointer  
Base Pointer  
Source Index  
Destination Index



Instruction Pointer  
Status Flags ---->



Code Segment  
Stack Segment  
Extra Segment  
Data Segment (1)  
Data Segment (2)  
Data Segment (3)

Bit Numbers for 8086 compatible flags


15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
-	NT	IOPL	OF	DF	IF	TF	SF	ZF	-	AF	-	PF	-	CF	-

NT=nested task      IF=interrupt flag      AF=auxiliary carry  
IOPL=I/O privilege level      TF=trap flag      PF=parity flag  
OF=overflow flag      SF=sign flag      CF=carry flag  
DF=direction flag      ZF=zero flag


Bit Numbers for extended 80386 flags

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RESERVED FOR INTEL ONLY														VM	RF


VM=virtual 8086 mode      RF=resume flag



Machine Control Register (bit 31=paging enable, bit 4=coprocessor extension type, bit 3=task switched, bit 2=emulate coprocessor, bit 1=monitor coprocessor, bit 0=protection enable)  
Page Fault Linear Address (entire 32-bits used for address)  
Page Directory Base Address (bits 12-31 are page directory base register, remaining bits reserved)  
Global Descriptor Table  
Interrupt Descriptor Table  
Local Descriptor Table  
Task State Segment



Debug Register 0 (linear breakpoint address 0)  
Debug Register 1 (linear breakpoint address 1)  
Debug Register 2 (linear breakpoint address 2)  
Debug Register 3 (linear breakpoint address 3)  
Intel Reserved  
Intel Reserved  
Breakpoint status  
Breakpoint Control



Test Control  
Test Status

Notes: 80286 also contains GDT, IDT, LDT, and TSS registers (see 80386 registers)

Source: Intel Microprocessor and Peripheral Handbook Volume 1, pages 2-12, 2-44, 2-97, 3-5 to 3-6, and 4-2 to 4-9

8.04. 8086 FAMILY CPU CHIP VERSIONS

Chip	Clock Speed	Comments
8086	5MHz	16-bit CPU in 40-pin CERDIP or plastic DIP package
8086-1	10MHz	16-bit CPU in 40-pin CERDIP or plastic DIP package
8086-2	8MHz	16-bit CPU in 40-pin CERDIP or plastic DIP package
80C86	5MHz	16-bit CMOS CPU in 40-pin DIP or 44-pin PLCC package
80C86-2	8MHz	16-bit CMOS CPU in 40-pin DIP or 44-pin PLCC package
8088	5MHz	8-bit CPU in 40-pin CERDIP package
8088-2	8MHz	8-bit CPU in 40-pin CERDIP package
80C88	5MHz	8-bit CMOS CPU in 40-pin DIP or 44-pin PLCC package
80C88-2	8MHz	8-bit CMOS CPU in 40-pin DIP or 44-pin PLCC package
80286-6	6MHz	16-bit Protection mode CPU in 68-pin LCC or PGA package
80286-8	8MHz	16-bit Protection mode CPU in 68-pin LCC or PGA package
80286-10	10MHz	16-bit Protection mode CPU in 68-pin LCC or PGA package
80286-12	12.5MHz	16-bit Protection mode CPU in 68-pin LCC or PGA package
80386	16 or 20MHz	32-bit Protection mode CPU in 132 PGA package

Notes: Numbers are Intel numbers only. NEC makes compatible CPUs with numbers like V10, V20, etc.

Source: Intel Microprocessor and Peripheral Handbook Volume 1

See Also: 9.36. 8088 and 8086 Pinouts  
9.37. 80286 Pinouts  
9.38. 80386 Pinouts

8.05. 8087 FAMILY INSTRUCTION SET SUMMARY

Instruction	Function	Clock Cycles	Transfers	Exception Flags Affected	8087	80287	80387
F2XM1	2 <sup>x</sup> ·1	310-630	0	Underflow, Precision	X	X	X
FABS	Absolute value	10 - 17	0	Invalid	X	X	X
FADD dest, source	Add real	70 - 125 + EA	0-6	Invalid, Denormalized, Overflow, Underflow, Precision	X	X	X
FADDP c*st, source	Add real and pop	75 - 105	0	Invalid, Denormalized, Overflow, Underflow, Precision	X	X	X
FBLD source	Packed decimal (BCD) load	290-310+EA	5-7	Invalid	X	X	X
FBSTP	Packed decimal (BCD) store and pop	520-540+EA	6-8	Invalid	X	X	X
FCHS	Change sign	10 - 17	0	Invalid	X	X	X
FCLEX/FNCLX	Clear exceptions	2-8	0	None	X	X	X
FCOM source	Compare real	40 - 75+EA	0-6	Invalid, Denormalized	X	X	X
FCOMP source	Compare real and pop	42-77+EA	0-6	Invalid, Denormalized	X	X	X
FCOMPP	Compare real and pop twice	45-55	0	Invalid, Denormalized	X	X	X
FCOS	Cosine	123-772	0	None	X	X	X
FDECSTP	Decrement stack pointer	6-12	0	None	X	X	X
FDIS/FNDISI	Disable interrupts	2-8	0	None	X	Ignored	Ignored
FDIV dest, source	Divide real	193-230+EA	0-6	Invalid, Denormalized, ZeroDivide, Overflow, Underflow, Precision	X	X	X
FDIVP dest, source	Divide real and pop	197-207	0	Invalid, Denormalized, ZeroDivide, Overflow, Underflow, Precision	X	X	X
FDIVR dest, source	Divide real reversed	194-231+EA	0-6	Invalid, Denormalized, ZeroDivide, Overflow, Underflow, Precision	X	X	X
FDIVRP dest, source	Divide real reversed and pop	198-208	0	Invalid, Denormalized, ZeroDivide, Overflow, Underflow, Precision	X	X	X
FENI/FENI	Enable interrupts	2-8	0	None	X	Ignored	Ignored
FFREE dest	Free register	9-16	0	None	X	X	X
FIADD source	Integer add	102-143+EA	1-4	Invalid, Denormalized, Overflow, Precision	X	X	X
FICOM source	Integer compare	72-91+EA	1-4	Invalid, Denormalized	X	X	X
FICOMP source	Integer compare and pop	74-93+EA	1-4	Invalid, Denormalized	X	X	X
FIDIV source	Integer divide	224-243+EA	1-4	Invalid, Denormalized	X	X	X
FIDIVR source	Integer divide reversed	225-245+EA	1-4	Invalid, Denormalized, ZeroDivide, Overflow, Underflow, Precision	X	X	X
FILD source	Integer load	46-68+EA	1-6	Invalid	X	X	X
FIMUL source	Integer multiply	124-144+EA	1-4	Invalid, Denormalized, Overflow, Precision	X	X	X
FINCSTP	Increment stack pointer	6-12	0	None	X	X	X
FINI/FININT	Initialize processor	2-8	0	None	X	X	X
FIST dest	Integer store	80-92+EA	2-5	Invalid, Precision	X	X	X
FISTP dest	Integer store and pop	82-105+EA	2-7	Invalid, Precision	X	X	X
FISUB source	Integer subtract	102-143+EA	1-4	Invalid, Denormalized, Overflow, Precision	X	X	X
FISUBR source	Integer subtract reversed	103-144+EA	1-4	Invalid, Denormalized, Overflow, Precision	X	X	X
FLD source	Load real	17-65+EA	0-7	Invalid, Denormalized	X	X	X
FLD1	Load +1.0	15-21	0	Invalid	X	X	X
FLDCW source	Load control word	7-14+EA	1-2	None	X	X	X
FILDENV source	Load environment	35-45+EA	7-9	None	X	X	X
FLD2E	Load log (2 <sup>x</sup> e)	15-21	0	Invalid	X	X	X
FLDL2T	Load log (2 <sup>x</sup> *10)	16-22	0	Invalid	X	X	X
FLDLG2	Load log (10 <sup>x</sup> *2)	18-24	0	Invalid	X	X	X
FLDLN2	Load log (e <sup>x</sup> *2)	17-23	0	Invalid	X	X	X
FLDPI	Load pi	16-22	0	Invalid	X	X	X
FLDZ	Load +0.0	11-17	0	Invalid	X	X	X
FMUL dest, source	Multiply real	90-169+EA	0-6	Invalid, Denormalized, Overflow, Underflow, Precision	X	X	X
FMULP dest, source	Multiply real and pop	94-148	0	Invalid, Denormalized, Overflow, Underflow, Precision	X	X	X
FNOP	No operation	10-16	0	None	X	X	X
FPATAN	Partial arctangent	250-800	0	Underflow, Precision	X	X	X
FPREM	Partial remainder (IEEE)	15-190	0	Invalid, Denormalized, Underflow	X	X	X
FPREM1	Partial remainder (IEEE)	95-185	0	Invalid, Denormalized, Underflow	X	X	X
FPTAN	Partial tangent	30-540	0	Invalid, Precision	X	X	X
FRNDINT	Round to integer	16-50	0	Invalid, Precision	X	X	X
FRCR source	Restore save:rd state	205-215+EA	47-49	None	X	X	X

(Continued)

Table 8.05. Continued

Instruction	Function	Clock Cycles	Transfers*	Exception Flags Affected	8087	80287	80387
FSAVE/FNSAVE dest	Save state	205-215+EA	48-50	None	X	X	X
FSCALE	Scale	32-38	0	Invalid, Overflow, Underflow	X	X	X
FSETPM	Enter protected mode	2-8	0	None		X	X
FSIN	Sine	122-771					X
FSINCOS	Sine and cosine	194-809					X
FSQRT	Square root	180-186	0	Invalid, Denormalized, Precision	X	X	X
FST dest	Store real	15-104+EA	0-7	Invalid, Overflow, Underflow, Precision	X	X	X
FSTQ/FNSTQW dest	Store control word	12-18+EA	2-4	None	X	X	X
FSTENV/FNSTENV dest	Store environment	40-50+EA	8-10	None	X	X	X
FSTP dest	Store real and pop	17-58+EA	0-8	Invalid, Overflow, Underflow, Precision	X	X	X
FSTSW/FNSTSW dest	Store status word	12-18+EA	2-4	None	X	X	X
FSUB dest, source	Subtract real	70-125+EA	0-6	Invalid, Denormalized, Overflow, Underflow, Precision	X	X	X
FSUBP dest, source	Subtract real and pop	75-105	0	Invalid, Denormalized, Overflow, Underflow, Precision	X	X	X
FSUBR dest, source	Subtract real reversed	70-125+EA	0-6	Invalid, Denormalized, Overflow, Underflow, Precision	X	X	X
FSUBRP dest, source	Subtract real reversed and pop	75-105	0	Invalid, Denormalized, Overflow, Underflow, Precision	X	X	X
FTST	Test stack top against +0.0	38-48	0	Invalid, Denormalized	X	X	X
FLICOM	Unordered compare	24					X
FUCOMP	Unordered compare and pop	26					X
FUCOMPP	Unordered compare and pop twice	26					X
FWAIT	Wait while 8087 is busy	3+5n**	0	None	X	X	X
FXAM	Examine stack top	12-23	0	None	X	X	X
FXCH dest	Exchange registers	10-15	0	Invalid	X	X	X
EXTRACT	Extract exponent and significand	27-35	0	Invalid	X	X	X
FYL2X	Y * Log <sub>2</sub> (2 <sup>n</sup> *X)	900-1100	0	Precision	X	X	X
FYL2XP1	Y * Log <sub>2</sub> (2 <sup>n</sup> *X+1)	700-1000	0	Precision	X	X	X

**Legend:**

- Dest=destination
- Source=source
- EA=effective address calculation

**Notes:**

- \*\*For 8086 only, 8088 transfers are likely to be higher; 80286 & 80386 are likely to be faster
- \*\*N=number of times CPU examines TEST line while 8087 is busy

**Source:**

8087 Applications and Programming for the IBM PC (Brady Books), Richard Startz, pages 244 to 258  
 Intel Microprocessor and Peripheral Handbook Volume 1, pages 2-140 to 2-143, 3-76 to 3-80, and 4-169 to 4-172

**8.06. 8087 FAMILY REGISTER SUMMARY**

	<----- 80 bits ----->			
	<-- 1 bit -->	<----- 15 bits ----->	<----- 64 bits ----->	<--- 2 bits --->
R0	Sign	Exponent	Significand	Tag field
R1	Sign	Exponent	Significand	Tag field
R2	Sign	Exponent	Significand	Tag field
R3	Sign	Exponent	Significand	Tag field
R4	Sign	Exponent	Significand	Tag field
R5	Sign	Exponent	Significand	Tag field
R6	Sign	Exponent	Significand	Tag field
R7	Sign	Exponent	Significand	Tag field

<----- 16 bits ----->	
Control register	
Status register	
Tag word	
Instruction Pointer*	
Data Pointer*	

**Notes:** \*32-bits in 8087 and 80287, 48 bits in 80387

**Source:** Intel Microprocessor and Peripheral Handbook Volume 1, pages 2-125, 3-64, and 4-139

**8.07. 8087 FAMILY CHIP VERSIONS**

Chip	Clock Speed	Comments
8087	5MHz	In 40-pin Cerdip or plastic DIP package
8087-1	10MHz	In 40-pin Cerdip or plastic DIP package
8087-2	8MHz	In 40-pin Cerdip or plastic DIP package
80287-3	3MHz	In 40-pin DIP package
80287-6	6MHz	In 40-pin DIP package
80287-8	8MHz	In 40-pin DIP package
80287-10	10MHz	In 40-pin DIP package
80387	16MHz	In 68-pin PGA package

**Notes:** Numbers are Intel numbers only.

**Source:** Intel Microprocessor and Peripheral Handbook Volume 1

**See Also:** 9.39. 8087 (Coprocesor) Pinouts  
 9.40. 80287 (Coprocesor) Pinouts  
 9.41. 80387 (Coprocesor) Pinouts

## 8.08. 8250 I/O PORT USAGE (REGISTERS)

I/O Port	Register	Direction	Comments
3F8H	Transmit data	Output	Only if line control register bit 7 is 0
	Receive data	Input	Only if line control register bit 7 is 0
	Baud rate divisor LO byte		Only if line control register bit 7 is 1
3F9H	Baud rate divisor HO byte		Only if line control register bit 7 is 1
	Interrupt enable		Only if line control register bit 7 is 0
3FAH	Interrupt ID		
3FBH	Line control		
3FCH	Modem control		
3FDH	Line status		
3FEH	Modem status		

**Source:** *The IBM PC From the Inside Out* (Addison Wesley), Sargent & Shoemaker, Page 367

**See Also:** 4.063. INT 14H, Modem Status Byte  
 4.064. INT 14H, Com Port Parameter Byte  
 7.36. Line Control Register  
 7.37. Divisor Latch Register  
 7.38. Line Status Register  
 7.39. Interrupt Identification Register  
 7.40. Interrupt Enable Register  
 7.41. Modem Control Register  
 7.42. Modem Status Register  
 8.09. 8253 I/O Port Usage (Registers)

## 8.09. 8253 I/O PORT USAGE (REGISTERS)

I/O Port	Register	Direction*	Comments
40H	Timer 0	Output	
41H	Timer 1	Output	
42H	Timer 2	Output	
43H	Control word	Input	See 8.10. 8253 Control Word Byte

**Source:** *The IBM PC From the Inside Out* (Addison Wesley), Sargent & Shoemaker, pages 2-117 to 2-121, 3-46 to 3-53, 4-106 to 4-119

**See Also:** 8.10. 8253 Control Word Byte

## 8.10. 8253 CONTROL WORD BYTE

## Bit Numbers

7	6	5	4	3	2	1	0	Function	Allowable Values
X	X							Timer number	00=timer 0, 01=timer 1, 10=timer 2
		X	X					Latch, read format	00=latch current count, 01=read low byte (no latching) 10=read high byte (no latching), 11=read low, then high byte
				X	X	X		Mode number	000=interrupt on terminal count 001=programmable one-shot 010=rate generator 011=square wave generator 100=software triggered strobe 101=hardware triggered strobe
							X	Count type	0=binary, 1=BCD

**Source:** *The IBM PC From the Inside Out* (Addison Wesley), Sargent & Shoemaker, pages 241 to 242

**See Also:** 8.09. 8253 I/O Port Usage (Registers)

**8.11. 8253 COMMAND REGISTER BYTE**

*Bit Numbers*

7	6	5	4	3	2	1	0	Function	Comments
X	X							Select counter	00=Counter 0, 01=Counter 1 10=Counter 2, 11=Illegal
		X	X					Read/load	00=counter latch op, 11=read/load LSB, then MSB 10=read/load MSB, 01=read/load LSB
				X	X	X		Mode	000=0, 001=1, X10=2, X11=3, 100=4, 101=5
							X	BCD	0=binary counter, 1=BCD counter (4 decades)

**Source:** Intel Microprocessor and Peripheral Handbook, Volume 2, page 2-17

**See Also:** 9.47. 8253 (Programmable Interval Controller) Pinouts

**8.12. 6845 REGISTERS**

Register	Function	Unit	CGA 40x25	CGA 80x25	CGA graphics	MDA 80x25
R0	Horizontal total	Chars	38	71	38	61
R1	Horizontal displayed	Chars	28	50	28	50
R2	Horizontal sync position	Chars	2D	5A	2D	52
R3	Horizontal sync width	Chars	A	A	A	F
R4	Vertical total	Char rows	1F	1F	7F	19
R5	Vertical total adjust	Scan lines	6	6	6	6
R6	Vertical displayed	Char rows	19	19	64	19
R7	Vertical sync position	Char rows	1C	1C	70	19
R8	Interlace mode		2	2	2	2
R9	Max scan line address	Scan lines	7	7	1	D
R10	Cursor start	Scan lines	6	6	6	B
R11	Cursor end	Scan lines	7	7	7	C
R12	Start address high		0	0	0	0
R13	Start address low		0	0	0	0
R14	Cursor high					0
R15	Cursor low					0
R16	Light pen high					
R17	Light pen low					

**Notes:** Except for register numbers, all values are in hex

**Source:** IBM Technical Reference Options and Adapters, pages MDA 5 and CGA 17

**See Also:** 8.13. 6845 Port and Select Factors  
9.43. 6845 (Video Controller) Pinouts

8.13. 6845 PORT AND SELECT FACTORS

Bit Numbers		0	1	2	3	4	5	6	7	Register	Function	Comments
X	X				X	X	X			Color Select (CGA=3D9)	Not used Active color set 320x200 Intensity/background Intensity Red Green Blue	00=set 1 (green/red/brown), 01=set 2 (cyan/magenta/white) Intensity in graphics, background color in alphanumeric mode Intense border in 40x25, intense background in 320x200, intense foreground in 640x200 Red border in 40x25, red background in 320x200, red foreground in 640x200 Green border in 40x25, green background in 320x200, green foreground in 640x200 Blue border in 40x25, blue background in 320x200, blue foreground in 640x200
				X	X	X	X			Mode Cntrl (CGA=3D8)	Blink 640x200 Video enable/disable Color/mono Mode Mode	0=no blink, 1=blink (in text modes) 1=select 640x200 B/W graphics 0=disable, 1=enable video 0=color mode, 1=monochrome mode 0=text, 1=320x200 graphics mode 0=40x25 text, 1=80x25 text
			X	X	X					Status (CGA=3DA)	Retrace Light pen Light pen Regen-buffer	1=raster is in vertical retrace mode 0=light pen switch on, 1=light pen switch off 1=light pen trigger set 1=regen-buffer memory access can be made without interfering with display
			X	X	X					Status (MDA=3BA)	B/W video RESERVED RESERVED Horizontal drive	
X	X		X	X	X	X	X			Control (MDA=3B8)	NOT USEU Enable blink Enable video High resolution mode	1=enabled 1=enabled

Source: IBM Technical Reference Options and Adapters, pages CGA 18-21, MDA 8

See Also: 8.12. 6845 Registers  
9.43. 6845 (Video Controller) Pinouts

**8.14. AT J18 RAM JUMPER**

Pin Number	Signal Name
1	No connection
2	-RAM SEL
3	Ground

**Notes:**

- Connector is a 3-pin keyed Berg-strip connector (keyed on pin 3)
- To enable 2nd 256K on system board jumper pins 1 and 2
- To disable 2nd 256K on system board jumper pins 2 and 3

**Source:** IBM PC/AT Technical Reference, pages 1-40 to 1-41

**8.15. AT DISPLAY SWITCH (SW1)**

Switch Number	Function	Settings
1	Display type	ON=CGA, EGA, or PGA is primary display OFF=MDA or EGA is primary display

**Notes:** ON is toward front of the machine

**Source:** IBM PC/AT Technical Reference, page 1-41

**8.16. PC SYSTEM BOARD SWITCH SETTINGS**

**For Switch 1:**

Switch Number	Function	Settings
1	Number of drives	ON=drives installed; OFF=no drives (see switch 7/8)
2	Not used (PC1)	Must be ON (PC1)
3 & 4	Memory on system board	ON ON = 16K (PC1) or 64K (PC2) OFF ON = 32K (PC1) or 128K (PC2) ON OFF = 48K (PC1) or 192K (PC2) OFF OFF = 64K (PC1) or 256K (PC2)
5 & 6	Display adapter	ON ON = no adapter OFF ON = CGA, 40-columns ON OFF = CGA, 80 columns OFF OFF = MDA, or more than one adapter
7 & 8	Floppy drives	ON ON = 1 drive OFF ON = 2 drives ON OFF = 3 drives OFF OFF = 4 drives

**For Switch 2:**

Switch Number	Function	Settings
1 through 5	Memory installed	ON ON ON ON ON = 16-64K* OFF ON ON ON ON = 96K** ON OFF ON ON ON = 128K** OFF OFF ON ON ON = 160K** ON ON OFF ON ON = 192K** OFF ON OFF ON ON = 224K** ON OFF OFF ON ON = 256K** OFF OFF OFF ON ON = 288K** ON ON ON OFF ON = 320K** OFF ON ON OFF ON = 352K** ON OFF ON OFF ON = 384K** OFF OFF ON OFF ON = 416K** ON ON OFF OFF ON = 448K** OFF ON OFF OFF ON = 480K** ON OFF OFF OFF ON = 512K** OFF OFF OFF OFF ON = 544K** ON ON ON ON OFF = 576K** OFF ON ON ON OFF = 608K** ON OFF ON ON OFF = 640K**
6 - 8	NOT USED	Must be OFF (Switch 7 reserved for 8087 on PC2)

**Notes:**

- \*SW1 switches 3 & 4 control total memory
- \*\*SW1 switches 3 & 4 should be OFF

**Source:** IBM PC Guide to Operations, Pages Options 6 to 24

**See Also:** 8.17. XT System Board Switch Settings

8.17. XT SYSTEM BOARD SWITCH SETTINGS

Switch Number	Function	Settings
1	Test	ON=loops on POST routine; OFF=normal operation
2	Coprocessor	ON=8087 installed; OFF=no 8087
3 & 4	System board RAM	ON ON = 64K OFF ON = 128K ON OFF = 192K OFF OFF = 256K
5 & 6	Display adapter	ON ON = no adapter OFF ON = CGA, 40-columns ON OFF = CGA, 80 columns OFF OFF = MDA, or more than one adapter
7 & 8	Floppy drives	ON ON = 1 drive OFF ON = 2 drives ON OFF = 3 drives OFF OFF = 4 drives

**Notes:** Normal switch setting would be OFF OFF OFF OFF OFF OFF ON ON (256K, 1 floppy, MDA)

**Source:** IBM PC/XT Technical Reference, pages 1-13 to 1-14

8.18. PC AND XT FLOPPY DISK CONTROLLER COMMAND SUMMARY

Command Name	Command Sequence	Direction	Comments	Bit Numbers							
				7	6	5	4	3	2	1	0
Read Data	Command code byte 1	Write	See bit mask at right	MT	MF	SK	0	0	1	1	0
	Command code byte 2	Write	See bit mask at right	*	*	*	*	*	HD	US1	US0
	Start cylinder	Write									
	Start head	Write									
	Start sector number	Write									
	Number bytes/sector	Write	Usually 512								
	Last sector on cylinder	Write									
	Gap length	Write	Usually 3								
	Data length	Write	Used if number/bytes sector is 0								
	Status register 0	Read	See 8.19. FDC Status Register 0								
	Status register 1	Read	See 8.20. FDC Status Register 1								
	Status register 2	Read	See 8.21. FDC Status Register 2								
	Current cylinder	Read	Location after read								
	Current head	Read	Location after read								
Current sector number	Read	Location after read									
Number bytes/sector	Read										
Read Deleted Data	Command code byte 1	Write	See bit mask at right	MT	MF	SK	0	1	1	0	0
	Command code byte 2	Write	See bit mask at right	*	*	*	*	*	HD	US1	US0
	Start cylinder	Write									
	Start head	Write									
	Start sector number	Write									
	Number bytes/sector	Write	Usually 512								
	Last sector on cylinder	Write									
	Gap length	Write	Usually 3								
	Data length	Write	Used if number/bytes sector is 0								
	Status register 0	Read	See 8.19. FDC Status Register 0								
	Status register 1	Read	See 8.20. FDC Status Register 1								
	Status register 2	Read	See 8.21. FDC Status Register 2								
	Current cylinder	Read	Location after read								
	Current head	Read	Location after read								
Current sector number	Read	Location after read									
Number bytes/sector	Read										
Write Data	Command code byte 1	Write	See bit mask at right	MT	MF	0	0	0	1	0	1
	Command code byte 2	Write	See bit mask at right	*	*	*	*	*	HD	US1	US0
	Start cylinder	Write									
	Start head	Write									
	Start sector number	Write									
	Number bytes/sector	Write	Usually 512								
	Last sector on cylinder	Write									
	Gap length	Write	Usually 3								
	Data length	Write	Used if number/bytes sector is 0								
	Status register 0	Read	See 8.19. FDC Status Register 0								
	Status register 1	Read	See 8.20. FDC Status Register 1								
	Status register 2	Read	See 8.21. FDC Status Register 2								
	Current cylinder	Read	Location after write								
	Current head	Read	Location after write								
Current sector number	Read	Location after write									
Number bytes/sector	Read										
Write Deleted Data	Command code byte 1	Write	See bit mask at right	MT	MF	0	0	1	0	0	1
	Command code byte 2	Write	See bit mask at right	*	*	*	*	*	HD	US1	US0
	Start cylinder	Write									
	Start head	Write									
	Start sector number	Write									
	Number bytes/sector	Write	Usually 512								

(Continued)

Table 8.18. Continued

Command Name	Command Sequence	Direction	Comments	Bit Numbers							
				7	6	5	4	3	2	1	0
Write Deleted Data	Last sector on cylinder	Write	Usually 3 Used if number/bytes sector is 0 See 8.19. FDC Status Register 0 See 8.20. FDC Status Register 1 See 8.21. FDC Status Register 2 Location after write Location after write Location after write								
	Gap length	Write									
	Data length	Write									
	Status register 0	Read									
	Status register 1	Read									
	Status register 2	Read									
	Current cylinder	Read									
	Current head	Read									
	Current sector number	Read									
Number bytes/sector	Read										
Read Track	Command code byte 1	Write	See bit mask at right See bit mask at right Usually 512 Usually 3 Used if number/bytes sector is 0 See 8.19. FDC Status Register 0 See 8.20. FDC Status Register 1 See 8.21. FDC Status Register 2 Location after read Location after read Location after read	0	MF	SK	0	0	0	1	0
	Command code byte 2	Write		*	*	*	*	*	HD	US1	US0
	Start cylinder	Write									
	Start head	Write									
	Start sector number	Write									
	Number bytes/sector	Write									
	Last sector on cylinder	Write									
	Gap length	Write									
	Data length	Write									
	Status register 0	Read									
	Status register 1	Read									
	Status register 2	Read									
	Current cylinder	Read									
	Current head	Read									
	Current sector number	Read									
Number bytes/sector	Read										
Read ID	Command code byte 1	Write	See bit mask at right See bit mask at right See 8.19. FDC Status Register 0 See 8.20. FDC Status Register 1 See 8.21. FDC Status Register 2 Location after read Location after read Location after read	0	MF	0	0	1	0	1	0
	Command code byte 2	Write		*	*	*	*	*	HD	US1	US0
	Status register 0	Read									
	Status register 1	Read									
	Status register 2	Read									
	Current cylinder	Read									
	Current head	Read									
	Current sector number	Read									
	Number bytes/sector	Read									
Format Track	Command code byte 1	Write	See bit mask at right See bit mask at right Usually 512 Usually 9 Usually 3 Data pattern to initialize sectors See 8.19. FDC Status Register 0 See 8.20. FDC Status Register 1 See 8.21. FDC Status Register 2 No meaning in this context No meaning in this context No meaning in this context No meaning in this context	0	MF	0	0	1	1	0	0
	Command code byte 2	Write		*	*	*	*	*	HD	US1	US0
	Bytes/sector	Write									
	Sectors per cylinder	Write									
	Gap length	Write									
	Filler byte	Write									
	Status register 0	Read									
	Status register 1	Read									
	Status register 2	Read									
	Current cylinder	Read									
	Current head	Read									
Current sector number	Read										
Number bytes/sector	Read										
Scan Equal	Command code byte 1	Write	See bit mask at right See bit mask at right Usually 512 Usually 3 1=compare contiguous, 2=compare alternate See 8.19. FDC Status Register 0 See 8.20. FDC Status Register 1 See 8.21. FDC Status Register 2 Location after scan Location after scan Location after scan	MT	MF	SK	.1	0	0	0	1
	Command code byte 2	Write		*	*	*	*	*	HD	US1	US0
	Start cylinder	Write									
	Start head	Write									
	Start sector number	Write									
	Number bytes/sector	Write									
	Last sector on cylinder	Write									
	Gap length	Write									
	Scan test code	Write									
	Status register 0	Read									
	Status register 1	Read									
	Status register 2	Read									
	Current cylinder	Read									
	Current head	Read									
	Current sector number	Read									
Number bytes/sector	Read										
Scan Low or Equal	Command code byte 1	Write	See bit mask at right See bit mask at right Usually 512 Usually 3 1=compare contiguous, 2=compare alternate See 8.19. FDC Status Register 0 See 8.20. FDC Status Register 1 See 8.21. FDC Status Register 2 Location after scan Location after scan Location after scan	MT	MF	SK	1	1	0	0	1
	Command code byte 2	Write		*	*	*	*	*	HD	US1	US0
	Start cylinder	Write									
	Start head	Write									
	Start sector number	Write									
	Number bytes/sector	Write									
	Last sector on cylinder	Write									
	Gap length	Write									
	Scan test code	Write									
	Status register 0	Read									
	Status register 1	Read									
	Status register 2	Read									
	Current cylinder	Read									
	Current head	Read									
	Current sector number	Read									
Number bytes/sector	Read										

(Continued)

Table 8.18. Continued

Command Name	Command Sequence	Direction	Comments	Bit Numbers							
				7	6	5	4	3	2	1	0
Scan High or Equal	Command code byte 1	Write	See bit mask at right	MT	MF	SK	1	1	1	0	1
	Command code byte 2	Write	See bit mask at right	*	*	*	*	*	HD	US1	US0
	Start cylinder	Write	Usually 512								
	Start head	Write									
	Start sector number	Write									
	Number bytes/sector	Write									
	Last sector on cylinder	Write									
	Gap length	Write		Usually 3							
	Scan test code	Write		1=compare contiguous, 2=compare alternate							
	Status register 0	Read		See 8.19. FDC Status Register 0							
	Status register 1	Read		See 8.20. FDC Status Register 1							
	Status register 2	Read		See 8.21. FDC Status Register 2							
	Current cylinder	Read		Location after scan							
	Current head	Read		Location after scan							
Current sector number	Read	Location after scan									
Number bytes/sector	Read										
Recalibrate	Command code byte 1	Write	See bit mask at right	0	0	0	0	0	1	1	1
	Command code byte 2	Write	See bit mask at right	*	*	*	*	*	0	US1	US0
Sense Int Status	Command code byte 1	Write	See bit mask at right	0	0	0	0	1	0	0	0
	Status register 0	Read	See 8.19. FDC Status Register 0								
	Present cylinder number	Read									
Specify	Command code byte 1	Write	See bit mask at right	0	0	0	0	0	0	1	1
	Command code byte 2	Write	HO=Step Rate Time, LO=Head Unload Time	SRT	SRT	SRT	SRT	HUT	HUT	HUT	HUT
	Command code byte 3	Write	Bits 1-7=Head Load Time, Bit 0=non-DMA	HLT	HLT	HLT	HLT	HLT	HLT	ND	ND
Sense Drive Status	Command code byte 1	Write	See bit mask at right	0	0	0	0	0	1	0	0
	Command code byte 2	Write	See bit mask at right	*	*	*	*	*	HD	US1	US0
	Status register 3	Read	See 8.22. FDC Status Register 3								
Seek	Command code byte 1	Write	See bit mask at right	0	0	0	0	1	1	1	1
	Command code byte 2	Write	See bit mask at right	*	*	*	*	*	HD	US1	US0
	Cylinder to seek	Write									
Invalid	Any invalid code	Write									
	Status register 0	Read	See 8.19. FDC Status Register 0								

**Legend:** \* = Value ignored, may be 1 or 0  
 MT = multitrack operation (high=TRUE)  
 MF = FM mode (high=MF, low=FM)  
 SK = skip deleted data address mark  
 HD = head number  
 US0 = unit select zero  
 US1 = unit select one

**Notes:** The terms "track" and "cylinder" are incorrectly used interchangeably in the IBM documentation.

**Source:** IBM PC/XT Technical Reference, pages 1-112 to 1-119

**See Also:** 8.19. PC and XT Floppy Disk Controller Status Register 0  
 8.20. PC and XT Floppy Disk Controller Status Register 1  
 8.21. PC and XT Floppy Disk Controller Status Register 2  
 8.22. PC and XT Floppy Disk Controller Status Register 3  
 8.24. XT Fixed Disk Controller Command Summary

**8.19. PC AND XT FLOPPY DISK CONTROLLER STATUS REGISTER 0**

Bit Numbers								Name	Function	Allowable Values
7	6	5	4	3	2	1	0			
X	X							Interrupt Code	Reports status due to last command	00=normal termination 01=abnormal termination 10=invalid command issued 11=abnormal termination due to change in ready state
		X						Seek end	Reports completion of seek op.	1=seek operation completed
			X					Equipment check	Set when fault received from FDD	(Also set when recalibrate fails to find track 0)
				X				Not ready	Reports FDD is not in ready state	1=not ready
					X			Head address	Reports state of head at interrupt	0=0 head, 1=1 head
						X	X	Unit select	Reports selected unit at interrupt	Bit 0=unit select 2, bit 1=unit select 1

**Source:** IBM PC/XT Technical Reference, page 1-120

**See Also:** 8.18. PC and XT Floppy Disk Controller Command Summary  
 8.20. PC and XT Floppy Disk Controller Status Register 1  
 8.21. PC and XT Floppy Disk Controller Status Register 2  
 8.22. PC and XT Floppy Disk Controller Status Register 3  
 8.24. XT Fixed Disk Controller Command Summary

8.20. PC AND XT FLOPPY DISK CONTROLLER STATUS REGISTER 1

Bit Numbers		7	6	5	4	3	2	1	0	Name	Function	Allowable Values
X										End of cylinder	Reports movement past last track	Set if FDC tries to access sector beyond final sector
	X									NOT USED		Always 0
		X								Data error	Reports CRC error in ID or data field	1=error, 0=no error
			X							Overrun	Reports FDC not serviced	1=FDC not serviced during data transfer within time limit
				X						NOT USED		Always 0
					X					No data	Reports FDD is not in ready state	1=error, 0=no error
						X				Not writable	Reports cannot find sector or ID	1=error, 0=no error
							X			Missing address mark	Reports write protect signal from FDD	1=write protect during write op., 0=no error
								X		Missing address mark	Reports FDC didn't find address mark	1=missing address mark, 0=no error

Source: IBM PC/XT Technical Reference, page 1-121

See Also:

- 8.18. PC and XT Floppy Disk Controller Command Summary
- 8.19. PC and XT Floppy Disk Controller Status Register 0
- 8.21. PC and XT Floppy Disk Controller Status Register 2
- 8.22. PC and XT Floppy Disk Controller Status Register 3
- 8.24. XT Fixed Disk Controller Command Summary

8.21. PC AND XT FLOPPY DISK CONTROLLER STATUS REGISTER 2

Bit Numbers		7	6	5	4	3	2	1	0	Name	Function	Allowable Values
X										NOT USED		Always 0
	X									Control mark	Reports deleted data address mark	1=deleted mark detected during read or scan, 0=no error
		X								Data error in data field	Reports CRC error in data	1=CRC error in data field, 0=no error
			X							Wrong cylinder	Track contents don't match track ID	1=error, 0=no error
				X						Scan equal hit	Reports scan found equal condition	1=scan equal, 0=scan not equal
					X					Scan not satisfied	Reports scan not satisfied condition	1=scan not satisfied, 0=scan satisfied
						X				Bad cylinder	Track contents don't match, FFH found	1=error, 0=no error
							X			Missing address in data field	Reports FDC couldn't find mark	1=couldn't find address mark, 0=no error

Source: IBM PC/XT Technical Reference, page 1-122

See Also:

- 8.18. PC and XT Floppy Disk Controller Command Summary
- 8.19. PC and XT Floppy Disk Controller Status Register 0
- 8.20. PC and XT Floppy Disk Controller Status Register 1
- 8.22. PC and XT Floppy Disk Controller Status Register 3
- 8.24. XT Fixed Disk Controller Command Summary

8.22. PC AND XT FLOPPY DISK CONTROLLER STATUS REGISTER 3

Bit Numbers

7	6	5	4	3	2	1	0	Name	Function	Allowable Values
X								Fault	FDD fault signal status	1=FDD fault, 0=no fault
	X							Write protected	FDD write protected status	1=write protected, 0=not protected
		X						Ready	FDD ready status	1=disk drive ready, 0=not ready
			X					Track 0	FDD at track zero signal	1=FDD is at track 0, 0=not at track 0
				X				Two sided	FDD two-sided media signal	1=two-sided media, 0=one-sided media
					X			Head address	FDD head selected	1=head 1, 0=head 0
						X		Unit select 1	FDD unit select 1 status	
							X	Unit select 0	FDD unit select 0 status	

Source: IBM PC/XT Technical Reference, page 1-123

- See Also:
- 8.18. PC and XT Floppy Disk Controller Command Summary
  - 8.19. PC and XT Floppy Disk Controller Status Register 0
  - 8.20. PC and XT Floppy Disk Controller Status Register 1
  - 8.21. PC and XT Floppy Disk Controller Status Register 2
  - 8.24. XT Fixed Disk Controller Command Summary

8.23. PC AND XT FDC DISK PROGRAM CONTROL REGISTERS

Register Name	I/O Address
Data register	3F5H
Main status register	3F4H
Digital output register	3F2H

Digital Output Register:

Bit Numbers

7	6	5	4	3	2	1	0	Name	Allowable Values
					X	X		Drive select	00=A, 01=B, 10=C, 11=D
						X		Not FDC reset	
			X					Enable INT & DMA requests	
				X				Drive A motor enable	1=motor on, 0=motor off
		X						Drive B motor enable	1=motor on, 0=motor off
	X							Drive C motor enable	1=motor on, 0=motor off
X								Drive D motor enable	1=motor on, 0=motor off

Source: IBM PC/XT Technical Reference, page 1-123

- See Also:
- 8.18. PC and XT Floppy Disk Controller Command Summary
  - 8.24. XT Fixed Disk Controller Command Summary

8.24. XT FIXED DISK CONTROLLER COMMAND SUMMARY

Command Name	Command Sequence	Direction	Bit Numbers								
			7	6	5	4	3	2	1	0	
Test Drive Ready	Command code byte 1	Write	0	0	0	0	0	0	0	0	0
	Command code byte 2	Write	0	0	DR	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
Recalibrate	Command code byte 1	Write	0	0	0	0	0	0	0	0	1
	Command code byte 2	Write	0	0	DR	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Command Code Byte 6	Write	RT	0	0	0	0	0	Step option		
Request sense status	Command code byte 1	Write	0	0	0	0	0	0	1	1	1
	Command code byte 2	Write	0	0	DR	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
Format drive	Command code byte 1	Write	0	0	0	0	0	1	0	0	
	Command code byte 2	Write	0	0	DR	Head number					
	Command code byte 3	Write	Hi cylinder	0	0	0	0	0	0	0	
	Command code byte 4	Write	Lo cylinder (cylinder=10 bit value)								
	Command code byte 5	Write	0	0	0	Interleave factor (1-16)					
	Command code byte 6	Write	RT	0	0	0	0	Step option			

(Continued)

Table 8.24. Continued

Command Name	Command Sequence	Direction	Bit Numbers								
			7	6	5	4	3	2	1	0	
Ready verify	Command code byte 1	Write	0	0	0	0	0	0	1	0	1
	Command code byte 2	Write	0	0	DR	Head number					
	Command code byte 3	Write	Hi cylinder		Sector number						
	Command code byte 4	Write	Lo cylinder (cylinder=10 bit value)								
	Command code byte 5	Write	Block count								
	Command code byte 6	Write	RT	RTO	0	0	0	Step option			
Format track	Command code byte 1	Write	0	0	0	0	0	0	1	1	0
	Command code byte 2	Write	0	0	DR	Head number					
	Command code byte 3	Write	Hi cylinder		Sector number						
	Command code byte 4	Write	Lo cylinder (cylinder=10 bit value)								
	Command code byte 5	Write	0	0	0	Interleave factor (1-16)					
	Command code byte 6	Write	RT	0	0	0	0	0	Step option		
Format bad track	Command code byte 1	Write	0	0	0	0	0	0	1	1	1
	Command code byte 2	Write	0	0	DR	Head number					
	Command code byte 3	Write	Hi cylinder		Sector number						
	Command code byte 4	Write	Lo cylinder (cylinder=10 bit value)								
	Command code byte 5	Write	0	0	0	Interleave factor (1-16)					
	Command code byte 6	Write	RT	0	0	0	0	0	Step option		
Read	Command code byte 1	Write	0	0	0	0	0	1	0	0	0
	Command code byte 2	Write	0	0	DR	Head number					
	Command code byte 3	Write	Hi cylinder		Sector number						
	Command code byte 4	Write	Lo cylinder (cylinder=10 bit value)								
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Command code byte 6	Write	RT	RTO	0	0	0	Step option			
Write	Command code byte 1	Write	0	0	0	0	1	0	1	0	0
	Command code byte 2	Write	0	0	DR	Head number					
	Command code byte 3	Write	Hi cylinder		Sector number						
	Command code byte 4	Write	Lo cylinder (cylinder=10 bit value)								
	Command code byte 5	Write	Block count								
	Command code byte 6	Write	RT	0	0	0	0	Step option			
Seek	Command code byte 1	Write	0	0	0	0	1	0	1	1	1
	Command code byte 2	Write	0	0	DR	Head number					
	Command code byte 3	Write	Hi cylinder		Sector number						
	Command code byte 4	Write	Lo cylinder (cylinder=10 bit value)								
	Command code byte 5	Write	*	*	*	*	*	*	*	*	*
	Command code byte 6	Write	RT	0	0	0	0	Step option			
Init drive characteristics	Command code byte 1	Write	0	0	0	0	1	1	0	0	0
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	HO max number of cylinders	Write									
	LO max number of cylinders	Write									
	Max number of heads	Write									
	HO reduced write cylinder	Write									
	LO reduced write cylinder	Write									
	HO write precomp cylinder	Write									
LO write precomp cylinder	Write										
Max ECC data burst length	Write										
Read ECC Burst	Command code byte 1	Write	0	0	0	0	1	1	0	1	1
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
Read Data from Sector Buffer	Command code byte 1	Write	0	0	0	0	1	1	1	0	0
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
Write data to sector buffer	Command code byte 1	Write	0	0	0	0	1	1	1	1	1
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*	*

(Continued)

Table 8.24. Continued

Command Name	Command Sequence	Direction	Bit Numbers							
			7	6	5	4	3	2	1	0
RAM diagnostic	Command code byte 1	Write	1	1	1	0	0	0	0	0
	Don't care	Write	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*
Drive diagnostic	Command code byte 1	Write	1	1	1	0	0	0	1	1
	Command code byte 2	Write	0	0	DR	*	*	*	*	*
	Command code byte 3	Write	*	*	*	*	*	*	*	*
	Command code byte 4	Write	*	*	*	*	*	*	*	*
	Command code byte 5	Write	*	*	*	*	*	*	*	*
	Command code byte 6	Write	RT	0	0	0	0	Step option		
Controller internal diagnostics	Command code byte 1	Write	1	1	1	0	0	1	0	0
	Don't care	Write	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*
	Don't care	Write	*	*	*	*	*	*	*	*
Read long (sector plus 4 bytes of ECC data)	Command code byte 1	Write	1	1	1	0	0	1	0	1
	Command code byte 2	Write	0	0	DR	Head number				
	Command code byte 3	Write	Hi cylinder		Sector number					
	Command code byte 4	Write	Lo cylinder (cylinder = 10 bits)							
	Command code byte 5	Write	Block count							
	Command code byte 6	Write	RT	0	0	0	0	Step option		
Write long (sector plus 4 bytes of ECC data)	Command code byte 1	Write	1	1	1	0	0	1	1	0
	Command code byte 2	Write	0	0	DR	Head number				
	Command code byte 3	Write	Hi cylinder		Sector number					
	Command code byte 4	Write	Lo cylinder (cylinder = 10 bits)							
	Command code byte 5	Write	Block count							
	Command code byte 6	Write	RT	0	0	0	0	Step option		

**Legend:** DR = drive (0 or 1)  
 RT = retries  
 RTO = retry option on data ECC

**Notes:** The terms "track" and "cylinder" are incorrectly used interchangeably in the IBM documentation.

**Source:** IBM PC/XT Technical Reference, pages 1-143 to 1-146

**See Also:** 8.18. PC and XT Floppy Disk Controller Command Summary

**8.25. XT FIXED DISK CONTROLLER PORT USAGE**

Port	Direction	Function
320H	Controller to system	Read data
320H	System to controller	Write data
321H	Controller to system	Read controller hardware status
321H	System to controller	Reset controller
322H	Controller to system	RESERVED
322H	System to controller	Generate controller-select pulse
323H	Controller to system	NOT USED
323H	System to controller	Write pattern to DMA and INT mask register

**Source:** IBM PC/XT Technical Reference, page 1-147

**See Also:** 7.03. I/O Port Usage Summary

**8.26. XT FIXED DISK CONTROLLER DEVICE CONTROL BLOCK**

Byte	Bit Numbers								Name	Allowable Values
	7	6	5	4	3	2	1	0		
Byte 0	X	X	X						Command class	000 and 111 are only values used
				X	X	X	X	X	Command opcode	00000=test drive ready 00001=recalibrate 00010=RESERVED 00011=request sense status 00100=format drive 00101=ready verify 00110=format track 00111=format bad track 01000=read 01001=RESERVED 01010=write 01011=seek 01100=initialize drive 01101=read ECC burst error length 01110=read data from sector buffer 01111=write data to sector buffer
Byte 1	0	0							Always zero	
			X						Drive number	
Byte 2				X	X	X	X	X	Head number	
	X	X							Hi order 2 bits of cylinder #	
Byte 3	X	X	X	X	X	X	X	X	Sector number	
Byte 4	X	X	X	X	X	X	X	X	Lo order 8 bits of cylinder #	
Byte 5	X	X	X	X	X	X	X	X	Interleave or block count	Interleave must be 0-16
Byte 5	X								Retries	1=disables 4 retries by controller during ops
		X							Retry option on data ECC error	1=no rereads; 0=reread attempted
			0	0	0				Always zero	
						X	X	X	Step option	000=3 milliseconds per step 001=NOT USED 010=NOT USED 011=NOT USED 100=200 microseconds per step 101=70 microseconds per step (BIOS setting) 110=3 milliseconds per step 111=3 milliseconds per step

**Source:** IBM PC/XT Technical Reference, pages 1-141 to 1-146

**See Also:** 8.24. XT Fixed Disk Controller Command Summary

**8.27. XT FIXED DISK CONTROLLER STATUS REGISTER**

7	6	5	4	3	2	1	0	Name	Allowable Values
0	0							Always Zero	
		X						Logical Unit Number	0 or 1
			0	0	0			Always Zero	
						X		Error Status	0=no error, 1=error occurred
							0	Always Zero	

**Source:** IBM PC/XT Technical Reference, page 1-137

**See Also:** 8.28. XT Fixed Disk Controller Sense Bytes  
8.29. XT Fixed Disk Controller Error Codes

**8.28. XT FIXED DISK CONTROLLER SENSE BYTES**

Byte	Bit Numbers								Name	Allowable Values
	7	6	5	4	3	2	1	0		
Byte 0	X								Address valid	1=address is valid
		0							Always zero	
			X	X					Error type	see 8.29. XT FDC Error Codes
Byte 1					X	X	X	X	Error code	see 8.29. XT FDC Error Codes
	0	0							Always zero	
			X						Drive number	0 or 1
Byte 2			X	X	X	X	X	X	Head number	
	X	X	X						HO 3 bits of cylinder #	
				X	X	X	X	X	Sector number	
Byte 3	X	X	X	X	X	X	X	X	LO 8 bits of cylinder #	

**Source:** IBM PC/XT Technical Reference, page 1-137

**See Also:** 8.27. XT Fixed Disk Controller Status Register  
8.29. XT Fixed Disk Controller Error Codes

**8.29. XT FIXED DISK CONTROLLER ERROR CODES**

Bit Numbers						Value	Error Description
5	4	3	2	1	0		
0	0	0	0	0	0	0 (0)	No error during previous operation
0	0	0	0	0	1	1 (1)	No index signal detected from drive
0	0	0	0	1	0	2 (2)	No seek complete signal detected from drive after seek requested
0	0	0	0	1	1	3 (3)	Write fault detected from drive during previous operation
0	0	0	1	0	0	4 (4)	Drive did not respond with ready signal after being selected
0	0	0	1	0	1	5 (5)	NOT USED
0	0	0	1	1	0	6 (6)	No Track 00 signal detected from drive when it was expected
0	0	0	1	1	1	7 (7)	NOT USED
0	0	1	0	0	0	8 (8)	Drive still seeking
0	1	0	0	0	0	10 (16)	ECC error in target ID field on the disk
0	1	0	0	0	1	11 (17)	Uncorrectable ECC error in target sector during read
0	1	0	0	1	0	12 (18)	No target address mark detected on the disk
0	1	0	0	1	1	13 (19)	NOT USED
0	1	0	1	0	0	14 (20)	Sector not found (cylinder and head found correctly)
0	1	0	1	0	1	15 (21)	Seek compare error (may be cylinder and/or head address)
0	1	0	1	1	0	16 (22)	NOT USED
0	1	0	1	1	1	17 (23)	NOT USED
0	1	1	0	0	0	18 (24)	Correctable ECC error in the target field detected
0	1	1	0	0	1	19 (25)	Bad track detected during previous operation

**Source:** IBM PC/XT Technical Reference, pages 1-138 to 1-139

**See Also:** 8.28. XT Fixed Disk Controller Sense Bytes

**8.30. AT FIXED DISK DRIVE TYPES**

Type	Cylinders	Heads	Write PreComp	Landing Zone
1	306	4	128	305
2	615	4	300	615
3	615	6	300	615
4	940	8	512	940
5	940	6	512	940
6	615	4	none	615
7	462	8	256	511
8	733	5	none	733
9	900	15	none	901
10	820	3	none	820
11	855	5	none	855
12	855	7	none	855
13	306	8	128	319
14	733	7	none	733
15	Extended			
16	612	4	all	663
17	977	5	300	977
18	977	7	none	977
19	1024	7	512	1023
20	733	5	300	732
21	733	7	300	732
22	733	5	300	733
23	306	4	none	336
24-255	RESERVED			

**Source:** IBM PC/AT Technical Reference, pages 1-63 and 1-66

**See Also:** 7.50. AT Real Time Clock Status Register A

**8.31. PS/2 POS I/O ADDRESS SPACE**

Address	Function	Comments/Bit Meanings
94 (148)	System board enable/setup register	Bit 7 set=enable functions, zero=setup functions Bit 5 set=enables VGA, zero=setup VGA
95 (149)	RESERVED	
96 (150)	Adapter enable /setup register	
97 (151)	RESERVED	
100 (256)	POS register 0 -- LO adapter ID byte	Read only
101 (257)	POS register 1 -- HO adapter ID byte	Read only
102 (258)	POS register 2 -- option select data byte 1	Read/write if implemented (bit 0=card enable)
103 (259)	POS register 3 -- option select data byte 2	Read/write if implemented
104 (260)	POS register 4 -- option select data byte 3	Read/write if implemented
105 (261)	POS register 5 -- option select data byte 4	Read/write if implemented (bit 7=channel active, bit 6=channel status)
106 (262)	POS register 6 -- LO subaddress extension	
107 (263)	POS register 7 -- HO subaddress extension	

**Notes:** Model 50, 60, and 80 only

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 2-21 to 2-28

**See Also:** 8.32. PS/2 POS Descriptor File Format  
8.33. PS/2 POS ID Assignments

8.32. PS/2 POS DESCRIPTOR FILE FORMAT

Command	Syntax	Function	Example	Example Explanation
ADAPTER ID number		Defines card's ID number	AdapterId 0DEAFh	Card's ID is 0DEAF hex
ADAPTER NAME string		Defines card's name	AdapterName "Thom's Hearing Aid"	Card's name is "Thom's Hearing Aid"
NUMBYTES number		Number of POS bytes used	NumBytes 2	Card uses 2 POS bytes
FIXED RESOURCES pos. setting resource. setting		Defines resources required by card	FixedResources POS1 = "XXXXXX01" int 3	Card uses first POS byte, LO 2 bits
NAMED ITEM prompt (choice...) help		Defines choices for a resource	Named_Item Prompt "Communications Port to Use:" choice "COM1" pos[0]=XXXXXXXX01b to 0318h-031fh int 4 choice "COM2" pos[0]=XXXXXXXX10b to 0218h-021fh int 3 Help "select one of the two serial ports listed"	Names an item in pos[0] used to store the user's choice of serial ports
PROMPT string		Defines a string		
CHOICE choice. name pos. setting resource. setting		Defines a named choice		
HELP string		Defines a help string		
POS(number)=bitlist		Defines one or more POS byte settings	Pos[0]=XX1XX0XX01b	X=ignored, 1=set bit, 0=clear bit
I/O (range...)		Defines one or more I/O address ranges		
INT (number...)		Defines one or more interrupts used		
ARB (number...)		Defines one or more arbitration levels	ARB 1	Sets arbitration level 1
MEM (range...)		Defines one or more memory ranges	MEM 0C0000h-0CFFFFh	Card uses memory from 0C000-CFFFFh

**Notes:** \*IO, INT, ARB, and MEM are resource\_settings

\*POS is a pos\_setting

\*Does not apply to Model 30

\*File must contain at least one Card\_ID, one Card\_Name, and NumBytes; all else is optional

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 2-38 to 2-46

**See Also:** 8.33. PS/2 POS ID Assignments

**8.33. PS/2 POS ID ASSIGNMENTS**

<i>ID</i>	<i>IBM Definition</i>
0000	RESERVED
0001-0FFF	Bus master
5000-5FFF	Direct memory access devices
6000-6FFF	Direct program control (includes memory-mapped I/O devices)
7000-7FFF	Storage or multiple function devices
8000-80FF	Video devices
FFFF	Device not attached

**Notes:** These IDs are IBM guidelines only; manufacturers are free to determine their own IDs, although to do so may cause conflicts.

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, page 2-108

**See Also:** 8.31. PS/2 POS I/O Address Space

**8.34. PS/2 MODEL 50/60/80 DMA I/O ADDRESS MAP**

<i>Address</i>	<i>Function</i>
0 (0)	Channel 0 memory address register
1 (1)	Channel 0 transfer count register
2 (2)	Channel 1 memory address register
3 (3)	Channel 1 transfer count register
4 (4)	Channel 2 memory address register
5 (5)	Channel 2 transfer count register
6 (6)	Channel 3 memory address register
7 (7)	Channel 3 transfer count register
8 (8)	Status register for channels 0-3
A (10)	Mask register (set/reset) for channels 0-3
B (11)	Mode register (write) for channels 0-3
C (12)	Clear byte pointer
D (13)	Master clear
E (14)	Clear mask register for channels 0-3
F (15)	Write mask register for channels 0-3
18 (24)	Extended function register
1A (26)	Extended function execute
81 (129)	Channel 2 page table address register (upper byte)
82 (130)	Channel 3 page table address register (upper byte)
83 (131)	Channel 1 page table address register (upper byte)
87 (135)	Channel 0 page table address register (upper byte)
89 (137)	Channel 6 page table address register (upper byte)
8A (138)	Channel 7 page table address register (upper byte)
8B (139)	Channel 5 page table address register (upper byte)
8F (143)	Channel 4 page table address register (upper byte)
C0 (192)	Channel 4 memory address register
C2 (194)	Channel 4 transfer count register
C4 (196)	Channel 5 memory address register
C6 (198)	Channel 5 transfer count register
C8 (200)	Channel 6 memory address register
CA (202)	Channel 6 transfer count register
CC (204)	Channel 7 memory address register
CE (206)	Channel 7 transfer count register
D0 (208)	Status register for channels 4-7
D4 (212)	Mask register for channels 4-7
D6 (214)	Mode register for channels 4-7
D8 (216)	Clear byte pointer
DA (218)	Master clear
DC (220)	Clear mask register for channels 4-7
DE (222)	Write mask register for channels 4-7

**Notes:**

- Channels 0-3 follow PC/AT guidelines
- Model 30 follows XT DMA guidelines

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, page 3-13

**See Also:** 8.35. PS/2 DMA Registers

8.35. PS/2 DMA REGISTERS

Register	Size	Comments	Bit Numbers							Allowable Values			
			7	6	5	4	3	2	1		0		
Memory address	24 bits	1 per channel											
I/O address	16 bits	1 per channel											
Transfer count	16 bits	1 per channel											
Temporary holding	16 bits	1 for all channels											always one more than the number of DMA transfers
Mask	4 bits	1 each for channels 0-3, 4-7	X	X	X	X							RESERVED Mask bit (0=clear, 1=set) Channel select. (00=0 or 4, 01=1 or 5, 10=2 or 6, 11=3 or 7)
Arbus	4 bits	1 each for channels 0 and 4	X	X	X	X							RESERVED Arbitration level (4-bit binary value)
Mode	8 bits	1 per channel	X	X	X	X							RESERVED (bit 5 must be set to 0) 00=verify op, 01=write op, 10=read op, 11=reserved op 00=select channel 0 or 4, 01=1 or 5, 10=2 or 6, 11=3 or 7
Status	8 bits	1 each for channels 0-3, 4-7	X	X									channel 3 or 7 request channel 2 or 6 request channel 1 or 5 request channel 0 or 4 request terminal count on channel 3 or 7 terminal count on channel 2 or 6 terminal count on channel 1 or 5 terminal count on channel 0 or 4
Function	8 bits	1 for all channels (see note in source on DMA Extended Operations, page 3-18, for extended use of function register)	X	X	X	X							When operating as function register: program count RESERVED channel number When operating as extended mode register: RESERVED (bit 4 must be 0) 0=8 bit transfer, 1=16-bit transfer 0=read memory transfer, 1=write to memory transfer 0=verify, 1=transfer data 0=I/O address equals 0000H, 1=use programmed I/O addr.
Refresh	9 bits	Independent of DMA											

**Notes:** Does not apply to Model 30

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 3-14 to 3-20

**See Also:** 8.34. PS/2 Model 50/60/80 DMA I/O Address Map

8.36. PS/2 COUNTER REGISTERS

Register	Address	Comments	Bit Numbers										Allowable Values				
			7	6	5	4	3	2	1	0							
Read/write counter 0	40 (64)																
Read/write counter 2	42 (66)																
Write control byte	43 (67)	For counter 0 and 2	X		X	X											SC1 and SC0: 00=counter 0, 10=counter 2 (others reserved) RW1 and RW2: 00=counter latch command 01=read/write counter bits 0-7 only 10=read/write counter bits 8-15 only 11=read/write counter bits 0-7, then 8-15
									X	X	X						M2, M1, and M0: 000=mode 0, 001=mode 1 010=mode 2, 011=mode 3 100=mode 4, 101=mode 5 BCD: 0=16 bit binary counter, 1=BCD decimal counter
Read/write counter 3	44 (68)																
Write control byte	47 (71)	For counter 3	X		X		X										SC1 and SC0: 00=counter 3 (others reserved) RW1 and RW2: 00=counter latch select counter 0 01=read/write counter bits 0-7 only 10=reserved 11=reserved
													X	X	X	X	Must be 0

Notes: Does not apply to Model 30

Source: IBM PS/2 Model 50 and 60 Technical Reference, pages 3-29 to 3-32

**8.37. PS/2 SYSTEM CONTROL PORT A (92H)***Bit Numbers*

7	6	5	4	3	2	1	0	Function	Allowable Values
X	X							Disk activity light	Any bit set to 1 turns activity light on
		X			X			RESERVED	
X			X					Watchdog timer status	R/O. 0=no timeout, 1=timeout occurred
				X				RT/CMOS security lock	0=unlocked, 1=locked (done by POST)
						X		A20 active indicator	0=A20 line is inactive, 1=A20 is active
							X	Alternate CPU reset	0=system reset or write, 1=pulse alt reset pin

**Notes:** Does not apply to Model 30

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 4-194 to 4-195

**See Also:** 8.38. PS/2 System Control Port B (61H)

**8.38. PS/2 SYSTEM CONTROL PORT B (61H)***Bit Numbers*

7	6	5	4	3	2	1	0	Function for Write Operations	Function for Read Operations
X								1=IRQ 0 reset (timer 0 output latch)	Parity check state (1=parity check occurred)
	X							RESERVED	Channel check state (1=channel check occurred)
		X						RESERVED	Mirrors timer 2 output condition
			X					RESERVED	Toggles on each refresh request
				X				1=Enable channel check (0=disable)	Channel check status
					X			1=Enable parity check (0=disable)	Parity check status
						X		1=Enable speaker data (0=disable)	Speaker data status
							X	1=Enable timer 2 gate (0=disable)	Timer 2 gate status

**Notes:** Does not apply to Model 30

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 4-192 to 4-194

**See Also:** 8.37. PS/2 System Control Port A (92H)

**8.39. PS/2 RT/CMOS AND NMI MASK (70H)***Bit Numbers*

7	6	5	4	3	2	1	0	Function	Allowable Values
X								Non-maskable interrupt (NMI)	0=NMI masked, 1=NMI enabled
	X							RESERVED	
		X	X	X	X	X	X	RT/CMOS RAM address	(Used with port 71H to write to that address)

**Notes:** Does not apply to Model 30

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 4-194 and 4-183

— SECTION —

9

Hardware  
Descriptions

---

**9.01. 9-PIN SERIAL PORT CONNECTOR**

Pin #	Description	Abbrev.	Direction*
1	Data carrier detect	DCD	In
2	Receive data	RX	In
3	Transmit data	TX	Out
4	Data terminal ready	DTR	Out
5	Signal ground	GND	
6	Data set ready	DSR	In
7	Request to send	RTS	Out
8	Clear to send	CTS	In
9	Ring indicator	RI	In

**Notes:**

- Pin numbers refer only to DB-9P connector
- RI connection not required to operate
- When AT configured as DTE device

**Source:** *Communications and Networking for the IBM PC and Compatibles* (Brady), Larry Jordan and Bruce Churchill, page 120

**See Also:** 9.02. 25-Pin Serial Port Connector  
9.04. RS-232C Serial Port Connector (DTE Device)

**9.02. 25-PIN SERIAL PORT CONNECTOR**

Pin #	Description	Abbrev.	Direction*
1	Chassis ground		
2	Transmit data	TX	Out
3	Receive data	RX	In
4	Request to send	RTS	Out
5	Clear to send	CTS	In
6	Data set ready	DSR	In
7	Signal ground	SG	
8	Carrier detect	DCD	In
9	Pos transmit current loop return**		Out
11	Neg transmit current loop data**		Out
18	Pos receive current loop data**		In
20	Data terminal ready	DTR	Out
22	Ring indicator	RI	In
25	Neg receive current loop return**		In

**Notes:**

- RI connection not required to operate
- Pin numbers refer to DB-25P connector only
- When PC configured as DTE device
- \*\*Used for current loop communications only

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Async 23 to 24

**See Also:** 9.01. 9-Pin Serial Port Connector  
9.04. RS-232C Serial Port Connector (DTE Device)

**9.03. PS/2 SERIAL PORT CONNECTOR**

Connector	Pin Number	Direction	Model 30	Model 50/60/80
System end (DB25)	1		Not connected	Not connected
	2	Out	Transmit data	Transmit data
	3	In	Receive data	Receive data
	4	Out	Request to send	Request to send
	5	In	Clear to send	Clear to send
	6	In	Data set ready	Data set ready
	7		Signal ground	Signal ground
	8	In	RLSD	Data carrier detect
	9		Not connected	Not connected
	10		Not connected	Not connected
	11	Out	Connected to pin 20	Not connected
	12		Not connected	Not connected
	13		Not connected	Not connected
	14		Not connected	Not connected

(Continued)

Table 9.03. Continued

Connector	Pin Number	Direction	Model 30	Model 50/60/80
System end (DB25)	15		Not connected	Not connected
	16		Not connected	Not connected
	17		Not connected	Not connected
	18		Not connected	Not connected
	19		Not connected	Not connected
	20	Out	Data terminal ready	Data terminal ready
	21		Not connected	Not connected
	22	In	Ring indicate	Ring indicate
	23		Not connected	Not connected
	24		Not connected	Not connected
	25		Not connected	Not connected


**Source:** IBM PS/2 Model 30 Technical Reference, page 1-122  
 IBM PS/2 Model 50 and 60 Technical Reference, page 4-171

**See Also:** 9.01. 9-pin Serial Port Connector  
 9.02. 25-Pin Serial Port Connector  
 9.04. RS-232C Serial Port Connector (DTE Device)

**9.04. RS-232C SERIAL PORT CONNECTOR (DTE DEVICE)**

Pin #	Definition	Abbrev	Direction	Used by PC	Used by AT
1	Protective ground (chassis ground)		NA	Yes, as defined	Yes, different pin
2	Transmitted data	TX	Out	Yes, as defined	Yes, different pin
3	Received data	FX	In	Yes, as defined	Yes, different pin
4	Request to send	RTS	Out	Yes, as defined	Yes, different pin
5	Clear to send	CTS	In	Yes, as defined	Yes, different pin
6	Data set ready	DSR	In	Yes, as defined	Yes, different pin
7	Signal ground	SG	NA	Yes, as defined	Yes, different pin
8	Received line signal detector	DCD	In	Yes, as defined	Yes, different pin
9	RESERVED		NA	(+t current loop)	No
10	RESERVED		NA	No	No
11	UNASSIGNED		NA	(-t current loop)	No
12	Secondary received line signal detector		In	No	No
13	Secondary clear to send		In	No	No
14	Secondary transmitted data		Out	No	No
15	Transmission signal element timing		Out	No	No
16	Secondary received data		In	No	No
17	Receiver signal element timing		In	No	No
18	UNASSIGNED		NA	(+r current loop)	No
19	Secondary request to send		Out	No	No
20	Data terminal ready	DTR	Out	Yes, as defined	Yes, different pin
21	Signal quality detector		In	No	No
22	Ring indicator	RI	In	Yes, as defined	Yes, different pin
23	Data signal rate selector			No	No
24	Transmit signal element timing		Out	No	No
25	UNASSIGNED		NA	(-r current loop)	No

**Notes:** •The IBM PC and AT are normally configured as a DTE device  
 •While not part of the standard, a DB-25P connector is often used at the DTE device, as in the IBM PC. Its pinouts look like this:



**Source:** EIA Standard RS-232-C, August 1969  
 IBM PC/XT Technical Reference, page 1-211

**See Also:** 9.01. 9-Pin Serial Port Connector  
 9.02. 25-Pin Serial Port Connector

**9.05. PS/2 15-PIN VIDEO CONNECTOR**

<i>Connector</i>	<i>Pin Number</i>	<i>Direction</i>	<i>Monochrome</i>	<i>Color</i>
System end (DB15)	1	Out	NO PIN	Red
	2	Out	Mono	Green
	3	Out	NO PIN	Blue
	4		NO PIN	NO PIN
	5		Self test	Self test
	6		KEY	Red return*
	7		Mono return	Green return*
	8		NO PIN	Blue return*
	9		NO PIN	NO PIN
	10		Digital ground	Digital ground
	11		NO PIN	Digital ground
	12		Digital ground	NO PIN
	13	Out	HSync	HSync
	14	Out	VSync	VSync
	15		NO PIN	NO PIN

**Notes:** \*Analog grounds

**Source:** IBM PS/2 Model 30 Technical Reference, page 1-78  
IBM PS/2 Model 50 and 60 Technical Reference,  
page 4-125

**See Also:** 9.10. MDA Video Connector  
9.11. CGA RGB Connector  
9.12. EGA RGB Connector

**9.06. CGA COMPOSITE VIDEO CONNECTOR**

<i>Pin #</i>	<i>Description</i>	<i>Direction*</i>
1	Peak to peak amplitude	Out
2	Ground	

**Notes:** •Video signal is approximately 1.5Vdc  
•Pin numbers refer to RCA phono jack (1=pin, 2=shell)  
\*From PC

**Source:** IBM Technical Reference Options and Adapters Volume 2,  
page Color/Graphics 24

**See Also:** 9.10. MDA Video Connector  
9.11. CGA RGB Connector  
9.12. EGA RGB Connector

**9.07. EGA FEATURE CONNECTOR**

Pin Number	Signal Name	Direction
1	GND	
2	-12V	
3	+12V	
4	J1	
5	J2	
6	G'OUT	Out
7	R'OUT	Out
8	B'OUT	Out
9	ATRS/L	
10	B OUT	Out
11	G OUT	Out
12	G	In
13	R'	In
14	B	In
15	R	In
16	R OUT	Out
17	FEAT 1	Out

Pin Number	Signal Name	Direction
18	BLANK	
19	FEAT 0	Out
20	FCI	In
21	FCO	In
22	G/I	In
23	B'/V	In
24	HIN	In
25	VIN	In
26	14 MHz	
27	Internal	Out
28	EXT OSC	Out
29	V OUT	Out
30	H OUT	Out
31	GND	
32	+5V	

**Notes:**       •Signals preceded by a minus sign are negative true

**Source:**       IBM Technical Reference Options and Adapters Volume 1, pages EGA 76-78

**See Also:**     9.12. EGA RGB Connector

**9.08. CGA LIGHT PEN CONNECTOR**

Pin #	Description	Direction*
1	-Light pen input	In
2	KEY (NOT USED)	
3	-Light pen switch	In
4	Chassis ground	
5	+5Vdc	Out
6	+12Vdc	Out

**Notes:**       •Pin numbers refer to 6-pin Berg Strip on CGA board (P2)  
                   •\*From PC

**Source:**       IBM Technical Reference Options and Adapters Volume 2, page Color/Graphics 25

**See Also:**     9.09. CGA RF Modulator Connector  
                   9.10. MDA Video Connector  
                   9.11. CGA RGB Connector  
                   9.12. EGA RGB Connector

**9.09. CGA RF MODULATOR CONNECTOR**

Pin #	Description	Direction*
1	+12Vdc	Out
2	KEY (NOT USED)	
3	Composite video output	Out
4	Logic ground	

**Notes:**       •Pin numbers refer to 4-pin Berg Strip on CGA board (P1)  
                   •\*From PC

**Source:**       IBM Technical Reference Options and Adapters Volume 2, page Color/Graphics 25

**See Also:**     9.08. CGA Light Pen Connector  
                   9.10. MDA Video Connector  
                   9.11. CGA RGB Connector  
                   9.12. EGA RGB Connector

**9.10. MDA VIDEO CONNECTOR**

Pin #	Description	Direction*
1	Ground	
2	Ground	
3	NOT USED	
4	NOT USED	
5	NOT USED	
6	+Intensity	Out
7	+Video	Out
8	+Horizontal	Out
9	-Vertical	Out

**Notes:**

- Pin numbers refer to DB-9 connector
- Signal voltages are 0.0 to 0.6 Vdc (0 level) and +2.4 to 3.5Vdc (1 level)
- Parallel port pinouts are documented separately; see 9.34. Parallel Printer Connector
- \*From PC

**Source:** IBM Technical Reference Options and Adapters Volume 2, page Monochrome 9

**See Also:** 9.09. CGA RF Modulator Connector  
 9.12. EGA RGB Connector  
 9.13. VGA RGB Connector  
 9.34. Parallel Printer Connector

**9.11. CGA RGB CONNECTOR**

Pin #	Description	Direction*
1	Ground	
2	Ground	
3	Red	Out
4	Green	Out
5	Blue	Out
6	+Intensity	Out
7	RESERVED	Out
8	+Horizontal drive	Out
9	-Vertical drive	Out

**Notes:**

- Pin numbers refer to DB-9 connector
- \*From PC

**Source:** IBM Technical Reference Options and Adapters Volume 2, page Color/Graphics 24

**See Also:** 9.06. CGA Composite Video Connector  
 9.08. CGA Light Pen Connector  
 9.09. CGA RF Modulator Connector  
 9.10. MDA Video Connector  
 9.12. EGA RGB Connector  
 9.13. VGA RGB Connector

**9.12. EGA RGB CONNECTOR**

Pin #	Description	Direction*
1	Ground	
2	S. red	Out
3	Red	Out
4	Green	Out
5	Blue	Out
6	Intensity/s. green	Out
7	S. blue/mono video	Out
8	Horizontal drive	Out
9	Vertical drive	Out

**Notes:**

- Pin numbers refer to DC-9 connector
- \*From PC

**Source:** IBM Technical Reference Options and Adapters Volume 1, page Enhanced Graphics Adapter 83

**See Also:** 9.10. MDA Video Connector  
 9.11. CGA RGB Connector

## 9.13. VGA RGB CONNECTOR

Pin #	Function	Mono Disp.	Color Disp.	Direction*
1	Red		Red output	Out
2	Green	Mono output	Green output	Out
3	Blue		Blue output	Out
4	RESERVED			
5	Digital ground	Self test	Self test	
6	Red return (analog ground)	KEY	Red return	
7	Green return (analog ground)	Mono return	Green return	
8	Blue return (analog ground)		Blue return	
9	Plug			
10	Digital ground	Digital ground	Digital ground	
11	RESERVED		Digital ground	
12	RESERVED	Digital ground		
13	Horizontal drive	Horizontal drive	Horizontal drive	Out
14	Vertical drive	Vertical drive	Vertical drive	Out
15	RESERVED			

**Notes:** •Pin numbers refer to DC-15 connector  
 •\*From PC

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, page 4-125

**See Also:** 9.10. MDA Video Connector  
 9.11. CGA RGB Connector  
 9.12. EGA RGB Connector

## 9.14. PC &amp; XT FLOPPY DISK CONTROLLER INTERNAL CONNECTOR

Pin Number	Signal Name	Direction
1	Ground	
2	UNUSED	
3	Ground	
4	UNUSED	
5	Ground	
6	UNUSED	
7	Ground	
8	Index	From drive
9	Ground	
10	Motor enable A	From controller
11	Ground	
12	Drive select B	From controller
13	Ground	
14	Drive select A	From controller
15	Ground	
16	Motor enable B	From controller
17	Ground	
18	Direction (stepper motor)	From controller
19	Ground	
20	Step pulse	From controller
21	Ground	
22	Write data	From controller
23	Ground	
24	Write enable	From controller
25	Ground	
26	Track 0	From drive
27	Ground	
28	Write protect	From drive
29	Ground	
30	Read data	From drive
31	Ground	
32	Select head 1	From controller
33	Ground	
34	UNUSED	

**Notes:** •All signals are at standard TTL levels  
 •Connector is a 34-pin keyed edge connector (key between pins 6 and 8)  
 •Even numbers are on component side of board

**Source:** IBM PC/XT Technical Reference, page 1-128

**See Also:** 9.15. PC & XT Floppy Disk Controller External Connector

**9.15. PC & XT FLOPPY DISK CONTROLLER EXTERNAL CONNECTOR**

Pin Number	Signal Name	Direction
1	UNUSED	
2	UNUSED	
3	UNUSED	
4	UNUSED	
5	UNUSED	
6	Index	From drive
7	Motor enable C	From controller
8	Drive select D	From controller
9	Drive select C	From controller
10	Motor enable D	From controller
11	Direction (stepper motor)	From controller
12	Step pulse	From controller
13	Write data	From controller
14	Write enable	From controller
15	Track 0	From drive
16	Write protect	From drive
17	Read data	From drive
18	Select head 1	From controller
19	NOT USED	

Pin Number	Signal Name	Direction
20	Ground	
21	Ground	
22	Ground	
23	Ground	
24	Ground	
25	Ground	
26	Ground	
27	Ground	
28	Ground	
29	Ground	
30	Ground	
31	Ground	
32	Ground	
33	Ground	
34	Ground	
35	Ground	
36	Ground	
37	Ground	

**Notes:** •All signals are at standard TTL levels  
 •Connector is a 37-pin D-Shell connector

**Source:** IBM PC/XT Technical Reference, page 1-129

**See Also:** 9.14. PC & XT Floppy Disk Controller Internal Connector

**9.16. XT FIXED DISK CONTROLLER CONNECTOR J1**

Pin Number	Signal Name	Direction
1	Ground	
2	-Reduced write current	From controller
3	Ground	
4	RESERVED	
5	Ground	
6	-Write gate	From controller
7	Ground	
8	-Seek complete	From drive
9	Ground	
10	-Track 00	From drive
11	Ground	
12	-Write fault	From drive
13	Ground	
14	-Head select 2 <sup>0</sup>	From controller
15	Ground	
16	RESERVED	
17	Ground	
18	-Head select 2 <sup>1</sup>	From controller
19	Ground	
20	-Index	From drive
21	Ground	
22	-Ready	From drive
23	Ground	
24	-Step	From controller
25	Ground	
26	-Drive select 1	From controller
27	Ground	
28	-Drive select 2	From controller
29	Ground	
30	RESERVED	From drive
31	Ground	
32	RESERVED	From controller
33	Ground	
34	-Direction in	From controller

**Notes:** •Signals preceded by a minus sign are negative true  
 •Connector is 34-pin double-row plug

**Source:** IBM PC/XT Technical Reference, page 1-149

**See Also:** 9.14. PC & XT Floppy Disk Controller Internal Connector  
 9.15. PC & XT Floppy Disk Controller External Connector  
 9.17. XT Fixed Disk Controller Connectors J2 and J3

**9.17. XT FIXED DISK CONTROLLER CONNECTORS J2 AND J3**

Pin Number	Signal Name	Direction
1	Drive select	From drive
2	Ground	
3	RESERVED	
4	Ground	
5	NO PIN (key)	
6	Ground	
7	RESERVED	
8	Ground	
9	UNUSED	
10	UNUSED	

Pin Number	Signal Name	Direction
11	Ground	
12	Ground	
13	MFM write data	From controller
14	-MFM write data	From controller
15	Ground	
16	Ground	
17	MFM read data	From drive
18	-MFM read data	From drive
19	Ground	
20	Ground	

**Notes:**

- Signals preceded by a minus sign are negative true
- Connector is 20-pin double-row plug with key notch at pin 5

**Source:** IBM PC/XT Technical Reference, page 1-149

**See Also:**

- 9.14. PC & XT Floppy Disk Controller Internal Connector
- 9.15. PC & XT Floppy Disk Controller External Connector
- 9.16. XT Fixed Disk Controller Connector J1

**9.18. PS/2 MODEL 30 DISKETTE DRIVE CONNECTOR**

Connector	Pin Number	Direction	Signal Name
	1		Signal ground
	2	Out	-High density select
	3		RESERVED
	4		RESERVED
	5		Signal ground
	6		RESERVED
	7		Signal ground
	8	In	-Index
	9		Signal ground
	10	Out	-Motor enable 1
	11		Signal ground
	12	Out	-Drive select 0
	13		Signal ground
	14	Out	-Drive select 1
	15		Signal ground
	16	Out	-Motor enable 0
	17		Signal ground
	18	Out	-Direction
	19		Signal ground
	20	Out	-Step
	21		Signal ground
	22	Out	-Write data
	23		Signal ground
	24	Out	-Write enable
	25		Signal ground
	26	In	-Track 0
	27		Signal ground
	28	In	-Write protect
	29		Signal ground
	30	In	-Read data
	31		Signal ground
	32	Out	-Head 1 select
	33		Signal ground
	34	In	-Diskette change
	35		Ground
	36		Ground
	37		Ground
	38	Out	+5V
	39		Ground
	40	Out	+12V

**Notes:** Drive gets power via this connector

**Source:** IBM PS/2 Model 30 Technical Reference, page 1-105

**See Also:** 9.20. PS/2 Model 50 Diskette Drive Connector

## 9.19. PS/2 MODEL 30 FIXED DRIVE CONNECTOR

Connector	Pin Number	Direction	Signal Name
	1	Out	RESET DRV
	2	In	-DISK installed
	3	In/out	D0
	4		Ground
	5	In/out	D1
	6		Ground
	7	In/out	D2
	8		Ground
	9	In/out	D3
	10		Ground
	11	In/out	D4
	12		Ground
	13	In/out	D5
	14		Ground
	15	In/out	D6
	16		Ground
	17	In/out	D7
	18		Ground
	19	Out	-IOR
	20		Ground
	21	Out	-IOW
	22		Ground
	23	Out	-DISK CS
	24		Ground
	25	Out	A0
	26		Ground
	27	Out	A1
	28		Ground
	29	Out	A2
	30	Out	+5V
	31		RESERVED
	32	Out	+5V
	33	Out	-DACK3
	34		Ground
	35	In	DRQ3
	36		Ground
	37	In	IRQ5
	38		Ground
	39	In	IO CH ready
	40	Out	+12V
	41		Spare
	42	Out	+12V
	43		Spare
	44	Out	+12V

**Notes:** Drive gets power via this connector

**Source:** IBM PS/2 Model 30 Technical Reference, page 1-107

**See Also:** 9.16. XT Fixed Disk Controller Connector J1  
9.17. XT Fixed Disk Controller Connectors J2 and J3

**9.20. PS/2 MODEL 50 DISKETTE DRIVE CONNECTOR**

Connector	Pin Number	Direction	Signal
50-pin PC Edge Connector	1	In	2nd drive installed
	2	Out	-High density select
	3		Ground
	4		Ground
	5		Ground
	6		RESERVED
	7		Signal ground
	8	In	-Index
	9		Signal ground
	10	Out	-Motor enable 0
	11		Signal ground
	12	Out	-Drive select 1
	13		Ground
	14	Out	-Drive select 0
	15		Signal ground
	16	Out	-Motor enable 1
	17		Signal ground
	18	Out	-Direction
	19		Signal ground
	20	Out	-Step
	21		Signal ground
	22	Out	-Write data
	23		Signal ground
	24	Out	-Write enable
	25		Signal ground
	26	In	-Track 0
	27		Signal ground
	28	In	-Write protect
	29		Signal ground
	30	In	-Read data
	31		Signal ground
	32	Out	-Head 1 select
	33		Signal ground
	34	In	-Diskette change
	35		Ground
	36		Ground
	37		Ground
	38		+5V
	39		Ground
	40		+12V
	41		RESERVED
	42		RESERVED
	43		RESERVED
	44		RESERVED
	45		RESERVED
	46		RESERVED
	47		RESERVED
	48		RESERVED
	49		RESERVED
	50		RESERVED

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, page 4-153

**See Also:** 9.18. PS/2 Model 30 Diskette Drive Connector

**9.21. PC & XT POWER SUPPLY CONNECTORS**

<i>Connector</i>	<i>Pin Number</i>	<i>Signal Name</i>
5.25 floppy drive	1	+12V
	2	Ground
	3	Ground
	4	+5V
Fixed disk drive (or 2nd floppy)	1	+12V
	2	Ground
	3	Ground
	4	+5V
System board 1	1	Ground
	2	Ground
	3	-5V
	4	+5V
	5	+5V
	6	+5V
System board 2	1	Power ground
	2	KEY
	3	+12V
	4	-12V
	5	Ground
	6	Ground

**Notes:** Connectors are 4-pin molex connectors or 12-pin, 2-row plugs

**Source:** IBM PC/XT Technical Reference, pages 1-21 to 1-24

**9.22. AT BATTERY CONNECTOR J21**

<i>Pin Number</i>	<i>Signal Name</i>
1	Ground
2	NOT USED
3	Key
4	6 Vdc

**Notes:** Connector is a 4-pin keyed Berg connector (keyed on pin 3)

**Source:** IBM PC/AT Technical Reference, page 1-72

**See Also:** 9.23. AT Power Supply Connectors PS8, PS9, PS10, PS11, and PS12

**9.23. AT POWER SUPPLY CONNECTORS PS8, PS9, PS10, PS11, and PS12**

<i>Connector</i>	<i>Pin Number</i>	<i>Signal Name</i>
System board 1 PS8 Back of board	1	Power good
	2	+5Vdc
	3	+12Vdc
	4	-12Vdc
	5	Ground
	6	Ground
System board 2 PS9 Front of board	1	Ground
	2	Ground
	3	-5Vdc
	4	+5Vdc
	5	+5Vdc
	6	+5Vdc
PS10 1st floppy	1	+12V
	2	Ground
	3	Ground
	4	+5V
PS11 2nd floppy	1	+12V
	2	Ground
	3	Ground
	4	+5V
PS12 Fixed disk	1	+12V
	2	Ground
	3	Ground
	4	+5V

**Notes:** Connectors are 4-pin molex connectors or 6-pin, 1-row plugs

**Source:** IBM PC/AT Technical Reference, pages 1-71 and 3-7

**See Also:** 9.22. AT Battery Connector J21

**9.24. PS/2 MODEL 30 POWER SUPPLY CONNECTORS**

<i>Connector</i>	<i>Pin Number</i>	<i>Signal Name</i>
P3 Rear of system	1	Power good
	2	Ground
	3	+12V
	4	-12V
	5	Ground
	6	Ground
P4 Front of system	1	Ground
	2	Ground
	3	-5V
	4	+5V
	5	+5V
	6	+5V

**Notes:** Connectors are 6-pin, 1-row plugs

**Source:** IBM PS/2 Model 30 Technical Reference, page 3-6

## 9.25. PS/2 MODEL 50 POWER SUPPLY CONNECTOR

Connector	Pin Number	Direction	Signal
50-pin PC edge connector	1		-12V
	2		Signal ground
	3		+12V
	4		Signal ground
	5		+12V
	6		Signal ground
	7		+12V
	8		Signal ground
	9		+12V
	10		Signal ground
	11		+12V
	12		Signal ground
	13		+12V
	14		Signal ground
	15		+5V
	16		Signal ground
	17		+5V
	18		Signal ground
	19		+5V
	20		Signal ground
	21		+5V
	22		Signal ground
	23		+5V
	24		Signal ground
	25		+5V
	26		Signal ground
	27		+5V
	28		Signal ground
	29		+5V
	30		Signal ground
	31		+5V
	32		Signal ground
	33		+5V
	34		Signal ground
	35		+5V
	36		Signal ground
	37		+5V
	38		Signal ground
	39		+5V
	40		Signal ground
	41		+5V
	42		Signal ground
	43		+5V
	44		Signal ground
	45		+5V
	46		Signal ground
	47		+5V
	48		Signal ground
	49	In	System status
	50	Out	Power good

Source: IBM PS/2 Model 50 and 60 Technical Reference, page 5-6

**9.26. PS/2 MODEL 60 POWER SUPPLY CONNECTOR**

Connector	Pin Number	Direction	Signal
15-pin arranged as 3x5 keyed matrix	1		+5V
	2		Signal ground
	3		+12V
	4		+5V
	5		Signal ground
	6		Signal ground
	7		+5V
	8		Signal ground
	9		-12V
	10		+5V
	11		Signal ground
	12	Out	Power good
	13		+5V
	14		Signal ground
	15	In	System status

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, page 5-7

**9.27. PC & XT KEYBOARD CONNECTOR**

Pin Number	Signal Name
1	+Keyboard clock (+5Vdc signal level)
2	+Keyboard data (+5Vdc signal level)
3	-Keyboard reset (not used by keyboard)
4	Ground
5	+5Vdc

**Notes:** Connector is a 5-pin DIN connector

**Source:** IBM PC/XT Technical Reference, page 1-29

**See Also:** 9.28. PS/2 Keyboard and Mouse Connector

**9.28. PS/2 KEYBOARD AND MOUSE CONNECTOR**

Connector	Pin Number	Signal Name
System end (6-pin DIN)	1	+KBD DATA
	2	RESERVED
	3	Ground
	4	+5V
	5	+KBD CLK
	6	RESERVED
	Shield	Frame ground
Keyboard end (5-pin phone)	A	RESERVED
	B	+KBD DATA
	C	Ground
	D	+KBD CLOCK
	E	+5V
	F	RESERVED
	Shield	Frame ground

**Source:** IBM PS/2 Model 30 Technical Reference, page 4-41

**See Also:** 9.27. PC & XT Keyboard Connector

**9.29. AT POWER LED AND KEYLOCK CONNECTOR J20**

Pin Number	Signal Name
1	LED power
2	Key
3	Ground
4	Keyboard inhibit
5	Ground

**Notes:** Connector is a 5-pin Berg strip

**Source:** IBM PC/AT Technical Reference, page 1-72

## 9.30. PS/2 MODEL 50/60/80 MEMORY MODULE CONNECTOR

Connector	Pin Number	Direction	Signal
30-pin	1		5V
	2	In	-Column address strobe
	3	In/out	D1
	4	In	A1
	5	In	A2
	6	In/out	D2
	7	In	A3
	8	In	A4
	9		Ground
	10	In/out	D3
	11	In	A5
	12	In	A6
	13	In/out	D4
	14	In	A7
	15	In	A8
	16	In/out	D5
	17	In	A9
	18		No connection
	19	In	RAS1*
	20	In/out	D6
	21	In	-Write strobe
	22		Ground
	23	In/out	D7
	24	Out	Presence detect 1
	25	In/out	D8
	26	Out	Presence detect 2
	27	In	Row address strobe
	28		No connection
	29	In/out	D9 (parity)
	30		+5V

**Notes:** \*Applicable only to 512 KB modules

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, page 4-181

## 9.31. PS/2 PARALLEL PORT CONNECTOR

Connector	Pin Number	Direction*	Signal
System end (DB25)	1	In/out	-STROBE
	2	In/out	D0
	3	In/out	D1
	4	In/out	D2
	5	In/out	D3
	6	In/out	D4
	7	In/out	D5
	8	In/out	D6
	9	In/out	D7
	10	In	-ACK
	11	In	BUSY
	12	In	PE
	13	In	SLCT
	14	Out	-AUTO FEED XT
	15	In	-ERROR
	16	Out	-INIT
	17	Out	-SLCT IN
	18		Ground
	19		Ground
	20		Ground
	21		Ground
	22		Ground
	23		Ground
	24		Ground
	25		Ground

**Notes:** \*From computer

**Source:** IBM PS/2 Model 30 Technical Reference, page 1-126  
IBM PS/2 Model 50 and 60 Technical Reference, page 4-179

**See Also:** 9.32. Centronics Parallel Connector  
9.34. Parallel Printer Connector

**9.32. CENTRONICS PARALLEL CONNECTOR**

Pin #	Definition	Direction
1	-Strobe	In
2	Data 1	In
3	Data 2	In
4	Data 3	In
5	Data 4	In
6	Data 5	In
7	Data 6	In
8	Data 7	In
9	Data 8	In
10	-Acknowledge	Out
11	Busy	Out
12	Paper End	Out
13	Select	Out
14	-Auto Feed	In
15	NOT USED	
16	Logical ground	
17	Chassis ground	
18	NOT USED	
19	Ground return for -Strobe	
20	Ground return for Data 1	
21	Ground return for Data 2	
22	Ground return for Data 3	
23	Ground return for Data 4	
24	Ground return for Data 5	
25	Ground return for Data 6	
26	Ground return for Data 7	
27	Ground return for Data 8	
28	Ground return for -Acknowledge	
29	Ground return for busy	
30	Ground	
31	-Printer Init	In
32	-Fault	Out
33	Ground	
34	NOT USED	
35	Pulled up to +5V through 4.7K ohm resistor	
36	-Select In	In

**Notes:** Connector is an Amphenol 57-30360 or equivalent (Centronics parallel)

**Source:** IBM Technical Reference Options and Adapters Volume 1, pages Graphics Printer 29 to 31

**See Also:** 9.04. RS-232C Serial Port Connector (DTE Device)  
9.31. PS/2 Parallel Port Connector  
9.34. Parallel Printer Connector

**9.33. GAME ADAPTER CONNECTOR**

Pin #	Direction	Signal Name	Active	Function
1	Out	+5Vdc		
2	In	Button 4	High	Paddle 1 button, joystick A button
3	In	Position 0	High	Paddle 1 position, joystick A x-coordinate
4		Ground		
5		Ground		
6	In	Position 1	High	Paddle 2 position, joystick A y-coordinate
7	In	Button 5	High	Paddle 2 button
8	Out	+5Vdc		
9	Out	+5Vdc		
10	In	Button 6	High	Paddle 3 button, joystick B button
11	In	Position 2	High	Paddle 3 position, joystick B x-coordinate
12		Ground		
13	In	Position 3	High	Paddle 4 position, joystick B y-coordinate
14	In	Button 7	High	Paddle 4 button
15	Out	+5Vdc		

**Notes:** Connector used is a female DB-15

**Source:** IBM Technical Reference Options and Adapters Volume 2, pages Game Adapter 6 and 7

## 9.34. PARALLEL PRINTER CONNECTOR

Pin #	Direction	Signal Name	Active	Function
1	Out	Strobe	Low	Indicates valid data available
2	Out	Data bit 0	High	Least significant bit of data byte
3	Out	Data bit 1	High	
4	Out	Data bit 2	High	
5	Out	Data bit 3	High	
6	Out	Data bit 4	High	
7	Out	Data bit 5	High	
8	Out	Data bit 6	High	
9	Out	Data bit 7	High	Most significant bit of data byte
10	In	Acknowledge	Low	Indicates data received and device is ready for more
11	In	Busy	High	Device cannot receive data
12	In	P. End	High	Device is "out of paper"
13	In	Select	High	Device is in "selected state"
14	Out	Auto Feed	Low	Device to perform line feed after each line sent
15	In	Error	Low	Device unable to perform
16	Out	Initialize printer	Low	Reset device to initial state
17	In	Select input	Low	Device can accept input
18	NA	Ground	NA	
19	NA	Ground	NA	
20	NA	Ground	NA	
21	NA	Ground	NA	
22	NA	Ground	NA	
23	NA	Ground	NA	
24	NA	Ground	NA	
25	NA	Ground	NA	

**Notes:**

- Connector used is a female DB-25
- The original printer adapter and monochrome display adapter parallel ports are output-only; no provision for parallel input was made until introduction of the PS/2

**Source:** IBM Technical Reference Options and Adapters Volume 2, page Printer Adapter 7

**See Also:** 9.31. PS/2 Parallel Port Connector  
9.32. Centronics Parallel Connector

## 9.35. PC &amp; XT SPEAKER CONNECTOR


Pin Number	Signal Name
1	Data
2	Key
3	Ground
4	+5 Volts

**Notes:** Connector is a 4-pin keyed Berg connector (keyed on pin 2)


**Source:** IBM PC/XT Technical Reference, page 1-20

9.36. 8088 AND 8086 PINOUTS

40-pin DIP packaging:



44-pin PLCC packaging:




Notes: Items in parentheses refer to function when chip is in Minimum mode (pin 33 held high)

Source: Intel Microprocessor and Peripheral Handbook Volume 1, pages 2-1 to 2-5, 2-31, 2-50, and 2-90


See Also: 9.37. 80286 Pinouts  
9.38. 80386 Pinouts

9.37. 80286 PINOUTS



(Continued)

Table 9.37. Continued



**Notes:** Items in parentheses refer to inner pin connections on PGA packaging

**Source:** Intel Microprocessor and Peripheral Handbook Volume 1, pages 3-2 to 3-4


**See Also:** 9.36. 8088 and 8086 Pinouts  
9.38. 80386 Pinouts

**See Also:** 9.36. 8088 and 8086 Pinouts  
9.38. 80386 Pinouts




9.39. 8087 (COPROCESSOR) PINOUTS

40-pin DIP packaging:




44-pin PLCC packaging:



Source: Intel Microprocessor and Peripheral Handbook Volume 1, pages 2-122 to 2-124

See Also: 9.40. 80287 (Coprocessor) Pinouts  
9.41. 80387 (Coprocessor) Pinouts


**9.40. 80287 (COPROCESSOR) PINOUTS**



**Source:** Intel Microprocessor and Peripheral Handbook Volume 1, pages 3-55 to 3-57

**See Also:** 9.39. 8087 (Coprocesor) Pinouts  
9.41. 80387 (Coprocesor) Pinouts

9.41. 80387 (COPROCESSOR) PINOUTS



Pin	Signal
A1	No Pin
A2	Data 9
A3	Data 11
A4	Data 12
A5	Data 14
A6	Vcc +5
A7	Data 16
A8	Data 18
A9	Vcc +5
A10	Data 21
A11	No Pin

Pin	Signal
B1	Data 8
B2	Vss Ground
B3	Data 10
B4	Vcc +5
B5	Data 13
B6	Data 15
B7	Vss Ground
B8	Data 17
B9	Data 19
B10	Data 20
B11	Data 22

Pin	Signal
C1	Data 7
C2	Data 6
C10	Data 23
C11	Vss Ground
D1	Data 5
D2	Data 4
D10	Data 24
D11	Data 25
E1	Vcc +5
E2	Vss Ground
E10	Data 26

Pin	Signal
E11	Data 27
F1	Vcc +5
F2	Vss Ground
F10	Vcc +5
F11	Vss Ground
G1	Data 3
G2	Data 2
G10	Data 28
G11	Data 29
H1	Data 1
H2	Data 0

Pin	Signal
H10	Data 30
H11	Data 31
J1	Vss Ground
J2	Vcc +5
J10	Vss Ground
J11	CKM
K1	PEREQ
K2	-Busy
K3	TIE HIGH
K4	W/-R
K5	Vcc +5

Pin	Signal
K6	NPS2
K7	-ADS
K8	-Ready
K9	No connection
K10	386Clk2
K11	387Clk2
L1	No Pin
L2	-Error
L3	-ReadyO
L4	STEN
L5	Vss Ground


Pin	Signal
L6	-NPS1
L7	Vcc +5
L8	-CMD0
L9	TIE HIGH
L10	Reset In
L11	No Pin

**Source:** Intel Microprocessor and Peripheral Handbook Volume 1, pages 4-152 to 4-153


**See Also:** 9.39. 8087 (Coprocesor) Pinouts  
9.40. 80287 (Coprocesor) Pinouts

9.42. RAM CHIP PINOUTS SUMMARY


4116 (16 KB x 1)



4164 (64 KB x 1)



(256 KB x 1)



Source:


The IBM PC From the Inside Out (Addison Wesley),  
Sargent and Shoemaker, page 227

See Also:

9.30. PS/2 Model 50/60/80 Memory Module Connector

9.43. 6845 (VIDEO CONTROLLER) PINOUTS

40-pin DIP packaging:




**Notes:** Only pins used in IBM monochrome and color adapters are shown

**Source:** IBM XT Technical Reference, pages D-27 and D-36

**See Also:** 8.12. 6845 Registers  
8.13. 6845 Port and Select Factors

9.44. 8284 (CLOCK GENERATOR) PINOUTS




**Notes:** Available as 8284A (5 or 8MHz) and 8284A-1 (10MHz) and available in CMOS versions 82C84A (8MHz) or 82C84A-5 (5MHz)

**Source:** Intel Microprocessor and Peripheral Handbook Volume 1, pages 2-144 to 2-145, 2-152 to 2-153

## 9.45. 8237 (DMA CONTROLLER) PINOUTS

40-pin DIP packaging:




**Notes:** Available as 8237A (3MHz), 8237A-4 (4MHz), 8237A-5 (5MHz) and CHMOS 82C37A-5 (5MHz)

**Source:** Intel Microprocessor and Peripheral Handbook, Volume 1, pages 2-205 to 2-207 and 2-223 to 2-226

**See Also:** 8.34. PS/2 50/60/80 DMA I/O Address Map  
8.35. PS/2 DMA Registers

9.46. 8250 (SERIAL INTERFACE CONTROLLER) PINOUTS


40-pin DIP packaging:



Source: *The IBM PC From the Inside Out* (Addison Wesley), Sargent and Shoemaker, page 365

See Also: 8.08. 8250 I/O Port Usage (Registers)  
8.09. 8253 I/O Port Usage (Registers)


9.47. 8253 (PROGRAMMABLE INTERVAL CONTROLLER) PINOUTS



Notes: Available as 8253, 8253-5, 8254 (8MHz), 8254-2 (10MHz), and 8254-5 (5MHz)

Source: Intel Microprocessor and Peripheral Handbook, Volume 2, pages 2-14 to 2-15 and 2-25 to 2-26

## 9.48. 8255 (PARALLEL INTERFACE CONTROLLER) PINOUTS




**Notes:** Available as 8255A or CHMOS 82C55A

**Source:** Intel Microprocessor and Peripheral Handbook, Volume 2, pages 2-63 and 2-87 to 2-88

**See Also:** 8.10. 8253 Control Word Byte


**9.49. 8259 (PROGRAMMABLE INTERRUPT CONTROLLER) PINOUTS**



- Notes:** Available as 8259A, 8259A-2, 8259A-8 and CHMOS 82C59A-2
- Source:** Intel Microprocessor and Peripheral Handbook, Volume 1, pages 2-234 to 2-235 and 2-258 to 2-259
- See Also:** 7.04. PC Interrupt Usage Summary

**9.50. 8288 (BUS CONTROLLER) PINOUTS**


20-pin DIP packaging:



- Notes:** Available as 8288 and 82C58
- Source:** Intel Microprocessor and Peripheral Handbook Volume 1, pages 2-161 to 2-163 and 2-169 to 2-170

9.51. MC146818 (AT CLOCK CONTROLLER) PINOUTS

24-pin DIP packaging



**Notes:** Only pins used in IBM AT are shown


**Source:** IBM AT Technical Reference, page 1-93

**See Also:**

- 7.49. AT Real Time Clock RAM Configuration Usage
- 7.50. AT Real Time Clock Status Register A
- 7.51. AT Real Time Clock Status Register B
- 7.52. AT Real Time Clock Status Register C
- 7.53. AT Real Time Clock Status Register D
- 7.54. AT Real Time Clock Diagnostic Status Byte
- 7.55. AT Real Time Clock Diskette Drive Type Byte
- 7.56. AT Real Time Clock Fixed Drive Type Byte
- 7.57. AT Real Time Clock Equipment Byte

**9.52. PD765 (FLOPPY DISK CONTROLLER) PINOUTS**


**40-pin DIP packaging:**



**Notes:** Only pins used in IBM floppy diskette adapters are shown

**Source:** IBM XT Technical Reference, pages D-46 to D-47

**9.53. PC & XT ADD-ON CARD SIZE**




Height: 4.2 inches (106.68 mm)  
 Width: 13.15 inches (334.01 mm)  
 Pin layout: 62 pins with 100-mil card spacing

**Source:** Original IBM PC/XT Technical Reference, page E-4

**See Also:** 9.54. AT Add-on Card Size  
 9.55. Microchannel Card Size  
 9.56. PC & XT I/O Channel (System Bus) Pinouts

## 9.54. AT ADD-ON CARD SIZE




Height: 4.5 inches (114 mm) -- shorter than PC/XT  
 Width: 13 inches (333 mm) -- same as PC/XT  
 Pin layout: 62 pins with 100-mil card spacing, plus 36-pin extension

**Source:** *IBM Personal System/2: A Business Perspective*  
 (John Wiley & Sons), Jim Hoskins, page 32

**See Also:** 9.53. PC & XT Add-on Card Size  
 9.55. Microchannel Card Size

## 9.55. MICROCHANNEL CARD SIZE



Height: 3.475 inches (88.27mm)  
 Width: 11.50 inches (292.1mm)  
 Pin layout: Dual 58-pin, 50-mil connector with 4 keyed positions  
 Also allows for optional dual 10-pin video extension

**Notes:** Not applicable to Model 30

**Source:** IBM PS/2 Model 50 and 60 Technical Reference,  
 pages 2-4 to 2-5 and 2-90 to 2-103

**See Also:** 9.53. PC & XT Add-on Card Size  
 9.54. AT Add-on Card Size

## 9.56. PC &amp; XT I/O CHANNEL (SYSTEM BUS) PINOUTS

Pin Number	Signal Name	Description	Direction
A1	-I/O CH CK	I/O channel check; active low=parity error	Input
A2	+D7	Data bit 7	Input/output
A3	+D6	Data bit 6	Input/output
A4	+D5	Data bit 5	Input/output
A5	+D4	Data bit 4	Input/output
A6	+D3	Data bit 3	Input/output
A7	+D2	Data bit 2	Input/output
A8	+D1	Data bit 1	Input/output
A9	+D0	Data bit 0	Input/output
A10	+I/O CH RDY	I/O channel ready; pulled low to lengthen memory cycles	Input
A11	+AEN	Address enable; active high when DMA controls bus	Output
A12	+A19	Address bit 19	Output
A13	+A18	Address bit 18	Output
A14	+A17	Address bit 17	Output
A15	+A16	Address bit 16	Output
A16	+A15	Address bit 15	Output
A17	+A14	Address bit 14	Output
A18	+A13	Address bit 13	Output
A19	+A12	Address bit 12	Output
A20	+A11	Address bit 11	Output
A21	+A10	Address bit 10	Output
A22	+A9	Address bit 9	Output
A23	+A8	Address bit 8	Output
A24	+A7	Address bit 7	Output
A25	+A6	Address bit 6	Output
A26	+A5	Address bit 5	Output
A27	+A4	Address bit 4	Output
A28	+A3	Address bit 3	Output
A29	+A2	Address bit 2	Output
A30	+A1	Address bit 1	Output
A31	+A0	Address bit 0	Output
B1	GROUND		
B2	+RESET DRV	Active high to reset or initialize system logic	Output
B3	+5V		
B4	+IRQ2	Interrupt request 2	Input
B5	-5VDC		
B6	+DRQ2	DMA request 2	Input
B7	-12V		
B8	-CARD SLCTD	Card Selected; activated by cards in XT's slot J8	Input
B9	+12V		
B10	GROUND		
B11	-MEMW	Memory Write	Output
B12	-MEMR	Memory Read	Output
B13	-IOW	I/O Write	Output
B14	-IOR	I/O Read	Output
B15	-DACK3	DMA Acknowledge 3	Output
B16	+DRQ3	DMA Request 3	Input
B17	-DACK1	DMA Acknowledge 1	Output
B18	+DRQ1	DMA Request 1	Input
B19	-DACK0	DMA Acknowledge 0	Output
B20	CLOCK	System Clock (210 ns, 4.77MHz); 33% duty cycle	Output
B21	+IRQ7	Interrupt Request 7	Input
B22	+IRQ6	Interrupt Request 6	Input
B23	+IRQ5	Interrupt Request 5	Input
B24	+IRQ4	Interrupt Request 4	Input
B25	+IRQ3	Interrupt Request 3	Input
B26	-DACK2	DMA Acknowledge 2	Output
B27	+T/C	Terminal Count; pulses high when DMA term. count reached	Output
B28	+ALE	Address Latch Enable	Output
B29	+5V		
B30	+OSC	High-speed clock (70 ns, 14.31818MHz); 50% duty cycle	Output
B31	GROUND		

**Notes:**

- All signals are at standard TTL levels
- Connector is a 62-pin edge connector
- A=component side of board; numbers start closest to rear panel of machine

**Source:** IBM PC/XT Technical Reference, pages 1-15 to 1-19

**See Also:** 9.57. AT I/O Channel (System Bus) Pinouts  
9.58. PS/2 Model 50/60/80 Microchannel Bus Pinouts

## 9.57. AT I/O CHANNEL (SYSTEM BUS) PINOUTS

Pin Number	Signal Name	Description	Direction
A1	-I/O CH CK	I/O channel check; active low=parity error	Input
A2	+D7	Data bit 7	Input/output
A3	+D6	Data bit 6	Input/output
A4	+D5	Data bit 5	Input/output
A5	+D4	Data bit 4	Input/output
A6	+D3	Data bit 3	Input/output
A7	+D2	Data bit 2	Input/output
A8	+D1	Data bit 1	Input/output
A9	+D0	Data bit 0	Input/output
A10	+I/O CH RDY	I/O Channel ready; pulled low to lengthen memory cycles	Input
A11	+AEN	Address enable; active high when DMA controls bus	Output
A12	+A19	Address bit 19	Output
A13	+A18	Address bit 18	Output
A14	+A17	Address bit 17	Output
A15	+A16	Address bit 16	Output
A16	+A15	Address bit 15	Output
A17	+A14	Address bit 14	Output
A18	+A13	Address bit 13	Output
A19	+A12	Address bit 12	Output
A20	+A11	Address bit 11	Output
A21	+A10	Address bit 10	Output
A22	+A9	Address bit 9	Output
A23	+A8	Address bit 8	Output
A24	+A7	Address bit 7	Output
A25	+A6	Address bit 6	Output
A26	+A5	Address bit 5	Output
A27	+A4	Address bit 4	Output
A28	+A3	Address bit 3	Output
A29	+A2	Address bit 2	Output
A30	+A1	Address bit 1	Output
A31	+A0	Address bit 0	Output
B1	GROUND		
B2	+RESET DRV	Active high to reset or initialize system logic	Output
B3	+5V		
B4	+IRQ2	Interrupt request 2	Input
B5	-5VDC		
B6	+DRQ2	DMA request 2	Input
B7	-12V		
B8	-CARD SLCTD	Card selected; activated by cards in XT's slot J8	Input
B9	+12V		
B10	GROUND		
B11	-MEMW	Memory write	Output
B12	-MEMR	Memory read	Output
B13	-IOW	I/O write	Output
B14	-IOR	I/O read	Output
B15	-DACK3	DMA acknowledge 3	Output
B16	+DRQ3	DMA request 3	Input
B17	-DACK1	DMA acknowledge 1	Output
B18	+DRQ1	DMA request 1	Input
B19	-DACK0	DMA acknowledge 0	Output
B20	CLOCK	System clock (210 ns, 4.77MHz); 33% duty cycle	Output
B21	+IRQ7	Interrupt request 7	Input
B22	+IRQ6	Interrupt request 6	Input
B23	+IRQ5	Interrupt request 5	Input
B24	+IRQ4	Interrupt request 4	Input
B25	+IRQ3	Interrupt request 3	Input
B26	-DACK2	DMA acknowledge 2	Output
B27	+T/C	Terminal count; pulses high when DMA term. count reached	Output
B28	+ALE	Address latch enable	Output
B29	+5V		
B30	+OSC	High-speed clock (70 ns, 14.31818MHz), 50% duty cycle	Output
B31	GROUND		
C1	SBHE	System bus high enable (data available on SD8-15)	Input/output
C2	LA23	Address bit 23	Input/output
C3	LA22	Address bit 22	Input/output
C4	LA21	Address bit 21	Input/output
C5	LA20	Address bit 20	Input/output
C6	LA19	Address bit 19	Input/output
C7	LA18	Address bit 18	Input/output

(Continued)

Table 9.57. Continued

Pin Number	Signal Name	Description	Direction
C8	LA17	Address bit 17	Input/output
C9	-MEMR	Memory read (active on all memory read cycles)	Input/output
C10	-MEMW	Memory write (active on all memory write cycles)	Input/output
C11	SD08	Data bit 8	Input/output
C12	SD09	Data bit 9	Input/output
C13	SD10	Data bit 10	Input/output
C14	SD11	Data bit 11	Input/output
C15	SD12	Data bit 12	Input/output
C16	SD13	Data bit 13	Input/output
C17	SD14	Data bit 14	Input/output
C18	SD15	Data bit 15	Input/output
D1	-MEM CS16	Memory 16-bit chip select (1 wait, 16-bit memory cycle)	Input
D2	-I/O CS16	I/O 16-bit chip select (1 wait, 16-bit I/O cycle)	Input
D3	IRQ10	Interrupt request 10	Input
D4	IRQ11	Interrupt request 11	Input
D5	IRQ12	Interrupt request 12	Input
D6	IRQ15	Interrupt request 15	Input
D7	IRQ14	Interrupt request 14	Input
D8	-DACK0	DMA acknowledge 0	Output
D9	DRQ0	DMA request 0	Input
D10	-DACK5	DMA acknowledge 5	Output
D11	DRQ5	DMA request 5	Input
D12	-DACK6	DMA acknowledge 6	Output
D13	DRQ6	DMA request 6	Input
D14	-DACK7	DMA acknowledge 7	Output
D15	DRQ7	DMA request 7	Input
D16	+5Vdc		
D17	-MASTER	Used with DRQ to gain control of system	Input
D18	Ground		

- Notes:**
- All signals are at standard TTL levels
  - Connector is a 62-pin edge connector with a secondary 36-pin edge connector
  - A or C=component side of board; numbers start closest to rear panel of machine

**Source:** IBM PC/AT Technical Reference, pages 1-25 to 1-37

**See Also:** 9.56. PC & XT I/O Channel (System Bus) Pinouts  
9.58. PS/2 Model 50/60/80 Microchannel Bus Pinouts

**9.58. PS/2 MODEL 50/60/80 MICROCHANNEL BUS PINOUTS**

Connector	Pin Number	Signal	Description
58-pin, 50-mil edge (component side)	A1	-CD SETUP	Card setup
	A2	MADE 24	Memory address enable 24
	A3	Ground	
	A4	A11	Address bit 11
	A5	A10	Address bit 10
	A6	A09	Address bit 9
	A7	+5V	
	A8	A08	Address bit 8
	A9	A07	Address bit 7
	A10	A06	Address bit 6
	A11	+5V	
	A12	A05	Address bit 5
	A13	A04	Address bit 4
	A14	A03	Address bit 3
	A15	+5V	
	A16	A02	Address bit 2
	A17	A01	Address bit 1
	A18	A00	Address bit 0
	A19	+12V	
	A20	-ADL	Address decode latch
	A21	-PREEMPT	Causes arbitration cycle to occur
	A22	-BURST	Used to signal extended use of channel
	A23	-12V	
	A24	ARB 00	Arbitration bus priority level bit 0
	A25	ARB 01	Arbitration bus priority level bit 1
	A26	ARB 02	Arbitration bus priority level bit 2

(Continued)

Table 9.58. Continued

Connector	Pin Number	Signal	Description
58-pin, 50-mil edge (component side)	A27	-12V	
	A28	ARB 03	Arbitration bus priority level bit 3
	A29	ARB/-GNT	High=arbitration in process, lo=channel awarded
	A30	-TC	Terminal count
	A31	+5V	
	A32	-SO	Status bit 0
	A33	-S1	Status bit 1
	A34	M/-IO	Memory/input output
	A35	+12V	
	A36	CD CHRDY	Channel ready
	A37	D00	Data bit 0
	A38	D02	Data bit 2
	A39	+5V	
	A40	D05	Data bit 5
	A41	D06	Data bit 6
	A42	D07	Data bit 7
	A43	Ground	
	A44	-DS 16 RTN	Data size 16 return
	A45	-REFRESH	Memory refresh in progress when active
	A46	KEY	
	A47	KEY	
	A48	+5V	
	A49	D10	Data bit 10
	A50	D11	Data bit 11
	A51	D13	Data bit 13
	A52	+12V	
	A53	RESERVED	
	A54	-SBHE	System byte high enable
	A55	-CD DS 16	Card data size 16
	A56	+5V	
	A57	-IRQ 14	Interrupt request 14
	A58	-IRQ 15	Interrupt request 15
	58-pin, 50-mil edge (non- component side)	B1	AUDIO GND
B2		AUDIO	Audio sum node (2.5v peak to peak)
B3		Ground	
B4		14.3 MHz Osc	Clock signal
B5		Ground	
B6		A23	Address bit 23
B7		A22	Address bit 22
B8		A21	Address bit 21
B9		Ground	
B10		A20	Address bit 20
B11		A19	Address bit 19
B12		A18	Address bit 18
B13		Ground	
B14		A17	Address bit 17
B15		A16	Address bit 16
B16		A15	Address bit 15
B17		Ground	
B18		A14	Address bit 14
B19		A13	Address bit 13
B20		A12	Address bit 12
B21		Ground	
B22		-IRQ 9	Interrupt request 9
B23		-IRQ 3	Interrupt request 3
B24		-IRQ 4	Interrupt request 4
B25		Ground	
B26		-IRQ 5	Interrupt request 5
B27		-IRQ 6	Interrupt request 6
B28		-IRQ 7	Interrupt request 7
B29		Ground	
B30		RESERVED	
B31		RESERVED	
B32		-CHCK	Channel check
B33		Ground	
B34		-CMD	Command (data is valid on bus)
B35		CHRDYRTN	Channel ready return
B36		-CD SFDBK	Card selected feedback
B37		Ground	
B38		D1	Data bit 1
B39		D3	Data bit 3
B40		D4	Data bit 4
B41		Ground	
B42		CHRESET	Channel reset (init all adapters)
B43		RESERVED	

(Continued)

Table 9.58. Continued

Connector	Pin Number	Signal	Description
58-pin, 50-mil edge (non- component side)	B44	RESERVED	
	B45	Ground	
	B46	Key	
	B47	Key	
	B48	D8	Data bit 8
	B49	D9	Data bit 9
	B50	Ground	
	B51	D12	Data bit 12
	B52	D14	Data bit 14
	B53	D15	Data bit 15
	B54	Ground	
	B55	-IRQ 10	Interrupt request 10
	B56	-IRQ 11	Interrupt request 11
	B57	-IRQ 12	Interrupt request 12
	B58	Ground	
	Video Extension (component side)	VA10	VSYNC
VA9		HSYNC	Horizontal sync
VA8		BLANK	Blank input of video DAC
VA7		Ground	
VA6		P6	PEL input 6 to video DAC
VA5		EDCLK	Output enable for DCLK buffer
VA4		DCLK	Video PEL clock
VA3		Ground	
VA2		P7	PEL input 7 to video DAC
VA1		EVIDEO	Enable output (P0-P7)
KEY			
Video Extension (non- component side)	VB10	ESYNC	Enable VSYNC, HSYNC, BLANK
	VB9	Ground	
	VB8	P5	PEL input 5 to video DAC
	VB7	P4	PEL input 4 to video DAC
	VB6	P3	PEL input 3 to video DAC
	VB5	Ground	
	VB4	P2	PEL input 2 to video DAC
	VB3	P1	PEL input 1 to video DAC
	VB2	P0	PEL input 0 to video DAC
	VB1	Ground	
KEY			

**Source:** IBM PS/2 Model 50 and 60 Technical Reference, pages 2-5 to 2-17

**See Also:** 9.56. PC & XT I/O Channel (System Bus) Pinouts  
9.57. AT I/O Channel (System Bus) Pinouts



## Bibliography

The following works were used as primary or secondary sources of information during the compilation of this book. These works formed my desktop reference group, and I recommend them as the solid core of a reference library for anyone dealing seriously with the IBM PC family. Other valuable works also exist, and I consulted a number of them during the course of my research. But on a desert island doing PC development, these would be my first choices.

Angermeyer, John, and Jaeger, Kevin. *MS-DOS Developer's Guide*. Indianapolis, IN: Howard Sams & Company, 1986.

A useful book. It contains information on network use, file recovery, and device drivers not found elsewhere, or at least not in as readable a form. An excellent second source for assembly-language programmers. (ISBN 0-672-22409-7)

Armbrust, Steven, and Forgeron, Ted. *Programmer's Reference Manual for IBM Personal Computers*. Homewood, IL: Dow Jones-Irwin, 1986.

If you deal with DOS function calls or interrupts, this is a book you must own. Detailed, accurate, and well organized, it includes programming examples in Pascal and C for every function call. An underrated work valued by most serious programmers. (ISBN 0-87094-765-6)

Davies, Russ. *Mapping the IBM PC and PCjr*. Greensboro, NC: Compute! Publications, 1985.

This is a useful compendium of highly technical information regarding the IBM PC and PCjr, but it does not include AT or PS/2 material, which lessens its current value to programmers. (ISBN 0-942386-92-2)

Duncan, Ray. *Advanced MS DOS*. Redmond, WA: Microsoft Press, 1986.

Regarded by some as *the* DOS reference, this work is well-organized, highly readable, and relatively complete, featuring good reference sections at the end. (ISBN 0-914845-77-2.)

IBM Corporation. *Disk Operating System Version 3.30: Reference*. 1st ed. Boca Raton, FL: IBM Corporation, April, 1987.

The sections on code pages and a few of the other changes specific to version 3.3 require close attention, but the basic material is stable, accurate, and well organized.

(IBM part number 80X0667)

IBM Corporation. *Disk Operating System Version 3.30: Technical Reference*. 1st ed. Boca Raton, FL: IBM Corporation, April, 1987.

Like any book filled with so many facts, this volume sometimes stumbles over details. Overall, though, it's still a valuable resource.

(IBM part number 80X0945)

IBM Corporation. *Personal System/2 and Personal Computer BIOS Interface Technical Reference*. 1st ed. Boca Raton, FL: IBM Corporation, April, 1987.

This is now IBM's stated standard for the BIOS. The material is all here, but listings are no longer provided. Note: Subfunctions (those that use the AL register to pass a function request) are documented within the functions, but it is not always clear where one subfunction ends and another begins. Also, register use is not always identified as applying before or after the call. Make notes in the margin to help keep your bearings.

(IBM part number 84X1514)

IBM Corporation. *Personal System/2 Model 30 Technical Reference*. 1st ed. Boca Raton, FL: IBM Corporation, January, 1987.

BIOS listings are dropped in the PS/2 documentation, but the organization and presentation are generally better than in earlier references.

(IBM part number 68X2201)

IBM Corporation. *Personal System/2 Model 50 and 60 Technical Reference*. 1st ed. Boca Raton, FL: IBM Corporation, April, 1987.

This reference has no BIOS listings, but it has better organization throughout as well as more detailed presentation than earlier sources. For the programmer trying to deal with all PCs, however, the inclusion of two machines in one reference can make cross-checking a

particular item difficult. Sometimes you'll find information about both models in one place; sometimes the information is separated.  
(IBM part number 68X2224)

IBM Corporation. *Technical Reference Options and Adapters*. 2 vols. Revised ed. Boca Raton, FL: IBM Corporation, April, 1984.

This is where IBM documents the PC adapter boards (especially the video and communications options). A lot of useful information is here, mixed with a lot of information appearing elsewhere in the IBM technical works.  
(IBM part numbers 6137804 and 6137806)

IBM Corporation. *Technical Reference PC Network*. First Edition. Boca Raton, FL: IBM Corporation, September, 1984.

This manual is one of the many technical documents you should own if you're doing network-oriented programming, but it is heavy reading.  
(IBM part number 6322916)

IBM Corporation. *Technical Reference: Personal Computer AT*. Revised ed. Boca Raton, FL: IBM Corporation, March, 1986.

Although not as well organized nor as complete as some of the other IBM references, this reference contains most of what you need to know about the PC/AT, including a full BIOS listing.  
(IBM part number 6280099)

IBM Corporation. *Technical Reference: Personal Computer XT*. First Edition. Boca Raton, FL: IBM Corporation, January, 1983.

Although the data is somewhat scattered, this early reference contains everything you need to know, including full BIOS listing.  
(IBM part number 6936763)

IBM Corporation. *Technical Reference: Personal Computer XT and Portable Personal Computer*. Boca Raton, FL: IBM Corporation, March, 1986.

Updated XT Technical Reference including the earlier (November 1982) BIOS listing and the most current (January 1986) BIOS listing.  
(IBM part number 6280089)

Intel Corporation. *Microprocessor and Peripheral Handbook*. Volume 1—Microprocessor. Volume 2—Peripheral. Santa Clara, CA: Intel Corporation, 1987.

This is the reprint of the major data sheets, application notes, articles, and design information Intel has released to its customers. Although updated on a yearly basis, the work tends to be slightly out of date. Nevertheless, it is the best first source for information released by Intel. If what you find here isn't enough, contact Intel directly at (800) 548-4725 to find additional sources.  
(Intel part number 230843)

Jourdain, Robert. *Programmer's Problem Solver for the IBM PC, XT & AT*. Bowie, MD: Robert J. Brady Co., 1986.

A useful compendium of assembly-language and BASIC routines used to drive low-level PC hardware, this book is an excellent source on how to use 8255, 8259, and other controller chips directly.  
(ISBN 0-89303-787-7)

Microsoft Corporation. *Microsoft MS-DOS: Programmer's Reference* (version 3.3). Redmond, WA: Microsoft Corporation, 1987.

I prefer Microsoft's presentation and organization of its MS-DOS technical reference to IBM's, but you still need both sources.  
(Document number 4106 30014-330-R04-0787)

Microsoft Corporation. *Microsoft Windows User's Guide* (version 2.0). Redmond, WA: Microsoft Corporation, 1987.

You will find minor differences between this and the earlier version, but this manual has a much better section on the more technical information, such as what goes in the WIN.INI file.  
(Document number 050050051-200-R01-0887)

Microsoft Corporation. *Microsoft Windows Software Development Kit Application Style Guide* (version 2.0). Redmond, WA: Microsoft Corporation, 1987.

(Document number 050051016-200-I01-1087)

Microsoft Corporation. *Microsoft Windows Software Development Kit Programmer's Reference* (version 2.0 ). Redmond, WA: Microsoft Corporation, 1987.

This reference is much, much better than the one that accompanied the original Windows 1.03 Toolkit. The organization has been improved and the index is better, which makes looking up information a lot faster. Note: Because my copy of this document, like some of the tables in this book, was based on a prerelease version of Windows 2.0, some information may have been changed or updated after the tables were compiled. (Document number 050051053-200-I02-1087)

Microsoft Corporation. *Microsoft Windows Software Development Kit Programming Tools* (version 2.0). Redmond, WA: Microsoft Corporation, 1987. (Document number 050051051-200-I01-1087; Part number 002 00476)

Morgan, Christopher, and Waite, Mitchell. *8086/8088 16-bit Microprocessor Primer*. New York, NY: Byte/McGraw-Hill Books, 1983.

One of the earliest books on the Intel microprocessors, this book is also one of the most approachable and understandable. Although not particularly specific to the IBM PC family, it is nevertheless a valuable reference worth owning. (ISBN 0-07-043109-4)

Norton, Peter. *The Peter Norton Programmer's Guide to the IBM PC*. Redmond, WA: Microsoft Press, 1985.

A much better work than the one Norton is best known for writing (*Inside the IBM PC*, Robert J. Brady Co.), this book contains good material on the PCjr and the PC/AT, as well as on the base PC and PC/XT models. Like Duncan's, this book is highly recommended. (ISBN 0-14-087-144-6)

Palmer, John and Morse, Stephen. *The 8087 Primer*. New York, NY: John Wiley & Sons, 1984.

This book contains much of the Intel technical material, made readable. A little more basic than the Startz book (see below). Uses FORTRAN programming examples.

Sargent, Murray, III and Shoemaker, Richard. *The IBM Personal Computer From the Inside Out*. Reading, MA: Addison-Wesley Publishing, 1986.

This book, along with Peter Norton's works, is probably the best overall discussion of the PC hardware and how to drive it with software. The current (revised) edition contains information about the IBM PC/AT, but not in as much detail as one would want. (ISBN 0-201-06918-0)

Scanlon, Leo J. *Assembly Language Programming for the IBM PC-AT*. Bowie, MD: Robert J. Brady Co., 1985.

One of the best assembly-language programming books targeted for PC and AT users, this book doesn't deal with low-level PC hardware as much as it does with BIOS and DOS functions. (ISBN 0-89303-484-3)

Startz, Richard. *8087 Applications and Programming for the IBM PC and Other PCs*. Bowie, MD: Robert J. Brady Co., 1983.

This book is probably the best of the 8087 references that I consulted; however, the emphasis is on high-level language interface to the 8087. (ISBN 0-89303-420-7)

The Waite Group. *The PC LAN Primer*. Indianapolis, IN: Howard Sams & Company, 1986.

This is a solid introduction to the world of LANs with a sprinkling of technical material throughout; it is not a primary source, but it is a useful introduction nonetheless. (ISBN 0-672-22448-8)

Walden, Jeff. *File Formats for Popular PC Software*. New York, NY: John Wiley & Sons, 1986.

If data interchange is an issue, this is about the only book you'll find that even begins to cover the subject. It has detailed information about Lotus 1-2-3, dBASE, DIF, SYLK, and WordStar file formats. Although getting a little out of date, it is still a useful book. (ISBN 0-471-83671-0)



## Index

### Symbols

@ (used in batch files) 52  
% (used in batch files) 52

### Numbers

146818 Clock Controller Pinouts 504  
4116 Pinouts 498  
4164 Pinouts 498  
6845 Video Controller 455-56  
6845 Pinouts 499  
765 Disk Controller Pinouts 505  
80286 Pinouts 492-93  
80287 Pinouts 496  
80386 Pinouts 494  
80387 Pinouts 497  
8086 Family  
    Chips 450  
    Instruction Set 445-49  
    Memory Addressing Modes 444  
    Registers 449  
8086 Pinouts 491  
8088 Pinouts 491  
8087 Family  
    Chips 453  
    Instruction Set 451-52  
    Integer Number Formats 21-22  
    Real Number Formats 21-22  
    Registers 453  
8087 Pinouts 495  
8237 DMA Controller Pinouts 500  
8250 Async Controller 454  
    Pinouts 501  
8253 Timer 454, 455  
    Pinouts 501  
8255 PIA Pinouts 502  
8259 Interrupt Controller Pinouts 503  
8284 Clock Generator Pinouts 499  
8288 Bus Controller Pinouts 503

### A

ACCELERATOR Resource Statement 307  
Accelerators 307  
ACK (ASCII acknowledge) 25  
Alt Keys 29  
AND 35  
ANSI  
    Character Codes 292-95  
    Control Strings 48  
    Display Attribute Strings 49  
APPEND 40, 41  
ASCII  
    Control Codes 25  
    Character Codes 25-26  
    IBM Character Codes 27-28  
ASCIIZ Strings 22  
ASSIGN 40, 64  
Async Adapter 396, 397, 430-32

AT. *See Section 7 for material relating directly to the IBM PC/AT*

AT Jumpers and Switches 457

ATTRIB 40, 42, 64

Auxiliary Device Functions. *See* INT 21H, Functions  
AVAILDEV 53

### B

BACKUP 40, 42, 64  
BASIC 64, 397  
BASICA 64  
BASICA Strings 22  
Batch Commands 52  
BCD (Binary Coded Decimal) 23, 24  
BEL (ASCII bell) 27  
Binary Conversion to Signed Decimal 12  
Binary Digits 33  
Binary Raster Ops (ROP2) 386  
BIOS  
    Memory Use 183-86, 187, 395  
    Parameter Block 176  
    Services 178-254, 394  
        10H,1 Set Mode 188  
        10H,1 Set Cursor Type 189  
        10H,2 Set Cursor Position 189  
        10H,3 Read Cursor Position 190  
        10H,4 Read Light Pen Position 190  
        10H,5 Select Display Page 191  
        10H,6 Init Window, Scroll Window  
            Up 191  
        10H,7 Init Window, Scroll Window  
            Down 192  
        10H,8 Read Character and Attribute 192  
        10H,9 Write Character and  
            Attribute 193  
        10H,0AH Write Character at Cursor 193  
        10H,0BH Set Color Palette 194  
        10H,0CH Write Pixel 195  
        10H,0DH Read Pixel 195  
        10H,0EH Write Text in Teletype  
            Mode 196  
        10H,0FH Get Current Display Mode 196  
        10H,10H Set Palette Registers 197  
        10H,11H Character Generator 197  
        10H,12H Alternate Select 198  
        10H,13H Write String 199  
        10H,14H Read/Write Display Codes 200  
        10H,1BH Return State 201  
        10H,1CH Return Save/Restore,  
            Save/Restore State 203-4  
        10H,FEH Get Video Buffer  
            (TopView) 204  
        10H,FFH Update Video Buffer  
            (TopView) 205  
        11H Get Equipment List 205  
        12H Get Memory Size 206  
        13H,0 Reset Disk System 206  
        13H,1 Get Disk System Status 207

BIOS, Services (*continued*)

13H,2 Read Disk 208  
 13H,3 Write Disk 208  
 13H,4 Verify Sectors 209  
 13H,5 Format Cylinder 210  
 13H,6 Format Cylinder Set Bad Sector  
     Flags 211  
 13H,7 Format Drive Starting at  
     Cylinder 212  
 13H,8 Read Drive Parameters 212  
 13H,9 Init Drive Pair  
     Characteristics 213  
 13H,0CH Seek 213  
 13H,0DH Alternate Disk Reset 214  
 13H,10H Test Drive Ready 214  
 13H,11H Recalibrate Drive 215  
 13H,15H Read DASD Type 215  
 13H,16H Diskette Change Line Status 216  
 13H,17H Set DASD Type for Format 216  
 13H,18H Set Media Type for Format 217  
 13H,19H Park Heads 218  
 13H,1AH Format Unit 218  
 14H,0 Init Communications Port 219  
 14H,1 Write Character 221  
 14H,2 Read Character 222  
 14H,3 Status Request 223  
 14H,4 Extended Init 223  
 14H,5 Read/Write Modem Control  
     Register 223-24  
 15H,0 Cassette Motor ON 224  
 15H,1 Cassette Motor OFF 225  
 15H,2 Cassette Read Data Blocks 225  
 15H,3 Cassette Write Data Blocks 226  
 15H,0FH Format Periodic Interrupt 226  
 15H,4FH Keyboard Intercept 227  
 15H,80H Open Device 227  
 15H,81H Close Device 228  
 15H,82H Program Terminate 228  
 15H,83H Event Wait 229  
 15H,84H Joystick Support 229  
 15H,85H System Request Key Pressed 230  
 15H,86H Wait 230  
 15H,87H Move Block 231  
 15H,88H Get Extended Memory Size 231  
 15H,89H Switch to Protected Mode 232  
 15H,90H Device Busy 233  
 15H,91H Interrupt Complete 234  
 15H,C0H Return System Config  
     Parameters 234  
 15H,C1H Return Extended BIOS Segment  
     Address 235  
 15H,C2H Pointing Device Functions 236-40  
 15H,C3H Watchdog Timeout 241  
 15H,C4H Programmable Option Select 241  
 16H,0 Read Character 242  
 16H,1 Read Status 242  
 16H,2 Read Flags 243  
 16H,5 Keyboard Write 244  
 16H,10H Extended Keyboard Read 244  
 16H,11H Extended Keystroke Status 245  
 16H,12H Extended Shift Status 245

BIOS, Services (*continued*)

17H,0 Write Character 246  
 17H,1 Initialize Printer Port 247  
 17H,2 Status Report 247  
 18H BASIC Loader 248  
 19H Bootstrap Loader 248  
 1AH,0 Read Clock Count 249  
 1AH,1 Set Clock Count 249  
 1AH,2 Read Real Time Clock Time 250  
 1AH,3 Set Real Time Clock Time 250  
 1AH,4 Read Real Time Clock Date 251  
 1AH,5 Set Real Time Clock Date 251  
 1AH,6 Set Real Time Clock Alarm 252  
 1AH,7 Turn off Real Time Clock Alarm 252  
 1AH,9 Read Real Time Clock Alarm 253  
 1AH,0AH Read System Timer Day Count 253  
 1AH,0BH Set System Timer Day Count 254  
 Summary 178-82  
 Video 179, 188-205  
 Disk 180, 206-19  
 Communications 180, 219-24  
 Miscellaneous Devices 181, 224-41  
 Keyboard 182, 242-46  
 Printer 182, 246-47  
 Time of Day 182, 249-54  
 Bisync Controller 396  
 Bit 23, 33  
 BitBlt Records 302  
 Bitmap Data Structures 388-89  
 BITMAP Resource Statement 303  
 BITMAP Structure 345  
 Block Device Function Codes 160  
 BREAK 40, 53  
 BS (ASCII backspace) 27  
 Build BIOS Parameter Block Device Request. See Device  
     Request Headers  
 BUFFERS 53  
 Byte 20, 23, 33  
  
**C**  
 C Strings 22  
 CALL 52  
 CAN (ASCII cancel) 27  
 Card Sizes 505-6  
 CF\_BITMAP 299  
 CF\_DIF 299  
 CF\_DSPBITMAP 299  
 CF\_DSPMETAFILEPICT 299  
 CF\_DSPTEXT 299  
 CF\_METAFILEPICT 299  
 CF\_OWNERDISPLAY 299  
 CF\_PRIVATEFIRST 299  
 CF\_SYLK 299  
 CF\_TEXT 299  
 CGA. See Color Graphics Adapter  
 Character Display Attributes 412, 416, 422-23, 429  
 Character Font Size 411, 412, 416, 422, 428  
 Character Sets  
     ANSI 292-95  
     ASCII 26-27  
     EBCDIC 31-32

Character Sets (*continued*)

- Extended 29
- Foreign 34-35
- IBM 27-28
- Graphic 27-28, 30
- Characters, Allowed in Filenames 69
- CHCP 40
- CHDIR 40, 64
- CHKDSK 40, 42, 64
- Clipboard Formats (Windows) 299
- Clipboard Messages. *See* Windows, Messages
- Clock Device Table 176
- Close Device Request. *See* Device Request Headers
- CLS 40, 64
- Code Page
  - Assignments 168
  - Layout 63
  - Parameter Blocks 167
- Color Graphics Adapter 395, 396, 413-17
- Color Palette 194
- [COLORS] Settings (WIN.INI) 309
- COM Files 62
- COM Port
  - Base Address 183
  - Parameter Byte 220
- COMMAND.COM 40, 42, 63
- COMP 40, 64
- COMSTAT Structure 345
- CONFIG.SYS 53
- Connectors 474-90
- Control Keys 29
- Control Messages. *See* Windows, Messages
- Control Word Byte 454
- CONTROLNAME Resource Statement 305-6
- Convertible. *See* Section 7 for material relating directly to the IBM Convertible
- Coprocessor 394
- COPY 40, 43, 64
- COUNTRY 53
- Country Codes 166
- Country Code Buffer 165
- CR (ASCII carriage return) 27
- CreateBrush 300
- CreateFont 300
- CreatePen 300
- CreatePatternBrush 301
- CreateRegion 301
- CREATESTRUCT Structure 345
- CTTY 40, 64
- CURSOR Resource Statement 303
- Cursor Types 189

**D**

## Data Formats

- 8086 Family 20
- 8087 Numbers 21-22
- MASM Real Numbers 21-22
- Numeric 21-22
- String 22
- Data Types
  - Available as C Keywords 311-12

Data Types (*continued*)

- Windows Argument Names 311
- DATE 40, 64
- Date Formats 58
- DC1 (ASCII device control 1) 27
- DC2 (ASCII device control 2) 27
- DC3 (ASCII device control 3) 27
- DC4 (ASCII device control 4) 27
- DCB Structure 346
- DDE. *See* Dynamic Data Exchange
- DEBUG 64
- DEBUG Command Summary 54
- Decimal Conversion
  - to Binary 16
  - to Hexadecimal 17
  - to Octal 18
- Decimal Digits 33
- DEL 40, 64
- DEVICE 53
- Device Attributes 161, 169
- Device BIOS Parameter Block (BPB) 176
- Device Data Word 160
- Device Driver Headers 169
- Device Functions. *See* INT 21H, Functions
- Device Names. *See* Reserved Device Names
- Device Parameter Blocks 161-62
- Device Request Headers 170-74
  - Build BIOS Parameter Block Request 172
  - Error Codes 170
  - Flush Request 174
  - INIT Device Request 172
  - Media Check Request 172
  - Non-Destructive Read with No Wait Request 173
  - Open or Close Request 174
  - Read Device Request 173
  - Removable Media Request 174
  - Status Request 174
  - Write Device Request 173
- Device Types 161
- [DEVICES] Settings (WIN.INI) 309
- DIALOG Resource Statement 304
- DIR 40, 43, 64
- Directory Attribute 57
- Directory Entries, Format of 57
- Directory Functions. *See* INT 21H, Functions
- DISKCOMP 40, 43, 64
- DISKCOPY 40, 43, 64
- Disk Boot Record 60
- Disk Connectors 479-83
- Disk Formats
  - Floppy 61
  - Hard 61
- Disk ID Byte 59
- Disk Partition Table 60
- Disk Read/Write Absolute 397
- Disk System Status Byte 207
- Display Codes 201
- Display Context, Default Settings 385
- Display Modes 188
- Divisor Latch Register (Async Controller) 431

DLE (ASCII data link escape) 27  
 DLGTEMPLATE Structure 347  
 DMA (Direct Memory Access Channel) 396  
 DMA, PS/2 469-72  
 DOS Command Line 22  
 DOS Commands 40-52, 64  
 DOS Display String 22  
 DOS Editing Keys 51  
 DOS Functions (INT 21H) 72-153. *See also*  
   INT 21H, Functions  
 DOS Interrupts 72-153, 256-70. *See also* INT 21H,  
   Functions  
     24H Error Codes 257  
     25H Absolute Disk Read 258  
     26H Absolute Disk Write 258  
     25H and 26H Error Codes 259  
     2FH Multiplex 259  
     2FH Error Codes 260  
     33H (*see* Mouse Functions)  
 DOS Register Use 79  
 Double Word 20, 23, 33  
 Drive Functions. *See* INT 21H, Functions  
 Drive Types, AT 467  
 DRIVER.SYS 53  
 DRIVPARM 53  
 Drives (included with machines) 394  
 Dynamic Data Exchange (DDE) 298

## E

EBCDIC Characters 31-32  
 ECHO 52, 64  
 Editing Keys 51  
 EDLIN 64  
 EDLIN Command Summary 55  
 EGA. *See* Enhanced Graphics Adapter  
 EM (ASCII end of medium) 27  
 ENQ (ASCII inquiry) 27  
 Enhanced Graphics Adapter 395, 396, 418-23  
 Environment Blocks 164  
 EOT (ASCII end of transmission) 27  
 Equipment Flag 205  
 ERASE 40, 64  
 Error Codes. *See* INT 21H, Error Codes  
 ERRORLEVEL 52  
 ESC (ASCII escape) 27  
 Escape Records 301  
 ETX (ASCII end of text) 27  
 EXE Files 62, 296  
 EXE File Header 62, 296 (Windows)  
 Expanded Memory Functions 271-85  
   67H.40H Get Status 272  
   67H.41H Get Page Frame Address 272  
   67H.42H Get Page Count 273  
   67H.43H Allocate Pages 273  
   67H.44H Map Memory 274  
   67H.45H Deallocate Page 274  
   67H.46H Get EMM Version 275  
   67H.47H Save Page Map 275  
   67H.48H Restore Page Map 276  
   67H.4BH Get Handle Count 276  
   67H.4CH Get Page Count for Handle 277

Expanded Memory Functions (*continued*)  
   67H.4DH Get Page Counts for All Handles 277  
   67H.4EH Get/Set/Swap Page Map 278-79  
   67H.60H Get Physical Window Array 280  
   67H.68H Get System Physical Window Array 280  
   67H.69H Map Page to Window 281  
   67H.6AH Get/Set/Swap System Map  
     Functions 281-84  
     Error Codes 285  
 Extended BIOS Data Area 187  
 Extended Character Set 29  
 EXTTEXTMETRIC Structure 347

## F

FASTOPEN 40  
 FAT Layout 58-59  
 FCB Error Codes 155  
 FCB Formats  
   Extended 154  
   Opened 154  
   Rename 155  
   Unopened 154  
 FCB Functions. *See* INT 21H, Functions  
 FCBS 53  
 FDISK 40, 64  
 FF (ASCII form feed) 27  
 File Attribute Byte 57  
 File Extensions. *See* File Types  
 File Functions. *See* INT 21H, Functions  
 Filename Separators 69  
 File Names 57, 69  
   Files Supplied with DOS 63  
 File Types 57, 65-67  
 FILES 53  
 FillRegion 302  
 FIND 40, 43, 64  
 Fixed Disk Adapter 396, 397, 458-67  
 Floppy Disk Adapter 396, 397, 458-62  
 Flush Device Request. *See* Device Request Headers  
 Font Files 63  
 Font File Format (Windows) 299  
 FONT Resource Statement 303  
 [FONTS] Settings (WIN.INI) 311  
 FOR 52, 64  
 FORMAT 40, 44, 64  
 Format Unit Modifier Bits 219  
 Formats, Clipboard. *See* Clipboard Formats  
 Formats, Disk. *See* Disk Formats  
 Formats, Font File. *See* Font File Format  
 Formats, Metafile. *See* Metafile Format  
 Formats, Paint Files. *See* Paint File Format  
 FrameRegion 302  
 FS (ASCII file separator) 27  
 Function Keys 29, 51  
 Functions, DOS. *See* INT 21H, Functions

## G

Game Adapter 433, 489  
 GDI Information Index Data 387  
 Global Descriptor Table 232  
 GOTO 52, 64

GRAFTABL 40, 44, 64  
 Graphic Characters 27-28  
 GRAPHICS 40, 44, 64  
 GS (ASCII group separator) 27

**H**

Handle Access Byte 158  
 Handle Functions. *See* INT 21H, Functions  
 Handle Pointer Movement Methods 159  
 Handle Types (Windows) 312  
 Handles, Predefined (DOS) 158  
 HANDLETABLE Structure 348  
 Hexadecimal Addition 7-8  
 Hexadecimal Conversion  
   to Binary 5  
   to Decimal 4  
   to Octal 6  
 Hexadecimal Digits 33  
 Hexadecimal Multiplication 9-11  
 Hidden File Attribute 57  
 HP LaserJet Printer Control Codes 437-39  
 HT (ASCII horizontal tab) 27

**I**

IBM PC. *See* Section 7 for material relating directly to the IBM PC  
 IBM PC/AT. *See* Section 7 for material relating directly to the IBM PC/AT  
 IBM PC/XT. *See* Section 7 for material relating directly to the IBM PC/XT  
 IBM Printer Control Codes 435-436  
 IBM PS/2. *See* Section 7 for material relating directly to the IBM PS/2  
 ICON Resource Statement 303  
 IF 52, 64  
 IF ERRORLEVEL 52  
 INCLUDE File Constants 313-44  
 Inherit Bit 158  
 INIT Device Request. *See* Device Request Headers  
 Initialization Messages. *See* Windows, Messages  
 Input Messages. *See* Windows, Messages  
 Instructions Sets. *See* entry for specific chip  
 INT 20H 162  
 INT 21H  
   Error Codes 156-57  
   Functions 72-153  
     Device-Oriented 77  
     FCB-Oriented 75  
     Handle-Oriented 76  
     Keyboard 74  
     Network 79  
     System 78  
       0H Terminate Program 72, 80  
       1H Read Keyboard and Echo 72, 74, 81  
       2H Display Character 72, 81  
       3H Auxiliary Input 72, 81  
       4H Auxiliary Output 72, 82  
       5H Print Character 72, 82  
       6H Direct Console I/O 72, 74, 83

INT 21H, Functions, System (*continued*)

7H Direct Console Input Without Echo 72, 74, 84  
 8H Read Keyboard Without Echo 72, 74, 84  
 9H Display String 72, 85  
 0AH Buffered Keyboard Input 72, 74, 85  
 0BH Check Keyboard Status 72, 74, 86  
 0CH Flush Buffer and Input Keystroke 72, 74, 86  
 0DH Reset Disk 72, 87  
 0EH Select Disk 72, 87  
 0FH Open File (with FCB) 72, 75, 88  
 10H Close File (with FCB) 72, 75, 89  
 11H Search for First Entry (with FCB) 72, 75, 90  
 12H Search for Next Entry (with FCB) 72, 75, 91  
 13H Delete File (with FCB) 72, 75, 92  
 14H Sequential Read (with FCB) 72, 75, 93  
 15H Sequential Write (with FCB) 72, 75, 94  
 16H Create File (with FCB) 72, 75, 95  
 17H Rename File (with FCB) 72, 75, 96  
 19H Get Current Disk 72, 96  
 1AH Set DTA 72, 78, 97  
 1BH Get Default Drive Data 72, 97  
 1CH Get Drive Data 72, 98  
 21H Random Read (with FCB) 72, 75, 99  
 22H Random Write (with FCB) 72, 75, 100  
 23H Get File Size 72, 101  
 24H Set Random Record Field (with FCB) 72, 75, 102  
 25H Set Interrupt Vector 72, 75, 78, 103  
 26H Create New PSP 72, 78, 103  
 27H Random Block Read (with FCB) 72, 75, 104  
 28H Random Block Write (with FCB) 72, 75, 105  
 29H Parse File Name 72, 106, 165  
 2AH Get Date 72, 78, 107  
 2BH Set Date 72, 78, 108  
 2CH Get Time 72, 78, 108  
 2DH Set Time 72, 78, 109  
 2EH Set/Reset Verify Flag 72, 78, 109  
 2FH Get DTA 72, 78, 110  
 30H Get DOS Version Number 72, 78, 110  
 31H Terminate but Stay Resident 72, 78, 111  
 33H Control-C Check 72, 78, 111  
 35H Get Interrupt Vector 72, 78, 112  
 36H Get Disk Free Space 72, 78, 122  
 38H,0 Get Country 72, 78, 113, 165, 166  
 38H,X Set Country 72, 78, 113, 166  
 39H Create Directory 72, 78, 114  
 3AH Remove Directory 72, 78, 114  
 3BH Change Current Directory 72, 78, 116  
 3CH Create File (using handle) 72, 76, 117  
 3DH Open File (using handle) 72, 76, 118, 158  
 3EH Close File (using handle) 72, 76, 118  
 3FH Read File or Device (using handle) 72, 74, 76, 119

INT 21H, Functions, System (*continued*)

- 40H Write File or Device (using handle) 72, 76, 120
- 41H Delete File (using handle) 72, 76, 121
- 42H Move File Pointer 72, 76, 122
- 43H Get/Set File Attributes 72, 76, 122-123
- 44H,0 IOCTL Get Data 72, 77, 123, 160
- 44H,1 IOCTL Set Data 72, 77, 124, 160
- 44H,2 IOCTL Read Character 72, 77, 124
- 44H,3 IOCTL Write Character 72, 77, 125
- 44H,4 IOCTL Read Block 73, 77, 125
- 44H,5 IOCTL Write Block 73, 77, 126
- 44H,6 IOCTL Get Input Status 73, 77, 126
- 44H,7 IOCTL Get Output Status 73, 77, 127
- 44H,8 IOCTL Is Changeable? 73, 77, 127
- 44H,9 IOCTL Is Redirected Block? 73, 77, 128
- 44H,0AH IOCTL Is Redirected Handle? 73, 77, 128
- 44H,0BH IOCTL Change Retry Count 73, 77, 129
- 44H,0CH Generic IOCTL for Handles 73, 77, 130
- 44H,0DH Generic IOCTL for Devices 73, 77, 131, 161-62
- 44H,0EH Get Drive Map 73, 77, 132
- 44H,0FH Set Drive Map 73, 77, 132
- 45H Duplicate File Handle 73, 76, 133
- 46H Force Duplicate File Handle 73, 76, 133
- 47H Get Current Directory 73, 78, 134
- 48H Allocate Memory 73, 78, 134, 164
- 49H Free Allocated Memory 73, 78, 135, 164
- 4AH SETBLOCK 73, 78, 135, 164, 166
- 4BH,0 Load and Execute Program 73, 78, 136, 163
- 4BH,3 Load Overlay 73, 78, 136, 164
- 4CH End Process 73, 78, 137
- 4DH Get Return Code of Subprocess 73, 78, 137
- 4EH Find First File (with handle) 73, 76, 138, 159
- 4FH Find Next File (with handle) 73, 76, 139, 159
- 54H Get Verify State 73, 78, 140
- 56H Rename File (with handle) 73, 76, 140
- 57H Get/Set Date/Time of File 73, 76, 141
- 58H Get/Set Allocation Strategy 73, 78, 142-43, 164
- 59H Get Extended Error 73, 78, 144, 156-57
- 5AH Create Temporary File 73, 76, 144
- 5BH Create New File 73, 76, 145
- 5CH,0 Lock File 73, 79, 145
- 5CH,1 Unlock File 73, 79, 146
- 5EH,0 Get Machine Name 73, 79, 146
- 5EH,2 Printer Setup 73, 79, 147
- 5FH,2 Get Assign List Entry 73, 79, 148
- 5FH,3 Make Assign List Entry 73, 79, 149
- 5FH,4 Cancel Assign List Entry 73, 79, 150
- 62H Get PSP Address 73, 78, 150
- 63H Get Lead Byte Table 73, 151

INT 21H, Functions, System (*continued*)

- 65H Get Extended Country Information 73, 78, 151, 166
- 66H Get/Set Global Code Page 73, 78, 152, 167, 168
- 67H Set Handle Count 73, 76, 153
- 68H Commit File 73, 76, 153
- INT 22H 162
- INT 23H 162
- INT 24H 162
- Integers 20, 21-22
- Integer Short 21-22
- Integer Long 21-22
- Integer Word 21-22
- Interrupt Enable Register (Async Adapter) 432
- Interrupt ID Register (Async Adapter) 432
- Interrupt Usage 397-99
- [INTL] Settings (WIN.INI) 310
- InvertRegion 301
- I/O Channel 396. *See also* POS for PS/2
  - PC 507
  - AT 508-9
  - PS/2 509-11
- I/O Ports 396
- IRQ 397-99

**J**

- JOIN 40, 64
- Joystick 433

**K**

- KERNPAIR Structure 348
- KERNTRACK Structure 348
- Keyboard Actions (in Windows), 288
- Keyboard Buffer, 183, 407
- Keyboard Connectors 487
- Keyboard I/O Commands, AT 408
- Keyboard Equivalents. *See* System Keys, Keyboard Actions
- Keyboard Flags Byte 243
- Keyboard Flags Byte, Extended 246
- Keyboard Functions. *See* INT 21H, Functions
- Keyboard Port Definitions, AT 408
- Keyboard Scan Codes
  - PC 400-1
  - AT 401-4
  - PS/2 405-6
- Keyboard Status Register, AT 407
- Keyboard Typematic Rates, AT 409
- KEYBxx 40, 64
- Key Numbers. *See* Keyboard Scan Codes
- Keys, System. *See* System Keys
- Keys, Virtual. *See* Virtual Keys
- Keys, VT52. *See* VT52 Key Emulation
- Kilobyte 23, 33

**L**

- LABEL 40, 64
- LASTDRIVE 53
- LIB Operators 56

Line Control Register (Async Adapter) 431  
 Line Status Register (Async Adapter) 431  
 LINK 64  
 LINK Parameters 56  
 Line Printer Port Base Address 183  
 LF (ASCII line feed) 27  
 Line Drawing Characters 30  
 LOGBRUSH Structure 348  
 LOGFONT Structure 349  
 LOGPEN Structure 349  
 Logical Drive Numbers 163  
 Logical Truth Tables 35

**M**

MDA. *See* Monochrome Display Adapter  
 Media Check Device Request. *See* Device Request Headers  
 Media Descriptor Table 175, 217  
 Media Parameter Table. *See* Media Descriptor Table  
 Megabyte 23, 33  
 Memory (included with machines) 394  
 Memory Allocation Strategies (DOS) 164  
 Memory Control Blocks, DOS 166  
 Memory Module Connector, PS/2 488  
 Memory Usage  
   DOS 68  
   PC, AT, and PS/2 395  
   Video 411, 413-15, 418-21, 424-28  
 MENU Resource Statement 304  
 MENUITEMTEMPLATE Structure 349  
 Metafile Format (Windows) 300-302  
 METAFILEPICT Structure 350  
 MKDIR 40, 64  
 MODE 40, 45-46, 64  
 Model Number Bytes 187  
 Modem Control Register (Async Adapter) 432  
 Modem Status Byte 220  
 Modem Status Register (Async Adapter) 432  
 Monochrome Display Adapter 395, 396, 411-13  
 MORE 40, 64  
 Mouse Cursor Mask 270  
 Mouse Driver, Default Parameters 270  
 Mouse Functions 260-70, 398  
   33H,0 Mouse Installed Flag 261  
   33H,1 Show Cursor 261  
   33H,2 Hide Cursor 262  
   33H,3 Get Position and Button Status 262  
   33H,4 Set Mouse Cursor Position 263  
   33H,5 Get Button Press Information 263  
   33H,6 Get Button Release Information 264  
   33H,7 Set Min and Max Horizontal Position 264  
   33H,8 Set Min and Max Vertical Position 265  
   33H,9 Set Graphics Cursor Block 265  
   33H,0AH Set Text Cursor 266  
   33H,0BH Read Mouse Motion Counters 266  
   33H,0CH Set User-Defined Subroutine Input Mask 267  
   33H,0DH Set Light Pen Emulation ON 267  
   33H,0EH Set Light Pen Emulation OFF 268  
   33H,0FH Set Mickey to Pixel Ratio 268

Mouse Functions (*continued*)  
   33H,10H Conditional OFF 269  
   33H,13H Set Double Speed Threshold 269  
 Mouse Port Status Bytes 239, 240  
 Mouse Screen Mask 260  
 Mouse Usage in Windows 290  
 MS-DOS Files 63, 64  
 MSG Structure 350

**N**

NAK (ASCII negative acknowledge) 27  
 Network Access Rights 158  
 Network Functions. *See* INT 21H, Functions  
 Nibble 20, 23, 33  
 NLSFUNC 40  
 NMI 397  
 Non-Client Area Messages. *See* Windows, Messages  
 Non-Destructive Read Device Request. *See* Device Request Headers  
 NOT 35  
 Notification Messages. *See* Windows, Messages  
 NUL (ASCII null) 27  
 Number Conversion 1-19  
 Number Formats 21-22, 24

**O**

Octal Conversion  
   to Binary 15  
   to Decimal 13  
   to Hexadecimal 14  
 Octal Digits 33  
 OFSTRUCT Structure 350  
 Open Device Request. *See* Device Request Headers  
 OR 35

**P**

Page 23  
 Paint File Format 298  
 PaintRegion 301  
 PAINTSTRUCT Structure 351  
 Paragraph 23  
 Parse Control Byte 165  
 Partitions, Disk 60  
 Pascal Strings 22  
 PATH 40, 64  
 PAUSE 52, 64  
 PC. *See* Section 7 for material relating directly to the IBM PC  
 PC-DOS Files 63, 64  
 [PIF] Settings (WIN.INI) 309-10  
 Pinouts 491-505, 507-11  
 POINT Structure 351  
 Polygon Records 301  
 Polyline Records 301  
 Ports (included with machines) 394  
 Ports. *See also* Printer, Async, Fixed Disk, Floppy Disk, and Video Adapters  
 [PORTS] Settings (WIN.INI) 310  
 POS Descriptor File Format 468  
 POS I/O Channel 467-69

Powers of Two 33  
 Power Supply 394  
     Connectors 484-87  
 PRINT 40, 47, 64  
 Printer Adapter 396, 397, 434  
 Printer Connectors 488-90  
 Printer Control Codes 435-39  
 Printer Status Byte 246  
 Print Screen 397  
 Processor 394. *See also entries for specific chip*  
 Program Parameter Block 163, 164  
 Program Segment Prefix (PSP) 162  
 PROMPT 40, 48, 49, 64  
 PROMPT  
     ANSI Control Strings 48  
     ANSI Display Attribute Strings 49  
     Special Characters 48  
 Prototype Card 396  
 PS/2. *See Section 7 for material relating directly to the IBM PS/2*

**R**

Read Device Request. *See Device Request Headers*  
 Read Only Attribute 57  
 Read Write Attribute 57  
 Real Time Clock  
     AT 398  
     PS/2 474  
     RAM Configuration, AT 439  
     Status Registers, AT 440-41  
 RECOVER 40, 64  
 RECT Structure 351  
 Registers. *See entry for specific chip or adapter*  
 REM 52, 64  
 Removable Media Device Request. *See Device Request Headers*  
 RENAME 40, 64  
 REPLACE 40, 49, 64  
 Reserved Device Names 168  
 Resource Script Files (Windows) 303-8  
 RESTORE 40, 50, 64  
 RGB Structure 351  
 RMDIR 40, 64  
 ROP2 386  
 RS (ASCII record separator) 27

**S**

Scan Codes. *See Keyboard Scan Codes*  
 Search First/Next Data Blocks 159  
 Segment 23, 33  
 SELECT 40, 64  
 SET 40, 64  
 Serial Adapter. *See Async Adapter*  
 Serial Port Connectors 474-75  
 SHARE 40, 50, 64  
 SHELL 53  
 SHIFT 52, 64  
 SI (ASCII shift in) 27  
 Size (of machines) 394  
 Slots 394

SO (ASCII shift out) 27  
 SOH (ASCII start of header) 27  
 SORT 40, 50, 64  
 Sort Order, International 34-35  
 Speaker Connector 490  
 STACKS 53  
 Standard Error (STDERR) 158  
 Standard In (STDIN) 158  
 Standard Out (STDOUT) 158  
 Status Registers. *See entry for specific adapter*  
 Status Request (Device). *See Device Request Headers*  
 StretchBlit 302  
 String Data Formats 22  
 STRINGTABLE Resource Statement 308  
 STX (ASCII start of text) 27  
 SUBST 40, 64  
 SWITCHAR 53  
 Symbolic Debugger. *See SYMDEB*  
 SYMDEB 389-90  
 SYN (ASCII synchronous idle) 27  
 SYS 40, 64  
 System Board 395  
     Switches 457-58  
 System Control Port, PS/2 472  
 System Descriptor Table 235  
 System File Attribute 57  
 System Information Messages. *See Windows, Messages*  
 System Keys (Windows) 288

**T**

Tagged Image File Format (TIFF) 296-97  
 Terminate Address 397  
 Tertiary Raster Ops 386  
 TEXTMETRIC Structure 352  
 TextOut Records 301  
 TIFF. *See Tagged Image File Format*  
 TIME 40, 64  
 Time Formats 58  
 Timer 396, 397  
 TopView 204-5  
 TREE 40, 64  
 Truth Tables 35  
 Two's Complements 19  
 TYPE 41, 64  
 Typeahead Buffer 407  
 Typematic Rates 409

**U**

US (ASCII unit separator) 27

**V**

VER 41, 64  
 VERIFY 41, 64  
 VGA Adapter 424-30  
 Video Adapters 410-30  
     Connectors 476-79  
     Modes 410  
 Video Monitors 411  
 Video I/O Port Usage 413, 417, 423, 430  
 Video State Buffer 202

Virtual Keys 289

VOL 41, 64

Volume Name File Attribute 57

VT (ASCII vertical tab) 27

VT52 Key Emulations 290

## W

Window Management Messages. *See* Windows, Messages

Window Styles 384

Windows 289-390

    Error Codes 383

    Files 291-92, 385

    Functions 361-82

    Logical Mapping of Coordinates 383

    Messages

        Clipboard Messages 358

        Control Messages 359

        Format of 353

        Initialization Messages 355

        Input Messages 356-57

        Non-Client Area Messages 360

        Notification Messages 360

        Numbering of 353

        System Information Messages 358

        Window Management Messages 354

Windows (*continued*)

    Programming Library 291

    Utilities 292

[WINDOWS] Settings (WIN.INI) 308

WINDOWS.H File 313-44

WIN.INI 308-11

WM\_DDE\_ACK 298

WM\_DDE\_ADVISE 298

WM\_DDE\_DATA 298

WM\_DDE\_EXECUTE 298

WM\_DDE\_INITIATE 298

WM\_DDE\_POKE 298

WM\_DDE\_REQUEST 298

WM\_DDE\_TERMINATE 298

WM\_DDE\_UNADVISE 298

WNDCLASS Structure 352-53

Word 20, 33

## X

XAND 35

XCOPY 41, 51, 64

XOR 35

XT. *See Section 7 for material relating directly to the IBM PC/XT*

电子科技书店 批发零售 邮购  
郑州市人民路25号 资料咨询